



DE 02

EN 05

NL 08

DA 11

FR 14

ES 17

IT 20

PL 23

FI 26

PT 29

SV 32

NO 35

TR 38

RU 41

UK 44

CS 47

ET 50

LV 53

LT 56

RO 59

BG 62

EL 65

SL 68

HU 71

SK 74


**AUTOMATIC
LEVEL**



**Laser
650 nm**



1H 1V



Laserliner®



Lesen Sie vollständig die Bedienungsanleitung und das beiliegende Heft „Garantie- und Zusatzhinweise“. Befolgen Sie die darin enthaltenen Anweisungen. Diese Unterlage ist aufzubewahren und bei Weitergabe der Lasereinrichtung mitzugeben.

Der automatische Kreuzlinien-Laser zum Ausrichten von Fliesen, Ständerwerk, Fenster, Türen etc.

Allgemeine Sicherheitshinweise

- Setzen Sie das Gerät ausschließlich gemäß dem Verwendungszweck innerhalb der Spezifikationen ein.



Laserstrahlung!
Nicht in den Strahl blicken!
Laser Klasse 2
< 1 mW · 650 nm
EN 60825-1:2014

- Achtung: Nicht in den direkten oder reflektierten Strahl blicken.
- Den Laserstrahl nicht auf Personen richten.
- Falls Laserstrahlung der Klasse 2 ins Auge trifft, sind die Augen bewusst zu schließen und der Kopf sofort aus dem Strahl zu bewegen.
- Betrachten Sie den Laserstrahl oder die Reflektionen niemals mit optischen Geräten (Lupe, Mikroskop, Fernglas, ...).
- Verwenden Sie den Laser nicht auf Augenhöhe (1,40 ... 1,90 m).
- Gut reflektierende, spiegelnde oder glänzende Flächen sind während des Betriebes von Lasereinrichtungen abzudecken.
- In öffentlichen Verkehrsbereichen den Strahlengang möglichst durch Absperrungen und Stellwände begrenzen und den Laserbereich durch Warnbeschilderung kennzeichnen.
- Manipulationen (Änderungen) an der Lasereinrichtung sind unzulässig.
- Dieses Gerät ist kein Spielzeug und gehört nicht in die Hände von Kindern.



Zum Transport immer alle Laser ausschalten und Pendel arretieren, AN/AUS-Schalter (4) nach rechts schieben.

1 Batterien einlegen


Das Batteriefach öffnen und Batterien (2 x Typ AA) gemäß den Installationssymbolen einlegen. Dabei auf korrekte Polarität achten.



- 1 Wahltaaste Laserlinien / Handempfängermodus
- 2 LED Nivellierung
rot: Nivellierung aus
grün: Nivellierung ein
- 3 Batteriefach (Rückseite)
- 4 AN/AUS-Schalter;
Transportsicherung
- 5 Laseraustrittsfenster
- 6 1/4"-Stativgewinde
(Unterseite)
- 7 LED Handempfängermodus

2 Horizontal und vertikal Nivellieren


Die Transportsicherung lösen, AN/AUS-Schalter nach links schieben. Das Laserkreuz erscheint. Mit der Wahltaaste können die Laserlinien einzeln geschaltet werden.





Zum horizontalen und vertikalen Nivellieren muss die Transportsicherung gelöst sein. Die LED (2) leuchtet konstant grün. Sobald sich das Gerät außerhalb des automatischen Nivellierbereichs von 5° befindet, blinken die Laserlinien und die LED (2) leuchtet rot auf. Positionieren Sie das Gerät so, dass es sich innerhalb des Nivellierbereichs befindet. Die LED (2) wechselt wieder auf grün und die Laserlinien leuchten konstant.

3 Neigungsmodus



Die Transportsicherung nicht lösen, AN/AUS-Schalter (4) nach rechts schieben. Die Laser mit der Wahltaaste anschalten und auswählen. Jetzt können schiefe Ebenen angelegt werden. In diesem Modus kann nicht horizontal bzw. vertikal nivelliert werden, da sich die Laserlinien nicht mehr automatisch ausrichten. Die LED (2) leuchtet konstant rot.

4 Handempfängermodus

Optional: Arbeiten mit dem Laserempfänger RX

Verwenden Sie zum Nivellieren auf große Entfernungen oder bei nicht mehr sichtbaren Laserlinien einen Laserempfänger RX (optional). Zum Arbeiten mit dem Laserempfänger den Linienlaser durch langes Drücken der Taste 1 (Handempfängermodus ein / aus) in den Handempfängermodus schalten. Jetzt pulsieren die Laserlinien mit einer hohen Frequenz und die Laserlinien werden dunkler. Der Laserempfänger erkennt durch dieses Pulsieren die Laserlinien.




Beachten Sie die Bedienungsanleitung des Laserempfängers für Linienlaser.

Kalibrierungsüberprüfung vorbereiten


Sie können die Kalibrierung des Laser kontrollieren. Stellen Sie das Gerät in die **Mitte** zwischen 2 Wänden auf, die mind. 5 m voneinander entfernt sind. Schalten Sie das Gerät ein (**LASERKREUZ AN**). Zur optimalen Überprüfung bitte ein Stativ verwenden.

1. Markieren Sie Punkt A1 auf der Wand.
 2. Drehen Sie das Gerät um 180° und markieren Sie Punkt A2.
- Zwischen A1 u. A2 haben Sie jetzt eine horizontale Referenz.



Kalibrierung überprüfen

3. Stellen Sie das Gerät so nah wie möglich an die Wand auf Höhe des markierten Punktes A1.
 4. Drehen Sie das Gerät um 180° und markieren Sie den Punkt A3.
- Die Differenz zwischen A2 u. A3 ist die Toleranz.




Wenn A2 und A3 mehr als 0,5 mm / m auseinander liegen, ist eine Justierung erforderlich. Setzen Sie sich mit Ihrem Fachhändler in Verbindung oder wenden Sie sich an die Serviceabteilung von UMAREX-LASERLINER.

Überprüfung der vertikalen Linie

Gerät ca. 5 m von einer Wand aufstellen. An der Wand ein Lot mit einer 2,5 m langen Schnur befestigen, das Lot sollte dabei frei pendeln. Gerät einschalten und den vertikalen Laser auf die Lotschnur richten. Die Genauigkeit liegt innerhalb der Toleranz, wenn die Abweichung zwischen Laserlinie und Lotschnur nicht größer als $\pm 2,5$ mm beträgt.

Überprüfung der horizontalen Linie

Gerät ca. 5 m von einer Wand aufstellen und Laserkreuz einschalten. Punkt B an der Wand markieren. Laserkreuz ca. 2,5 m nach rechts schwenken und Punkt C markieren. Überprüfen Sie, ob waagerechte Linie von Punkt C $\pm 2,5$ mm auf der gleichen Höhe mit dem Punkt B liegt. Vor-gang durch Schwenken nach links wiederholen.



Überprüfen Sie regelmäßig die Kalibrierung vor dem Gebrauch, nach Transporten und langer Lagerung.

Technische Daten

Technische Änderungen vorbehalten. 01.17

Selbstnivellierbereich	$\pm 5^\circ$
Genauigkeit	$\pm 0,5$ mm / m
Arbeitsbereich (von Raumhelligkeit abhängig)	10 m
Laserwellenlänge	650 nm
Laserklasse	2 / < 1 mW
Stromversorgung	2 x 1,5 V Alkalibatterien (Typ AA, LR6)
Betriebsdauer	15 Std. (Alkalibatterien)
Betriebstemperatur	0°C ... +40 °C
Lagertemperatur	-10°C ... +70 °C
Abmessungen (B x H x T)	55 x 85 x 75 mm
Gewicht (inkl. Batterien)	260 g

EU-Bestimmungen und Entsorgung

Das Gerät erfüllt alle erforderlichen Normen für den freien Warenverkehr innerhalb der EU.

Dieses Produkt ist ein Elektrogerät und muss nach der europäischen Richtlinie für Elektro- und Elektronik-Altgeräte getrennt gesammelt und entsorgt werden.

Weitere Sicherheits- und Zusatzhinweise unter:

www.laserliner.com/info





Read the operating instructions and the enclosed brochure „Guarantee and additional notices“ completely. Follow the instructions they contain. This document must be kept in a safe place and if the laser device is passed on, this document must be passed on with it.

The automatic cross-line laser for aligning tiles, wall studding, windows, doors etc.

General safety instructions

- The device must only be used in accordance with its intended purpose and within the scope of the specifications.



Laser radiation!
Do not stare into the beam!
Class 2 laser
< 1 mW · 650 nm
EN 60825-1:2014


- Attention: Do not look into the direct or reflected beam.
- Do not point the laser beam towards persons.
- If a person's eyes are exposed to class 2 laser radiation, they should shut their eyes and immediately move away from the beam.
- Under no circumstances should optical instruments (magnifying glass, microscope, binoculars) be used to look at the laser beam or reflections.
- Do not use the laser at eye level (1.40 ... 1.90 m)
- Reflective, specular or shiny surfaces must be covered whilst laser devices are in operation.
- In public areas shield off the laser beam with barriers and partitions wherever possible and identify the laser area with warning signs.
- Tampering with (making changes to) the laser device is not permitted.
- This device is not a toy - keep out of the reach of children.



Always turn off all lasers and latch the pendulum in place before transporting, ON/OFF switch in its „OFF“ position!

1 Inserting batteries


Open the battery compartment and insert batteries (2 x type AA) according to the symbols. Be sure to pay attention to polarity.



- 1 Laser line selection button / Hand receiver mode
- 2 LED levelling red: levelling off green: levelling on
- 3 Battery compartment (backside)
- 4 ON / OFF switch, transport retainer
- 5 Laser output windows
- 6 1/4" tripod threads (bottom)
- 7 LED hand receiver mode

2 Horizontal and vertical levelling


Release the transport restraint, set the ON/OFF switch to „ON“. The laser cross will appear. The laser lines can be switched individually with the selection button.





The transport restraint must be released for horizontal and vertical levelling. The LED (2) shows a permanent green light. The laser lines flash and the LED (2) lights red as soon as the device is outside the automatic levelling range of 5°. Position the device such that it is within the levelling range. The LED (2) switches back to green and the laser lines stop flashing (steady light).

3 Slope mode



Do not release the transport restraint, set the ON/OFF switch to „OFF“. Select and switch on the laser with the selection button. Sloping planes can now be measured. This mode cannot be used to perform horizontal or vertical levelling as the laser lines are no longer aligned automatically. The LED (2) lights constantly red.

4 Hand receiver mode

Optional: Working with the laser receiver RX

Use an RX laser receiver (optional) to carry out levelling at great distances or when the laser lines are no longer visible. To work with a laser receiver, switch the line laser to hand-held receiver mode by keeping button 1 (handheld receiver mode on / off) pressed. The laser lines will now pulsate with high frequency, making the laser lines darker. The laser receiver can detect these pulsating laser lines.




Observe the laser receiver's operating instructions for line lasers.

Preparing the calibration check


It is possible for you to check the calibration of the laser. To do this, position the device **midway** between 2 walls, which must be at least 5 metres apart. Switch the device on (**LASER CROSS ON**). The best calibration results are achieved if the device is mounted on a tripod.

1. Mark point A1 on the wall.
 2. Turn the device through 180° and mark point A2.
- You now have a horizontal reference between points A1 and A2.



Performing the calibration check

3. Position the device as near as possible to the wall at the height of point A1.
4. Turn the device through 180° and mark point A3. The difference between points A2 and A3 is the tolerance.




When A2 and A3 are more than 0.5 mm / m apart, an adjustment is necessary. Contact your authorised dealer or else the UMAREX-LASERLINER Service Department.

Checking the vertical line

Position the device about 5 m from a wall. Fix a plumb bob with a line of 2.5 m length on the wall, making sure that the bob can swing freely. Switch on the device and align the vertical laser to the plumb line. The precision is within the specified tolerance if the deviation between the laser line and the plumb line is not greater than ± 2.5 mm.

Checking the horizontal line

Position the device about 5 m from a wall and switch on the cross laser. Mark point B on the wall. Turn the laser cross approx. 2.5 m to the right and mark point C. Check whether the horizontal line from point C is level with point B to within ± 2.5 mm. Repeat the process by turning the laser to the left.



Regularly check the calibration before use, after transport and after extended periods of storage.

Technical data

Subject to technical alterations. 01.17

Self-levelling range	$\pm 5^\circ$
Accuracy	± 0.5 mm / m
Operating range (depending on room illumination)	10 m
Laser wavelength	650 nm
Laser class	2 / < 1 mW
Power supply	2 x 1.5 V alkaline batteries (type AA, LR6)
Operating time	15 hours (alkaline batteries)
Operating temperature	0°C ... +40°C
Storage temperature	-10°C ... +70°C
Dimensions (W x H x D)	55 x 85 x 75 mm
Weight (incl. batteries)	260 g

EU directives and disposal


This device complies with all necessary standards for the free movement of goods within the EU.

This product is an electric device and must be collected separately for disposal according to the European Directive on waste electrical and electronic equipment.

Further safety and supplementary notices at:

www.laserliner.com/info





SERVICE



Umarex GmbH & Co. KG

– Laserliner –

Möhnestraße 149, 59755 Arnsberg, Germany

Tel.: +49 2932 638-300, Fax: +49 2932 638-333

laserliner@umarex.de

Umarex GmbH & Co. KG

Donnerfeld 2

59757 Arnsberg, Germany

Tel.: +49 2932 638-300, Fax: -333

www.laserliner.com



Laserliner®