

735mm

01

Pro Tips

• Each time you change the label, please run the automatic label identification.

• Press the feeder button on the printer to skip a blank label.

• To run a self-test, press and hold the feeder button until the blue light flash once.

• Avoid poor quality labels as they can damage the printer.

• Regularly clean the print head.

• If the paper is jammed and the blue light is flashing slowly, run the automatic label identification.

• Insert Label Printer into the same USB port on your computer every time. This will avoid creating duplicate copies of the printer in your operating system.

02

FAQ

Please visit our official website to check FAQ file.

03

LED Status

Light

Printer Status

● Solid blue

Standby

+ Blue flashing slowly

Label jams or label detection error

✱ Blue flashing quickly

Wrong media tracking

● Solid red

Printer head is over-heated

+ Red flashing slowly

Cover is not closed

✱ Red flashing quickly

Paper shortage

● Solid purple

Printing

✱ Purple flashing slowly

Pause printing

04

Feeder Button Instruction

Desired Action

Execution

Skip a label

When the printer is standby (not printing), press the feeder Button once.

05

Specifications

Method

Direct Thermal

Resolution

203 dpi

Max Printing Speed

150 mm/s

Paper Width

25.4-117 mm

Paper Thickness

0.06-0.25 mm

Power Adapter

24 V/2.5 A

Printing Life

TPH 50 KM

Operating Environment

Temperature: 5 to 50 °C
Humidity: 20-85% (non-condensing)

Storage Environment

Temperature: -20 to 60 °C
Humidity: 5-95% (non-condensing)

Connection

USB: PM-246S / PM-241
USB+BT: PM-241-BT / PM-24S-BT / PM-24S-BT / PL70

Weight

1.59lb./0.72kg

Dimensions

USB: 250 X 88 X 88mm(L*W*H)
USB+BT: 213 X 80 X 95mm(L*W*H)

06

Safety Notices

• The print head may be very hot after printing labels. Do not touch the print head.

• Do not bend the power cord excessively or place objects on the cord.

• Do not use the printer if you find any irregularities as these could result in fire or electrocution.

• Keep the printer out of reach of children.

• Use only approved accessories and do not try to disassemble, repair the unit by yourself.

• Keep the printer away from water and other objects that could penetrate the components.

• Please unplug the printer when it is not in use for a long time.

English

ISED Warning statement:
This device contains licence-exempt transmitter(s) / receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:
1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

French

Déclaration d'avertissement ISCED:
L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:
1. L'appareil ne doit pas produire de brouillage;
2. L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

07

FCC Warning

• This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: ESD protection has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

English

ISED RF exposure statement:
This equipment complies with ISCED Radiation exposure limits set forth for uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the product and your body.

French

ISED RF Déclaration de exposition:
L'équipement est conforme à la limite d'exposition aux radiations de la ISCED établie pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec une distance minimale de 20 cm entre le radiateur et votre corps.

1

2

3

4

5

6

8

色值:黑白印刷

	Pantone (参考)	C(%)	M(%)	Y(%)	K(%)
	-	0	0	0	85

材质:80g书写纸

工艺:双面印刷/折页

单页尺寸:105×148mm

印刷要求:封面在上

01

Hinweise für Vorbereitung

• Jedes Mal, wenn Sie das Etikett wechseln, lassen Sie bitte die automatische Etiketterkennung laufen.

• Drücken Sie die Einzugsaste am Drucker, um ein leeres Etikett zu überspringen.

• Um einen Selbsttest durchzuführen, halten Sie die Einzugsaste gedrückt, bis das blaue Licht einmal aufleuchtet.

• Bitte vermeiden Sie, unqualifizierte Etiketten zu verwenden, die den Drucker beschädigen können.

• Reinigen Sie den Druckkopf regelmäßig.

• Wenn das Papier gestaut ist und das blaue Licht langsam blinkt, führen Sie die automatische Etiketterkennung durch.

Schließen Sie den Drucker immer an denselben USB-Anschluss Ihres Computers an, um zu vermeiden, dass der Drucker doppelte Kopien erstellt.

02

FAQ

Besuchen Sie bitte unsere offizielle Website, um die FAQ-Datei zu lesen.

03

Einführung der Statusleuchte

Lichtsignal

Drucker-Status

● Festes Blau

Standby und Druckbereit

+ Blau blinkt langsam

Etikettenstatus oder Etiketterkennungsfehler

✱ Blau blinkt schnell

Falsche Medienverfolgung

● Festes Rot

Der Druckkopf ist überhitzt

+ Rot blinkt langsam

Die Abdeckung ist NICHT richtig geschlossen.

✱ Rot blinkt schnell

Etiketten sind ausgelaufen oder nicht richtig eingelegt

● Festes Lila

Drucken

✱ Lila blinkt langsam

Druck anhalten

04

Einführung der Vorschubtaste

Ziel

Weise

Wie man ein Etikett überspringt

Fügen Sie Ihre Etiketten glatt ein. Drücken Sie die Vorschubtaste, während sich der Drucker im Standby-Modus befindet und bereit zum Drucken ist.

05

Spezifikationen

Methode

Direct Thermal

Auflösung

203 dpi

Max. Druckgeschwindigkeit

150 mm/s

Papierbreite

25.4-117 mm

Papierdicke

0.06-0.25 mm

Spannungsadapter

24 V/2.5 A

Lebensdauer

TPH 50 KM

Betriebsumgebung

Temperatur: 5 bis 50 °C
Luftfeuchtigkeit: 20-85% (nicht kondensierend)

Speicherumgebung

Temperatur: -20 bis 60 °C
Luftfeuchtigkeit: 5-95% (nicht kondensierend)

Verbindung

USB: PM-246S / PM-241
USB+BT: PM-241-BT / PM-24S-BT / PM-24S-BT / PL70

Gewicht

1.59lb./0.72kg

Abmessungen

USB: 250 X 88 X 88mm(L*W*H)
USB+BT: 213 X 80 X 95mm(L*W*H)

06

Sicherheitshinweise

• Berühren Sie den Druckkopf nicht. Nach dem Drucken kann der Druckkopf erhitzt werden.

• Bitte vermeiden Sie, das Netzkabel zu biegen oder Gegenstände auf dem Kabel zu legen.

• Verwenden Sie den Drucker nicht, wenn Sie Unregelmäßigkeiten bemerken, die zu Bränden oder Stromschlägen führen können.

• Halten Sie den Drucker außerhalb der Reichweite von Kindern.

• Verwenden Sie nur zugelassenes Zubehör. Versuchen Sie nicht, der Drucker selbst zu zerlegen oder zu reparieren.

• Halten Sie den Drucker von Wasser und anderen.

• Ziehen Sie den Netzstecker aus der Steckdose, wenn der Drucker längere Zeit nicht benutzt wird.

Maintenance Guide

Wartungshinweise

8

9

10

11

12

封面(105mm)

Maintenance Guide

Wartungshinweise

封面(148mm)

封面(105mm)

Maintenance Guide

Wartungshinweise

封面(148mm)