Ages 3+

Kids Edition Tablet

Selbstlernfunktion, ermöglicht SPI

User Guide

English	01-09
Deutsch	10-18
Français	19-27
Español	28-36
Italiani	37-45
中英文	46-54
Warranty	55

English

iWawa Kids

Start-up and click iWawa Kids to start children's software.

Activate iWawa Kids Software

Need to allow the following permissions, by selecting "OK"...

Activate iWawa Kids Software

Allow iWawa to access photos, media, and files on your device

Internet Register

Internet Register There is no network connection right now. Please set your network by clicking the WiFi Setting.

Use WiFi

Turn on the WiFi, all the WiFi connections available will be listed.

Internet Register

By Clicking the "connect" to finish the "Iwawa Kids Software Activation".

Kids Home Desktop

Child Lock

Kids could not exit kids desktop except parents input the password.

Parental Control

Back to parental control, and click Application to enter the Application limited interface.

Filtering Apps

Parents can select apps which are shown in kids desktop.

Kid Desktop

Apps will be shown in this kid desktop when parents select apps or games in the applications interface.

Media Content

Parents can create specific media files for kids, which kids can enjoy their own music, photos and videos.

Safe Websites

Parents also can create proper websites for kids so kids will not visit other unsafe websites.

Support Multiple Accounts

Kids can share more than one kid, don't worry, Every kids can have their own account and what they are playing can be distinguished.

Parent Remote Control

There are swift can be remotely controlled by parents mobile phones all apps in Kid.

Parental Desktop

NOTE: The tablet has preinstalled games and software, it is specially designed for kids, but it is impossible to filter all apps from unknown sources after quit the child interface, then we can not guarantee the application compatibility, the safe use of kids, as well as the experience and stability of the product.

Parental Desktop

If you want to Re-enter the kids desktop, please click the iWawa Kids icon.

Parental Desktop

Back to the Kids mode. Please find the 'iWawa Kids' icon and click it..

Deutsch

iWawa Kids

Starten Sie und klicken Sie auf iWawa Kids, um die Kidssoftware zu starten.

Aktivieren Sie die iWawa Kids Software

Sie müssen die folgenden Berechtigungen zulassen, indem Sie "OK" auswählen.

Aktivieren Sie die iWawa Kids Software

Ermöglichen Sie iWawa den Zugriff auf Fotos, Medien und Dateien auf Ihrem Gerät.

Internet Register

Internet-Registrierung Kein Netzwerk vorhanden Verbindung jetzt. Bitte stellen Sie Ihr Netzwerk ein, indem Sie auf die WLAN-Einstellung klicken.

Verwenden Sie WiFi

Schalten Sie das WLAN ein, das gesamte WLAN verfügbare Verbindungen werden aufgelistet.

Internet registrieren

Durch Klicken auf "Fortschreiben" beenden Sie den Vorgang"Iwawa Kids Software Activation".

Kids Home Desktop

Kindersicherung

Kinder können den Kindermodus nicht verlassen außer Eltern geben das Passwort ein.

Elterliche Kontrolle

Zurück zur Kinderbetreuung und Eltern können Anwendung Eingabe der Anwendung sorgt eine Schnittstelle.

Filtern von Apps

Eltern können Apps auswählen, die in Kinderbech angezeigt.

Kid Desktop

Apps werden auf diesem KidsDesktop angezeigt wenn Eltern Apps oder Spiele auswählen die Anwendungsschnittstelle.

Medieninhalt

Eltern können bestimmte Mediendateien erstellen für Kinder, die Kinder ihre eigenen gemeißen können Musik, Fotos und Videos.

Sichere Websites

Eltern können auch richtig erstellen. Kinder können so dass Kinder nicht Besuchen Sie andere unsichere Websites.

Unterstützung mehrerer Konten

Wenn Eltern mehr als ein Kind haben, tun Sie es nicht Sorge, Jedes Kind kann sein eigenes Konto haben und was sie spielen können unterschieden werden.

wird ferngesteuert kontrolle

Apps werden auf diesem KidsDesktop angezeigt wenn Eltern Apps oder Spiele auswählen die Anwendungsschnittstelle.

Elterlicher Desktop

WARNING: Ist kein Tablet mit Spiele vorinstalliert und Software, es ist speziell für Kinder konzipiert, aber es ist unmöglich, alle Apps von unbekannten installierte unbekannte Quellen nach dem Verlassen des Kindes Schnittstelle, dann können wir die nicht Kompatibilität der Anwendung garantieren, die Verwendung von Kinder, sowie die Erfahrung und Stabilität des Produkts.

Elterlicher Desktop

Wenn Sie den Kinderbereich erneut eingeben möchten, klicken Sie bitte auf das Iiwawa Kids-Symbol.

Elterlicher Desktop

Zurück zum Kindermodus. Finden Sie das "iiwawa Kids"-Symbol und klicken Sie darauf.