产品与监管指南•制造商的硬件保修协议

製品取扱説明書・製造者のハードウェアに関する制限付き保証 および契約書

안전 및 규정 가이드 • 제조업체의 하드웨어 유한 보증 및 계약 คู่มือผลิตภัณฑ์และกฎระเบียบข้อบังคับ • ข้อตกลงและการรับประกัน สำหรับ ฮาร์ดแวร์ที่จำกัดของผ้ผลิต

Hướng dẫn về Sản phẩm và Quy định • Thỏa thuận & Bảo hành Phần cứng có Giới hạn của Nhà sản xuất

PRODUCT MANUAL

AGREEMENT TO XBOX WARRANTY AND SOFTWARE YOU MUST ACCEPT HARDWARE WARRANTY &

AGREEMENT, MICROSOFT SERVICES AGREEMENT, AND SOFTWARE LICENSE TERMS By purchasing or using your Microsoft Product, you

- Agreement (Manufacturer's Hardware Warranty & Agreement in some countries) below and at support.microsoft.com/warranty.
- Microsoft Services Agreement at microsoft.com/msa.
- It governs use of Xbox online service and Microsoft · Software License Agreement at xbox.com/slt
- Please read these agreements. If you do not accept them, do not set up or use your Xbox Product (console or accessory). Return the Xbox product to Microsoft or your retailer for a refund.

This symbol identifies safety and health messages in this guide. Read this guide for important safety and health information for the product that you have purchased

NOTICE: Read safety and health information effective. Please read this guide for important safety and

nealth information about your device and for the terms of the Limited Warranty that applies to your device. The guide is intended to help you be more comfortable and productive while using this device. Failure to follow the nstructions for proper set up, use, and care for your device can increase the risk of serious personal injury, death, or property damage. You can find additional support at support.xbox.com. **NOTICE: Read use instructions**

Failure to properly set up, use, and care for this product can increase the risk of damage to your device or devices. Read this guide and keep all printed guides for future reference. For replacement guides, go to support.xbox.com or refer to the Microsoft Help and Support section for contact information.

Exposed device cables and cords pose a potential tripping hazard. Arrange all cables and cords so that people and pets are not likely to trip over or accidentally pull on them as they move around or walk through the area. Do not allow children to play with cables and cords.
To avoid damaging the cords and cables:

- Protect cords from being walked on or crushed. · Protect cords from being pinched or sharply bent, (mains) outlet, the power supply unit, and your device. Do not jerk, knot, sharply bend, stretch, or otherwise
- abuse the power cords. Do not wrap your power cord too tightly, especially around the power brick. Instead, wrap it using loose coils rather than tight angles. When positioning your device or PSU make sure that the cords are not bent sharply and that the connectors
- are not pushed against a wall or hard surface.
- Do not allow pets or children to bite or chew on power cords. When disconnecting the power cord, pull on the plug—do not pull on the cord.
- Inspect your power cords and cables regularly. If a power cord or cable becomes warm, frayed, cracked or damaged in any way, stop using it immediately We recommend that you replace your damaged power cord or cable with a genuine Microsoft Unplug your charging cable or cord during lighting

MARNING: General Battery Safety Your device uses disposable or rechargeable batterie Improper use or misuse of disposable or rechargeable

storms or when unused for long periods.

batteries may cause injury, death, property damage, and may damage your device or its accessories as a result of battery fluid leakage, fire, overheating, or explosion. Battery fluid is corrosive and may be toxic. It can cause burns and may be harmful or fatal if swallowed. To reduce the risk of injury when using disposable or rechargeable batteries · Keep batteries out of the reach of children.

 Charge rechargeable batteries only with the charger provided with your device. Using an improper charging method may result in fire or explo-Immediately remove old, weak, or worn out batteries from your device. Recycle or dispose of old, weak, or worn batteries in accordance with local, regional, or

•---

- national law or regulation. · Remove the batteries from your device before storing your device for an extended period.
- · Avoid contact with battery fluid. If a battery leaks: Keep the leaked fluid from touching your skin, eyes, clothes, or other surfaces. If the battery fluid contacts your skin, eyes, or clothes,
- immediately wash the affected area with water and contact your doctor or other medical
- provider as appropriate. • Carefully remove all batteries by reversing the battery installation instructions provided with
- Before inserting new batteries, thoroughly clean the battery compartment with a dry cloth, or follow the battery manufacturer'
- We recommend that you use Microsoft approved battery packs. Replace the disposable or
- rechargeable batteries supplied with your device with batteries of the same type and rating. Do not disassemble, crush, open, puncture, shred, short external contacts or circuits, expose to
- nperature above 40 °C (104 °F), or dispose of batteries in fire or water. Do not mix new and old batteries or batteries of different types (for example, carbon-zinc and alkaline batteries).
- Do not allow metal objects to touch the battery terminals on the device; they can become hot and
- cause burns. Do not carry or place batteries or battery packs together with other metal objects.
- Do not leave a battery-powered device in direct sunlight for an extended period.
- Do not immerse batteries in water or allow them to Do not use a battery if it has become wet. Do not attempt to dry a battery or battery pack with a hair dryer, in a conventional oven, or in a microwave oven.
- Do not connect batteries directly to wall outlets or car cigarette-lighter sockets. Do not strike, throw, step on, or subject batteries to severe physical shock. Do not modify or remanufacture, attempt to insert
- foreign objects into the battery, immerse or expose to water or other liquids, expose to fire, explosion or other hazard. Do not recharge batteries near a fire or in extremely
- Dropping your device or its battery, especially on a hard surface, can damage the device and its battery. We recommend that you seek professional assistance to inspect your device if you believe damage has
- Never use a damaged battery. If your battery appears scratched, or nicked, immediately place it aside and dispose of it properly. Use of a damaged battery can cause electrical shorts, overheating, and other component failures.

 WARNING: Battery replacement and device repairs (user replaceable batteries)
Batteries in devices with user-replaceable batteries can be changed by opening the battery receptacle and seek professional assistance for all other device repairs. and that you use caution if undertaking do-it-yourself repairs. Opening and/or repairing your device can present electric shock, device damage, fire, and personal injury risks, and other hazards

NOTICE: Handling Handle your Microsoft device with care. It is made of metal and plastic and has sensitive electronic components inside. Your device can be damaged if ropped, burned, punctured, or crushed, or if it comes in contact with liquid. If you suspect damage to your device or its battery, discontinue use of your device, as it may

ause overheating or injury. NOTICE: Heat-related concerns for wearable devices Your device may become very warm during normal use. limits defined by the International Standards for Safety

It complies with the user-accessible surface temperature (IEC 60950-1 and IEC 62368). To reduce heat-related concerns, follow these guidelines:

- pillow, blanket or other soft material in contact with our device, because the material can block the airflow which may result in the device overheating
- If your device gets uncomfortably warm, remove it and take a break. If your device is used for long periods, its surface can become very warm. While the temperature may not feel hot to the touch, if you maintain physical contact with the device for a long time, your skin

might suffer a low-heat injury.

 Never place the power supply unit (PSU) for your device on furniture or any other surface that might be marred by exposure to heat since the surface of the PSU may increase in temperature during normal

A CAUTION: Skin irritation (wearable devices) This device is made of materials commonly used in wearable consumer electronic devices. However, certain people may develop skin irritation due to allergies or

- sitivities. To reduce the risk of skin irritation · Clean your device regularly.
- Avoid using lotions or other products under the portions of the device that contact your skin. · Do not wear over injured skin.
- · Where applicable, tighten the adjustment until snug, but not uncomfortably tight. If your skin becomes irritated, stop using device. • If symptoms are severe or persist, consult your
- WARNING: Be aware of your surrou To reduce the potential risk of injury or death due to distractions, do not use your device while driving operating machinery, cycling, walking, or engaging ir other activities that require your undivided atter Using your device alone or with headphones or a headset (even if used only in one ear) while driving a vehicle or cycling is not recommended and may be Always keep the volume on your headphones o headset low enough to hear people talking, sounds that might alert you to hazardous conditions, and better protect your hearing. Review and obey the laws and

產品與法規指南 • 製造商的硬體保固服務合约

Never type, or review texts or emails. **XBOX ACCESSORY** Never input navigation information. · Never surf the web or do any other tasks that divert

WARNING: Risk in Repairs Opening and/or repairing your device can present electric shock, device damage, fire, and personal injury

risks, and other hazards. Microsoft recommends that you onal assistance for device repairs, and that vou use caution if undertaking do-it-yourself repairs. MARNING: Parts of this device are magnetic

Parts of your device are magnetic and may attract metallic items. To reduce the potential risk of sparks and resulting amage to your device, other objects, and/or possible personal injury, verify the electrical connection areas are free of metallic objects before interconnecting devices or charging connectors. Do not place magnetically sensitive devices, credit cards, other magnetic storage media near your device to reduce the potential for magnetic rence between your device and other devices, possible disruption of medical device operation, or corruption of magnetically stored data.

MARNING: Cleaning

- The risk of fire, shock or damage to your Microsoft device during cleaning might be reduced by taking the following precautions Unplug all cables and turn your device off before
- · Only clean the exterior of your device · Clean your device with a dry cloth.
- · For devices with fans, vents, ports or similar openings: Gently clean the exterior surface of the fan, vent
- or other opening to remove any dust buildup • Do not insert objects into the fan, vents, ports, or other opening. Do not attempt to clean connectors through
- immersion in liquids. Only gently wipe and dry with

WARNING: Photosensitive seizures Some people may experience a seizure when exposed to flashing lights or patterns in moving images or video games. Even people who have no history of seizures or epilepsy may have an undiagnosed condition that can cause "photosensitive seizures" while watching moving images or video games. These seizures may have a variety of symptoms, including lightheadedness, altered vision, eye or

- face twitching, jerking or shaking of arms or legs, disorientation, confusion, or momentary loss of awareness. Photosensitive seizures may also cause loss of consciousness or convulsions that can lead to injury from falling or striking nearby objects. Immediately str playing and consult a doctor if you experience any of these symptoms. Parents should watch for or ask their children about the above symptoms — children and teenagers are more likely than adults to experience these seizures. The risk of photosensitive seizures may be educed by taking the following precautions: · Sit farther from the video screen.
- · Use a smaller video screen. Play in a well-lit room.
- Do not play when you are drowsy or fatigued. If you or any of your relatives have a history of seizures or WARNING: Musculoskeletal disorders

injuries or disorders. When using a computer, as with many activities, you may experience occasional discomfort n your hands, arms, shoulders, neck, or other parts of your body. However, if you experience symptoms such as persistent or recurring discomfort, pain, throbbing, aching, tingling, numbness, burning sensation, or stiffness, DO NOT IGNORE THESE WARNING SIGNS. PROMPTLY SEE A OUALIFIED HEALTH PROFESSIONAL even if symptoms occur when you are not working at your computer. Symptoms like these can be associated with painful and sometimes permanently disabling injuries or disorders of the nerves, muscles, tendons, or other parts of the body. These musculoskeletal disorders (MSDs) include carpal tunnel syndrome, tendonitis, tenosynovitis, and other conditions. While researchers are not yet able to answer many questions about MSDs, there is general agreement that many factors may be linked to their occurrence. ing: overall health, stress and how one copes with it, medical and physical conditions, and how a person positions and uses his or her body during work and other activities (including use of a keyboard or mouse). The

Some guidelines that may help you work more comfortably with your device and possibly reduce your risk of experiencing an MSD can be found at https://support.microsoft.com and xbox.com/playhealthy (Healthy Gaming Guide).

This device may contain small parts that may be a choking hazard to children under 3 years. Keep small

amount of time a person performs an activity may also

▲ WARNING: Using Video Gaming Accessories Make sure children using video gaming accessories with their Xbox console play safely, within their limits, and that they understand proper use of the console and

Frequent or extended exposure to loud noise or sounds when using a headset or headphones can

cause temporary or permanent hearing loss. Individual susceptibility to noise-induced hearing loss and potential hearing problems varies. Also, the sound volume produced by a device may vary depending on the nature of the sound, device settings, and the headset or headphones used. As a result, there is no single volume ing that is appropriate for everyone or for every nbination of sound, settings, and equipment. Here are a few common-sense recommendations to

minimize your exposure to loud noises or sounds when using a headset or headphones with your device: · Minimize your time listening to loud sound. All of the sound you are exposed to each day adds up. At maximum volume, listening to music or

other content on your device with a headset or headphones can permanently damage your hearing in 15 minutes. If you are exposed to other loud sounds also, it takes less time listening at high volumes to cause hearing damage.

 The more time you spend exposed to loud sounds, the more likely you are to damage your hearing. The louder the sound, the less time that is required to Always turn the volume on your device down before plugging a headset or headphones into your device.

Set the volume loud enough to hear clearly in quiet surroundings, and no louder. Do not increase the volume after you start listening Your ears can adapt over time so that high volume sounds normal, but the high volume could still damage your hearing.

Do not increase the volume to block outside noise. The combination of outside noise and sound from your headset or headphones can damage your hearing. Sealed or noise-cancelling headphones can reduce outside noise so that you don't have to turn

normally, turn down the volume. Sound that drowns out normal speech can damage your hearing. Even with sealed or noise-cancelling headphones, you should be able to hear nearby people speak. To minimize the potential for hearing damage, keep

the volume low enough that you can carry on a conversation with people nearby. Headphones and headsets can attract dangerous

objects like staples and paper clips. Always check Use of a headset or headphones while driving may be prohibited or restricted in your area; check your local laws and regulations for further informatio Finally, be aware of hearing loss symptoms. It's a good dea to have your hearing checked regularly by an audiologist. Stop using a headset or headphones with

your device and have your hearing checked if: · You experience any hearing loss symptoms • You hear ringing in your ears.

· Your speech sounds muffled, dull, or flat. WARNING: Personal medical devices Radio-frequency emissions and magnetic fields from electronic equipment can negatively affect the operation of other electronic equipment, causing them to nalfunction. Although your device is designed, tested, and manufactured to comply with regulations governing radio frequency emission in countries such as the United

States, Canada, the European Union, and Japan, the wireless transmitters and electrical circuits in the device may cause unintentional interference in other electronic Persons with pacemakers should always take the

The American Heart Association recommends that a

minimum separation of 15 cm (6 inches) be maintained rence with the pacemak If you use your mobile device with a case or holder select one without metallic parts.

· Do not carry your device in a chest pocket. If you have any reason to suspect that interference is occurring immediately turn off your device. If you use a medical device other than a pacemaker,

electronic devices near your medical device. MARNING: Wireless devices aboard aircraft Before boarding any aircraft or packing a wireless device in luggage that will be checked, remove the batteries eless device (if removable) or turn the w device off (if it has an on/off switch). Listen for the in-flight ncement that tells you if you are allowed to us your device during a flight. In-flight wireless use is at the retion of the airline.

consult the device manufacturer or your physician for information and instructions about the use of other

WARNING: Exposure to radio frequency (RF) rices that contain Wi-Fi and Bluetooth® radio transmitters have been designed, manufactured and tested to meet the Federal Communications Commis (FCC), Industry Canada and European guidelines for RF exposure and Specific Absorption Rate.

To ensure that your exposure to RF energy generated by the Wi-Fi and Bluetooth radios does not exceed the exposure limits set forth by these guidelines, orient devices with display screens such that the display side is not directly in contact with your body (i.e. placing the display side face down on your lap or upper body). Additional information about RF safety can be found on the FCC website at http://www.fcc.gov/oet/rfsafety and the Industry Canada website at http://www.ic.gc.ca/eic/site/smt-gst.nsf/eng/sf01904.html.

XBOX WARRANTY FOR AUSTRALIA & NEW ZEALAND MANUFACTURER'S HARDWARE WARRANTY &

This Manufacturer's Hardware Warranty & Agreement ("Warranty") is an agreement between you and the applicable Microsoft contracting entity identified at the bottom of this Warranty ("Microsoft"). BY PURCHASING OR USING YOUR MICROSOFT

READ AND SAVE A COPY FOR YOUR RECORDS II YOU DO NOT ACCEPT THIS WARRANTY, DO NOT USE YOUR MICROSOFT PRODUCT AND RETURN IT UNUSED TO YOUR RESELLER OR MICROSOFT FOR A REFUND. IF YOU RETURN IT, THIS WARRANTY WILL GOVERN WHAT OCCURS BEFORE YOUR RETURN.

RELATION TO CONSUMER LAW. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS AND IS IN ADDITION TO, NOT IN PLACE OF, ANY RIGHTS YOU MAY HAVE LINDER CONSLIMER OR OTHER LAWS APPLICABLE TO YOU. YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY BY STATE OR COUNTRY. Other than as permitted by law, microsOft does not exclude, limit, or suspend other rights you may have.

In Australia: Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss o damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

(a) "Microsoft Product" means a genuine Microsoft hardware product, or a replacement component sold separately purchased from Microsoft or an authorise reseller. Some Microsoft hardware products have thei own limited warranties instead of this one. (b) "Normal Use Conditions" means ordinary consumer use under normal conditions according to the

instruction manual, technical specifications, and any other support documentation provided by Microsof for the Microsoft Product. 2. Duration Without prejudice to any legal (statutory) rights to which

you may be entitled under your local law, this Warranty lasts for one year (90 days for Xbox accessories except Elite Wireless Controller Series 2, two years for HoloLens 2 Industrial Edition only) from the date of original purchase from Microsoft or an authorised eseller. For replacement components sold separately,

3. Territory This Warranty is valid only in Australia and New Zealand. 4. Warranty

(a) Microsoft warrants that the Microsoft Product will not malfunction due to a defect in materials or workmanship under Normal Use Conditions. (b) Subject to your legal (statutory) rights under your local law, this Warranty is the only guarantee, warranty, or condition Microsoft gives for your Microsoft Product. No one else may give any guarantee, warranty, or condition on Microso

5. How to Get Warranty Service

support.microsoft.com/warranty.

this Warranty lasts for 90 days.

Prior to providing warranty service, Microsoft or its agents may require you to provide proof of purchase (a) Before starting the warranty process, please use the troubleshooting tips at support.microsoft.com (b) If the troubleshooting tips do not resolve your problem, then follow the online process at

(c) Back up your Data or Applications and Delete **Confidential Information.** Before sending your Microsoft Product to Microsoft for service, be sure i. keep a copy of any DATA or APPLICATIONS YOU want to save. Microsoft IS not responsible for Your DATA or APPLICATIONS AND WILL erase them; and

Delete anything You consider confidential. Microsoft

information if you leave that confidential information

IS not responsible for the confidentiality of your

Warranty service may be available only in the country where you purchased the Microsoft Product. If warranty service is unavailable to you in the country where the device is located when warranty service is requested, Microsoft may offer you other support options for an additional charge.

6. Microsoft's Responsibility

(a) If Microsoft determines that the Microsoft Product malfunctioned under Normal Use Conditions during the warranty period due to a defect in materials or workmanship, Microsoft will (at its option) repair or replace it or the defective part, or refund the purchase price in exchange for the return of the Microsoft Product, unless a mandatory provision of your local law provides otherwise. Goods presented for repair may be replaced by refurbished goods of the same type rather than being repaired. Refurbished parts may be used to repair the goods. Repair facilities and spare parts may not be available. When replacing the unit, Microsoft may use either the same unit model or, if unavailable, the model nearest to the original model's form, functionality, performance, and color in Microsoft's sole discretion. The Microsoft Product or all parts of your Microsoft Product that Microsoft has replaced become Microsoft's property

(b) Unless a mandatory provision of your local law provides otherwise, after repair or replacement, your Microsoft Product will be covered by this Warranty for the longer of the remainder of your original warranty eriod or 90 days after Microsoft ships it to you (c) UNLESS A MANDATORY PROVISION OF YOUR RESPONSIBILITY to repair or replace Your Microsoft product, or to refund the purchase price, is Your

(d) Subject to your local law, if your Microsoft Product malfunctions after the warranty period or if your Microsoft Product is otherwise excluded from thi Warranty, Microsoft may charge you a fee for its efforts (whether successful or not) to diagnose and service any problems with it. 7. Warranty Exclusions

To the extent permitted by your local law, Microsoft is not responsible, and this Warranty does not apply (and Microsoft may not offer service even for a fee) to: (a) a Microsoft Product not purchased from Microsoft or (b) damage caused by use with products, applications, or services not manufactured, licensed, or supplied by Microsoft (including, for example, games and accessories not manufactured or licensed by Microsoft, and "pirated" games);

(c) a Microsoft Product that has had its serial or IME number altered or removed; (d) damage caused by any external cause (including, for example, by being dropped, exposed to liquid, or used with inadequate ventilation); (e) damage caused by use not in accordance with the user manual, technical specifications, or any other instruction Microsoft provided; (f) damage caused by repairs or modifications done

by someone other than Microsoft or a Microsoft authorised service provider, or damage caused by using another company's parts; (g) scratches, dents, other cosmetic damage, or damage reasonably expected as a result of normal wear and (h) damage caused by hacking, cracking, viruses or other malware, or by unauthorised access to services, accounts, computer systems, or networks; or (i) a Microsoft Product that has had its software or hardware modified to alter its functionality or capabilities using malicious code, malware, bots,

orms, trojans, backdoors, exploits, cheats, fraud hacks, hidden diagnostics, or other mechanisms: i. to disable security or content-protection mechanisms; ii. to give the user an unfair advantage or degrade othe users' online experience; iii. to deceive or defraud Microsoft or others; or

iv. that may harm the product or our systems This Warranty applies only if your Microsoft Product is used with the operating system Microsoft preinstalled in your Microsoft Product, or any later version of that operating system. This Warranty does not apply to (a) consumable parts that

ninish over time, such as reduced charging capacity of the battery resulting from its natural end-of-product life, unless the failure occurred due to a defect in materials or workmanship, or (b) a SIM card or any network or system on which the Microsoft Product operates. This Warranty does not apply to any software distributed Microsoft does not guarantee that your use of the

Microsoft Product will be uninterrupted, timely, secure, or error-free, or that data loss will not occur. 8. EXCLUSION OF CERTAIN DAMAGES AND LIMITATION OF LIABILITY UNLESS OTHERWISE PROVIDED UNDER YOUR LOCAL LAW, MICROSOFT IS NOT responsible FOR ANY INDIRECT, INCIDENTAL, SPECIAL, OR CONSEQUENTIAL DAMAGES: ANY LOSS OF DATA, PRIVACY, CONFIDENTIALITY, OR PROFITS; OR ANY INABILITY TO USE YOUR Microsoft product, THESE EXCLUSIONS APPLY EVEN IF MICROSOFT HAS BEEN ADVISED OF THE POSSIBILITY OF THESE DAMAGES, AND EVEN IF ANY REMEDY FAILS OF ITS ESSENTIAL PURPOSE

SOME STATES AND COUNTRIES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU. TO THE EXTENT PERMITTED BY YOUR LOCAL LAW, IF YOU HAVE ANY BASIS FOR A REMEDY BEYOND REPAIR REPLACEMENT, OR REFUND—SEE SECTION 6(c), MICROSOFT'S LIABILITY TO YOU CAN BE NO MORE THAN THE PURCHASE PRICE PAID FOR THE MICROSOFT PRODUCT (AS APPLICABLE)

All parts of this Warranty apply to the maximum extent permitted by your local law or unless prohibited by your local law. If a court or arbitrator holds that Microsoft cannot enforce a part of this Warranty as written, those parts shall be deemed replaced with similar terms which reflect the intended economic purpose as closely as possible to the extent enforceable under the relevant law or determined by the statutory provisions (or where a local court or arbitrator will not amend this Warranty, such part will be severed), but the rest of this Warranty

10. Choice of Law In Australia, this Warranty is governed by and is to be construed in accordance with the laws applicable in New South Wales. In New Zealand, this Warranty is governed by and is to be construed in accordance with the laws

Country of Purchase	Microsoft Contracting Entity	Address	Phone Customer Support	
Australia	Microsoft Pty Limited	1 Epping Road, North Ryde NSW 2113, Australia	13 20 58	
New Zealand	Microsoft New Zealand Limited	Level 5, 22 Viaduct Harbour Avenue, Auckland, New Zealand	0800 800 004	

EN-ANZ-XB-02-01

SUMMARY OF MANUFACTURER'S LIMITED WARRANTY Please read the entire Limited Warranty at support.microsoft.com/warranty. By purchasing or using the Microsoft Product, you agree to its terms Microsoft warrants that the Microsoft Product will no malfunction under normal use conditions for one year (90 days for replacement components sold sepa refurbished Xbox consoles, and all Xbox accessor except Xbox Elite Wireless Controller Series 2; two ears for HoloLens 2 Industrial Edition only) from

e date of original purchase from an authorized reselle The warranty excludes normal wear and tear, cosmetic damage, damage caused by external causes including being dropped, exposed to liquid, inadequate ventilat use not in accordance with Microsoft's instructions, hacking viruses or other malware, and damage caused by repairs or modifications by someone other than Microsoft or a Microsoft-authorized service provider, or by using anothe company's parts. If your local law gives you any implied warranty, including of merchantability, its duration is the same as this warranty. Some states, provinces,

or countries do not allow limitations on how long a

mplied warranty lasts, so the above limitation may

not apply to you. To obtain warranty service, first use

the troubleshooting tips at support.microsoft.com. If they do not solve your problem, follow the online process at support.microsoft.com/warranty Other exclusions and limitations apply This warranty gives you specific contractual rights and is in addition to, not in place of, any statutory rights you may have under local consumer or other laws applicable to you. You may also have other rights which vary fron state to state or by province or country. Other than as permitted by law, Microsoft does not exclude, limit, or suspend other rights you may have, including those that may arise from the nonconformity of a sales contract. EN-APOC-XB-02-01

REGULATORY INFORMATION · Not intended for use in machinery, medical, or industrial applications.

This product is for use with NRTL Listed (UL, CSA ETL. etc.), and/or IEC/EN 60950-1 or IEC/EN 62368-1 ompliant (CE marked) Information Technology equipment. · No serviceable parts included. • Operating temperature: +5°C (+41°F) to +35°C

Exposure to Radio Frequency (RF) EnergyModel 1790, 1914, 1944, 2065: This device contains radio transmitters and has been designed, manufactured and tested to meet the Federal Communications Commi (FCC), Innovation, Science and Economic Developme Canada and European guidelines for RF exposure and

Product Specific Absorption Rate (SAR) information is available at sar.microsoft.com. FCC website at www.fcc.gov/general/radio-frequency-safety-0

ISED website at www.ic.gc.ca/eic/site/smt-gst.nsf/eng/sf01904.html For 802.11a and 802.11n 5GHz devices only
This device operation in the band 5150-5250 MHz is
only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems.

Microsoft Corporation; One Microsoft Way; Redmond WA 98052-6399; U.S.A. United States: (800) 426-9400; Canada: (800) 933-4750. Disposal of waste batteries and electrical and electronic equipment This symbol on the product or its batteries or its packaging means that this product and any batteries it contains must not be disposed of with

your household waste. Instead, it is your sponsibility to hand this over to an applicable collection point for the recycling of batteries and electrical and electronic equipment. This separate collection and recycling will help to conserve natural resources and prevent potential negative consequences for human health and the environment due to the possible presence of hazardous substances in batteries and electrical and electronic equipment, which could be caused by inappropriate disposal. For more information about where you should drop off your batteries and electrical and electronic waste, please contact your local city/municipality office, your household waste disposal service, or the shop where you purchased this product.
Contact eRecycle@microsoft.com for more information

and waste batteries This product may use Lithium, NiMH, or alkaline

about waste from electrical and electronic equipment

Complies with MDA standards DA107473 R - NZ

COPYRIGHT logo, Xbox, the Xbox logo are trademarks of the Microsoft group of companies

CUSTOMER SUPPORT For answers to common questions, troubleshooting steps, and Xbox Customer Support contact information, visit support.microsoft.com.

XBOX 配件产品手册

XBOX 保修协议与软件许可条款 您必须接受《硬件保修和协议》、《MICROSOFT 服务协 议》和《软件许可条款》 购买或使用 Microsoft 产品,即表示您同意:

 制造商限期硬件保修和协议(某些国家或地区的制造 商硬件保修和协议)请在下方或前 support.microsoft.com/warranty 查看。 Microsoft 服务协议请前往 microsoft.com/msa 查看该协议适用于 Xbox 在线服务和 Microsoft Studio 游 戏和应用程序的使用。 软件许可条款,请参见xbox.com/slt 请阅读这些协议。若您不接受,请勿设置或使用 Xbox 产品 (主机或配件)。请将 Xbox 产品退还给 Microsoft 或您的零售商,以办理退款。

此符号指示本指南中有关安全及健康的信息。 请阅读本指南 , 了解您所购买产品的重要安全与健康

注意:请阅读安全与健康信息 ft产品本着安全和有效的理念开发而成。请阅读 本指南,了解关于设备的重要安全与健康信息,以及适 用于设备的有限保证条款。本指南旨在帮助你更加舒适和高效地使用本设备。未遵守说明和未正确设置、使用 和维护本设备,会增加发生严重人身伤害、死亡或财产 你可以在 support.xbox.com 上获得更多支持。

注意:请阅读使用说明 未能正确设置、使用和维护本产品可能会增加设备损坏的风险。请阅读本指南并保留所有印刷指南以供将来参 表。要获得更换指南,请前往 support.xbox.com或参阅"Microsoft帮助和支持"板块以获取联系信息。 ▲ 小心:线缆安全 散开的设备线缆和由线存在潜在的继倒危险 备必使所

有线缆远离人员和宠物,避免其在该区域活动或穿行时 偶然绊倒或拉动这些线缆。请勿让儿童玩耍线缆。为避 免线缆和电线损坏。 保护电线不被踩踏或挤压。 避免电线被挤压或过度弯曲,尤其是连接至墙上的 请勿猛拉、打结、过度弯曲、拉扯或以其他粗暴方式对待电源线。不要将电源线缠得太紧,尤其 是在电源模块周围。请松散地盘绕起来,切勿对 放置设备或电源供应器时,请确保电源线没有过于弯 曲,请勿将连接器推撞墙壁或坚硬的表面。

请勿将电源线暴露于热源处。

请勿让宠物或儿童啃咬或咀嚼电源线。

、磨损、破裂或任何形式的损坏,立即停止使 。我们建议您使用正品的 Microsoft 备用电源或电 **缴更换损坏的电源线或电缆。** 发生雷雨或长期闲置时,请拔下充电线或电缆。 警告:常规电池安全 您的设备中使用了一次性或可充电电池。一次性电池或可充电电池使用不当或误用可能会导致受伤、死亡、设 备损失,并可能由于电池漏液、着火、过热或爆炸而损

• 断开电源线时,请拿住插头拉拔,切勿拉动电源线。

定期检查电源线和电缆。如果电源线或电缆出现发

渗漏的电池液有腐蚀性,并且可能有毒。它可以造成烧伤,如果被误食,可能会造成伤害或是致命。 为了减少使用一次性或可充电电池时受伤的风险 • 将电池置干儿童无法接触之处。 仅使用设备附带的充电器对充电电池进行充电。不 当的充电方法可能导致火灾或爆炸。 当设备中的电池变得老旧、电量不足或耗尽,请立即取出。根据当地、地区或国家法律或法规,回收 或外理老旧 电量不足或耗尽的电池。

若您的设备将要长期闲置,请取出电池。

避免接触电池液。如果电池漏液 避免泄漏的液体接触到您的皮肤。眼睛。衣物。 睛或衣物,请立即用水冲洗接触到的地方,并 酌情联系医生或其他医疗服务提供者 遵循设备提供的电池安装说明,小心地取出 • 插入新电池前,用干燥布料彻底清洁电池舱 或遵照电池制造商的清洁建议操作。 我们建议您使用经 Microsoft 批准的电池组。使用相 司类型和额定值的电池,替换设备随附的一次性或

请勿拆卸、挤压、打开、穿刺、切损、短接外部的 点或电路,不要将其暴露于 40°C (104°F)以上的温 度下,或将电池置入火中或水中。 新旧电池或不同种类的电池(例如碳锌电池和碱性 电池)不得混用。 请勿使金属物体接触设备上的电池端子,否则可能 发热并导致烫伤。 请勿将电池或电池组与其他金属物体一同携带或置 请勿将电池供电设备长时间暴露于直射阳光下。

请勿将电池浸入水中或使其沾湿。 如果电池受潮,请勿使用。请勿尝试使用电吹风、 烤箱或微波炉干燥电池或电池组。 请勿将电池直接与壁装电源插座或汽车点烟器插 请勿撞击、抛掷、踩踏电池或使电池遭受严重的物 请勿改装或改制电池,试图将异物插入电池,请勿将其浸入或暴露在水中或其他液体中,请勿将其暴 露在火中、爆炸或其他危险中。 请勿靠近火源或在高温条件下对电池充电。 摔落设备或其电池,特别是摔落在坚硬的表面上 可能会损坏设备及其电池。如果您认为设备已损 坏,我们建议您寻求专业协助以进行检查。 切勿使用损坏的电池。如果电池出现划痕或刮痕

请立即将其放置在一旁并妥善处理。使用损坏的电 池可能会导致短路、过热以及其他组件故障。 ▲ 警告:电池更换和设备维修(用户可更换电池) 设备中的电池如果是用户可自行置换的电池,则可以打开电池盒,按照《快速入门指南》上的电池更换说明来更换电池。Microsoft建议您寻求专业人员帮助来处理所 有其他设备的维修,如果您自行维修,则请格外小心

拆解和/或维修设备可能会有电击、设备损坏、火灾、人 身伤害的风险以及其他危险。 谨慎使用您的 Microsoft 设备。 本设备由金属和塑料制 成,内部包含敏感的电子元件。如掉落、遇火、穿刺或压碎,或者与液体接触,可能会受损。如果您怀疑设备或其地冲存在损坏,请停止使用,因为它可能会导致过

警告:可穿戴设备发热相关注意事项 您的设备可能在正常使用时发热。本设备符合《国际安全标准》(IEC 60950-1和 IEC 62368)所规定的可供用 户接触的表面温度限值。 为减少热量相关问题,请遵守

当您的设备在接触到枕头、毛毯或其他柔软材料的情 况下运行时,请格外小心,因为这些材料可能妨碍空 气流动,从而导致设备过热。 如果您的设备发热令您感到不适,请取下设备,休 如果您的设备已使用了很长时间,则它的表面可能会 温度很高。虽然温度不至于灼热到无法触摸,但是

如果长时间与设备保持物理接触,那么可能会对您的

皮肤造成低热损伤。 切勿将您设备的供电电源(PSU)置于家具或其他可 能因受热而损坏的表面上,因为 PSU 表面的温度在 正常使用过程中可能会升高。 ▲ 注意:皮肤刺激(可穿戴设备) 该装置由通常用于可穿戴消费电子设备的材料制成。但是,某些人可能因为过敏或敏感原因产生皮肤刺激。为

了降低皮肤刺激的风险: • 请完期清洁你的设备 • 避免在设备接触皮肤的部分使用洗剂或其他产品。 • 请勿在受损皮肤处佩戴。 在适当的情况下,请收紧调整装置,直至佩戴舒适 又不至干紧勒。 • 如果对您的皮肤产生刺激,请停止使用本设备。

• 如果症状很严重或没有改善,请向医生进行咨询。 ♠ 警告:注意周围环境 为了减少因分心造成伤害或死亡的潜在风险,请勿在驾 驶、操作机器、骑行、步行或从事其他需要专注精力的 活动时使用您的设备。建议不要在驾驶车辆或骑行时 单独使用本设备,也不要通过耳麦或耳机进行使用(即 使仅在一只耳朵中使用),上述情况可能在您的社区中 请将耳机或耳麦的音量始终保持在能够听清旁人讲话以 及注意危险情况提示声的水平,以便更好地保护您的听

多动设备的法律法规。 其他减少与分心相关风险的常识 性建议包括: • 切勿输入或查看短信或电子邮件。 切勿輸入导航信息。 • 切勿在网上冲浪或执行任何其他转移注意力的任务。 警告:维修风险

打开和/或维修设备可能会有电击、设备损坏、火灾、 人身伤害的风险以及其他危险。Microsoft 建议您寻求设备维修的专业协助,并且如果需要自行维修,请多 ▲ 警告:本设备零部件具有磁性 设备所包含的一些磁性部件,可能会吸引金属物体。为 了降低产生火花以及对您的设备、其他物品或人体可能 发生的伤害的潜在风险。在连接设备或充由连接器之 ,请确认电气连接区域没有金属物体存在。 请勿将磁 感设备 信用卡 其他磁性存储介质置于设备附近 避

免本设备与其他设备之间出现干扰、引起医疗设备操作

中断或者磁性存储数据损坏。

抹布轻轻擦拭并擦干。

▲ 警告:清洁 通过采取以下预防措施,可以减少清洁期间起火、触电 或损坏 Microsoft 设备的风险: • 清洁之前,请拔下所有电缆并关闭设备。 仅清洁设备外部。 • 仅使用干布清洁. 对于带有风扇、通风孔、端口或类似开口的设备 轻轻清洁风扇、通风孔或其他开口的外表面,

• 请勿将物体插入风扇、通风孔、端口或其他

请勿尝试通过浸入液体来清洁接头。只能用干净的

▲ 警告:光敏性癫痫发作 些图案时可能会引发癫痫症状。即使无发作记录或癫 病史的人也可能存在未确诊的病症,在观看电子游戏或 移动图像时引发此类"光敏性癫痫发作" 此类癫痫发作可能具有多种症状包括头晕、视力模糊、 眼部或面部抽搐、手臂或腿部抽动或摇动、方向感丧 失、意识模糊或暂时失去意识。癫痫发作还可能引发知觉丧失或惊厥,从而导致跌倒或撞击邻近的物体。若您出现任何此类症状,立即停止玩游戏并就医。家长应观 察并询问子女是否出现以上症状—儿童和青少年比成年 人更易于出现此类癫痫发作。通过采取以下预防措施, 可降低发生光敏性癫痫的风险:

 与视频屏幕保持一定距离。 • 使用较小的视频屏幕。 当您困倦或疲劳时切勿玩游戏。 若您或您的任何亲属有发作记录或癫痫病史,请在玩游

▲ 警告:肌肉骨骼症候群 使用电子输入设备可能导致严重受伤或功能失调。和许 多活动一样,您在使用计算机时,手部、臂部、肩部、 颈部或其他身体部位可能偶尔出现不适。但是,如果不适、疼痛、抽痛、刺痛、麻痹、灼热感或僵硬感等症状 持续存在或反复出现,则切勿忽视这些警告信号,应立 即向合格的专业医疗人员问诊,即使这些症状不是在 您使用计算机时出现的也应如此。此类症状可能与神经、肌肉、肌腱或身体其他部位的疼痛、永久性损伤或

这些肌肉骨骼失调症 (MSD) 包括腕管综合症、腱鞘炎、肌腱滑膜炎以及其他相关的病症。虽然研究人员还不能回答很多有关肌肉骨骼失调症的问题,但是普遍认为很 每个人在工作和从事其他活动(包括使用键盘或鼠标) 期间调整和使用其身体的方式等。从事某项活动的时间长短也可能成为不适感产生的原因。

您可以访问 https://support.microsoft.com 和 xbox.com/playhealthy 并查看指南("健康游戏指南"),它们有助于您更舒心地使用设备并降低发生 MSD 的风险。 警告: 窒息的风险 该设备包含的一些细小部件具有风险,可能会造成3岁以下的儿童窒息。请将小零件放置于远离儿童的地方。

确保使用视频游戏配件与 Xbox 主机玩游戏的孩子可以 在其限制范围内安全地玩耍,并确保他们了解主机和配 件的正确用法。 ▲ 警示: 听力安全 佩戴耳机或耳麦时频繁或长时间暴露在高噪声或声音环 境中会造成暂时性或永久性的听力损伤。个体对噪音引起的听力损伤和潜在听力问题的敏感性各不相同。此 外,设备产生的音量可能会因声音的特性、设备设置 和所使用的耳机或耳麦而有所差别。因此,这里没有 个适用于每个用户或每个声音、设置和设备组合的

♠ 警告:使用视频游戏配件

这里介绍了一些常识性建议,帮助您在设备上使用耳机或耳麦时最大限度地减少高噪声或声音的暴露危险: • 请最大限度地减少收听高音量声音的时间。您在一 天中听到的所有声音会有叠加效果。如果使用耳机 或耳麦以最大音量收听设备的音乐或其他内容,则 只需 15 分钟就会对您的听力造成永久性损害。如果 您同时处于其他高音量环境中,那么因收听高音量 而导致听力受损所需的时间就更短。 将耳机或耳麦插入设备之前,请始终先关闭设备上的 音量。声音越大,损害听力所需的时间就会越短。

将耳机或耳麦插入设备之前,请始终记得调小设备 的音量。将音量设置为在安静环境下可清晰听到即 可,不要再提高音量。 请勿在开始收听后提高音量。耳朵在一定时间后可 以适应高音量,这样高音量听起来就像正常音量一 样,但高音量声音仍然可以损害您的听力。 请勿提高音量来掩盖外部的噪音。 外部噪音和耳机或 耳麦的声音叠加在一起就可能损害您的听力。密封或 降噪耳机可削弱外部噪音,使您无须调高音量。 如果您听不清旁边的人以正常音量所说的话,则请 降低音量。可以盖住正常声音的音量可能会损害您 的听力。即使在使用封闭式耳机或降噪耳机的情况 下,您也应该确保能够听清旁人讲话的声音。

耳机和耳麦可能会吸入一些危险物品,如订书钉和 回形针。使用前请务必检查耳机或耳麦。 您所在地区可能禁止或限制驾车时使用耳机或耳 麦;请查阅当地法律和法规了解更多信息。 最后,留意听力受损的症状。最好的方式就是定期进行 耳科听力检查。如果发生下列情况,请停止在本设备上 使用耳机或耳麦,并检查您的听力状况 • 出现任何听力受损症状。 出现耳鸣。

• 说话的声音听起来模糊不清,单调而沉闷。

若要尽量减少听力损害的可能性,请将音量保持在

能与旁边的人正常交谈的水平。

警告: 个人医疗设备 电子设备发出的射频辐射和磁场会对其他干扰其他电子 设备的运行,导致它们发生故障。虽然您的设备在设计,测试和制造上均符合美国,加拿大,欧盟和日本等 国家/地区的射频发射规定,但设备中的无线发射器和电 路仍可能会对其他电子设备造成意外干扰。 使用起搏器的人应始终遵循以下注意事项: 美国心脏协会建议,无线设备与起搏器之间应至少保 持 15 厘米 (6 英寸) 的距离 , 以免对起搏器造成潜在

• 如果您为移动设备配备手机壳或手机支架,请选择

• 请勿将设备放置于胸前的口袋中。

非金属材质。

如果您有任何怀疑发生了干扰,请立即关闭设备 如果您使用的不是起搏器,而是其他医疗设备,请咨询 该设备制造商或您的医生,以便了解在该设备附件使用 其他设备的信息和获得指导 注意:无线设备登机 在登上任何航空器或将无线设备放入将接受检查的行李之前,请取出无线设备中的电池(如可拆卸),或关闭 无线设备(如有开/关装置)。请听取机上的广播,其中

会说明是否允许在机上使用设备。机上无线设备的使用 规定由航空公司自行决定。 ▲ 警告:射频 (RF) 能量暴露 设备包含的 Wi-Fi 和 Bluetooth® 无线发射器的设计、制造和测试均符合美国联邦通信委员会 (FCC)、加拿大工业 为了确保您暴露于 Wi-Fi 和蓝牙无线电产生的 RF 能量不 这些准则所规定的暴露限制,请调整带有显示屏的 设备、使显示屏侧不直接接触您的身体(例如避免将显 示器面朝下平放在膝盖或是与您的上半身直接接触)。 有关射频安全的其他信息,可以访问 FCC 网站 http://www.ic.gc.ca/eic/site/smt-gst.nsf/eng/sf01904.html

制造商有限硬件保证和协议 本制造商有限硬件保证和协议(以下简称"保证")是您 与微软(中国)有限公司(以下简称 "MICROSOFT")签订 您购买或使用 MICROSOFT 产品 , 即表示您同意本保 证。请阅读并保存一份副本,留作记录。如果您不接受本保证,请勿使用您的 MICROSOFT 产品,并向您的经销商 k MICROSOFT 退还未经使用的该产品 , 获取退款。如 果您退货,本保证将适用于在您退货前发生的情况。 等权利是对您根据消费者法或适用于您的其他法律享 有的任何权利的补充,而非替代。您可能还拥有其他权

外, MICROSOFT不会排除, 限制或暂停您可能享有的其

他权利,包括由于与销售合同不一致而产生的权利。

(a) "Microsoft 产品"是指从 Microsoft 或授权经销商 处购买的正版 Microsoft 硬件产品,或单独出售的更换组件。某些 Microsoft 硬件产品拥有自己的有限保 证而非本保证。 (b) "正常使用条件"是指根据说明手册、技术规格和 Microsoft 为 Microsoft 产品提供的任何其他支持文 档,在正常条件下的普通使用。 2. 持续时间 在不损害您根据当地法律有权享有的任何法律(法定) 权利的情况下,对于 Xbox主机和 Surface 计算机(包括笔记本电脑和平板电脑),本保证的有效期为自最初从 Microsoft 或授权经销商外购买之日起两年: 但对于 Xbo 和 PC 配件(控制器、鼠标、键盘、摄像头、耳机、耳塞、触控笔等)以及所有其他产品,本保证的有效期为自 最初从 Microsoft 或授权经销商外购买之日起一年。对于单

票之日;或(2)销售订单确定之日;或(3)Microsoft产

独出售的更换组件,本保证的有效期为三个月。

为避免疑义,该"购买之日"以下列时间中最早发生的一

1. 定义

3. 区域 本保证仅在中国有效。 4. 保证 (a) Microsoft 保证,在正常使用条件下, Microsoft产品 不会发生故障。 (b) 在不违背当地法律赋予您的法律(法定)权利的前 提下,本保证是 Microsoft 为您的 Microsoft 产品提 供的唯一担保、保证或条件。没有其他人可以代表 Microsoft 提供任何担保、保证或条件。 (c) 如果您当地法律给予您任何默示保证,包括针对特定目的的适销性或适用性的默示保证,则其有效期与本 保证相同。某些州、省或国家/地区不允许对默示保 证的持续时间加以限制,因此上述限制可能对您不适

5. 如何获得保证服务 在提供保证服务之前,Microsoft 或其代理商可能要求您提供 Microsoft 产品的购买证明。 (a) 在启动保证流程之前,请查看 support.microsoft.com 上的疑难解答提示。 (b) 如果疑难解答提示不能解决您的问题,请按照 support.microsoft.com/warranty上的在线流程进行操

Microsoft 产品寄给 Microsoft 进行维修之前,请确 保留您想要保存的任何数据或应用程序的富 本。Microsoft 对您的数据或应用程序概不负责,并 且将删除所有数据或应用程序;及 ii. 删除您认为属于机密信息的任何内容。如果您将机密 信息留在设备上,Microsoft 对您信息的机密性概不 负责。 保证服务可能仅在您购买 Microsoft 产品的国家/地区提 供。如果在请求保证服务时,设备所在的国家/地区

不提供保证服务,则 Microsoft 可能会为您提供其他

(c) **备份您的数据或应用程序并删除机密信息**。 在将

支持选项,并需要额外收费。 6. Microsoft 的责任 (a) 如果 Microsoft 确定在保证期内或任何法定保证期内 在正常使用条件下发生故障,Microsoft将(由其自行选择)维修或更换 Microsoft 产品或发生故障的零 件,或者在客户退回 Microsoft 产品后按购买价格退 款,除非您当地法律的强制性条款另有规定。除非您 当地法律的强制性条款另有规定,否则维修可能会使 用新的或翻新的零件,并且可能使用新的或翻新的设 A新的或翻新的专件,并且可能使用新的或翻新的设备进行更换。更换设备时,Microsoft 可自行决定使用相同型号的设备,或者在不可用时使用与原始型号 设备的外形、功能、性能以及颜色最接近的设备。替 换下来的 Microsoft 产 均归 Microsoft 所有。 (b) 除非您当地法律的强制性条款另有规定,否则在维修 或更换后, 您的 Microsoft 产品将在原始保证期的剩 余时间内或 Microsoft 向您发货后的 90天 内 (以较长 时间为准)受本保证保护。 (c) 除非您当地法律的强制性条款另有规定,否则 soft 负责维修或更换 Microsoft 产品或按购买价

期或任何法定保证期之后出现故障,或者如果您的 Microsoft 产品不在本保证范围之内,则 Microsoft 可 能会因为诊断和维修 Microsoft 产品的任何故障 (无 论成功与否)而向您收取费用。 7. 保证范围 在您当地法律允许的范围内, Microsoft 对以下情况不 承担任何责任,并且本保证不适用于以下情况(并且 osoft 可能不提供服务,包括收费服务)

(a) 您的 Microsoft 产品并非从 Microsoft 或授权经销商处

退款是您的唯一补救措施。

(b) 因使用非 Microsoft 制造、许可或提供的产品、应用 程序或服务(包括非 Microsoft 制造或许可的游戏和配件以及"盗版"游戏)而造成的损坏; c) Microsoft 产品的序列号或 IMEI 号被更改或删 (d) 由于任何外部原因 (包括掉落、暴露在液体中或在通 风不良的情况下使用) 造成的损坏 (e) 因使用不符合用户手册、技术规格或 Microsoft 提供 的任何其他说明而造成的损坏; (f) 由 Microsoft 或 Microsoft 授权的服务提供商以外的其 他人进行修理或修改而造成的损坏;或因使用其他公 (g) 划痕、凹痕、其他外观损坏或由于正常磨损而合理预 (h) 因黑客入侵、破解、病毒或其他恶意软件或未经授权 访问服务、帐户、计算机系统或网络而造成的损坏。

(i) 对 Microsoft 产品的软件或硬件进行修改,以使用恶

埜田安全性武内容保护机制

Microsoft 产品,或不会发生数据丢失。

8 某些损害的排除和责任限制

意代码、恶意软件、自动程序、蠕虫病毒、木马病毒、后门程序、攻击、作弊、欺诈、黑客、隐藏诊断

或其他机制来更改 Microsoft 产品的功能或性能,包

ii. 让某些用户获得不公平的优势或降低其他用户的在线

iii 欺骗或欺诈 Microsoft 或其他公司: 或 iv. 可能损害产品或我们的系统。 仅当您的 Microsoft 产品与预先安装在 Micro Microsoft 操作系统,或该操作系统的任何更高版本一起 使用时,本保证才适用。 本保证不适用于 (a)性能随时间推移而降低的易损件。例 低,或 (b) Microsoft 产品在其上运行的 SIM 卡或任何网 络戓系统 本保证不适用于与 Microsoft 产品一起由 Microsoft 分销 Microsoft 不能保证无中断、及时、安全、无错误地使用

偶发、特殊或后果性损害;数据、隐私、机密性或利润的 任何损失,或无法使用您的 Microsoft 产品的任何情况概 不承担任何责任。即使已告知 Microsoft 该等损害的可能 性,并且即使任何补救措施均未达到其基本目的,该等排 除条款仍然适用。某些州、省和国家/地区不允许排除或 限制附带性或后果性损害的赔偿责任,因此上述限制或排 除条款可能对您不适用。 在法律允许的范围内,如果您有依据证明除本保证第6(c) 条约定的维修、更换和退货之外还可以主张其他救济的,则 Microsoft 对您的责任不超过为 Microsoft 产品支付的购 买价(如适用)。

除非您当地法律另有规定,否则 Microsoft 对任何间接、

斤原条款所反映的经济目的的方式予以替代实施(或者 当法院仲裁人/仲裁机构并未对该部分条款进行修正的情况,该部分条款予以分割处理),而未被认定无法执行 的其他条款将不发生变化。 本保证受中国法律约束并按中国法律解释。 ZH-CN-XB-02-01

本保证中约定的条款,除被当地法律禁止的部分外,将在(法律允许的)最大限度和范围内予以执行。如果本保证

中的一部分内容被法院或者仲裁人/仲裁机构认定不得由

Microsoft按照书面规定的内容予以执行,则该等无法执行的部分所涉及的事项将按照相关法律、法规所允许的最接

9. 附加条款

法规信息

及/武 IEC/EN 60950-1或 IEC/EN 62368-1兼容 (CE 标 志)的信息技术设备一同使用。 未包含可维修部件. 操作温度: +5°C (+41°F) 至 +35°C (+95°F)。 射频 (RF) 能量的辐射: 号 1914、1790、1944,2065: 本设备包含无线电发射 ,其设计、制造和测试符合联邦通信委员会 (FCC)+3

本产品用于与 NRTL 列出的 (UL、CSA、ETL等)

不适用于机械、医疗或工业用途。

加拿大创新、科学和经济发展部以及欧盟有关 RF 暴露和 产品特定吸收率 (SAR) 信息可前往 sar.microsoft.com 获 FCC 网站

www.fcc.gov/general/radio-frequency-safety-0 www.ic.gc.ca/eic/site/smt-gst.nsf/eng/sf01904.htm 仅适用于 802.11a 和 802.11n 5Ghz 设备

此设备在 5150-5250 MHz 频带内的操作仅用于室内,以

降低对同频道移动卫星系统产生有害干扰的可能性。

Microsoft Corporation; One Microsoft Way; Redmond WA 98052-6399; U.S.A. 美国: (800) 426-9400;加拿 废旧电池与电气和电子设备的处置 产品或其电池或包装上的此符号表示此产品及其 所含的任何电池不得与生活垃圾一同丢弃。同 时,您有义务将其移送至适用的收集点,以便回 收利用电池以及电气和电子设备。由于电池和电 子电气设备中可能存在有害物质,因而分类收集 和同收利用有助于保护自然资源。防止由于处理 不当而 对人类健康和环境造成潜在的负面后果。如需深入了解 在何处投放电池以及电气和电子废物,请联系您当地的

证的元以次。 城市市政管理机构、您的生活垃圾处置服务机构或购实 此产品的商店。请联系 eRecycle@microsoft.com,获取 有关电气和电子设备废物以及废旧电池废物的更多信 此产品可使用锂电池、镍氢电池或碱性电池。

©2024 Microsoft Corporation. Microsoft . Microsoft 微标 Xbox, Xbox 徽标等商标皆为 Microsoft 集团公司所有。 更多详情如常见问答,故障排除步骤以及 Xbox 客户支

部件名称	有害物质					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr (VI))	多溴 联苯 (PBB)	多溴二苯醚 (PBDE)
外壳	0	0	0	0	0	0
连接件	0	0	0	0	0	0
电路板 组件	Х	0	0	0	0	0
线缆	0	0	0	0	0	0
GB/T 2	有害物 26572	勿质在 规定的	该部份	#所有均 要求以	下。	中的含量均在
出 GB/T265	72 规划	定的限	量要才	₹.		
注:本广品技术或部件		хн	3/尿囚:	定:巩膜	川牧汉生	可供选择的替代

有害物质 部件名称
 电池组
 O
 O
 O
 O

 连接线
 O
 O
 O
 O
 本表格依据 SJ/T 11364 的规定编制。 :表示该有害物质在该部件所有均质材料中的含量均在GB/T26572规定的限量要求以下。

: 表示该有害物质至少在该部件的某一均质材料中的含量超 出 GB/T26572 规定的限量要求。 注:本产品标有"X"的原因是:现阶段没有可供选择的替代 技术或部件。 型号 1944: 有害物质 部件名称 扬声器 O O O O O X 0 0 0 0 0 本表格依据 SJ/T 11364 的规定编制。 O: 表示该有害物质在该部件所有均质材料中的含量均在 GB/T 26572 规定的限量要求以下。 :表示该有害物质至少在该部件的某一均质材料中的含量超

注:本产品标有"X"的原因是:现阶段没有可供选择的替代 技术或部件。 型号 1984: 有害物质 b) 汞(Hg) 镉(Cd) 氘(NB) 祭溴 本醚 (PBDE) 部件名称 电路板
 扬声器
 O
 O
 O
 O

 缆线
 O
 O
 O
 O
 本表格依据 SJ/T 11364 的规定编制。 :表示该有害物质在该部件所有均质材料中的含量均在 GB/T 26572 规定的限量要求以下。 :表示该有害物质至少在该部件的某一均质材料中的含量超 出 GB/T26572 规定的限量要求。

出 GB/T26572 规定的限量要求。

注:本产品标有"X"的原因是:现阶段没有可供选择的替代 有害物质
 示
 (Hg)

 (Cd)
 (Cd)

 (Cd)
 (Cr (VI))

 (PBB)
 (PBDE)
 x | 0 | 0 | 0 | 0 | 扬声器 0 0 0 0
 电池
 O
 O
 O
 O

 连接线
 O
 O
 O
 O
 本表格依据 SJ/T 11364 的规定编制。 :表示该有害物质在该部件所有均质材料中的含量均在 GB/T 26572 规定的限量要求以下。

: 表示该有害物质至少在该部件的某一均质材料中的含量超 出 GB/T 26572 规定的限量要求。 注:本产品标有"X"的原因是:现阶段没有可供选择的替代 技术或部件。 有害物质 部件名称 | x | o | o | o | o | 连接线 O O O O O 本表格依据 SJ/T 11364 的规定编制。 O : 表示该有害物质在该部件所有均质材料中的含量均在 GB/T 26572 规定的限量要求以下。 :表示该有害物质至少在该部件的某一均质材料中的含量超 出 GB/T 26572 规定的限量要求。

注:本产品标有"X"的原因是:现阶段没有可供选择的替代

XBOX 配件產品手冊 XBOX 瑕疵擔保和軟體授權條款的合約

您必須接受硬體瑕疵擔保與合約、MICROSOFT 服務合約 及軟體授權條款 購買或使用您的 Microsoft 產品‧表示您同意: • 下列及位於 support.microsoft.com/warranty 的製造 商有限硬體瑕疵擔保與合約(在某些國家/地區則為 製造商的硬體瑕疵擔保與合約)。 • 位於 microsoft.com/msa 的 Microsoft 服務合約。其 規範 Xbox 線上服務及 Microsoft Studio 遊戲和應用 位於 xbox.com/slt 的軟體授權合約

注意:請閱讀安全與健康資訊 Microsoft 產品是基於安全性和有效性而開發。請閱讀本 指南·了解有關您裝置的重要安全與健康資訊,以及適 用於您裝置的有限擔保條款。本指南旨在協助讓您使用 此裝置時更舒適且更具生產力。未依照指示正確安裝 使用與維護您的裝置,可能會提高造成嚴重個人傷害 死亡或財產損害的風險。 您可以在 support.xbox.com 找到其他支援。

↑ 注音·續線與雷線安全 外露的裝置纜線和電線會造成潛在的絆倒危險。請妥善 整理所有的纜線和電線、避免人員或寵物走動或經過該 區域時遭到絆倒或被意外拉扯到。請勿讓兒童把玩纜線 和電線。為了避免損壞纜線和電線: 保護好電線,以免遭踩踏或碾壓。 保護好電線,以免受擠壓或產生銳角彎折,尤其是 在連接到牆壁電源 (主電源) 插座、電源供應器和您 裝置的地方,更應注意。 非緊繃的角度) 來纏繞雷源線。 銳角彎折·並且連接器並未抵著牆壁或堅硬表面 請勿讓電源線暴露於熱源。 • 請勿讓寵物或兒童啃咬電源線 拔除電源線時、請拉動插頭、不要拉扯電線

▲ 警告:一般電池安全 您的裝置使用一次性或可充電式電池。不當使用或濫用 一次性或可充電式電池可能會導致電池液洩漏、火災、 過熱或爆炸・因而造成受傷、死亡、財產損毀・以及損壞您的裝置和其配件。 電池液具腐蝕性,而且可能有毒。這會造成灼傷,如果 吞食,還可能有害或致命。 為了降低使用一次性或可充電式電池時造成傷害的風險 • 請將電池放在兒童接觸不到的地方。 請僅使用裝置所提供的充電器·為可充電式電池進 行充電。不當的充電方式可能會導致火災或爆炸。 立即取出裝置中廢舊、電量低或破損的電池。依據 當地、區域或國家/地區法律或規定回收或處置廢 舊、電量低或破損的電池。 長時間收存您的裝置之前、請先取出其中的電池 • 避免接觸電池液。如果電池液外洩:

提供的一次性或可充電式電池更換成類型及額定值

Microsoft

包含 Wi-Fi 與 Bluetooth® 無線電發射器的裝置·在設計、製造和測試上均符合美國聯邦傳播委員會 (FCC)、 加拿大工業部與歐盟針對射頻 (RF) 暴露與特定吸收率所 制定的準則。

如需其他關於射頻 (RF) 安全性的資訊,請前往 FCC 網

製造商有限保固摘要 限保固。購買或使用 Microsoft 產品 · 即表示貴用戶同 故障·本保固期間為一年(單獨銷售的替換元件、整修的 Xbox 主機·以及 Xbox Elite 無線控制器 Series 2 除外 外觀損壞、因外部原因(包括掉落、接觸到液體、不當過 授權的服務供應商以外的其他人所進行的修復或修改

(包括適售性的默示擔保),則其有效期間與本保固相同 美國某些州、省或某些國家/地區並不允許對默示擔保 之期限有任何限制,因此上述限制可能並不適用於貴用 戶。若要取得保固服 務 · 請先使用 support.microsoft.com 的疑難排解提示。如果疑難排解提示無法解決貴用戶的問題 · 請遵循

適用其他排除條款和限制。 本保固授予貴用戶特定的合約權利,且係外加於當地消費 者或其他適用於貴用戶之法律所賦予的任何法定權利。 而非加以取代。根據美國各州及依照各省或各國家/地區而非加以取代。根據美國各州及依照各省或各國家/地區而定,貴用戶亦可能享有其他權利。除了法律許可的情況 以外, Microsoft 不會排除、限制或暫時停止費用戶可 能享有的其他權利·包括可能因與銷售合約不相符而產

• 不適用於機械、醫療或工業用途。 資訊技術設備 不含可維修零件

暴露於射頻 (RF) 能量:

您可以在 sar.microsoft.com 找到有關產品特定吸收率 ISED 網站 www.ic.gc.ca/eic/site/smt-gst.nsf/eng/sf01904.html 僅限 802.11a 和 802.11n 5GHz 裝置 這個在頻帶 5150-5250 MHz 的裝置操作僅限室內使用

以降低對同通道行動通訊衛星系統造成有害干擾的可

Microsoft Corporation; One Microsoft Way; Redmond

WA 98052-6399; U.S.A. 美國: (800) 426-9400;加拿 力。請查閱並遵守所在社區有關開車或驗腳踏車時使用 行動裝置的法律規定。 其他可避免與分心相關聯之風險 取得審驗證明之低功率射頻器材,非經核准,公司、商號 3.使用有另个特值百至支票中,加入另中3.安全所成了之 特性及功能。低功率射頻器材之使用不得影響飛航安全及 干擾合法通信;經發現有干擾現象時,應立即停用,並改 善至無干擾時方得繼續使用。前述合法通信,指依電信管 通信或工業、科學及醫療用電波輻射性電機設備之干擾

您的裝置零件具有磁性,可能會吸引金屬物品。為了降低發生火花、導致裝置、其他物品損壞和/或可能造成人身傷害的潛在風險,在將裝置或充電連接器互相連接之 電子設備中可能含有有害物質、這種分開收集和 回收的方式將有助於自然資源保護,並且避免因為不適 請先確認電氣連接區域沒有金屬物品。為了降低您 當的處理而對人類的健康和環境造成潛在的負面影響 如需有關如何丟棄電池與電子電機廢棄物的詳細資訊 作或毀損磁性儲存資料的可能性,請勿在此裝置附近放 置對磁性敏感的裝置、信用卡或其他磁性儲存媒體。

• 輕輕清潔風扇、通風口或其他開口的外部表 面,以擦去任何堆積的灰塵。 • 請勿將物品插入風扇、通風孔、連接埠或其 請勿試圖以浸入液體的方式來清潔連接器。請只用 有些人可能會因為動態影像或電玩遊戲中出現的閃光或 如需一般問題的解答、疑難排解步驟以及 Xbox 客戶支援 部門連絡資訊·請前往 support.microsoft.com 圖形而出現癲癇症狀。甚至連沒有突然發作經歷或癲癇

けます。

商雷洲

意識。光敏性癲癇還會導致失去意識或抽筋,並因此摔 請立即停止遊戲並就醫診治。家長應該在場看顧或詢問 其子女是否有以上症狀 — 兒童及青少年比成人更有可能 發生此類癲癇症。您可以採取下列預防措施來降低發生 への同意 - ドウェアの保証と同意、Microsoft サービス規約 あります たものと見なされます。

> めの指示事項をこのマークで表しています。 ご購入の製品の安全な取り扱いに関する情報について は、このガイドをお読みください。 通知:安全と健康に関する情報をお読みください

> support.xbox.com で必要に応じた追加サポートが得られます。 通知:取扱説明書をお読みください 本製品のセットアップ、使用、および取り扱いを適切 に行わなかった場合、製品の損傷の可能性が高まるお それがあります。このガイドをお読みになり、印刷物 はすべて保管しておいてください。または、 とサポートのセクションを参照し、連絡先を確認して

が通る場所から遠ざけて配置してください。お子様 でいたり誤って引き抜くことのないように、人やペットが通る場所から遠ざけて配置してください。お子様 がケーブルやコードで遊ばないようにしてください。 コードとケーブルの損傷を回避するため、以下の点に 注意してください。 コードが踏まれたり押しつぶされないように保護 してください。 電源コードをはさんだり、折り曲げたりしないて ください。特に、壁の電源コンセント、電源アダ プター、製品と接続されている部分については注 意してください。 電源コードを引っ張ったり、結んだり、折り曲げ

デバイスまたは PSU を配置するときは、コードが 急激に曲がっていないこと、およびコネクタが壁 や硬い表面に押し付けられていないことを確認し 電源コードを熱源に近づけないでください。 ペットやお子様が電源コードを口に入れないよう

雷雨の際や、長期間にわたって使用していない場 合は、充電ケーブルまたはコードを取り外してく ▲ 警告: 一般的なバッテリーの安全性

使い捨て電池や充電池を使用する場合の傷害の危険性 を抑えるため、以下の点に注意してください。

古い電池、電力が弱くなった電池、すり切れた電池 はすぐに製品から取り外してください。古い電池、電力が弱くなった電池、すり切れた電池は、地方自 治体または国の法律や規制に従ってリサイクルする 製品を長期間保管する場合は前もって製品から電 電池液に触れないでください。液漏れの場合は、

• 請勿讓金屬物品觸碰裝置的電池接線端子,這些物

請勿將電池或電池組與其他金屬物品一起攜帶或

請勿讓雷池供雷的裝置在陽光直射下長時間曝曬。

如果電池受潮,請勿使用。請勿嘗試使用吹風機 傳統烤箱或微波爐乾燥電池或電池組。

請勿直接將電池連接到牆壁插座或汽車點煙器插

請勿改裝或重製電池、試圖將外來物品插入電池 將電池浸入或暴露在水中或其他液體、暴露在火

讓您的裝置或其電池掉落 (尤其是落在堅硬表面上) 可能會損壞裝置及其電池。如果認為已發生損壞

絕不使用損壞的電池。如果您的電池出現刮痕或凹

痕·請立即取出電池並適當丟棄。使用損壞的電池

警告:電池更換和裝置維修 (使用者可更換的電池)

池。Microsoft 建議您對裝置的所有其他修復工作皆應尋

謹慎。打開及/或維修裝置可能會引起電擊、裝置損壞

請小心搬動您的 Microsoft 裝置。 此裝置是以金屬和塑

膠製成,並且內部具有敏感的電子組件。 裝置可能因掉落、燃燒、穿刺、擠壓或與液體接觸而損壞。 如果您認

為裝置或其電池已損壞、請停止使用裝置、以免裝置過

您的裝置在正常使用過程中可能會變得非常熱。 裝置符合國際安全標準 (IEC 60950-1 和 IEC 62368) 所定義的使

用者無障礙介面溫度限制。 若要減少因變熱所引發的潛

• 在有枕頭、毛毯或其他柔軟材質接觸裝置的情況下操

如果您的裝置出現令人不舒服的溫度,請取下裝置

如果長時間使用您的裝置,其表面可能會變得非常

保持實體接觸,您的皮膚可能會遭受低溫燙傷。

此裝置是由一般用於穿戴式消費者電子裝置的材料所製成。不過,某些人可能會因過敏或敏感而逐漸產生皮

膚疼痛或發炎的狀況。 為了減少皮膚因刺激而產生的

• 避免在裝置接觸皮膚的部分使用乳液或其他產品。

• 適當地調整鬆緊度・使之穿戴合身・但不要過緊造

• 如果您的皮膚出現不適症狀,請停止使用裝置

▲ 警告:注意周圍環境 為避免使用因分心而造成傷亡的潛在風險·請勿在開

使用亦然),這可能是您的社區所禁止的行為。

請勿打字,或者查看簡訊或電子郵件。

警告:本裝置的零件具有磁性

請勿輸入導航資訊。

維修,請務必小心。

▲ 警告:清潔

• 僅清潔裝置的外觀。

他開口

警告:光敏性癲癇

光敏性癲癇的風險:

慮的因素。

▲ 警告:窒息危險

危險。請避免讓兒童接觸到細小零件。

▲ 警告:使用視訊遊戲配件

如何正確使用主機和配件。

注意:聽力安全

與設備的組合。

乾布輕輕擦拭和擦乾。

• 以乾布清潔裝置。

車、操作機械、騎腳踏車、走路或從事需要您全神貫注

始終讓頭戴式裝置或耳機的音量調低到足以使您聽到他

人說話、提醒您危險狀態的聲響,並妥善保護您的聽

請勿瀏覽網路或谁行任何會轉移注音力的工作。

人員受傷或其他危險的風險。對於裝置維修·Microsoft 建議您尋求專業人員的協助·如果您要進行自己動手做

• 先拔除所有纜線並關閉裝置電源‧再進行清潔。

• 整理有風扇、通風孔、連接埠或類似開口的裝置時

病史的使用者也會在觀看動態影像或視訊遊戲時,發生

癲癇有各種症狀,包括頭昏眼花、視幻覺、眼部或臉部

抽搐、手腳痙攣、暫失方向感、精神混淆或者暫時失去

倒或碰撞附近物品而造成受傷。若出現上述任何症狀。

如果您自己或您的親友有癲癇史‧請在進行遊戲之前先

使用電子輸入裝置時,可能會因不當使用而導致嚴重傷

害或身體不適。與大部分的活動一樣,在使用電腦時

您可能偶爾會覺得手、手臂、肩膀、脖子或其他身體部

立有不適的感覺。但是,您若有長期或重複性的生理不

治療,即使症狀並非在您使用電腦期間出現,也不應忽

這些肌肉骨骼失調症 (MSD) 包括腕骨隧道症候群、肌

解答許多有關 MSD 的問題,但一致認為這些症狀的病

因與許多因素有關,其中包括:整體健康情況、壓力與

個人調適方式、醫療生理狀況,以及在工作或從事其他

活動 (包括使用鍵盤與滑鼠) 期間,個人調整與使用其

身體的方式。從事某項工作的時間長短可能也是需要考

有些指引可協助您更舒適地使用裝置·同時可能降低罹患

MSD 的風險,您可以在 https://support.microsoft.com 和

此裝置包含細小零件,可能會讓 3 歲以下兒童有窒息的

請確認兒童能在不超過自己極限的範圍內,安全地搭配

使用他們的 Xbox 主機與視訊遊戲配件,並確認他們了解

經常或長時間在使用頭戴式裝置或耳機時接觸大音量噪

經常或反时间住使用與戴式裝置或斗號时接觸入自星際 音或聲響·可能會導致暫時性或永久性聽力減損。個人 可能罹患噪音所致聽力減損和潛在聽覺問題的程度各有

不同。此外,裝置產生的音量也可能因音效性質、裝置 設定以及所用頭戴式裝置或耳機而異。因此,沒有單一 音量設定適用於所有的人,或適用於每一種音效、設定

以下提供一些常識性建議·希望您在搭配裝置使用頭戴式裝置或耳機時·盡量避免接觸大音量噪音或聲響:

• 縮短聆聽大音量聲響的時間。您每天接觸的所有聲

響都會加在一起產生影響。如果戴上頭戴式裝置或 耳機後,以最大音量聆聽裝置播放的音樂或其他內

容 · 15 分鐘內就會造成聽力的永久損害。如果您同

時又暴露在其他大音量聲響下,以高音量聆聽而造成聽力損害所需的時間會更短。

您接觸大音量聲響的時間越長,您的聽力就越有可

能遭到損害。聲響越大,造成聽力損害所需的時

務必先調低您裝置的音量,再將頭戴式裝置或耳機

插入裝置。將音量設定為可在安靜環境下清楚聽 見·不要調得再大聲。

• 開始聆聽後·請勿調高音量。對於大音量·您的耳

朵久而久之即可適應,因此聽起來就像一般音量一樣,但大音量依舊會損害您的聽力。

不要为了阳级外界隔音,而终音量調点。外面的隔

損害您的聽力。耳塞式或噪音消除耳機可以減少外

如果您無法了解附近正常說話者的意思,請調低音

為了降低聽力受損的可能性,請保持在適度的低音

耳機和頭戴式裝置可能會吸引造成危險的物品,例

您所在的地區可能會禁止或限制邊開車邊使用頭戴

最後·請留意聽力減損症狀。最好定期找聽力矯治醫師

檢查您的聽力。如果您遇到下列情況,請停止使用頭戴

美國心臟協會 (American Heart Association) 建議無線裝

• 如果您使用有護殼或護套的行動裝置,請選擇不具

置與心律調節器之間至少保持 15 公分 (6 英吋) 的距離

如訂書釘或回紋針。使用您的頭戴式裝置或耳機或之前,請務必先做檢查。

式裝置或耳機;如需詳細資訊・請查看您當地的法

所用的是耳塞式或噪音消除耳機·您也應該能聽到

音與頭戴式裝置及耳機內的聲響兩相結合

量。淹沒一般說話語音的聲響可能捐書聽力

界噪音、讓您不需要調高音量。

量,不妨碍您和附近的人繼續交談。

式裝置或耳機, 並就醫檢查聽力:

附近的人說話。

xbox.com/playhealthy (健康遊戲指南) 中找到這些資訊

腱炎、腱鞘炎和其他疾病等。雖然目前研究人員尚未能

的疼痛現象,也可能成為永久性失能傷害或失調。

適、疼痛、顫抖、刺痛、麻痺、燒熱感或僵硬等症狀。

可能引發「光敏性癲癇」的未確診病情。

• 坐在距離視訊螢幕較遠的地方。

在照明充足的室內進行遊戲。

▲ 警告: 肌肉骨骼失調疾病

不在感覺疲累或倦怠時進行遊戲。

• 使用較小的視訊螢幕。

• 如果症狀嚴重或持續存在,請洽詢您的醫師。

其他可能因接觸高溫而損傷的表面上。

▲ 注意:皮膚刺激性(穿戴式裝置)

定期清潔您的裝置。

• 不要穿戴在已受傷的皮膚上。

熱。 儘管裝置摸起來不感覺熱,但要是與其長時間

由於裝置的電源供應器 (PSU) 表面溫度可能會在正常使用過程中升高·絕不可將 PSU 放置在家具或任何

作裝置時·請務必小心謹慎·因為這些材質能阻擋空 氣流通·導致裝置過熱。

請勿敲擊、投擲、踩踏電池,或施以物理衝擊。

請勿在火源附近或在高溫條件下為電池充電

可能會造成短路、過熱及其他元件故障。

裝置若採用可由使用者更換的電池、請打開電池座

並依照《快速入門指南》的電池更換指示更換電

求專業協助・如果您要自己動手進行修復・請務。

火災和人員受傷或其他危險的風險

▲ 注意事項:高溫所引發的疑慮

在疑慮,請依照下列指導方針進行

建議您尋求專業協助以檢查裝置。

品可能會變熱並造成灼傷

• 請勿將電池浸入水中或沾到水。

源、爆炸或其他危險中

▲ 警告:暴露在射頻 (RF) 能量中 為確保您接觸到 Wi-Fi 與藍牙無線電所產生的射頻 (RF) 能量未超過上述準則所規定的暴露限值·請改變裝置的方向·避免顯示側直接與您的身體接觸·例如避免將顯示 器正面朝下平放在膝蓋或上半身。

站.網址為 http://www.fcc.gov/oet/rfsafety 以及加拿大工業局網站.網址為 http://www.ic.gc.ca/eic/ site/smt-gst.nsf/eng/sf01904.html •

請於 support.microsoft.com/warranty 閱讀完整的有 Microsoft 保證·Microsoft 產品在一般使用情況下不會 的所有 Xbox 配件的保固期間為 90 天: 僅限 HoloLens 2 工業版的保固期間為兩年)·從貴用戶向授權轉銷商原始購買日期當天開始計算。本保固排除一般磨損和撕扯 風、未依照 Microsoft 指示之使用、駭客、病毒或其他惡意程式) 所造成的損壞,以及因 Microsoft 或 Microsoft (或因使用另一家公司的零件) 所造成的損壞。如果貴用 戶的當地法律為貴用戶提供任何默示擔保

support.microsoft.com/warranty 的線上程序。

ZH-APOC-XB-02-01

法規資訊 本產品適用於通過 NRTL 認證 (UL、CSA、ETL等) 及/ 或符合 IEC/EN 60950-1 或 IEC/EN 62368-1 (CE 標示) 的

· 操作溫度: +5°C (+41°F) 至 +35°C (+95°F)

(FCC)、加拿大工業部指導方針與歐盟針對射頻 (RF) 暴露 與特定吸收率所制定的準則 FCC 網站 www.fcc.gov/general/radio-frequency-safety-0

型號 1790、1914、1944、2065 : 此裝置含有無線電發射器·其設計、製造與測試均符合美國聯邦傳播委員會

應避免影響附近雷達系統之操作。 廢棄雷池與雷子雷機設備的處置

當本符號出現在產品、產品電池或產品包裝上時,代表該產品及其電池不得與家庭廢棄物一同

表棄。您必須負責將其交予適當的收集點·以利

於電池和電機電子設備的回收。由於電池和電機

請連絡營富地的縣市政府、家庭廢棄物處理廠商或當初購買本產品的商店。請洽詢eRecycle@microsoft.com以取得有關電子電機設備廢棄物和廢棄電池的詳細資 本產品可使用鋰電池、鎳氫電池或鹼性電池

> ©2024 Microsoft Corporation. Microsoft、Microsoft 標 誌、Xbox、Xbox 標誌為 Microsoft 公司集團的商標

> XBOX の品質保証およびソフトウェア ライセンス条件 およびソフトウェアライセンス条項に同意する必要が Microsoft 製品を購入または使用すると、以下に同意し

以下および support.microsoft.com/warranty で製造

Microsoft サービス規約 (microsoft.com/msa) が適用

元のハードウェアの限定保証(一部の国では製造元のハードウェア保証および契約)をご確認いただ

XBOX アクセサリー取扱説

されます。Xbox オンラインサービスと Microsoft Studio ゲームおよびアプリの使用を管理します。 • Xbox.com/slt でのソフトウェア ライセンス契約。 これらの契約をお読みください。同意されない場 合、Xbox 製品 (本体またはアクセサリ) をセット アップまたは使用しないでください。Xbox 製品を Microsoft 社または小売店に返品し、返金を受けて

A このガイドでは、製品を安全にお使いいただくた

Microsoft の製品は安全性と有効性を考慮に入れて開発されています。本製品の安全な取り扱いに関する情報 およびお使いの製品に適用される品質保証規定の条項 およびお使いの製品に適用される品質保証規定の条項 については、このガイドをお読みください。このガイ ドでは、本製品を効果的に、そして快適に使用する方 法を紹介しています。デバイスの適切なセットアッ ブ、使用、および取り扱いに関する指示に従わない と、重大な人身事故、死亡、または物的損害の危険性 が高まるおそれがあります。

ください。 ▲ 注意: ケーブルおよびコードの安全な取り扱い 製品のケーブルやコードが散乱していると、つまずく 危険性があります。ケーブルおよびコード類は、つま

たりするなど、不適切な使い方をしないでください。特に電源アダプター本体の周りにコードをきつく巻きつけないでください。代わりに、ライト アングルではなく、ルーズコイルを使用して巻き

電源コードをコンセントから抜く際は、コードを 引っ張るのではなく、プラグを持って抜いてくだ 電源コードとケーブルは定期的に点検してくださ い。電源コードが熱くなっている、すり減っている、割れている、または何らかの損傷を受けている 場合、直ちに使用を中止してください。損傷した電 やケーブルと交換することを推奨しています。

お使いの機器は使い捨て電池、または充電式電池を使 用しています。使い捨て電池または充電式電池の不適 切な使用または誤用は、電池の液漏れ、火災、過熱、 または爆発が引き起こされ、その結果、怪我、死亡 する可能性があります。 電解質液は腐食性であり、人体に有害な物質が含まれていることがあります。可燃性であり、飲み込むと有 害もしくは致命的な問題を引き起こす可能性がありま

・ 漏れた液が肌、目、衣服、他の表面に触れな

 請閱讀這些合約。如果您不接受,請勿安裝或使用 您的 Xbox 產品 (主機或配件)。請將 Xbox 產品退還 給 Microsoft 或您的零售商以取回退款 ▲ 此符號代表本指南中的安全與健康訊息。 請閱讀本指南,了解關於您所購買產品的重要安全與健 (d) 根据您当地的法律,如果您的 Microsoft 产品在保证 注意:請閱讀使用指示 未正確安裝、使用與維護本產品·可能會提高裝置損壞的風險。請閱讀本指南並保存所有書面指南·以供日後 參考。如需更換指南·請前往 support.xbox.com·或參考「Microsoft 說明及支援」區段·以取得連絡資訊。

> 使用電源線。請勿將電源線纏繞得太緊,尤其是纏 繞在電力轉換盒上。相反地,請使用寬鬆的線圈 (而 放置您的裝置或電源供應器時,請確保電線未出現 定期檢查您的電源線和纜線。如果電源線或纜線因 任何原因變熱、磨損、破裂或損壞,請立即停止使

用。我們建議您將損壞的電源線或纜線更換為正版

在雷雨期間或長時間不使用裝置時,請拔除充電纜

Microsoft 替換雷源線或續線。

線或電線。

• 避免讓外洩的液體接觸皮膚、眼睛、衣服或其 他表面。如果電池液接觸到您的皮膚、眼睛或 衣服·立即用水清洗受影響的部位·並視情況 連絡您的醫生或其他醫療提供者。

 放入新電池之前,使用乾布徹底清理電池槽或依照電池製造商的建議進行清理。 我們建議你使田 Microsoft 核准的雷池组。終裝置 請勿將電池拆解、碾壓、打開、戳刺、切碎、短路 外部接點或迴路、暴露在攝氏 40°C (華氏 104°F) 以上溫度,或丟棄到火或水中。 請勿混用新舊電池或不同類型電池 (例如,碳鋅電

依照裝置所附電池安裝指示的相反順序,小心

• 您感覺到任何聽力減損症狀。 產生耳鳴。 您的說話聲聽起來隱約、沉悶或單調。 警告:個人醫療裝置 電子設備所發射的射頻和產生的磁場可對其他電子設備運作造成負面影響,使其故障。雖然您的裝置在設計、 測試及製造上,皆符合美國、加拿大、歐盟和日本等國 家/地區所制定的射頻發射規範,裝置中的無線發射器及電子電路仍可能對其他電子設備造成無意的干擾。 配帶心律調節器的個人應始終採取下列預防措施:

> • 如果您有任何理由懷疑發生干擾狀況‧請立即關 閉装置 如果您使用心律調節器以外的裝置,請洽詢裝置製造商 或您的醫師,以取得有關在您的醫療裝置附近使用其他 電子裝置的資訊與指示 注意事項・搭乘飛機時的無線裝置 在搭乘任何飛機,或是將無線裝置裝入託運的行李之前,請先取出無線裝置的電池(若可取出),或關閉無線

• 不要將您的裝置放在胸前口袋中攜行。

以避免對心律調節器產生干擾。

金屬部分的殼套。

裝置的雷源 (若裝置有雷源按鈕)。 聆聽飛航涌知,了解 以在飛航時使用裝置。能否在機上使用無線裝 置取決於航空公司。

池を取り外してください。

• 電池は小さいお子様の手の届かない場所に保管し 充電をするときには、製品に同梱の充電器以外は 使用しないでください。誤った充電方法は火災や 爆発につながるおそれがあります。 か、廃棄してくだい。

24.01.24 00:14

1-249711.indd

regulations in your community on the use of mobile devices when you drive or cycle. Other common-sens recommendations to reduce the risks associated with

distractions include: