

Handleiding Manual

Tandwiel.net elektromotor set

15W



100W



CE

Attentie: houd bij het monteren van de motor in een machine of een systeem rekening met de benodigde veiligheidsmaatregelen.

Attention: be aware of the safety precautions by mounting the motor in a machine or system.

Ingebruikname

Verbind alle onderdelen met elkaar middels de connectoren en de motor kan draaien.

Draai niet aan de uitgaande as van de motor. Als de motor uit staat, is de as geblokkeerd!

De draairichting kan worden aangepast door de 2 aansluitdraden uit de motor om te wisselen.

De motor is tegen overbelasting beveiligd met een zekering. Deze brand door als er teveel stroom gaat lopen. Een reservezekering is meegeleverd.

15W motor: 20x5mm T 2,5A

100W motor: 20x5mm T 10A

Installation

Connect all parts together by using the connectors and the motor will be able to turn.

Do not turn the output shaft of the motor. When the motor is not running, the output shaft is blocked!

The direction of rotation can be adjusted by swapping the 2 connecting wires from the motor.

The motor is protected against overload by a fuse. The fuse will burn if there is too much power going. A spare fuse is included.

15W motor: 20x5mm T 2,5A

100W motor: 20x5mm T 10A