

the Soft Top™ Luxe

Instruction Book – Suits all BKE735 models



Breville®



Contents

- 2 Breville® Recommends Safety First
- 8 Components
- 9 Functions
- 10 Care & Cleaning
- 12 Warranty

BREVILLE® RECOMMENDS SAFETY FIRST

At Breville[®] we are very safety conscious. We design and manufacture consumer products with the safety of you, our valued customer, foremost in mind. In addition we ask that you exercise a degree of care when using any electrical appliance and adhere to the following precautions.

IMPORTANT SAFEGUARDS

READ ALL INSTRUCTIONS BEFORE USE AND SAVE FOR FUTURE REFERENCE

- Before using for the first time please ensure that your electricity supply is the same as shown on the rating label on the underside of the appliance. If you have any concerns please contact your local electricity company.
- Appliances can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance.

- Remove and safely discard any packaging material and promotional labels before using the kettle for the first time.
- To eliminate a choking hazard for young children, remove and safely discard the protective cover fitted to the power plug of this appliance.
- This kettle has been designed specifically for the purpose of boiling drinking quality water only.
Under no circumstances should this product be used to boil any other liquids or foodstuffs.
- Do not place the kettle near the edge of a bench or table during operation. Ensure that the surface is level, clean and free of water and other substances.
- Do not operate the kettle on a sink drain board.
- Do not place the kettle on or near a hot gas burner, electric element or where it could touch a heated oven.
- Keep the kettle clear of walls, curtains and other heat or steam sensitive materials. Minimum 20cm distance.
- Always ensure the kettle is properly assembled before use. Follow the instructions provided in this book.
- The kettle must be used only with the power base supplied.
- This kettle is not intended to be operated by means of an external timer or separate remote control system.
- Do not touch hot surfaces. Use the handle for lifting and carrying the kettle.
- Do not place anything on top of the lid.

- Always ensure the kettle switch is in the 'off' position, then turn the power off at the power outlet and remove the plug from the power outlet before attempting to move the appliance, when the appliance is not in use and before cleaning and storing.
- Use caution when pouring water from the kettle, as boiling water and steam will scald. Do not pour water too quickly.
- To protect against electric shock, do not immerse the kettle base, power base, power cord or power plug in water or allow moisture to come in contact with these parts.
- Do not remove the kettle from the power base during operation. Ensure the kettle is switched to 'off' position after the water has boiled before removing the kettle from the power base.
- Do not move the kettle while it is switched on.
- Do not open the lid during operation.
- Do not overfill the kettle past the maximum water level mark. If the kettle is overfilled, boiling water may be ejected.
- Keep the kettle clean. Follow the cleaning instructions provided in this book.

IMPORTANT SAFEGUARDS FOR ALL ELECTRICAL APPLIANCES

- Unwind the power cord fully before use.
- Do not let the power cord hang over the edge of a bench or table, touch hot surfaces or become knotted.
- Connect only to a 230V or 240V power outlet.

- To protect against electric shock, do not immerse the power cord, power plug or appliance in water or any other liquid.
- Always turn the appliance to the OFF position, switch off at the power outlet, remove the plug and allow all parts to cool before attempting to move the appliance, when the appliance is not in use, before cleaning and when storing.
- The appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

Cleaning and user maintenance shall not be made by children unless they are 8 years or above and are under supervision. Keep the appliance and its cord out of reach of children aged less than 8 years.

- It is recommended to regularly inspect the appliance. To avoid a hazard do not use the appliance if power cord, power plug or appliance becomes damaged in any way.
Return the entire appliance to the nearest authorised Breville® Service Centre for examination and/or repair.
- This appliance is for household use only. Do not use this appliance for anything other than its intended use. Do not use in moving vehicles or boats. Do not use outdoors. Misuse may cause injury.

- The installation of a residual current device (safety switch) is recommended to provide additional safety protection when using electrical appliances. It is advisable that a safety switch with a rated residual operating current not exceeding 30mA be installed in the electrical circuit supplying the appliance. See your electrician for professional advice.
- For safety reasons it is recommended you plug your Breville® appliance directly into its own electrical outlet on a dedicated circuit separate from other appliances. If the electrical circuit is overloaded with other appliances, your appliance may not function properly. Using in conjunction with a power strip or extension cord is not recommended.
- Do not spill water onto the connector.
- Children shall not play with the appliance.
- Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised.
- Keep the appliance and its cord out of reach of children less than 8 years.
- It is recommended to regularly inspect the appliance. Do not use the appliance if power supply power cord, plug or appliance becomes damaged in any way. Return the entire appliance to the nearest authorised Breville® Service Centre for examination and/or repair.
- Any maintenance, other than cleaning, should be performed at an authorised Breville® Service Centre.

- The use of attachments not sold or recommended by Breville® may cause fire, electric shock or injury.
- The appliance is not intended to be operated by means of an external timer or separate remote control system.

WARNING

- Do not operate the kettle on an inclined surface. Do not move the kettle while it is switched on.
- The heating element surface is subjected to residual heat after use.
- The appliance is designed for boiling of drinking quality water only. Never use to heat or boil any other liquids or foodstuffs. The lid should always be firmly in place and locked into the closed position before use.
- Do not press the lid release button to open the lid during and after operation. This may result in boiling water splashing from the kettle. Pour out all the hot water from the kettle before opening the lid to refill.
- Never immerse the kettle base, switch area, power base, power cord or power plug in water, or allow moisture to come into contact with these parts.
- To prevent damage to the kettle do not use chemicals, alkaline cleaning agents, steel wool or abrasive cleaners to clean the inside or outside of the kettle. Use a mild cleaning agent with a soft damp cloth.

SAVE THESE INSTRUCTIONS



Components



- A. Cushion controlled lid with viewing window.
- B. Removable scale filter.
- C. Stainless steel vessel.
- D. 1.7 litre/7 cup capacity.
- E. BPA Free* dual water windows.
- F. Auto shut off & boil dry protection.

- G. Rapid boil 2400W concealed element.
- H. Lid release button.
- I. Ergonomic Handle.
- J. Illuminated power 'On/Off' switch with ready bell.
- K. Multi directional base with cord storage.

Breville Assist™ plug (not shown)

*Breville® makes its BPA free claim for this product based on independent laboratory testing performed for all the food contact plastic materials of the product per EU Commission regulation No 10/2011.



Functions

BEFORE FIRST USE

Remove any promotional material attached to your kettle. It is recommended that before first use, the kettle is filled to the maximum level with cold tap water, boiled and water discarded. Your kettle will only operate when positioned on the power base with the 'On/Off' switch in the 'On' position. The kettle will automatically switch off once the water has boiled.

OPERATION OF YOUR KETTLE

To fill the kettle, remove it from the power base and open lid by pressing the lid release button. Fill with the desired amount of water.



NOTE

Always fill the kettle between the minimum (500ml) and maximum (1700ml) marks on the water window. Too little water will result in the kettle switching 'Off' before the water has boiled. Filling above the maximum mark (MAX) may result in boiling water splashing from the kettle.

Ensure the lid is locked firmly into place. Position the kettle securely onto the power base. Insert the power plug into a 230/240V power outlet and switch on.

Press the 'On/Off' switch to the 'On' position for water to boil.



NOTE

This kettle must only be used with the power base supplied. Use caution when pouring water from your kettle, as boiling water will scald. Do not pour the water too quickly.

The kettle will automatically switch 'Off' once the water has boiled. Lift the kettle from the power base and pour the water. Take care to hold the kettle level, especially when filled to the maximum level. To re-boil it may be necessary to wait for up to 30 seconds to allow the control to reset.

If further heating of the kettle is not required, switch 'Off' at the power outlet, unplug the power cord and empty the water from the kettle. Replace the kettle onto the power base and close the lid.

SAFETY BOIL DRY PROTECTION

The kettle is fitted with a safety device, which protects against overheating should the appliance be operated with insufficient water. If this occurs, the kettle will stop heating. Switch 'Off' at the power outlet and allow kettle to cool before refilling. Remove the kettle from the power base and add water. Return the kettle to the power base. The safety device will then automatically reset.

For additional safety, your kettle is fitted with an additional thermal cut out. In the event of overheating, the kettle will automatically shut down to prevent further damage. Should this occur, take your kettle to an authorised Breville® Service Centre.



Care & Cleaning

Always switch 'Off' at the power outlet and unplug the appliance from the power outlet before cleaning.

REMOVABLE FILTER

The kettle features a removable mesh filter to remove scale deposits for cleaner water. To remove the scale deposits from the filter, open the lid and slide the filter up and out of the kettle.

The filter can be cleaned by running under hot water and rubbing with a cleaning cloth or brush. To replace filter, simply slide the filter down into the slot behind the spout of the kettle and push back into position.



NOTE

The filter could become damaged with time. Please check regularly and replace if found damaged.



NOTE

The concealed element in the base of the kettle is made from high quality stainless steel. Any brown stains appearing are the result of mineral deposits and are not rust.

DESCALING

It is essential that regular descaling takes place. Frequency will depend on the usage of the kettle and the hardness of the water in your area. A build-up of scale may cause the inside of the kettle to discolour and ultimately may damage the element. This will affect the efficiency of the appliance and may invalidate the warranty agreement. We recommend the use of Breville® Kettle Cleaner as it's specially formulated for descaling kettles. To order visit www.breville.com/kr

Directions for use:

1. Add 60ml of Breville® Kettle Cleaner to 1 litre of water.
2. Fill kettle with mixture on a protected surface.
3. Bring kettle to boil and let stand for 30 minutes.
4. Clean spout by using a soft cloth dampened with Breville® Kettle Cleaner, rub well, then wipe off.
5. Bring the kettle to boil for a second time, then empty solution.
6. Fill kettle with fresh water and bring to the boil, discard boiled water. Now your kettle is ready to make your next cup of tea or coffee.



NOTE

Do not use chemicals, alkaline cleaning agents, steel wool or abrasive cleaners to clean the inside or outside of the kettle. Use a mild cleaning agent with a soft damp cloth.

STORAGE

Ensure the kettle is switched off, clean and dry before storing. Ensure the lid is closed and locked securely into place. Wrap the power cord around the cord storage under the power base. Stand the kettle upright on the power base. Do not store anything on top.



Warranty

2 YEAR WARRANTY

Breville provides product warranty for domestic use in specified territories for 2 year from date of purchase by faulty workmanship and materials. During this warranty period, Breville will provide repairs and replacement for any defective product (based on Breville's Warranty Policy).

Also, all legal warranty rights under Korea's legislation will be protected and will not be impaired by our warranty. For full terms and conditions on the warranty, as well as instructions on how to make a claim, please visit www.breville.com/kr



Notes

the Soft Top™ Luxe

설명서 - 모든 BKE735 모델에 적합



Breville®



목차

- 2 Breville®은 안전을 최우선으로 합니다
- 8 제품 구조
- 9 기능
- 10 관리 및 청소
- 12 보증

BREVILLE®은 안전을 최우선으로 합니다

Breville®은 안전을 매우 중요하게 생각합니다. 우리는 소중한 고객의 안전을 최우선으로 생각하여 제품을 설계하고 제조합니다. 아울러 전기 제품을 사용할 때는 각별한 주의를 기울이고 다음의 예방 조치를 준수해 주시기 바랍니다.

중요 안전 지침

사용하기 전에 모든 지침을 읽고 나중에 참조할 수 있도록 보관하시기 바랍니다

- 처음 사용하기 전에 전기 공급이 제품 밑면의 정격 라벨에 표시된 것과 동일한지 확인합니다. 문제가 있는 경우 지역 전력 회사에 문의하시기 바랍니다.
- 신체적, 감각적, 정신적 능력이 떨어지거나 경험과 지식이 부족한 사람도 안전한 방법으로 제품을 사용하는 방법에 관해 보호자의 감독을 받거나 지침이 주어지고 관련된 위험을 이해하는 경우 제품을 사용할 수 있습니다.
- 어린이가 제품을 가지고 놀면 안 됩니다.
- 주전자를 처음 사용하기 전에 모든 포장재와 판촉 라벨을 제거하고 안전하게 폐기해야 합니다.

- 어린이의 질식 위험을 방지하기 위해 이 제품의 전원 플러그에 장착된 보호 커버를 제거하고 안전하게 폐기합니다.
- 이 주전자는 음용수만 끓일 수 있도록 특별히 설계되었습니다. 어떠한 경우에도 이 제품을 다른 액체나 식품을 끓이는데 사용하면 안 됩니다.
- 작동 중 주전자를 조리대나 테이블 가장자리 근처에 두면 안 됩니다. 표면이 평평하고 깨끗하며 물과 기타 물질이 없는지 확인합니다.
- 주전자를 싱크대 식기 건조판에 놓고 작동하면 안 됩니다.
- 고압 가스 버너나 전열기 위 또는 근처, 가열된 오븐에 닿을 수 있는 곳에 주전자를 두면 안 됩니다.
- 주전자를 벽, 커튼 및 기타 열 또는 증기에 민감한 소재에서 멀리합니다.

최소 20cm 거리를 유지해야 합니다.

- 사용하기 전에 항상 주전자가 올바르게 조립되었는지 확인합니다. 이 책자에 명시된 지침을 따릅니다.
- 주전자는 제공된 전원 받침대로만 사용해야 합니다.
- 이 주전자는 외부 타이머나 별도의 원격 제어 시스템으로 작동하도록 제작되지 않았습니다.
- 뜨거운 표면을 만지면 안 됩니다. 손잡이를 사용하여 주전자를 들어올리고 옮깁니다.
- 뚜껑 위에 어떤 것도 올려 놓으면 안 됩니다.
- 항상 주전자가 꺼져 있는지 확인한 다음, 주전자를 이동하거나, 사용하지 않을 때, 청소 및 보관하기 전에 전원 콘센트의 전원을 끄고 전원 콘센트에서 플러그를 분리합니다.

- 주전자의 물을 부을 때는 끓는 물과 증기에 데일 수 있으므로 주의합니다. 물을 너무 빨리 부으면 안 됩니다.
- 감전 위험이 있으므로 주전자 베이스, 전원 받침대, 전원 코드, 전원 플러그를 물에 담그거나 수분에 닿게 하면 안 됩니다.
- 작동 중에는 전원 받침대에서 주전자를 분리하면 안 됩니다. 전원 받침대에서 주전자를 분리하기 전에 물이 끓은 후 주전자의 스위치가 '끄기(Off)' 위치로 전환되었는지 확인합니다.
- 전원이 켜져 있는 동안 주전자를 움직이면 안 됩니다.
- 작동 중에는 뚜껑을 열면 안 됩니다.
- 최대 수위 표시를 초과하여 주전자를 넘치게 채우면 안 됩니다. 주전자에 물을 너무 많이 채우면 끓는 물이 튀어나올 수 있습니다.

- 주전자를 깨끗하게 유지합니다. 이 책자에 명시된 청소 지침을 따릅니다.

모든 전기 제품에 대한 중요 안전 지침

- 사용하기 전에 전원 코드를 완전히 풀어 줍니다.
- 전원 코드가 조리대나 테이블 가장자리에 걸리거나 뜨거운 표면에 닿거나 매듭이 생기지 않도록 주의합니다.
- 230V 또는 240V 전원 콘센트에만 연결합니다.
- 감전 위험이 있으므로 전원 코드, 전원 플러그, 제품을 물이나 다른 액체에 담그면 안 됩니다.
- 제품을 이동하기 전, 제품을 사용하지 않을 때, 청소 및 보관하기 전에 항상 제품의 스위치를 '끄기(OFF)' 위치로 하고, 전원 콘센트의 전원을 끄고 전원 콘센트에서

플러그를 뽑고, 모든
부품을 식힙니다.

- 8세 이상 어린이나 신체적, 감각적, 정신적 능력이 떨어지거나 경험과 지식이 부족한 사람도 안전한 방법으로 제품을 사용하는 방법에 관해 보호자의 감독을 받거나 지침이 주어지고 관련된 위험을 이해하는 경우 이 제품을 사용할 수 있습니다.

8세 미만의 어린이가 보호자의 감독 없이 청소 및 사용자 유지 보수를 하면 안 됩니다. 제품과 코드를 8세 미만 어린이의 손이 닿지 않는 곳에 보관해야 합니다.

- 제품을 정기적으로 검사하는 것을 권장합니다. 위험을 예방하기 위해 전원 코드, 전원 플러그, 제품이 어떤 식으로든 손상된 경우 제품을 사용하면 안 됩니다. 검사 및/또는 수리가 필요한 경우, 가까운 공인 Breville® 서비스 센터에 제품 전체를 맡깁니다.

- 이 제품은 가정용입니다. 이 제품을 원래 용도 이외의 목적으로 사용하면 안 됩니다. 움직이는 차량, 선박 또는 야외에서 사용하면 안 됩니다. 잘못 사용하면 부상을 입을 수 있습니다.

- 전기 제품을 사용할 때는 추가적인 안전 보호를 위해 누전 차단기(안전 스위치)를 설치하는 것을 권장합니다. 제품에 전기를 공급하는 전기 회로에 정격 잔류 작동 전류가 30mA 이하인 안전 스위치를 설치하는 것을 권장합니다. 전문적인 조언은 전기 기술자에게 문의합니다.

- Breville® 제품을 안전하게 사용하려면 다른 제품과 함께 사용하지 않는 별도의 전기 콘센트를 사용하는 것이 좋습니다. 전기 회로가 다른 기기로 인해 과부하되면 제품이

- 올바르게 작동하지 않을 수도 있습니다. 멀티탭이나 연장 코드를 함께 사용하는 것은 권장하지 않습니다.
- 커넥터에 물을 흘리면 안 됩니다.
- 어린이가 제품을 가지고 놀면 안 됩니다.
- 8세 미만의 어린이가 보호자의 감독 없이 청소 및 사용자 유지 보수를 하면 안 됩니다.
- 제품과 코드를 8세 미만 어린이의 손이 닿지 않는 곳에 보관해야 합니다.
- 제품을 정기적으로 검사하는 것을 권장합니다. 전원 공급 장치 전원 코드, 플러그 또는 제품이 어떤 식으로든 손상된 경우 제품을 사용하면 안 됩니다. 검사 및/또는 수리가 필요한 경우, 가까운 공인 Breville® 서비스 센터에 제품 전체를 맡깁니다.

- 모든 유지 보수(청소 제외)는 공인 Breville® 서비스 센터에서 수행해야 합니다.
- Breville®에서 판매하거나 권장하지 않는 부속품을 사용하면 화재, 감전 또는 부상을 초래할 수 있습니다.
- 이 제품은 외부 타이머나 별도의 원격 제어 시스템으로 작동하도록 제작되지 않았습니다.

경고

- 경사진 곳에서 주전자를 작동하면 안 됩니다. 전원이 켜져 있는 동안 주전자를 움직이면 안 됩니다.
- 발열체 표면에는 사용 후 잔열이 있을 수 있습니다.
- 이 제품은 음용수만 끓일 수 있도록 설계되었습니다. 다른 액체나 식품을 가열하거나 끓이는 데 절대 사용하면 안 됩니다. 뚜껑은 항상 제자리에 단단하게 있어야 하며 사용 전에 닫힌 위치에 고정되어 있어야 합니다.

- 작동 중 및 작동 후에 뚜껑을 열 때 뚜껑 열림 버튼을 누르면 안 됩니다. 주전자에서 끓는 물이 튀어 나올 수 있습니다. 다시 채우기 위해 뚜껑을 열기 전에 주전자에서 온수를 전부 따라냅니다.
- 절대 전기 주전자의 하체 부속, 스위치 부위, 전원 받침대, 전원 코드, 전원 플러그를 물에 담그지 마시고, 해당 부분이 물기에 닿지 않게 하십시오.
- 주전자의 손상을 방지하려면 주전자의 내부 또는 외부를 청소할 때 화학 약품, 알칼리성 세척제, 철 수세미 또는 연마성 세제를 사용하면 안 됩니다. 부드럽고 젖은 천에 순한 세척제를 사용합니다.

이 설명서를 잘 보관하시기 바랍니다



제품 구조



- A. 보기 창이 있는 쿠션 제어 뚜껑.
- B. 착탈식 스케일 필터.
- C. 스테인리스 스틸 용기.
- D. 1.7리터/7컵 용량.
- E. BPA 무함유* 양면 수위 창.
- F. 자동 차단 및 보일 드라이 방지.
- G. 급속 가열 2400W 은폐 전열기.

- H. 뚜껑 열림 버튼.
 - I. 인체공학적 손잡이.
 - J. 준비 알림음이 있는 불이 들어오는 전원 '켜기/끄기(On/Off)' 스위치.
 - K. 코드 보관이 가능한 다방향 받침대.
- Breville Assist™ 플러그(표시되지 않음)

*Breville®은 EU Commission regulation No 10/2011에 따라 본 제품의 모든 식품 접촉 플라스틱 물질에 대해 독립적 실험실 테스트를 수행하여, 그 결과를 기반으로 이 제품에 BPA가 함유되지 않았음을 알려드립니다.



기능

처음 사용하기 전에

주전자에 부착된 판촉물을 제거합니다. 처음 사용하기 전에 주전자에 찬 수도물을 최대한 채우고 끓여서 버리는 것을 권장합니다. 주전자는 '켜기/끄기(On/Off)' 스위치가 '켜기(On)' 위치에 있는 상태에서 전원 받침대에 위치할 때만 작동합니다. 물이 끓으면 주전자가 자동으로 꺼집니다.

주전자 작동

주전자를 채우려면 전원 받침대에서 주전자를 분리하고 뚜껑 열림 버튼을 눌러 뚜껑을 열고 원하는 만큼 물을 채웁니다.



참고

항상 수위 창 의 최소(500ml)와 최대(1700ml) 표시 사이로 주전자를 채워야 합니다. 물이 너무 적으면 물이 끓기 전에 주전자가 '끄기(Off)' 상태로 전환됩니다. 최대 표시(MAX) 위로 채우면 주전자에서 끓는 물이 튀어 나올 수 있습니다.

뚜껑이 제자리에 단단히 고정되었는지 확인합니다. 주전자를 전원 받침대에 확실하게 올려놓습니다. 전원 플러그를 230/240V 콘센트에 꽂고 전원을 켭니다.

'켜기/끄기(On/Off)' 스위치를 '켜기(On)' 위치로 눌러 물을 끓입니다.



참고

이 주전자는 제공된 전원 받침대로만 사용해야 합니다. 주전자의 물을 부을 때는 끓는 물에 데일 수 있으므로 주의합니다. 물을 너무 빨리 부으면 안 됩니다.

물이 끓으면 주전자가 자동으로 꺼집니다. 전원 받침대에서 주전자를 들어 올려 물을 붓습니다. 특히 최대 수위까지 채울 때는 주전자 높이를 유지하도록 주의합니다. 다시 끓이려면 컨트롤이 재설정될 때까지 최대 30초를 기다려야 할 수 있습니다.

주전자를 더 가열할 필요가 없으면 전원 콘센트를 끄고 전원 코드를 뽑은 다음 주전자에서 물을 비웁니다. 주전자를 전원 받침대에 원위치시키고 뚜껑을 닫습니다.

비등 방지 안전 장치

주전자에는 물이 부족한 상태에서 작동할 때 과열을 방지하는 안전 장치가 장착되어 있습니다. 이런 일이 발생하면 주전자가 가열을 멈춥니다. 전원을 끄고 다시 채우기 전에 주전자를 식힙니다. 전원 받침대에서 주전자를 분리하고 물을 추가합니다. 주전자를 전원 받침대에 다시 올려놓으면 안전 장치가 자동으로 재설정됩니다.

추가적인 안전을 위해 주전자에는 추가 열 차단 장치가 장착되어 있습니다. 과열되면 주전자가 자동으로 꺼져 추가 손상을 방지합니다. 이런 일이 발생하면 주전자를 공인 Breville® 서비스 센터에 맡겨야 합니다.



관리 및 청소

청소하기 전에 항상 전원 콘센트를 끄고 전원 콘센트에서 제품의 플러그를 분리합니다.

착탈식 필터

주전자에는 더 깨끗한 물을 위해 스케일 침전물을 제거하기 위한 착탈식 메시 필터가 있습니다. 필터에서 스케일 침전물을 제거하려면 뚜껑을 열고 필터를 위로 밀어 주전자에서 빼냅니다.

필터는 온수에 적셔 청소용 천이나 브러시로 문질러 청소할 수 있습니다. 필터를 교체하려면 필터를 주전자 주둥이 뒤의 구멍에 꽂고 제자리에 되밀어 넣으면 됩니다.



참고

필터는 시간이 지나면 손상될 수 있습니다. 정기적으로 점검하고 손상된 경우 교체합니다.



참고

주전자 바닥의 은폐 전열기는 고품질 스테인리스 스틸로 만들어져 있습니다. 나타나는 갈색 얼룩은 미네랄 침전물로 인한 것이며 녹이 아닙니다.

디스케일링

정기적인 디스케일링은 필수입니다. 빈도는 주전자의 사용과 사용하는 지역의 물 경도에 따라 다릅니다. 스케일이 쌓이면 주전자 내부가 변색되어 궁극적으로 부품이 손상될 수 있습니다. 이는 제품의 효율성에 영향을 미치고 보증서를 무력화할 수 있습니다. 주전자 디스케일링용으로 특별히 제조된 Breville® Kettle Cleaner를 사용하는 것을 권장합니다. 주문하려면 www.breville.com/kr를 참조합니다.

사용 지침:

1. 물 1리터에 Breville® Kettle Cleaner 60ml를 추가합니다.
2. 보호된 표면에서 혼합물을 주전자에 채웁니다.
3. 혼합물을 끓이고 30분 동안 그대로 둡니다.
4. Breville® Kettle Cleaner로 적신 부드러운 천으로 주둥이를 청소하고 잘 문지른 다음 닦아 냅니다.
5. 혼합물을 두 번째로 끓인 다음 혼합물을 따라냅니다.
6. 주전자에 신선한 물을 채웁니다. 물을 끓여서 끓인 물을 버립니다. 이제 주전자가 차 또는 커피를 만들 준비가 되었습니다.



참고

주전자 내부 또는 외부를 청소할 때 화학약품, 알칼리성 세척제, 철 수세미 또는 연마성 세제를 사용하면 안 됩니다. 부드럽고 젖은 천에 순한 세척제를 사용합니다.

보관

주전자가 꺼져 있는지 확인하고 보관하기 전에 청소하고 말립니다. 뚜껑이 닫혀 있고 제자리에 단단히 고정되어 있는지 확인합니다. 전원 받침대 아래의 코드 보관함 주위에 전원 코드를 감아 줍니다. 주전자를 전원 받침대에 똑바로 세웁니다. 위에 어떤 것도 올려놓으면 안 됩니다.



보증

2년 품질 보증

Breville은 구입일로부터 2년 동안 대한민국 내에서 가정용으로 사용되는 제품의 잘못된 제조 공정 및 자재로 인한 결함에 대하여 보증 서비스를 제공합니다. 보증기간 동안 Breville은 결함이 있는 제품에 대해 수리 또는 교체를 제공합니다(Breville의 보증 정책에 따름).

또한, 고객이 대한민국의 법률에 따라 제품의 하자에 관하여 행사할 수 있는 법적 권리는 보호되며 Breville의 보증정책으로 인하여 이러한 법적 권리가 훼손되는 것은 아닙니다.

Breville의 보증 서비스에 관한 자세한 내용과 고객센터에 대한 문의 방법을 살펴 보시려면 **www.breville.com/kr**를 방문해 주시기 바랍니다.

브레빌코리아 유한회사
서울특별시 강남구 테헤란로 518, 13층 125호 (대치동)
고객 서비스 센터: 080-822-1691

Breville®
Master Every Moment™

Copyright Breville Pty. Ltd. 2022.

지속적인 제품 개선으로 인해, 본 책자에 담긴 제품 삽화 및 사진은 실제 제품과 약간 다를 수 있습니다.

BKE735 KOR - C22