

55

1

2

3

4

5

imation Magnetic Wireless Power Bank With Stand

MAGNETIC WIRELESS POWER BANK STAND

IMWP200M

USER GUIDE

O-Jin Corporation | www.imation.com

imation Magnetic Wireless Power Bank With Stand

사용 가이드

imation Magnetic Wireless Power Bank With Stand를 구매해 주셔서 진심으로 감사드리며, 다음은 해당 제품의 설치 가이드와 품질 보증 관련 안내입니다. 아이폰 12 시리즈 이후 모델 혹은 맥세이프 액세서리(마그네틱 스트리커, 케이스)를 착용한 후 사용해 주시기 바랍니다.

■ 구성품

Magnetic Wireless Power Bank With Stand 본체 x 1

충전용 케이블(C to C 케이블) x 1

사용 설명서 x 1

■ 연결하기

1. 사용하기 전에 반드시 사용 설명서를 읽고, 제품을 안전하고 올바르게 사용하십시오.

2. 제품의 하단에 위치한 버튼을 짧게 한번 누르면 배터리 레벨 LED(왼쪽)가 켜진 후 동작 대기 상태로 전환 됩니다.

3. 제품이 켜진 상태에서 하단 오른쪽 전원 버튼을 짧게 두번 누르면 제품의 전원이 꺼지며, 대기 상태에서 5초 이내 아무런 조치가 없어도 제품은 자동으로 종료됩니다.

4. 제품에 Type C 케이블을 연결한 후 모바일 디바이스에 케이블을 연결하면 자동으로 유선 충전이 진행됩니다.

5. 무선 충전시에는 무선충전 패드에 모바일 디바이스를 올려면 제품의 전원을 켜지 않고도 자동으로 충전이 진행 됩니다.

■ 주의사항

1. 본 제품을 가격하거나, 구부리거나, 떨어뜨리거나, 습기 또는 액체에 접촉시키거나 과도한 힘을 가하지 마십시오, 본체가 손상되어 올바르게 작동하지 않을 수 있습니다.

2. 본 제품을 분해하거나 훼손하지 마십시오, 사용자가 본 제품을 훼손한 경우 제품에 대해서 보증하지 않습니다.

3. 사용하기 전에 충전하려는 제품이 무선 충전을 지원하는지 확인하십시오.

4. 무선 충전시 충전하려는 제품의 무선 충전 지원되는 부분의 위치를 확인하고 사용하십시오.

5. 안전한 충전을 위해서 MagSafe가 지원되는 케이스 혹은 케이스 없이 사용하십시오.

6. 본 제품의 적정 사용 온도는 0℃~35℃(32℉~95℉)입니다, 온도가 높으면 충전 속도가 느려지게 되며 모든 무선 충전기에 발생하는 정상입니다.

7. 기기를 충전할 때 제품이 따뜻하다고 느껴질 수 있으며, 이는 충전중 발생하는 정상적인 현상입니다.

8. 제품을 장기간 사용하지 않을 경우 배터리 성능이 저하될 수 있으므로 2개월마다 한 번 충전 및 방전해야 합니다.

■ 안전사항

1. 본 제품은 고온, 높은 습도 혹은 강한 전자기장 주변에서 사용할 수 없습니다.

2. 안전을 위해 뒷면 손으로 플러그를 만지지 마십시오.

3. 유아나 어린이가 쉽게 만질 수 있는 곳에서 제품을 사용하지 마십시오.

4. 물이나 먼지에 오염되었을 때 사용하지 마십시오, 본 제품은 방수를 지원하지 않습니다.

5. 제품을 임의로 분해 시키지 마십시오, 전기 사고의 원인이 됩니다.

■ 보증정책

imation Magnetic Wireless Power Bank With Stand의 품질보증기간은 해당 제품의 최초 구입일로부터 2년 입니다. imation 제품 보증 정책에 따라 정상적인 사용 환경에서 제품 불량이나 발생하였을 경우, 제품 보증 서비스를 받으실 수 있습니다. 명시된 보증 기간이 완료되면 imation은 디자인 보증 서비스를 제공하지 않습니다.

■ 보증의 제한

다음과 같은 사유로 인하여 발생한 제품의 파손과 손실에 대해서는 제품 보증을 받으실 수 없습니다.

1. 고객의 취급 부주의

2. 다른 장비로 인한 오작동으로 인하여 발생한 문제

3. 화재, 홍수, 지진 등 천재지변에 의한 고장 및 손상

4. 구입한 이후의 수송 낙하 등으로 인한 고장 및 손상

5. 제품의 커넥터가 파손된 경우

■ 제품 사용시 주의 사항

imation은 고객의 사용상의 부주의로 인한 제품의 손상 및 파손에 관하여 보장하지 않습니다.

1. 전지를 해체하여 열거나 자르지 마십시오.

2. 전지의 단락에 주의하십시오.

3. 전지를 고온에 노출시키지 마십시오.

4. 사용 전 사용설명서를 읽어주십시오.

■ 제품 스펙

용량	19Wh, 3.8V, 5,000mAh
USB C 입력	5V=3A, 9V=2.22A, 12V=1.67A
USB C 출력	20W MAX
무선 출력	15W Max
제품 사이즈	105,2 x 66,9 x 12,9mm (L x W x H)
제품 무게	146g

본 제품은 아이폰 12 혹은 이후에 출시된 아이폰에 호환됩니다.

■ 제품 보증서

모델명	Magnetic Wireless Power Bank With Stand
구입일	
보증기간	
구매처	상호
	전화번호
구매자	성명
	전화번호
	주소

오전장사처

고객상담실 : 1899-3743

주소 : 서울시 양천구 신정로 11길 54, 오전상사 물류 고객 지원 센터

imation 및 imation 로고는 오전상사의 상표권입니다. 다른 로고 및 상표권은 각 소유자에게 권한이 있습니다. MagSafe 및 iPhone은 Apple Inc.의 상표입니다.

imation Magnetic Wireless Power Bank With Stand

Quick Start Guide

Thank you for purchasing imation Magnetic Wireless Power Bank With Stand. Please refer below for installation guide of proper installation and warranty policy, imation Magnetic Wireless Power Bank With Stand is compatible with iPhone 12 or later version. Please use a MagSafe compatible case or a magnetic sticker to secure your phone properly.

■ What's in the box

Magnetic Wireless Power Bank With Stand x 1

Cable(C to C) x 1

User Guide x 1

■ How to connect

1. Read User Manual before using imation Magnetic Wireless Power Bank With Stand and follow all instructions.

2. Press the power button to start the device, the white LED will light up first and the device is ready to charge.

3. Press the power button twice to turn off the power bank. If there is no charging activities in 5 seconds, the device will be power-off automatically.

4. Connect your phone and the device with a Type-C cable. The device will charge your phone automatically.

5. Place your phone on the wireless charging pad, it will charge automatically.

6. Make sure there is any metal or small objects between the charging device and the power bank. It may cause malfunction or errors.

7. Please use 18W or higher power adapter (Power Delivery, AFC, QC2.0/3.0 or Higher compatible charger) to charge the device properly.

8. The device is only compatible with the USB Type-C, please check your cable before use.

■ The Components

Wireless Charging Pad

Battery Level Indicator LED

USB C Port

Power Button

■ Battery Level Indicator LED UI

Battery Level	LED1	LED2	LED3	LED4
75% ~ 100%	●	●	●	●
50% ~ 75%	●	●	●	○
25% ~ 50%	●	●	○	○
5% ~ 25%	●	○	○	○
<5%	○	○	○	○
LED Status	● LED ON / ○ LED OFF / ● LED Blinking			

■ LED Status

STATUS	Wireless Charging Indicator LED	Battery Level Indicator LED
Recharging an imation Power Bank	—	Current Battery Level
Charging a device using a charging cable	—	Current Battery Level
Charging a device wirelessly	White On	Current Battery Level
Charging a device wirelessly and recharging an imation Power Bank simultaneously	White On	Current Battery Level

■ Precautions

1. Do not strike, bend, drop, wet or apply excessive force to imation Magnetic Wireless Power Bank With Stand. This may cause damages to the product.

2. Do not disassemble or damage imation Magnetic Wireless Power Bank With Stand. If the Power Bank has been disassembled by user, all warranties will be void.

3. Please confirm whether your devices have wireless charging function before use.

4. Please check whether the devices deviate from the wireless inductive charging area of the charger.

5. Please use MagSafe compatible mobile case or without mobile case for charging the devices properly.

6. It is recommended charging or use the power bank with ambient temperature ranging between 0℃~35℃ (32℉~95℉). If the temperature is too high, the performance of the power bank may drop.

7. Charging or using the power bank may cause warm heat. This symptom is ordinary.

8. Fully charge and discharge the power bank every 2 months to maintain the power bank performance if you do not use it for a long time.

■ Safety Notes

1. Avoid using in the environment of high temperature, humidity, strong static electricity and strong magnetic field.

2. For your safety, please do not use a wet hand plug and unplug electrical appliances.

3. Avoid putting the charger in a place easily accessible to infants and children.

4. Do not use the product if it is contaminated with water or dirt. This product does not support waterproofing.

5. Non-professional personnel are not allowed to open and repair without authorization.

■ Warranty Policy

imation Magnetic Wireless Power Bank With Stand covered by 2 years limited warranty from the original purchase date. Pursuant to the terms of imation warranty policy, imation will provide proper warranty service if product fail under normal use. For the products that are out-of-warranty period hereunder, imation may refuse to provide any warranty service. Product customer service will be varied by region or country. If the product service is not available, please contact resellers.

■ Warranty Limitations

The warranty stated herein does not apply if any product failure caused by

1. Act of improper use such as prolonged exposure to

2. Malfunction of other equipment

3. Acts of nature

4. Defects or damages from moving or dropping after purchase

5. Damaged connector or cable

■ Warning and Precaution

imation is not responsible for any cost caused by defects or damages of products from misuse or neglect.

■ Product Specification

Capacity	19Wh, 3.8V, 5,000mAh
USB C Input	5V=3A, 9V=2.22A, 12V=1.67A
USB C Output	20W MAX
Wireless Output	15W Max
Physical Dimension	105,2 x 66,9 x 12,9mm (L x W x H)
Weight	146g

Compatible with iPhone 12 or later version.

■ FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications (including the antennas) to this device that are not expressly approved by the manufacturer may void the user's authority to operate the equipment.

Note

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

Modifications not expressly approved by the manufacturer could void your authority to operate the equipment under FCC rules.

FCC RF exposure statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

6

7

8

9

10