

REMINGTON®

EST. NEW YORK 1937



Volume & Curl AS7051

 remington-europe.com

Register online for an EXTRA year guarantee

Visit uk.remington-europe.com/product-registration You must register within 28 days of purchase.



Thank you for buying your new Remington® product. Please read these instructions carefully and keep them safe. Remove all packaging before use.

WARNING: This appliance is hot. Keep out of reach of children at all times.



IMPORTANT SAFEGUARDS

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been supervised/instructed and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be done by children unless they are older than 8 and supervised. Keep the appliance and cable out of reach of children under 8 years.
 -  Do not use this appliance near bathtubs, showers, basins or other vessels containing water.
 - When the appliance is used in a bathroom, unplug it after use since the proximity of water presents a hazard even when the appliance is switched off.
 - For additional protection, the installation of a residual current device (RCD) having a rated residual operating current not exceeding 30 mA is advisable in the electrical circuit supplying the bathroom*.
- * Currently, the fitting in a bathroom of an electrical socket suitable or capable of operating the appliance is not permitted in the UK (see BS7671).
- Burn hazard. Keep the appliance out of reach from young children, particularly during use and while cooling down.
 - Never leave the appliance unattended when it is connected to the power supply.
 - Always place the appliance with its stand, if any, on a heat-resistant, stable flat surface.

- If the supply cord of this unit becomes damaged, discontinue use immediately and return the appliance to your nearest authorised Remington® service dealer for repair or replacement in order to avoid a hazard.
- Do not allow any part of the appliance touch the face, neck or scalp.
- Keep the power plug and cord away from heated surfaces.
- Do not use attachments other than those we supply.
- Do not use the appliance if it is damaged or malfunctions.
- Do not twist or kink the cable, or wrap it round the appliance. Check the cord regularly for any sign damage.
- This appliance is not intended for commercial or salon use.

PARTS

- | | |
|---|-----------------------------------|
| 1. 1000W power handle | 6. Speed/ heat setting switch |
| 2. 50mm thermal mixed bristle brush | 7. Cool shot |
| 3. 30mm retractable bristle curling brush | 8. Attachment lock/release button |
| 4. 21mm thermal mixed bristle brush | 9. Heat proof storage bag |
| 5. Concentrator | 10. Swivel cord |
-

INSTRUCTIONS FOR USE

- Wash and condition your hair as normal.
 - Squeeze out excess moisture with a towel and comb through.
 - Hairsprays contain flammable material – do not use while using this product.
 - Section the hair prior to styling. Style the lower layers first.
 - Select your attachment before you turn on the appliance.
 - Attachments can be connected to the power handle by aligning the arrow above the attachment lock/release button with the power handle and clicking to the left to lock.
1. Plug the product into the mains power supply.
 2. The product can be switched on by sliding the heat/speed setting switch to position .
 3. Dry roots completely and dry length 90% dry, ready for styling.
 4. To dry hair use the concentrator attachment.
 5. For smaller and medium curls use the 21mm thermal bristle brush. Best for use on short and medium length or layered hair.
 6. To create medium to loose curls use the 30mm retractable brush.
 7. The 50mm thermal volume brush adds root volume and fullness. it can also be used to fix the ends of long hair and smooth out natural curls.
 8. Select the desired temperature and speed setting using the switch on the handle.

9. To increase the setting slide the heat/speed setting switch to position 
10. For all brush attachments: Take a section of hair and place the ends around the brush. Rotate the styler allowing the hair to wrap around the barrel of the brush drying and styling as you go.
11. Hold the styler in the hair for 10-20 seconds then unwind the hair by rotating the styler in the opposite direction.
12. Allow the hair to cool before styling.
13. Let the attachments cool before removing.
14. To remove the attachment press the attachment lock/release button, twist the attachment slightly to the right and pull attachment away from the main housing.
15. After use, turn the appliance off and unplug.
16. Let the appliance cool down before cleaning and storing away.

Cool shot

To set your style and add shine use the cool shot function. To operate press the cool shot button down and slide forward. Slide back to turn off.

CLEANING AND MAINTENANCE

- Unplug the appliance and allow to cool.
- To maintain peak product performance and to prolong motor life, it is important to regularly remove any dust and dirt from the air filter grille and clean with a soft brush.
- Don't use harsh or abrasive cleaning agents or solvents.

RECYCLING



To avoid environmental and health problems due to hazardous substances, appliances and rechargeable and non-rechargeable batteries marked with one of these symbols must not be disposed of with unsorted municipal waste. Always dispose of electrical and electronic products and, where applicable, rechargeable and non-rechargeable batteries, at an appropriate official recycling/ collection point.

SERVICE AND GUARANTEE

Defects affecting product functionality appearing within the guarantee period will be corrected by replacement or repair at our option provided the product is used and maintained in accordance with the instructions.

This warranty shall not be valid where it is contrary to U.S. and other applicable laws, or where the warranty would be prohibited under any economic sanctions, export control laws, embargos, or other restrictive trade measures enforced by the United States or other applicable jurisdictions. This includes, without limitation, any warranty claims implicating parties from, or otherwise located in, Cuba, Iran, North Korea, Syria and the Crimea region.

Your statutory rights are not affected.

Consumables are excluded.

Defects from repair by an unauthorised dealer are not covered.



Guarantee period = 3 years from first retail purchase.

To claim the extra 1 year guarantee, register your product online within 28 days of purchase: **uk.remington-europe.com/product-registration**

If you call the Service Centre, please have the model number to hand, as we won't be able to help you without it. The model number can be found on the rating plate of the appliance.

SERVICE CENTRE

United Kingdom

 Tel 0800 212 438 (free call mainland UK)

Spectrum Brands (UK) Ltd

Fir Street, Failsworth, Manchester

M35 0HS, UK

www.remington.co.uk

Product support:

productsupport@Remington.co.uk

Ireland

 Tel 142 951 40

Remington Consumer Products,

Unit B12, Ballymount Corporate Park,

Ballymount, Dublin 12

<https://ie.remington-europe.com>

Product support:

productsupport@Remington.co.uk

شكرا لقيامك بشراء منتج Remington® الجديد. يرجى قراءة هذه التعليمات بعناية والاحتفاظ بها في مكان آمن. قم بإزالة جميع مواد التعبئة قبل الاستخدام. **تحذير: هذا الجهاز ساخن. أبقيه بعيداً عن متناول الأطفال في جميع الأوقات.**



إجراءات وقائية هامة

- يمكن استخدام هذا الجهاز بواسطة الأطفال الذين تتراوح أعمارهم من 8 سنوات وما فوق والأشخاص ذوي القدرات البدنية أو الحسية أو العقلية المنخفضة أو قليلي الخبرة والمعرفة إذا تم الإشراف عليهم/إرشادهم ويفهمون المخاطر المعنية. ويجب ألا يعيب الأطفال بالجهاز. ويجب ألا يقوم الأطفال بالتنظيف والصيانة إلا إذا كان عمرهم أكبر من 8 سنوات وتحت إشراف. احفظ الجهاز والكابلات بعيداً عن متناول الأطفال دون سن 8 سنوات.
- ⊗ لا تستخدم هذا الجهاز بالقرب من أحواض الاستحمام أو الحمامات أو أي أحواض أخرى تحتوي على ماء.
- عند استخدام الجهاز في حمام، قم بفصله بعد الاستخدام طالما أن القرب من الماء يمثل خطراً حتى عند إيقاف الجهاز.
- تحذير - للحماية الإضافية، ينصح بتركيب أي جهاز تيار متبقي (RCD) بمقنن تيار تشغيل متبقي لا يتجاوز 30 مللي أمبير في الدائرة الكهربائية المغذية للحمام. استشر كهربائي.
- وفي حالة تلف سلك تغذية هذه الوحدة، توقف عن استخدامها فوراً وأعد الجهاز لأقرب أخصائي خدمة معتمد من Remington® للإصلاح أو الاستبدال لتجنب الأخطار.
- لا تلف السلك حول الوحدة. تحقق من انتظام السلك للبحث عن أي علامة تلف.
- لا تستخدم الجهاز إذا كان تالفاً أو به خلل.
- لا تسمح لأي جزء من الجهاز بلمس الوجه أو العنق أو فروة الرأس.
- حافظ على تدفق الهواء المباشر بعيداً عن العينين أو الأماكن الحساسة الأخرى.
- تأكد دائماً أثناء الاستخدام من أن شوكات المدخل والمخرج غير مسدودة بأي شكل من الأشكال لأن ذلك سوف يتسبب في إيقاف الوحدة تلقائياً.
- وإذا حدث ذلك، أوقف الوحدة ودعها تبرد.
- لا تترك الجهاز بدون مراقبة أثناء توصيله.
- لا تقيد الجهاز أثناء تشغيله.
- لا تضع الجهاز على أي مفروشات ناعمة.
- لا تستخدم ملحقات غير الملحقات التي نقوم بتوريدها.
- هذا الجهاز غير مخصص للاستخدام التجاري أو الصالونات.

الأجزاء

1. أوات 1000 مقبض طاقة
2. فرشاة حجم شعر خشن مختلط حرارية
3. 50 ملم
4. فرشاة تجعيد 30 مم لتصفيف الشعر المجعد
5. فرشاة شعر خشن مختلط حرارية 21 ملم
6. مفتاح لإعداد السرعة/الحرارة
7. الهواء البارد
8. قفل الملحق/زر الإخراج
9. حقيبة تخزين مقاومة للحرارة
10. سلك دوار

تعليمات الاستخدام

- اغسل ورتب شعرك كالمعتاد.
 - قم بإزالة الرطوبة الزائدة بمنشفة ومشط.
 - تحتوي سوائيل رش الشعر على مواد قابلة للاشتعال - لا تستخدمها أثناء استخدام هذا المنتج.
 - حدد مرفق الخاص بك قبل تشغيل الجهاز.
1. يمكن ربط الملحقات بمقبض الطاقة بمحاذاة السهم الموجود فوق قفل الملحق/زر الإخراج مع مقبض الطاقة والنقر إلى اليسار للقفل.
 2. قم بتوصيل المنتج بالكهرباء.
 3. تقسيم الشعر قبل التصفيف. وتصفيف الطبقات السفلى أولاً.
 4. يمكن تشغيل المنتج بتحرك مفتاح إعداد السرعة/الحرارة إلى وضع (X).
 5. يجب التجفيف بالكامل مع تجفيف 90% من الطول ليصبح الشعر جاهز للتصفيف.
 6. لتجفيف الشعر استخدم ملحق المكثف.
 7. لتجديدات الشعر الصغيرة والمتوسطة استخدم فرشاة الشعر الخشن الحرارية 21 ملم. ويكون أفضل استخدام لها على الطول القصير والمتوسط أو الشعر ذو الطبقات.
 8. لإنشاء تجديدات متوسطة إلى حرة استخدم الفرشاة القابلة للسحب 30 ملم.
 9. تضيف فرشاة الحجم الحرارية 50 ملم حجم جذر وامتلاء. ويمكن أن تستخدم أيضاً لتثبيت أطراف الشعر الطويل وتنعيم التجديد الطبيعي.
 10. حدد درجة الحرارة المطلوبة واضبط السرعة باستخدام المفاتيح الموجودة على المقبض.
 11. لزيادة الإعداد، حرك مفتاح إعداد الحرارة/السرعة إلى الوضع (X).
 12. لجميع ملحقات الفرشاة: خذ قسماً من الشعر وضع النهايات حول الفرشاة. قم بتدوير جهاز التصفيف ودع الشعر يلتف حول اسطوانة الفرشاة للتجفيف والتصفيف وأنت تعمل.
 13. أمسك جهاز التصفيف في الشعر لمدة 20-10 ثانية ثم قم بفك الشعر بتدوير جهاز التصفيف في الاتجاه المعاكس.
 14. أمسك المقبض وقم بلف جزء من الشعر حول الاسطوانة الساخنة.
 15. دع الملحقات تبرد قبل إخراجها.
 16. لإخراج الملحق، اضغط قفل الملحق/زر الإخراج وقم بلف الملحق قليلاً إلى اليمين واسحب من المبيت الرئيسي.
 17. قم بإيقاف الجهاز وفصله بعد الاستخدام.
 18. دع الجهاز يبرد قبل تنظيفه وتخزينه.

الهواء البارد


لتعيين نمطك وإضافة تآلق، استخدم وظيفة الطلقة الباردة. ولإيقاف، حرك المفتاح للخلف.

التنظيف والصيانة

- افصل الجهاز ودعه يبرد.
- للحفاظ على أفضل أداء للمنتج وإطالة عمر الموتور، من المهم إزالة أي غبار وأوساخ من شبكة فلتر الهواء بانتظام وتنظيفه بفرشاة ناعمة.
- لإخراج الشبكة الخلفية للتنظيف - أمسك مقبض المجفف بيد واحدة ثم ضع باليد الأخرى الإبهام والسبابة على القطعة الوسطى للشبكة الخلفية. أدر الشبكة عكس اتجاه عقارب الساعة واسحبها من المجفف.
- لاستبدال الشبكة الخلفية، أدخل قطعة الشبكة الخلفية في خلف المجفف وأدراها في اتجاه عقارب الساعة لوضعها مكانها.

إعادة التدوير

لتجنب المشاكل البيئية والصحية الناجمة عن المواد الخطرة، يجب عدم التخلص من الأجهزة، والبطاريات القابلة لإعادة الشحن والبطاريات غير القابلة لإعادة الشحن التي تحمل علامة واحدة من هذه الرموز مع نفايات البلدية غير المصنفة. يجب دائماً التخلص من المنتجات الكهربائية والإلكترونية، وكذلك إذا أمكن، البطاريات القابلة لإعادة الشحن وغير القابلة لإعادة الشحن، في نقطة رسمية مناسبة لإعادة التدوير/ تجميع المخلفات.



الخدمة والضمان

سيتم تصحيح العيوب التي تؤثر على وظائف المنتج التي تظهر خلال مدة الضمان بالاستبدال أو الإصلاح وفقاً لخيارنا بشرط استخدام المنتج والحفاظ عليه وفقاً للتعليمات. لا تتأثر حقوقك القانونية.

يتم استبعاد المواد الاستهلاكية.

لا يتم تغطية العيوب الناجمة عن الإصلاح بواسطة موزع غير معتمد.

إذا طلبت مركز الخدمة، يرجى أن يكون لديك رقم الموديل فلن نكون قادرين على مساعدتك دون ذلك. ويمكن العثور على رقم الموديل على لوحة مقنن الجهاز.

اطلب ضمانك الإضافي لمدة 1 سنة بتسجيل منتجك على الإنترنت. فقط اذهب لموقع:

www.remington-europe.com/register/





Ref. No. AS7051

Type No. AS7051

21/UK/ AS7051 T22-7002207 Version 06 /21

Remington® is a Registered Trade Mark of Spectrum Brands, Inc., or one of its subsidiaries.

Spectrum Brands (UK) Ltd

Fir Street,

Failsworth,

Manchester

M35 0HS

remington-europe.com

© 2021 Spectrum Brands, Inc.