包装信息	型号：E2 Gen2 成品尺寸：140*185MM 材质：80g书写纸，骑马钉 公差：不大于±1MM 工艺：四色印刷 版本号：V1.0-20240628	备注信息	**封面背面留白** **较V1.0_20240625版本样品修改了25/33页页码，优化了第25/29/31/33/41/43/45页字体**

封底　　封面

CONTENTS

English 01-12
Deutsch 13-23
中文 24-34
日本語 35-46

Description

The Maonocaster E2 Gen2 is an upgraded version of a popular podcast and streaming audio console. Its 5 motorized faders and 4 programmable buttons per channel provide precise control over audio levels, while the console's sends and return functionality is further improved, with separate send and streaming audio buttons. The E2 Gen2 also features built-in 24-bit, 192kHz professional-grade sound cards and a USB-C connection for high-quality audio recording and streaming. Additionally, the console's intuitive design and customizable RGB lighting make it easy to personalize your setup and create a professional-looking environment. Overall, the Maonocaster E2 Gen2 is an all-in-one solution for podcasters and streamers who want to take their audio production to the next level.

Product Features

- 5 pcs 60 mm motorized fader for live control
- Instrument and Aux Input to record your content
- 4 programmable buttons per channel
- Independent microphone and instrument volume control
- Separate send and streaming audio buttons
- Advanced voice-controlling algorithm to reduce ambient noise
- 24-bit, 192kHz professional-grade sound cards
- USB-C for stable connection and high-quality audio recording
- Compatible with Windows and macOS
- RGB lighting with 16.8 million colors and 20 ambient
- Left Phantom power button for XLR mic use
- Dedicated headphone mix control knob

Applications

Recording, Podcasting, Streaming, and Conference Computer, tablets, and cell phones. Compatible with livestream recording and streaming software.

Specification

Input Sound Source	USB	Mobile Type	3.5mm jack
Sampling Rate	192kHz	Phantom Power	48V
Color	RGB	Charging Current	5V/1A
Headphone Output	20mW (32Ω), THD+N 1%	Charging Port	Type-C
Mic Input Gain	0-60dB	Net Weight	1.6kg (3.53lbs)
Dimension (L*W*H)	320*220*70mm	Warranty	1 year (Free lifelong technical support)

Accessory List

Maonocaster E2 Gen2 Podcast Console
USB-A to USB-C 1.5m Cable

3.5mm TRRS Audio Cable
User Manual

Layout

1. XLR Input 1 Microphone Input
Connect your microphone to this microphone input.
2. XLR Input 2 Microphone and Instrument Input Level Gain 2 Switch
Connect your microphone or instrument to this microphone input. Switch to Gain 2 for microphone or switch to Gain 1 for instrument.
3. 3.5mm Line Out
Connect to your computer speaker or other audio device. It inputs to 3.5mm TRS or TRRS cable.
4. 3.5mm Stream Out
Connect to your computer or smartphone with a headphone jack for recording or streaming purposes. It outputs to 3.5mm TRS or TRRS cable.
5. USB-C Slot
Connect to your computer with provided devices.
6. Headphone Jack
Connect your headphones via power and charging. When using a compatible mobile device, you can connect an external mobile audio source from the mobile device and mix for them. Please use a smooth adapter when in use.

7. Mic Gain Knob
Adjust the gain of the microphone.
8. Line Gain Knob
Adjust the gain of the line input.



9. Headphone Gain Knob
Adjust the volume of the headphones.
10. 3.5mm Headphone Jack
Connect your headphones via 3.5mm TRS or TRRS plug. Please note that the headphone input of this module is not supported. The module is not recommended for the use of the device.



11/12. XLR Input Gain Knob, ☐, Fader, ☐, and Mute, ☐
Adjust the gain of the microphone or instrument connected to the XLR input jack.
Pan: Adjust the stereo position of the channel.
Fader: Adjust the volume of the channel.
Mute: Press to mute the channel. Press again to unmute.
13. Mute Button
Press to mute the microphone.
14. Monitor Mix Knob
Adjust the balance between the input signal and the playback signal.
15. Mute Button
Press to mute the microphone.
16. Phantom Power Button
Press to turn on the phantom power for the microphone and instrument inputs, allowing you to record or stream with a condenser microphone.
17. Play Button
Press to play the audio from Stream Out.
18. Record Button, ☐ Key Record, Presets, ☐
Record the voice for a length of a fixed effect. Turn it all the way to the left to turn off the sound.
19. Effect Button
Press to apply the effect to the microphone.
20. Stream Button
Press to apply the effect to the instrument.
21. Ducking Button
Press to activate the ducking function. When activated, the volume of the music will automatically lower when you speak into the microphone, creating a smooth transition between the two audio sources.
22. Aux Button
Press to activate the Aux function. When activated, you can control the volume of the audio source connected to the Aux input jack using the volume knob.
23. Bluetooth Button
Press to activate the Bluetooth function. When activated, you can connect your Bluetooth-enabled device to the console and stream audio wirelessly. Press again to disconnect.
24. Mute Button
Press to mute the Aux input.
25. Stream Mix Knob
Adjust the balance between the input signal and the playback signal.
26. Mute Button
Press to mute the Stream input.
27. Volume Knob
Adjust the volume of the headphones.
28. Mute Button
Press to mute the headphones.

Setup Guide

1. PC Connection

2. Smartphone or tablet connection

3. Bluetooth Connection
The Maonocaster supports Bluetooth music playback. Please follow these steps to connect and play music:
1. Please ensure that your Bluetooth device is turned on and in pairing mode.
2. Press the Bluetooth button on the Maonocaster console to enter Bluetooth pairing mode. The Maonocaster E2 Gen 2 will start to broadcast its presence.
3. On your Bluetooth device, search for available Bluetooth devices and select "Maonocaster E2 Gen 2" from the list to initiate the connection.
4. Once the connection is established, you will hear a confirmation tone from the Maonocaster console.
5. You can now play music from your Bluetooth device, and the audio will be streamed wirelessly to the Maonocaster console.
Note:
- Make sure that your Bluetooth device is within the recommended range for a stable connection.
- If you experience any issues with the connection, try restarting both your Bluetooth device and the Maonocaster console.
- To disconnect your Bluetooth device, simply turn off Bluetooth on your device or press the Bluetooth button on the Maonocaster console.

4. Charging
1. When using the device for the first time, please ensure it is fully charged.
2. To charge your device, connect it to a power source using the provided USB-C to USB-A cable.
3. Please check the status of the device's battery indicator to monitor the charging progress.
4. It may take a few hours to fully charge the device, depending on the battery's current level.
5. Once the battery is fully charged, it is recommended to unplug it to avoid any overcharging issues.

5. Troubleshooting
1. Please check the following:
2. Please ensure that your Bluetooth device is turned on and in pairing mode.
3. Please check that your Bluetooth device is within the recommended range for a stable connection.
4. Please restart the console and your Bluetooth device.
5. If the issue persists, please refer to the user manual for your Bluetooth device or contact its manufacturer for further assistance.

6. Please check whether the "Listen Back" of the sound card upwards. You can probably increase the "Playback Volume" and "Capture Volume".
7. Please check whether the sound card of the computer is set to the default device.
8. Please check whether the Bluetooth connection is disconnected. If it is disconnected, please reconnect.
9. Please check whether the Bluetooth connection is connected to the correct device. If it is connected to the wrong device, please disconnect and reconnect to the correct device.
10. Please check whether the Bluetooth connection is connected to the correct device. If it is connected to the wrong device, please disconnect and reconnect to the correct device.
11. Please check whether the Bluetooth connection is connected to the correct device. If it is connected to the wrong device, please disconnect and reconnect to the correct device.