



이 설치 가이드는 PLC제어를 위해 간략한 동작 설명을 제공합니다. 제품을 사용하기 전에 안전을 위한 주의 사항 등을 반드시 읽고 정확하게 사용하여 주십시오.

1 안전을 위한 주의사항

■ 경고/주의 표기의 의미

	경고	취급을 잘못할 경우 사용자가 사망 또는 중상을 입을 위험이 예상되는 경우
	주의	취급을 잘못할 경우 사용자가 상해를 입거나 또는 물적 손해만 발생하는 위험이 예상되는 경우

⚠ 경고

- 전원이 인가된 상태에서 단자대를 만지지 마십시오.
- 제품 내부의 금속성 이물질이 유입되지 않도록 하여 주십시오.
- 배터리는 충전, 분해, 가열, Short, 솔더링 등을 하지 마십시오.

⚠ 주의

- 제품의 정격전압과 단자 배열을 확인한 후 정확하게 배선하여 주십시오.
- 배선 시 단자의 나사를 규정 토크로 단단하게 조여 주십시오.
- 가연성 물질이 있는 주변에 설치하지 마십시오.
- 제품에 직접 진동이 인가되지 않도록 하십시오.
- 전문 서비스원 외에는 제품을 분해, 수리 또는 개조하지 마십시오.
- 사용설명서와 데이터시트에 명기된 일반규격의 조건에서 사용해 주십시오.
- 출력단에 연결하는 부하는 규정된 정격 이내의 것을 사용하십시오.
- 제품과 배터리를 폐기할 경우 산업 폐기물로 처리하여 주십시오.

2 사용 환경에 대하여

■ 설치 시 아래 환경 조건을 준수하여 주시기 바랍니다.

No	항목	규격			관련규격	
1	사용온도	0℃ ~ 55℃			-	
2	보관온도	-25℃ ~ 70℃			-	
3	사용습도	5~95%RH, 이슬이 맺히지 않을 것			-	
4	보관습도	5~95%RH, 이슬이 맺히지 않을 것			-	
5	내진동	단속적인 진동이 있는 경우			-	IEC 61131-2
		주파수	가속도	진폭	횟수	
		5≤f<8.4Hz	-	3.5mm	X,Y, Z 각 방향 10회	
		8.4≤f≤150Hz	9.8m/s²(1g)	-		
		연속적인 진동이 있는 경우				
		주파수	가속도	진폭		
		5≤f<8.4Hz	-	1.75mm		
		8.4≤f≤150Hz	4.9m/s²(0.5g)	-		


3 사용 가능한 버전

■ 시스템 구성 시 아래와 같은 버전을 사용해야 정상적인 동작이 가능합니다.

- XBC타입 : E(V1.1이상), SU(V1.0이상), H(V1.1이상)
- XEC타입 : E(V1.1이상), H(V1.1이상), U(V1.2이상)
- XBMS : V3.03 이상
- XG5000 Software : V4.0 이상


4 제품의 각 부 명칭 및 외형치수 (mm)

■ 제품의 전면부에 대한 설명입니다. 각 부의 명칭을 참조하여 시스템 운전 시 참조하시기 바랍니다. 자세한 설명은 사용설명서를 참조하십시오.





5 제품의 장착 및 설치

■ XEC 표준/경제형 기본유닛 9 또는 10슬롯(Slot)에 다음과 같이 장착합니다.



- 옵션 보드 설치 시 그림과 같이 커넥터간 원활한 접촉을 위하여 아랫부분(①)을 먼저 눌러주시기 바랍니다.
- 아랫부분(①)이 완전히 장착된 후 윗 부분(②)을 눌러 옵션 보드의 장착을 완전히 고정시킵니다.



6 성능규격

■ 아날로그 입력 옵션보드의 성능 규격은 아래와 같습니다


항목		XBO-AD02A		
아날로그 입력	종류	전압	전류	
	범위	DC 0~10V	DC 4~20mA DC 0~20mA	
디지털 출력	형태		12비트 바이너리 데이터	
	범 위	부호없는 값	0~4,000	
		부호있는 값	-2,000~2,000	
		정규값	0~1,000 (DC 0 ~ 10V)	400~2,000(DC 4~20mA) 0~2,000(DC 0~20mA)
		백분위값	0~1,000	
최대분해능		1/4,000		
정밀도		±1.0% 이하		

7 배선

■ 설치 케이블

- 교류전원 라인과 아날로그 입력 옵션 보드의 외부 입력 신호 라인을 가까이 두지 마십시오. 충분한 거리를 유지하여야 교류 측에서 발생하는 서지 또는 유도 노이즈의 영향을 받지 않습니다.
- 전선은 주위온도, 허용하는 전류를 고려해서 선정되어야 하며, AWG22(0.3mm²) 이상이 좋습니다.
- 전선은 고온이 발생하는 기기나 물질에 너무 가까이 있거나 기름 등에 장시간 직접 접촉하게 되면, 합선의 원인이 되어 파손이나 오작동을 할 수 있습니다.
- 단자 대 배선 시 극성을 확인 하십시오.
- 배선을 고압선이나 동력선과 함께 배선하는 경우에는 유도 장애를 일으켜 오작동이나 고장의 원인이 될 수 있습니다.
- 사용하는 채널만 채널 운전으로 설정하여 사용하십시오.

■ 배선 예



- 전류 입력 시 V+단자와 I+ 단자를 연결하십시오.
- 전류 입력회로의 입력 저항은 250Ω (typ.)입니다.
- 전압 입력회로의 입력 저항은 1MΩ (min.)입니다.

8 보증 내용

- 구입하신 제품의 보증 기간은 제조일로부터 36개월입니다.
- 최초 고장 진단은 고객사에서 진행함을 원칙으로 합니다. 고객사에서 요청할 경우 당사에서 유상으로 지원 가능하며, 고장 원인이 당사에 있는 경우 무상 처리됩니다.
- 보증 외 범위
 - 소모, 수명 부품(릴레이, 퓨즈, 전해 CAP, 배터리, LCD 등)의 교환
 - 사용설명서에 명기된 이외의 부적당한 조건·환경·취급으로 발생한 경우
 - 고장의 원인이 당사의 제품 이외의 것으로 발생한 경우
 - 당사의 양해 없는 제품의 개조 등에 의한 고장
 - 제품 본래의 사용 방법이 아닌 경우
 - 당사에서 출하 시 과학·기술의 수준에서는 예상이 불가능한 사유에 의한 경우
 - 화재, 이상 전압 등의 불가항력에 의한 외부 요인 및 천재지변에 의한 고장
 - 기타 당사에 책임이 없는 경우
- 제품 보증내용 관련 상세내용은 당사 홈페이지 내 사용설명서를 참조하시기 바랍니다.
- 제품 성능 개선을 위해 설치가이드의 내용은 사전 예고 없이 변경될 수 있습니다.

LS ELECTRIC Co., Ltd. www.ls-electric.com 10310001187 V4.5 (2024.6)



한번 맺은 인연을
가장 소중히
여깁니다!

■ 서비스 대표 전화 (전국 어디서나)
1544-2080

■ 구입 문의

서울영업	TEL:(02)2034-4623~38	FAX:(02)2034-4057
부산영업	TEL:(051)310-6855~60	FAX:(051)310-6851
대구영업	TEL:(053)603-7741~8	FAX:(053)603-7788
서부영업(광주)	TEL:(062)510-1891~92	FAX:(062)526-3262
서부영업(대전)	TEL:(042)820-4240~42	FAX:(042)820-4298

■ 제조사(공장): 충남 천안시 동남구 목천읍 삼성4길 56 (우 31226)





This installation guide provides simple function information of PLC control. Please read carefully this data sheet and manuals before using products. Especially read safety precautions and handle the products properly.

1 Safety Precautions

■ Meaning of warning and caution inscription

	WARNING	WARNING indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury
	CAUTION	CAUTION indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices

WARNING

- Do not contact the terminals while the power is applied.
- Protect the product from being gone into by foreign metallic matter.
- Do not manipulate the battery(charge, disassemble, hitting, short, soldering).

CAUTION

- Be sure to check the rated voltage and terminal arrangement before wiring.
- When wiring, tighten the screw of terminal block with the specified torque range.
- Do not install the flammable things on surroundings.
- Do not use the PLC in the environment of direct vibration.
- Except expert service staff, do not disassemble or fix or modify the product.
- Use the PLC in an environment that meets the general specifications contained in this datasheet.
- Be sure that external load does not exceed the rating of output module.
- When disposing of PLC and battery, treat it as industrial waste.

2 Operating Environment

■ To install, observe the below conditions.

No	Item	Specification			Standard	
1	Ambient temp.	0 ~ 55℃			-	
2	Storage temp.	-25 ~ 70℃			-	
3	Ambient humidity	5 ~ 95%RH, non-condensing			-	
4	Storage humidity	5 ~ 95%RH, non-condensing			-	
5	Vibration Resistance	Occasional vibration			-	IEC 61131-2
		Frequency	Acceleration	Amplitude	Number	
		5≤f<8.4Hz	-	3.5mm	10 times in each direction for X, Y, Z	
		8.4≤f≤150Hz	9.8m/s ² (1g)	-		
		Continuous vibration				
		Frequency	Acceleration	Amplitude		
		5≤f<8.4Hz	-	1.75mm		
		8.4≤f≤150Hz	4.9m/s ² (0.5g)	-		


3 Applicable Support Software

■ For system configuration, the following version is necessary.

- XBC Type : E(V1.1 or above), SU(V1.0 or above), H(V1.1 or above)
- XEC Type : E(V1.1 or above), SU(V1.1 or above), H(V1.2 or above)
- XG5000 Software : V4.0 or above


4 Parts Name and Dimension (mm)

■ This is front part of the Module. Refer to each name when driving the system. For more information, refer to user manual.



5 Installing / Removing Modules

■ Option Board can be installed in 9 or 10 slot of the Main Unit(Standard/Economic Type) as shown below.



- When installing Option Board, push the lower part(①) of the Option Board to contact with connector.
- After pushing the lower part(①) completely, push the upper(②) part of the Option Board entirely.



6 Performance Specifications

■ Performance specifications are as follows


Item			XBO-AD02A	
Analog input	Type		Voltage	Current
	Range		DC 0~10V	DC 4~20mA DC 0~20mA
Digital output	Type		12bit binary data	
	Range	Unsigned value	0~4,000	
		Signed value	-2,000~2,000	
		Precise value	0~1,000 (DC 0 ~ 10V)	400~2,000(DC 4~20mA) 0~2,000(DC 0~20mA)
		Percentile value	0~1,000	
Max. resolution			1/4,000	
Accuracy			±1.0% or less	

7 Wiring

■ Precaution for wiring

- Don't let AC power line near to analog input module's external output signal line. With an enough distance kept away between, it will be free from surge or inductive noise.
- Cable shall be selected in due consideration of ambient temperature and allowable current. More than AWG22 (0.3mm²) is recommended.
- Don't let the cable too close to hot device and material or in direct contact with oil for long, which will cause damage or abnormal operation due to short-circuit.
- Check the polarity when wiring the terminal.
- Wiring with high-voltage line or power line may produce inductive hindrance causing abnormal operation or defect.
- Enable the channel that you want to use.

■ Wiring example



- In case of current input, connect V+ terminal and I+ terminal.
- Input resistance of current input circuit is 250Ω. (typ.)
- Input resistance of voltage input circuit is 1 MΩ. (min.)

8 Warranty

- The warranty period is 36 months from the date of manufacture.
- The initial diagnosis of faults should be conducted by the user. However, upon request, LS ELECTRIC or its representative(s) can undertake this task for a fee. If the cause of the fault is found to be the responsibility of LS ELECTRIC, this service will be free of charge.
- Exclusions from warranty
 - Replacement of consumable and life-limited parts (e.g. relays, fuses, capacitors, batteries, LCDs, etc.)
 - Failures or damages caused by improper conditions or handling outside those specified in the user manual
 - Failures caused by external factors unrelated to the product
 - Failures caused by modifications without LS ELECTRIC's consent
 - Use of the product in unintended ways
 - Failures that cannot be predicted/solved by current scientific technology at the time of manufacture
 - Failures due to external factors such as fire, abnormal voltage, or natural disasters
 - Other cases for which LS ELECTRIC is not responsible
- For detailed warranty information, please refer to the user's manual.
- The content of the installation guide is subject to change without notice for product performance improvement.

LS ELECTRIC Co., Ltd. www.ls-electric.com 10310001187 V4.5 (2024.6)

E-mail: automation@ls-electric.com



- Headquarter/Seoul Office
- LS ELECTRIC Shanghai Office (China)
- LS ELECTRIC (Wuxi) Co., Ltd. (Wuxi, China)
- LS-ELECTRIC Vietnam Co., Ltd. (Hanoi, Vietnam)
- LS ELECTRIC Middle East FZE (Dubai, U.A.E.)
- LS ELECTRIC Europe B.V. (Hoofddorp, Netherlands)
- LS ELECTRIC Japan Co., Ltd. (Tokyo, Japan)
- LS ELECTRIC America Inc. (Chicago, USA)

Tel: 82-2-2034-4033, 4888, 4703
 Tel: 86-21-5237-9977
 Tel: 86-510-6851-6666
 Tel: 84-93-631-4099
 Tel: 971-4-886-5360
 Tel: 31-20-654-1424
 Tel: 81-3-6268-8241
 Tel: 1-800-891-2941

• Factory: 56, Samseong 4-gil, Mokcheon-eup, Dongnam-gu, Cheonan-si, Chungcheongnam-do, 31226, Korea