Manufacturer: Shenzhen Yuanxiang Technology(Shenzhen)Co., LTD.
Address: Room 1002, 4th Floor, Building 1, 1024 Hongkong Road, Nanwan Community, Longgang District, Shenzhen, China.

Email: shengxingyuanxiang@outlook.com

RoHS

QUICK START GUIDE

BS

Switch Power Bank with Magnetic Clip

TABLE OF CONTENTS

- P01 - P06 — English
- P07 - P11 — Deutsch
- P12 - P16 — Français
- P17 - P21 — Italiano
- P22 - P26 — Español
- P27 - P32 — 日本語

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment.

This device has been validated to be used around RF exposure requirements.

The antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

PACKAGE CONTENTS

BS Power Bank ×1 | 2in1(C+Magnetic Clip) ×1 | 2in1(C+Magnetic Clip) ×1

USB-C to USB-C Cable 1m ×1 | USB-A To USB-C Cable 1m ×1

PRODUCT DESCRIPTION

① **Magnetic Wireless Charging Area:** Compatible with iPhone 15-16 series or Magsafe cases. Supports 15W fast charging (Adapter Required).

② **Power Button:** Short press to power on. Double press to activate cell charging function (available only when the battery level is above 20%).

③ **USB-C Input/Output:** Supports 20W fast charging power. Compatible with power input and USB-C output.

④ **Battery LED Indicators:**

LED INDICATOR GUIDE

Charging Status

- Red LED: When the battery level is below 20%, it will blink red, indicating that it's time to recharge.
- Blue LED: When the battery level is above 20%, it will blink blue.

Discharging Status

- Press LED Indicator: It will turn ON when discharging (battery level > 5%) or connected to an input device. Discharging: LED1 and LED2 will turn ON. Charging: LED1 and LED2 will blink.
- Low Power Mode: When the battery level is below 5%, the LED indicator will turn OFF.
- Auto Power Saving Mode: When no device is connected, the charging mode will be disabled to save power.

Note:

- Please ensure the battery is charged to 100% before first use to maximize battery performance.
- Avoid exposing the device to extreme temperatures (below 0°C or above 45°C) during charging.
- Do not use the device while it is charging.

SWITCH MAGNETIC CHARGING CLIP SET

① Align the clip's positioning protrusion with the Switch's top groove. Once you hear a click, the clip is securely attached.

② Press and hold the power button for 3 seconds to turn on the magnetic clip power (may vary by model). Wireless charging will begin automatically.

③ To remove the clip, insert a pick tool or a fine plastic tool into the slot between the clip and the Switch. Gently pry the clip upward to release it.

SWITCH 2 MAGNETIC CHARGING CLIP SET

① Align the two Switch positioning notches on the clip with the two tabs on the underside of the Switch. Press down until you hear a click.

② Press the power button on the Switch and hold for more than 3 seconds to turn on the clip's power supply. Wireless charging will begin automatically.

③ To remove the clip, insert a pick tool or a fine plastic tool into the slot between the clip and the Switch. Gently pry the clip upward to release it.

SPECIFICATIONS

Battery Capacity	5000 mAh (Rated capacity: 4850 mAh)
USB-C Input	5V⎓3A/9V⎓2.22A/12V⎓1.67A
USB-C Output	5V⎓3A/9V⎓2.22A/12V⎓1.67A
Wireless Charging Power	15W (Adapter Required)
Wired Charging Power	20W max
Product Size/Weight	4.65*2.3*1.0inch / 5oz (132.08g)

PACKUNGSINHALT

BS Power Bank ×1 | Magnetische Clip für Switch ×1 | Magnetischer Clip für Switch 2 ×1

USB-C to USB-C Kabel 1m ×1 | USB-A To USB-C Kabel 1m ×1

PRODUKTBESCHREIBUNG

① **Magnetischer kabelloser Ladebereich:** Kompatibel mit iPhone 15-16 Serie oder Magsafe-Hüllen. Unterstützt 15W Schnellladung (Netzteil erforderlich).

② **Ein-/Ausschalttaste:** Kurz drücken zum Einschalten. Doppelt drücken zum Ausschalten, wenn der Akkustand über 20 % liegt.

③ **USB-C Ein-/Ausgang:** Unterstützt eine Ladeleistung von bis zu 20W. Geeignet für Stromeingang und -ausgang.

④ **Batterieanzeigen:**

LED-ANZEIGEANLEITUNG

Ladestatus

- Akku unter 20 %: Leuchtet rot und blinkt, um anzuzeigen, dass es Zeit zum Aufladen ist.
- Akku über 20 %: Blinkt blau.

Entladestatus

- Anzeige-Taste: Leuchtet, wenn der Akkustand über 5 % liegt oder ein Gerät angeschlossen ist. Beim Entladen: LED1 und LED2 leuchten. Beim Laden: LED1 und LED2 blinken.
- Niedrige Leistung: Wenn der Akkustand unter 5 % liegt, schaltet sich die LED-Anzeige aus.
- Automatischer Leistungsmodus: Wenn kein Gerät angeschlossen ist, wird der Ladevorgang deaktiviert, um Strom zu sparen.

Hinweis:

- Stellen Sie sicher, dass der Akku vor dem ersten Gebrauch auf 100 % aufgeladen ist, um die Akkuleistung zu maximieren.
- Setzen Sie das Gerät während des Ladevorgangs keinen extremen Temperaturen (unter 0 °C oder über 45 °C) aus.
- Verwenden Sie das Gerät nicht, während es aufgeladen wird.

BEDIENTEILE LIST

Magnetische Ladefigurkantenschutz-Lösung (Nur für Switch 2)
Hinweis: Kompatibel mit Switch 2 und Switch OLED.

Magnetisch kabelloses Ladegerät
Hinweis: Kompatibel mit iPhone 12 und neueren Modellen mit Magsafe-Hüllen, sowie Geräten mit QI2-Unterstützung.

Ständer
Hinweis: Kompatibel mit Ihrem Switch und Switch OLED, optimiert für Switch 2. Inkompatibel mit Switch Lite und Switch.

SWITCH MAGNETISCHER LADECLIP-SATZ

① Richten Sie die beiden Positionierungsvorsprünge des Clips mit den beiden Nuten auf der Unterseite der Switch aus. Drücken Sie nach unten, bis Sie ein Klicken hören.

② Drücken Sie die Ein-/Aus-Taste 3 Sekunden lang, um das magnetische Ladegerät einzuschalten. Das Gerät beginnt nun automatisch mit dem kabellosen Aufladen.

③ Um den Clip zu entfernen, führen Sie ein Spudger oder ein ähnliches Werkzeug in den Spalt zwischen Clip und Switch ein. Hebeln Sie den Clip vorsichtig nach oben, um ihn zu lösen.

SWITCH 2 MAGNETISCHER LADECLIP-SATZ

① Richten Sie die beiden Positionierungskerben des Clips mit den beiden Laschen auf der Unterseite der Switch aus. Drücken Sie nach unten, bis Sie ein Klicken hören.

② Drücken Sie die Ein-/Aus-Taste 3 Sekunden lang, um das magnetische Ladegerät einzuschalten. Das Gerät beginnt nun automatisch mit dem kabellosen Aufladen.

③ Um den Clip zu entfernen, führen Sie ein Spudger oder ein ähnliches Werkzeug in den Spalt zwischen Clip und Switch ein. Hebeln Sie den Clip vorsichtig nach oben, um ihn zu lösen.