

Wireless Speaker

Reference Guide	參考指南	Panduan Referensi
Довідковий посібник	คู่มืออ้างอิง	دليل مرجعي
Panduan Rujukan		
ULT FIELD 5		Model, 型號: YY7859E

	
	
https://rd1.sony.net/help/speaker/7859/h_zz/	
	
5-064-353-71(1) ©2025 Sony Corporation Printed in Vietnam https://www.sony.net/	

English

Wireless Speaker

Model: YY7859E

The term "product" in this document refers to the unit or its accessories.

CAUTION: To avoid deterioration of the water-resistant performance, make sure that the cap is closed completely when using the unit.

The nameplate and important information concerning safety are attached in the following locations:

- the inner surface of the cap on the rear side of the unit

The term "product" in this document refers to the unit or its accessories.

CAUTION: To avoid deterioration of the water-resistant performance, make sure that the cap is closed completely when using the unit.

The nameplate and important information concerning safety are attached in the following locations:

- the inner surface of the cap on the rear side of the unit

Do not install the product in a confined space, such as a bookcase or built-in cabinet.

Do not expose the batteries (battery pack or batteries installed) to excessive heat, such as sunshine, fire or the like, for a long time.

Do not subject the batteries to extreme low temperature conditions that may result in overheating and thermal runaway.

Do not dismantle, open, or shred secondary batteries.

In the event of a secondary battery leaking, do not allow the liquid to come in contact with the skin or eyes. If contact has been made, wash the affected area with copious amounts of water and seek medical advice.

Secondary batteries need to be charged before use. Always refer to the manufacturer's instructions or product manual for proper charging instructions.

After extended periods of storage, it may be necessary to charge and discharge the secondary batteries several times to obtain maximum performance.

Dispose of properly.

Charging this unit

Connect the USB AC adaptor to this unit using the USB Type-C® cable, then connect the USB AC adaptor to an AC outlet.

Do not expose the unit to naked flame sources (for example, lighted candles).

This unit has been tested and found to comply with the limits set out in the EMC regulation using a connection cable shorter than 3 m.

Without permission granted by the NCC, no company, enterprise, or user shall change frequency, enhance transmitting power or alter original characteristics as well as performance of approved low power radio-frequency devices.

The low power radio-frequency devices shall not influence aircraft security nor interfere with legal communications; if found, the user shall cease operating immediately until no interference is achieved.

The said legal communications refer to radio communications operated in compliance with the Telecommunications Management Act. The low power radio-frequency devices must endure interference from legal communications or ISM radio wave radiated devices.

- Do not dismantle, open or shred secondary cells or batteries.
- Do not expose cells or batteries to heat or fire. Avoid storage in direct sunlight.
- Do not subject cells or batteries to mechanical shock.
- In the event of a cell leaking, do not allow the liquid to come in contact with the skin or eyes. If contact has been made, wash the affected area with copious amounts of water and seek medical advice.
- Do not use any charger other than that specifically provided for use with the unit.
- Do not use any cell or battery which is not designed for use with the unit.
- Seek medical advice immediately if a cell or a battery has been swallowed.
- Always purchase the battery recommended by the device manufacturer for the unit.
- Wipe the cell or battery terminals with a clean dry cloth if they become dirty.
- Secondary cells and batteries need to be charged before use. Always use the correct charger and refer to the manufacturer's instructions or product manual for proper charging instructions.
- Always purchase the battery recommended by the device manufacturer for the unit.
- After extended periods of storage, it may be necessary to charge and discharge the cells or batteries several times to obtain maximum performance.
- Use only cells or batteries that are appropriate for the intended use.
- Dispose of properly.

- This product will generate heat when charging. Always charge in a well ventilated area. Do not charge under pillows, blankets or on flammable surfaces.
- Keep this product away from heat sources, direct sunlight, combustible gas, humidity, water or other liquids.
- Do not disassemble, open, microwave, incinerate, paint or insert foreign objects into this product.
- Do not subject this product to mechanical shock such as crushing, bending, puncturing or shredding.
- Avoid dropping or placing heavy objects on this product.
- Do not short-circuit this product or store it in a receptacle where it may be short-circuited by other metallic or conductive objects.
- Do not operate this product if it has been wet or otherwise damaged, to prevent electric shock, explosion and/or injury. Contact the dealer or authorised agent for assistance.
- This product usage by children should be supervised.
- Please read this document (including charging instructions and information on the minimum and maximum operating temperatures), supplied with this product.

This product has magnet(s) which may interfere with pacemakers, programmable shunt valves for hydrocephalus treatment, or other medical devices. Do not place this product close to persons who use such medical devices. Consult your doctor before using this product if you use any such medical device.

Never insert the USB plug when the main unit or charging cable is wet. If the USB plug is inserted while the main unit or charging cable is wet, a short circuit may occur due to liquid (tap water, seawater, soft drink, etc.) or foreign matter on the main unit or charging cable, and cause abnormal heat generation or malfunction.

Complies with IMDA Standards DB00353

The term "product" in this document refers to the unit or its accessories.

The nameplate and important information concerning safety are attached in the following locations:

- the inner surface of the cap on the rear side of the unit

Do not install the product in a confined space, such as a bookcase or built-in cabinet.

Do not expose the batteries (battery pack or batteries installed) to excessive heat, such as sunshine, fire or the like, for a long time.

Do not subject the batteries to extreme low temperature conditions that may result in overheating and thermal runaway.

Do not dismantle, open, or shred secondary batteries.

In the event of a secondary battery leaking, do not allow the liquid to come in contact with the skin or eyes. If contact has been made, wash the affected area with copious amounts of water and seek medical advice.

Secondary batteries need to be charged before use. Always refer to the manufacturer's instructions or product manual for proper charging instructions.

After extended periods of storage, it may be necessary to charge and discharge the secondary batteries several times to obtain maximum performance.

Dispose of properly.

Charging this unit

Connect the USB AC adaptor to this unit using the USB Type-C® cable, then connect the USB AC adaptor to an AC outlet.

Do not expose the unit to naked flame sources (for example, lighted candles).

This unit has been tested and found to comply with the limits set out in the EMC regulation using a connection cable shorter than 3 m.

Without permission granted by the NCC, no company, enterprise, or user shall change frequency, enhance transmitting power or alter original characteristics as well as performance of approved low power radio-frequency devices.

The low power radio-frequency devices shall not influence aircraft security nor interfere with legal communications; if found, the user shall cease operating immediately until no interference is achieved.

The said legal communications refer to radio communications operated in compliance with the Telecommunications Management Act. The low power radio-frequency devices must endure interference from legal communications or ISM radio wave radiated devices.

- Do not dismantle, open or shred secondary cells or batteries.
- Do not expose cells or batteries to heat or fire. Avoid storage in direct sunlight.
- Do not subject cells or batteries to mechanical shock.
- In the event of a cell leaking, do not allow the liquid to come in contact with the skin or eyes. If contact has been made, wash the affected area with copious amounts of water and seek medical advice.
- Do not use any charger other than that specifically provided for use with the unit.
- Do not use any cell or battery which is not designed for use with the unit.
- Seek medical advice immediately if a cell or a battery has been swallowed.
- Always purchase the battery recommended by the device manufacturer for the unit.
- Wipe the cell or battery terminals with a clean dry cloth if they become dirty.
- Secondary cells and batteries need to be charged before use. Always use the correct charger and refer to the manufacturer's instructions or product manual for proper charging instructions.
- Always purchase the battery recommended by the device manufacturer for the unit.
- After extended periods of storage, it may be necessary to charge and discharge the cells or batteries several times to obtain maximum performance.
- Use only cells or batteries that are appropriate for the intended use.
- Dispose of properly.

- This product will generate heat when charging. Always charge in a well ventilated area. Do not charge under pillows, blankets or on flammable surfaces.
- Keep this product away from heat sources, direct sunlight, combustible gas, humidity, water or other liquids.
- Do not disassemble, open, microwave, incinerate, paint or insert foreign objects into this product.
- Do not subject this product to mechanical shock such as crushing, bending, puncturing or shredding.
- Avoid dropping or placing heavy objects on this product.
- Do not short-circuit this product or store it in a receptacle where it may be short-circuited by other metallic or conductive objects.
- Do not operate this product if it has been wet or otherwise damaged, to prevent electric shock, explosion and/or injury. Contact the dealer or authorised agent for assistance.
- This product usage by children should be supervised.
- Please read this document (including charging instructions and information on the minimum and maximum operating temperatures), supplied with this product.

This product has magnet(s) which may interfere with pacemakers, programmable shunt valves for hydrocephalus treatment, or other medical devices. Do not place this product close to persons who use such medical devices. Consult your doctor before using this product if you use any such medical device.

Never insert the USB plug when the main unit or charging cable is wet. If the USB plug is inserted while the main unit or charging cable is wet, a short circuit may occur due to liquid (tap water, seawater, soft drink, etc.) or foreign matter on the main unit or charging cable, and cause abnormal heat generation or malfunction.

Complies with IMDA Standards DB00353

Licenses

This product contains software that Sony uses under a licensing agreement with the owner of its copyright. We are obligated to announce the contents of the agreement to customers under requirement by the owner of copyright for the software. Please access the following URL and read the contents of the license.

https://rd1.sony.net/help/speaker/s125/

This product is protected by certain intellectual property rights of Microsoft Corporation. User or distributor of such technology outside of this product is prohibited without a license from Microsoft or an authorized Microsoft subsidiary.

Services offered by third parties may be changed, suspended, or terminated without prior notice. Sony does not bear any responsibility in these sorts of situations.

 Notes on waterproof and dustproof features (Read before using the unit) The supplied accessories are neither waterproof nor dustproof.
On waterproof and dustproof performance of the unit The unit, with the cap fastened securely, has a waterproof specification of IPX7, as specified in "Degree of protection against water immersion" of the IEC60529 "Ingress Protection Rating (IP Code)", and a dustproof specification of IP6X as specified in "Degrees of protection against solid foreign objects". The supplied accessories and the connectors of this unit (USB, AUDIO IN) are neither waterproof nor dustproof. To reduce the risk of fires or electric shocks, do not expose the unit to water or droplets while using any connectors (USB, AUDIO IN). Note that malfunctions as a result of water immersion or dust intrusion caused by misuse by the customer are not covered by the warranty.

To maintain waterproof and dustproof performance

Carefully note the precautions below to ensure proper use of the unit.

- Do not pour high-temperature water or blow hot air from a hair dryer or any other appliance on the unit directly. Also never use the unit in a place subject to high temperatures, such as in a sauna or near a heat source.

CAUTION : Handle the cap [Ⓐ] with care. The cap plays a very important role in maintenance of the waterproof and dustproof performance. When using the unit, make sure that the cap is closed completely. When closing the cap, be careful not to allow foreign objects inside. If the cap is not closed completely, the waterproof and dustproof performance may deteriorate and may cause a malfunction of the unit as a result of water or dust particles entering the unit.

Precautions

On placement

- To eliminate the risk of malfunctions, avoid the following locations when placing or leaving this unit.
 - A place subject to high temperatures, such as under direct sunlight or lighting equipment, near a heat source, or in a sauna
 - Inside a vehicle with the windows closed (especially in summertime)
 - A place exposed to hot air, such as from a hair dryer
- Place this unit on a flat, level surface. When placed on a sloped surface, the unit may fall over or fall off the surface due to its own vibration, resulting in injuries, malfunctions, or performance degradation.

- This unit is not anti-magnetic. Keep objects susceptible to magnetism (recorded tapes, watches, cash cards and credit cards with magnetic coding, etc.) away from the unit. When you carry around the unit, keep this in mind as well.

How to care for the unit

- Although the fabric part of the unit has water repellent treatment applied, you can use the unit more comfortably and for a longer period of time by following the maintenance procedure below.
- If the surface of the unit gets dirty in the following cases, wash the unit with fresh water (tap water, etc.) promptly to remove the dirt. Leaving dirt on its surface may cause the fabric part or the passive radiator section [Ⓐ] to discolour or deteriorate, or the unit to malfunction.

- When salt, sand, etc. is stuck on the unit after using it on a beach, pool side, etc.
- When the unit is stained with sweat or foreign substances (sunscreen, suntan oil, etc.)

Note

- If the surface of the unit gets dirty, do not use detergent, thinner, benzine, alcohol, etc. to clean the unit because it will affect the water repellent function of the fabric part of the unit.
- If sand grains, etc. enter the fabric or other part of the unit, remove them carefully. Never use a vacuum cleaner, etc. on the unit. It may cause damage of the speaker section or other part of the unit.

On BLUETOOTH® communications

- Microwaves emitting from a BLUETOOTH device may affect the operation of electronic medical devices. Turn off this unit and other BLUETOOTH devices in the following locations, as it may cause an accident:
 - in hospitals, near priority seating in trains, locations where inflammable gas is present, near automatic doors, or near fire alarms.

Other notes

- When placed in an extremely hot or cold environment, the unit stops battery charging for safety reasons. When the battery is kept charging itself for an extended period of time, the unit may stop battery charging as well. In such a case, make sure that the ambient temperature is within the battery charging temperature range (5 °C - 35 °C), unplug and plug the USB cable, and then charge the battery all over again.
- Even if you do not intend to use the unit for a long time, charge the battery to its full capacity once every 6 months to maintain its performance.
- If your skin remains in contact with the light for a long time while the light is turned on, there is a risk of low-temperature burns. To carry the speaker using the shoulder strap, etc. while it is powered on, turn the light (lighting function) off.
- When the unit's light seems bright or glaring, turn on the room lights or turn off the lighting function.
- If you have any questions or problems concerning this unit that are not covered in this manual, please consult your nearest Sony dealer.

Trademarks

- Microsoft and Windows are registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- The BLUETOOTH™ word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Sony Group Corporation and its subsidiaries is under license.
- USB Type-C® and USB-C® are registered trademarks of USB Implementers Forum.
- LDAC and LDAC logo are trademarks of Sony Group Corporation or its affiliates.

All other trademarks and registered trademarks are trademarks or registered trademarks of their respective holders. In this manual, "®" and "™" marks are not specified.

Specifications

BLUETOOTH section
Frequency band 2.4 GHz band (2,400 0 GHz - 2,483 5 GHz)
General inputs AUDIO IN jack (Ø 3.5 mm) DC OUT USB Type-C® port (for charging the battery of a connected device) (DC 5 V/MAX. 1.5 A)
Power DC 5 V 3.0 A or DC 9 V 3.0 A (using a commercially-available USB PD compatible AC adaptor capable of feeding in 3.0 A) or, using built-in lithium-ion battery
Operating temperature −5 °C - +35 °C
Battery charging temperature 5 °C - 35 °C
Dimensions (W × H × D) Including projecting parts and controls Approx. 320 mm × 144 mm × 125 mm
Mass (Including battery) Approx. 3.3 kg
Included items Wireless Speaker (1) USB Type-C® cable (USB-C® to USB-C®) (1) Shoulder strap (1) Documents (1 set) * A charging cable exclusively designed for the unit. Do not use the cable for any other purposes.
System requirements for charging battery using USB USB AC adaptor: - Using a commercially-available USB AC adaptor capable of delivering an output current of 1.5 A or more. USB AC adaptor compatible with USB PD (USB Power Delivery): - Using a commercially-available USB PD compatible AC adaptor capable of delivering DC 5 V/3.0 A or DC 9 V/3.0 A.* * We do not guarantee the operations with all the devices compatible with USB PD.
Design and specifications are subject to change without notice.

Українська	Бездротовий динамік
Модель: YY7859E Термін «виріб» у цьому документі відноситься до пристрою або його аксесуарів.	

УВАГА! Щоб уникнути послаблення водостійкості, повністю закривайте ковпачок під час використання пристрою.

Заводська табличка і важлива інформація щодо безпеки містяться в наступних місцях:

- внутрішній поверхні кришки на задньому боці пристрою

Не встановлюйте пристрій у замкненому просторі, наприклад у книжковій шафі чи вбудований шафі-купе.

Не піддавайте елементи живлення (батарейні блоки або вбудовані елементи живлення) дії джерел надмірного тепла протягом тривалого часу, наприклад сонячних променів, вогню тощо. Не піддавайте елементи живлення дії екстремально низьких температурних умов, що може призвести до перегрівання і теплового розгону.

Не розбирайте, не відкривайте та не робіть акумулятор.

У випадку витоків акумулятора унікайте контактні рідини зі шкірою або очима. Якщо контакт відбувся, промийте уражену зону великою кількістю води і зверніться за медичною допомогою. Перед використанням акумулятору необхідно зарядити. Завжди див. інструкції і правильного заряджання в інструкції виробника або керівництві виробу.

Після тривалих періодів зберігання можливо знадобиться зарядити і розрядити акумулятори декілька разів для отримання максимальної продуктивності.

Утилізуйте належним чином.

Не піддавайте пристрій дії джерел відкритого вогню (наприклад, запалених свічок).

Пристрій пройшов перевірку і відповідає обмеженням, викладеним у нормативах EMC для випадку використання з'єднувального кабелю, коротшого за 3 м.

Підключіть USB-адаптер змінного струму до цього пристрою за допомогою кабелю USB Type-C®, а потім підключіть USB-адаптер змінного струму до розетки змінного струму.

Не піддавайте пристрій дії джерел відкритого вогню (наприклад, запалених свічок).

Умови зберігання.

Продукцію зберігають в з'єднуваному виді в темних, сухих, чистих, добре вентильованих приміщеннях, ізольованих від місць зберігання кислот і лугів. Температура зберігання: від -20 до 60 °C. Відносна вологість зберігання не більше ніж 80%, без утворення конденсату. Термін зберігання не встановлений.Робоча температура: від -5 до 35 °C. Робоча відносна вологість не більше ніж 80%, без утворення конденсату.

Справжнім Сони Корпорейшн заявляє, що тип радіобладнання [YY7859E / Бездротовий динамік] відповідає Технічному регламенту радіобладнання, повний текст декларації про відповідність доступний на веб-сайті за такою адресою:

http://www.compliance.sony.ua/

Виробник: Сони Корпорейшн, 1-1-1 Конан Мінато-ку Токіо, 108-0075 Японія

Вироблено у В'єтнамі

Дата виготовлення зазначена на упаковці в наступному форматі: DD-MM-YYYY, де DD – це дата, MM – місяць і YYYY – рік виготовлення.

Цей виріб містить магніти, які можуть перешкодити роботі кардіостимуляторів, програмованих шунтувальних клапанів, призначених для лікування діабету/фалії, та інших медичних пристроїв. Не кладіть цей виріб поблизу людей, що використовують такі медичні пристрої. Якщо ви використовуєте буд-який із цих медичних пристроїв, проконсультуйтеся з лікарем, перш ніж починати користуватися цим виробом.

Ніколи не вставляйте штекер USB, якщо основний блок або зарядний кабель вологий. Якщо вставити USB-штекер, коли основний пристрій чи кабель вологі, може статися коротке замикання через рідину (водопровідна вода, морська вода, напіи тощо) або сторонні речовини на основному пристрої чи зарядному кабелі, що призведе до надмірного нагрівання або несправності.

Про звукові квазівки**ВАЖЛИВО**

Звукові квазівки для цього продукту доступні тільки англійською мовою.

Звукові квазівки можна почути з продукту у наступних ситуаціях:

- Пристрій переходить у режим сплучення: «Pairing» (Сполучення)
- При натисканні кнопки BATTERY для перевірки заряду акумулятора, коли пристрій увімкнено: «Battery fully charged/Battery case mode, Fully charged, Battery about 90%/Battery about 80%/Battery about 60%/Battery about 40%/Low Battery» (Акумулятор повністю заряджено/Режим догляду за акумулятором, Повністю заряджено, Акумулятор на рівні 90%/Акумулятор на рівні 80%/Акумулятор на рівні 60%/Акумулятор на рівні 40%/Низький заряд акумулятора)
- Коли акумулятор розряджається під час живлення пристрою: «Low Battery» (Низький заряд акумулятора)
- Коли заряд акумулятора падає до рівня, при якому пристрій не може запуститися: виводиться повідомлення «Battery is empty» (Акумулятор порожній), після чого пристрій вимикається.
- При натисканні й утриманні кнопки BATTERY для зміни режиму заряджання під час живлення пристрою: «Battery case mode, ON/Battery case mode, OFF» (Режим догляду за акумулятором, увімкнено/Режим догляду за акумулятором, вимкнено)
- Коли встановлено з'єднання в режимі Stereo
- Вихід із динаміка лівого каналу: «Left» (Лівий)

Вихід із динаміка правого каналу: «Right» (Правий)

Ліцензії

Цей виріб містить програмне забезпечення, яке компанія Sony використовує за ліцензійною угодою з власником авторських прав на це програмне забезпечення. Ми повинні оголосити вист усім клієнтам за винятком власника авторських прав на програмне забезпечення.

Перейдіть за такою адресою URL і прочитайте текст ліцензії.

https://rd1.sony.net/help/speaker/s125/

- Цей виріб захищений певними правами на інтелектуальну власність корпорації Microsoft Corporation. Використання або поширення такої технології, окрім як у цьому пристрої, забороняє без ліцензії корпорації Microsoft або уповноваженого представництва корпорації Microsoft.

- Послуги, які пропонуються третіми сторонами, можуть змінюватися, призунинятися або анулюватися без попереднього повідомлення. Sony не несе жодної відповідальності в такій ситуації.

 Примітки щодо водонепроникності і пилонепроникності (прочитайте перед використанням пристрою)
Аксесури з комплекту постачання не є антиводонепроникними, ані пилонепроникними.

Про характеристики водонепроникності й пилонепроникності пристрою

Цей пристрій і шийний захисний кришечка мають специфікацію водонепроникності IPX7, як зазначено в розділі «Ступінь захисту від проникнення води» стандарту IEC60529 «Клас захисту від зовнішніх впливів (код IP)», та специфікацію пилонепроникності IP6X, як зазначено в розділі «Ступінь захисту від твердих частинок предметів».

- Аксесури з комплекту постачання та роз'єми цього пристрою (USB, AUDIO IN) не є анти водонепроникними, ані пилонепроникними. Для збереження безпеки при використанні електричного струму беріть пристрій від впливу води або крапель під час використання буд-якої роз'ємі (USB, AUDIO IN).

Зверніть увагу, що несправності внаслідок занурення у воду або проникнення пилу через неправильну експлуатацію покупцем гарантією не покриваються.

 Як підтримувати характеристики водонепроникності й пилонепроникності
Ретельно вивчіть квази нижче застережні заходи для забезпечення належного використання пристрою. Не розливайте гарячу воду та не спрямовуйте гаряче повітря з фена або іншого приладу безпосередньо на пристрій. Також в жодному випадку не використовуйте пристрій у місці, яке знаходиться під впливом високих температур, наприклад у сауні або поряд з джерелом тепла.

УВАГА! : Обережно поведіться з кришкою [Ⓐ]. Кришка відіграє дуже важливу роль у забезпеченні характеристик водонепроникності та пилонепроникності. Під час використання пристрою переконайтеся, що кришка повністю закрита. Закривачи кришки, пильнітьте, щоб усередини не потрапили сторонні предмети. Якщо кришка закрили не повністю, характеристики водонепроникності і пилонепроникності можуть погіршитися, що може призвести до несправності пристрою внаслідок потрапляння води або часток пилу в пристрій.

Застережні заходи

 Застережні заходи Стосовно розміщення
Щоб виключити ризик виникнення несправностей, унікайте розміщення або залишення даного пристрою в наступних місцях. - Місця, які знаходяться під впливом високих температур, наприклад під прямими сонячними променями або освітлювальним обладнанням, поряд з джерелом тепла або в сауні - Всередині автомобілів з закритими вікнами (особливо вілтку) - Місця, що знаає впливу гарячого повітря, наприклад з фена

- Розміщуйте цей пристрій на плоскій, рівній поверхні. При розміщенні на нахилений поверхні пристрій може перекинутися або власти з поверхні під впливом своєї власної ваги, що призведе до травм, несправностей або погіршення характеристик.
- Цей пристрій не є антимагнітним. Тримайте предмети, чутливі до магнітних полів (магнітні стрічки, годинники, платіжні картки та кредитні картки з магнітним кодуванням тощо) подалі від пристрою. Також пам'ятайте про це при транспортуванні пристрою.

Хоча компоненти пристрою, виготовлені з тканини, оброблено водовідштовхувальними матеріалами, дотримуйтеся наведених нижче процедури з обслуговування, щоб підвищити зручність використання пристрою протягом тривалішого періоду часу.

- Якщо пристрій забрудниться на поверхні в наведених нижче випадках, якнайшвидше почистьте пристрій прісною (водопровідною тощо) водою, щоб видалити бруд. Залишки бруду на його поверхні можуть призвести до знебарвлення чи погіршення характеристик тканинної частини або секції пасивного випромінювача [Ⓐ] або до несправності пристрою.

Приклади

- Якщо після використання на пляжі, біля басейну тощо на пристрої залишаться сіль, пісок і подрібнені матеріали
- Якщо на пристрій потраплять пінт або сторонні речовини (сонцезахисний крем, олія для засмаги то

