

Benutzerhandbuch / User Manual

DEUTSCH

Der ATMEL AVR USB ASP ISP Programmer ermöglicht

- EEPROM beschreiben / lesen
- flashen einer Firmware
- Chip löschen
- OSCAL - Register lesen unterstützt des Weiteren
- fuse bits
- lock bits

Der ATMEL AVR USB ASP ISP Programmer ist auf folgenden Betriebssystem lauffähig

Windows (Treiber wird auf unserer Internetseite bereitgestellt)

Mac OS X (kein Treiber notwendig)

Linux (kein Treiber notwendig)

Dabei sind für die jeweiligen Betriebssysteme eine Vielzahl von Programmen, wie beispielsweise

- eXtreme Burner (Win)
 - Khazama (Win)
 - AVRDUDE (OS X, Linux, Win)
 - uvm.
- verfügbar.

ENGLISH

The ATMEL AVR USB ASP ISP Programmer supports

- writing and reading EEPROM
- flashing Firmware
- Chip erase
- read OSCAL - Register supports
- fuse bits
- lock bits

The ATMEL AVR USB ASP ISP Programmer supports

Windows (required Driver is available on our website)

Mac OS X (no Driver required)

Linux (no Driver required)

Also variety of AVR programming software supports the USB asp isp programmer, including

- eXtreme Burner (Win)
- Khazama (Win)
- AVRDUDE (OS X, Linux, Win)
- and much more

