





Návod k použití



Handheld Fan Life7(5000mAh)

Před použitím si pečlivě přečtěte tento návod. Dbejte na to, abyste jej používali v
přiloženém souledu s požadavky uvedenými v návodu, a návod řádně uschovejte pro
budoucí použití.

Popis vzhledu



- | | |
|---|--------------------------|
| 1 Výstup vzduchu | 6 Přívod vzduchu |
| 2 Otvorovka displeje | 7 Šrouby |
| 3 Rychlost ventilátoru/výkon v procentech | 8 Přepínač |
| 4 Tlačítko napájení/rychlosti | 9 Protiskluzová podložka |
| 5 Zadní kryt (odnímatelný) | 10 konektor Typ-C |

Upozornění před použitím

1. Před zapnutím zkontrolujte, zda výrobek a napájecí kabel nejsou poškozeny, ujistěte se, že jsou v dobrém stavu, a sestavte je podle návodu.
2. Před nabíjením výrobku zkontrolujte, zda napětí použitého napájecího zdroje odpovídá štítku výrobku.
3. Výrobek nerozebírejte, neopravujte ani neopravujte, abyste předešli úrazu elektrickým proudem a požáru, a o opravu požádejte servisní středisko určené původním prodejcem nebo výrobcem.

Pokyny k použití

A. Vypínač napájení/nastavení rychlosti

Krátkým stisknutím tlačítka zapnutí-vypnutí projdete pěti rychlostními nastaveními ventilátoru a vypnete jej; dlouhým stisknutím při jakékoli rychlosti jej vypnete.

B. Zobrazení stavu obrazovky



Operace/stav	Zobrazení obsahu obrazovky
Zapnutí napájení	Zobrazuje aktuální úroveň nabití baterie, po 5 sekundách se přepne na zobrazení rychlosti ventilátoru.
Nastavení rychlosti ventilátoru	Zobrazuje aktuální rychlost ventilátoru; během nabíjení se po 5 sekundách přepne zpět na zobrazení nabíjení.
Zobrazení baterie	Stav vypnutí: Dvojitým kliknutím na tlačítko se zobrazí aktuální úroveň nabití baterie, po 5 sekundách zhasne. Stav zapnutí: Při zapnutí zobrazuje aktuální úroveň nabití baterie (po 5 sekundách se přepne na zobrazení aktuálních otáček ventilátoru); při zobrazení otáček ventilátoru se dvojitým kliknutím zobrazí aktuální úroveň nabití baterie (po 5 sekundách se přepne na zobrazení aktuálních otáček ventilátoru).
Nežve spustit s vybitou baterií	Po stisknutí tlačítka se na displeji zobrazí 0 % baterie, ikona baterie třikrát blikne a poté displej zhasne.
Upozornění na slabou baterii	Pokud je úroveň nabití baterie <10 %, ikona baterie během režimu rychlosti ventilátoru nadále bliká a během režimu stavu baterie nadále bliká (jednočíslný ukazatel úrovně nabití baterie a ikona baterie).

Nabíjení	Jednomístné číslo úrovně nabití baterie nadále bliká; při zobrazení rychlosti ventilátoru ikona baterie nadále bliká.
Plně nabitá	Úroveň nabití baterie 100 % zůstává svítit, ikona baterie zůstává svítit a po odpojení vstupu napájení zhasne.

Upozornění: Pokud je baterie nabitá na méně než 15 % a používáte ji během nabíjení, je k dispozici pouze první rychlost ventilátoru.

C. Provoz ventilátoru

1. Pro ovládání držte rukojeť. 2. Otočte hlavu masky do úhlu 100° a položte ji na pracovní plochu pro použití.



D. Jak čistit

Sejmutí zadního krytu

Poznámka: Před sejmutím zadního krytu vypněte napájení, dokud ventilátor zcela nepřestane pracovat.

Pomocí šroubováku odšroubujte šrouby pod zadním krytem a poté otáčejte zadním krytem proti směru hodinových ručiček, dokud neuslyšíte zvuk „cvaknutí“, čímž jej otevřete.




Čištění a údržba

1. Před čištěním výrobku se ujistěte, že bylo odpojeno napájení.
2. Zadní kryt lze čistit vodou a lopatky ventilátoru a masku lze odfit čistým hadříkem. Po vyčištění masky, zadního krytu a lopatek ventilátoru je před opětovnou instalací k použití nechte zcela vyschnout.
3. K čištění elektrických součástí (např. motoru, vypínače atd.) nepoužívejte vodu ani jiné tekutiny.
4. Nedotýkejte se napájecích a elektrických součástí mokřima rukama nebo vlhkým hadříkem.

Instalace zadního krytu

Přidrte okraj přičky zadního krytu, zasuněte ji svisle dolů, oběma rukama přidrte rám zadního krytu, otáčejte jej ve směru hodinových ručiček, dokud neuslyšíte zvuk ovačnutí, poté pomocí šroubováku zašroubujte šrouby pod zadním krytem a dokončete úkon.



Vyjmutí baterie

před vyfazením výrobku je nutné vyjmout baterii. Před vyjmutím baterie se ujistěte, že je výrobek vypnutý. Baterii bezpečně zlikvidujte v souladu s místními předpisy.

1. Pomocí nářadí sejměte levý a pravý kryt rukojeti ventilátoru, odšroubujte levý a pravý šroub (Obrázek 1).
2. Odstraňte protiskluzovou podložku, vyšroubujte šrouby krytu hlavy ventilátoru a sejměte kryt hlavy (Obrázek 2).
3. Pomocí nářadí vypáče zadní kryt rukojeti ventilátoru, odpojte zástrčku a vyjměte baterii k bezpečné likvidaci v souladu s místními předpisy (Obrázek 3).



Obrázek 1



Obrázek 2



Obrázek 3

Bezpečnostní upozornění

Abyste zajistili bezpečnost používání a předešli zranění a škodám na majetku vás i ostatních, dodržujte následující bezpečnostní opatření. Nesprávné používání bez dodržení bezpečnostních upozornění může vést k nehodám.

1. Tento výrobek není dětská hračka, zajistěte, aby si kojenci a děti nehrali s tímto výrobkem jako s hračkou. Děti mladší 14 let jej prosím používejte pod dohledem dospělé osoby.

2. Tento výrobek není určen pro použití uživateli (včetně dětí) s nedostatečnou fyziologií, vnímáním, mentálními schopnostmi, zkušenostmi nebo znalostmi, pokud není bezpečně používán pod dohledem nebo s vědomím osoby odpovědné za jejich bezpečnost.
3. Neťoukejte přímo na lidské tělo po delší dobu, zejména u starších osob a dětí, abyste předešli fyzickému nepohodlí.
4. Při používání nekládejte prsty, ostré předměty a kovové předměty apod. které by způsobily selhání výrobku a riziko úrazu elektrickým proudem, případně zranění.
5. Při používání nesmíte mít mokré ruce, používat mokré ručníky a jiné, aby nedošlo k úrazu elektrickým proudem.
6. Tento výrobek není vodoúšný, nepoužívejte vodu k přímému oplachování výrobku nebo v koupelně, silnou vlhkost, místa pro skladování vody k použití; povrchovou vodu, prosím, včas vysušte, než se pokusíte zapnout používání; zcela nasáklou a vnitřní vodu do zákazu opakovaného použití.
7. Nezakrývejte výstup a přítok vzduchu, například zavěšenými oděvy, ručníky, oblečením a jinými předměty, aby nedošlo k poškození výrobku.
8. Zabráňte používání a skladování v prostředí s vysokou teplotou (vyšší než 60 °C) a v uzavřených prostorách, jako jsou skleníky, staveniště, krby, exponované prostory automobilů a další prostředí, které způsobí deformaci plastu, plamen s větrem způsobí požár, výbuch baterie a další poruchy a nehody.
9. Baterii nestlačujte, nerozebírejte a neumisťujte na delší dobu do prostředí s vysokou teplotou (60 °C a více), jinak hrozí nebezpečí úniku kapaliny nebo výbuchu.
10. Pokud spotřebitelé používají k nabíjení napájecí adaptér, vstupní jmenovité napětí a proud napájecího adaptéru by měly být v rozmezí 5,0 V 2,0 A a před použitím by měly být spínány povinné národní bezpečnostní certifikace.
11. Tento výrobek používá lithium-iontovou baterii, nemá paměťovou funkci, přebíjení nebo nadměrné vybití ovlivní životnost výrobku, nabíjejte včas a po úplném nabití odpojte napájení, dlouhou dobu (více než 3 měsíce) nepoužívejte, prosím, plně nabíjte.

12. Pokud dojde k výskytu kouře, požáru a jiných poruch při používání, okamžitě vypněte napájení, abyste přestali přístroj používat, a pošlete jej prodejci nebo výrobci, aby se s ním vypořádal, nerozebírejte jej, abyste předešli nebezpečí.
13. Během nabíjení neohýbejte ani netahujte za napájecí kabel, aby nedošlo ke špatnému kontaktu.

Specifikace

Značka: JissuLife

Název produktu: Handheld Fan Life7

Product Model: Handheld Fan Life7

Vstup: 5.0V/2.0A

Kapacita baterie: 5000 mAh (18,5Wh/3,7V)

Baterie: Lithium-iontová baterie

Doba nabíjení: 4-5 hodin

Doba provozu: 3,5-19,5 hodiny (v závislosti na různých rychlostech/nastaveních a způsobech použití)

Product Weight: Přibližně 250 g

Rozměry výrobku: 250 × 250 mm: 84 × 42 × 193 mm

Obsah balení

Handheld Fan Life7 * 1

Nabíjecí kabel USB-C * 1

Štěrka na lok * 1

Uživatelská příručka * 1

Obsah této příručky a specifikace výrobku se mohou změnit bez předchozího upozornění.

Dodavatel/Distributor

Sunnysoft s.r.o.

Kovanecká 2390/1a


190 00 Praha 9

Česká republika

www.sunnysoft.cz




User Guide



Handheld Fan Life7(5000mAh)

Please read this manual carefully before use. Be sure to use it in strict accordance with the requirements of the manual, and keep the manual properly for future use.

Appearance Description



Air outlet - - - - -	①	Air inlet - - - - -	⑥
Display screen - - - - -	②	Screws - - - - -	⑦
Fan speed/power percentage - - - - -	③	Toggle Switch - - - - -	④
Power/Speed Button - - - - -	⑤	Anti-slip pad - - - - -	⑨
Rear cover (removable) - - - - -	⑧	Type-C input port - - - - -	⑩

Precautions Before Use

1. Please check the product and power cord for any damage and make sure they are in good condition and assemble them according to the instructions before powering them on.
2. Before charging the product, please check whether the voltage of the power supply used is consistent with the product label.
3. Please do not disassemble, modify or repair the product to avoid electric shock and fire accidents, and ask the service station designated by the original seller or manufacturer for repair.

Instructions for Use

A. Power Switch/Speed Adjustment

Short press the On-Off Key to cycle through the five-speed fan settings and power off; long press at any speed to turn off.

B. Display Screen Status



Current battery percentage
Battery indicator lit



Fan speed indicator lit
Current fan speed setting

Operations/Status	Display Screen Content
Power On	Shows current battery level; switches to display fan speed after 5 seconds.
Adjusting Fan Speed	Displays current fan speed; switches back to charging display after 5 seconds during charging.
Battery Display	Power-off state: Double-click the button to show the current battery level; extinguishes after 5 seconds. Power-on state: Displays current battery level when turning on (switches to display current fan speed after 5 seconds); double-clicks to show current battery level when displaying fan speed (switches to display current fan speed after 5 seconds).
Unable to Start with Low Battery	Pressing the button, battery display shows 0%, battery icon flashes three times, then the screen extinguishes.
Low Battery Warning	When battery level is <10%, the battery icon continues to flash during fan speed mode, and the single-digit battery level and battery icon continue to flash during battery status mode.

Charging	Single-digit battery level continues to flash; when displaying fan speed, the battery icon continues to flash.
Fully Charged	Battery level 100% stays on, battery icon stays on, and extinguishes after disconnecting power input.

Friendly reminder: When the battery is less than 15%, and you are using it while charging, only the first fan speed is available.

C. Fan Operation

1. Hold the handle for operation.
2. Rotate the mask to 100° and place it on the desktop for use.
3. Connect the fan to the hanging rope and wear it around the neck, directing the airflow towards the head and neck.



D. How to Clean

Removing the Rear Cover

Note: Before removing the rear cover, please turn off the power until the fan completely stops working.

Use a screwdriver to unscrew the screws beneath the rear cover, then rotate the rear cover counterclockwise until you hear a "click" sound to open it.




Cleaning and Maintenance

1. Before cleaning the product, ensure that the power has been disconnected.
2. The rear cover can be cleaned with water, and the fan blades and mask can be wiped with a clean cloth. After cleaning the mask, rear cover, and fan blades, let them air-dry completely before reinstalling for use.
3. Do not use water or other liquids to clean electrical components (such as the motor, power switch, etc.).
4. Avoid touching the power and electrical components with wet hands or a damp cloth.

Installing the Rear Cover

Hold the edge of the rear cover crossbar, insert it vertically downwards, hold the rear cover frame with both hands, rotate clockwise until you hear a "click" sound, then use a screwdriver to screw in the screws beneath the rear cover to complete the operation.



Removing the Battery

Before discarding the product, the battery must be removed. Ensure that the product is powered off before removing the battery. Dispose of the battery safely in accordance with local regulations.

1. Use tools to remove the left and right covers of the fan handle, unscrew the left and right screws (Figure 1).
2. Remove the anti-slip pad, unscrew the screws of the fan's head cover, and remove the head cover (Figure 2).
3. Use tools to pry open the back cover of the fan handle, unplug the power plug, and remove the battery for safe disposal in accordance with local regulations (Figure 3).



Figure 1



Figure 2



Figure 3

Safety Precautions

To ensure the safety of use and to avoid injury and property damage to you and others, please observe the following safety precautions; incorrect use without observing the safety warnings may lead to accidents.

01. This product is not a child's toy, please ensure that infants and children do not play with this product as a toy; Children under 14 years of age, please use it under the supervision of a guardian.

02. This product is not intended for use by users (including children) with inadequate physiology, perception, mental ability, experience, or knowledge, unless used safely under the supervision or knowledge of a person responsible for their safety.
03. Please do not blow directly on the human body for a long time, especially the elderly and children, to avoid physical discomfort.
04. When using, please do not put fingers, sharp objects and metal objects, etc., which will cause product failure and the risk of electric shock, or injury.
05. When using, prohibit the use of wet hands, wet towels and other plugging power to avoid electric shock.
06. This product is not waterproof, please do not use water to directly rinse the product or in the bathroom, heavy moisture, water storage places to use; surface water, please dry in time to dry before trying to turn on the use; completely soaked and internal water into the prohibition of re-use.
07. Do not cover the air outlet and air inlet, such as hanging clothes, towels, clothes, and other items, so as not to cause product failure.
08. Prohibit the use and storage in high temperature (higher than 60°C) environments and confined spaces, such as greenhouses, construction sites, fireplaces, exposed car rooms and other environments, which will cause plastic deformation, flame with the wind to cause fire, battery explosion and other failures and accidents.
09. Do not squeeze, disassemble the battery or place the battery in a high-temperature environment (60°C and above) for a long time, otherwise there may be a risk of liquid leakage or explosion.
10. If consumers use the power adapter to charge, the power adapter input rated voltage and current should be within 5.0V $\pm$ 2.0A, and the national mandatory safety certification before use.
11. This product uses lithium-ion battery, no memory function, overcharge or overdischarge will affect the service life of the product; please charge in time and disconnect the power after full charge, long time (more than 3 months) do not use please fully charge.

12. If there is smoke, fire and other failures in use, please immediately turn off the power to stop using, and send it to the dealer or manufacturer to deal with, do not disassemble themselves to avoid danger.
13. Do not bend or pull the power cord during charging to avoid poor contact.

Product Specifications

Brand: JisuLife

Product Name: Handheld Fan Life7

Product Model: Handheld Fan Life7

Input: 5.0V ~ 2.0A

Battery Capacity: 5000mAh (18.5Wh/5.7V)

Battery: Lithium-ion Battery

Charging Time: 4-5 hours

Working Time: 3.5-19.5 hours (depending on different speed/settings and usage scenarios)

Product Weight: Approximately 250g

Product Dimensions: 84*42*193mm

Package Accessories

Handheld Fan Life7 * 1

USB-C Charging Cable * 1

Lanyard * 1

User Manual * 1

The content of this manual and the specifications of the product are subject to change without prior notice.



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.