30 mm

OPERATING INSTRUCTIONS:
NON DATE WATCH

Pull the crown out to position B
Advance hands clockwise to the correct time
Return to position A

NOTE: Do not wind the crown when it is in position A.
If your watch has a second (sweep) hand you will notice that on pulling the crown out to position B, the second hand stops – this is normal.

This product contains button cell batteries.
Scan the QR code for more information.

'Contains Non-Replaceable Button Cell Batteries'

WARNING: Button Cell Batteries are Hazardous (new or used). Keep away from Children.Button Cell Batteries can cause severe or fatal injuries in 2 hours or less if they are swallowed or placed inside any part of the body.

If you suspect your child has swallowed or inserted a button cell battery, call the 24hour poisons information centre in Australia on 131126 or in New Zealand 0800 764 766 or contact your country's emergency dept.
Used batteries must be disposed of in the garbage or a battery recycle facility.

⚠ WARNING: CHOKING HAZARD
SMALL PARTS. NOT SUITABLE FOR CHILDREN UNDER 3 YEARS.

168 mm