



| FN组合    | WIN系统       | MAC系统  |
|---------|-------------|--------|
| FN+ ESC | 、           | 、      |
| FN+ 1!  | F1          | 屏幕亮度-  |
| FN+ 2@  | F2          | 屏幕亮度+  |
| FN+ 3#  | F3          | 任务控制   |
| FN+ 4\$ | F4          | 控制台    |
| FN+ 5%  | F5          |        |
| FN+ 6^  | F6          |        |
| FN+ 7&  | F7          | 上一曲    |
| FN+ 8*  | F8          | 播放/暂停  |
| FN+ 9(  | F9          | 下一曲    |
| FN+ 0)  | F10         | 静音     |
| FN+ -   | F11         | 音量-    |
| FN+ =+  | F12         | 音量+    |
| FN+ O   | PAUSE       | F15    |
| FN+ I   | SCROLL LOCK | F14    |
| FN+ U   | PRTSC       | F13    |
| FN+ J   | INSERT      | INSERT |
| FN+ K   | HOME        | HOME   |
| FN+L    | PGUP        | PGUP   |
| FN+M    | DELETE      | DELETE |
| FN+,>   | PGDN        | PGDN   |
| FN+,<   | END         | END    |

产品USB设备名为： C1D00 C60

**特殊灯光设置**

左上角的灯，默认为RGB流光灯效

键盘指示灯： 大写时CAPS LOCK亮白灯，锁WIN后，WIN键亮白灯

更多操作，请使用网页驱动 <https://cidoo.driveall.cn/#/>

A detailed diagram of a standard QWERTY keyboard layout. The keyboard is shown from a top-down perspective, highlighting the arrangement of keys. The top row includes function keys (F1-F12) and a numeric keypad. The main typing area is organized into three rows: the top row for letters Q-W-E-R-T-Y, the middle row for A-S-D-F-G-H-J-K-L, and the bottom row for Z-X-C-V-B-N-M. The diagram also shows the spacebar, backspace, and various control keys like Shift, Ctrl, and Alt.

minimalistic design inheriting the originality style  
THIS IS EXACTLY WHAT I LIKE THANK YOU

| FN                         | WIN                           | MAC                          |
|----------------------------|-------------------------------|------------------------------|
| FN+ ESC                    | `                             | `                            |
| FN+ !                      | F1                            | Screen brightness decrease   |
| FN+ 2@                     | F2                            | Screen brightness increase   |
| FN+ 3#                     | F3                            | Task control                 |
| FN+ 4\$                    | F4                            | Console                      |
| FN+ 5%                     | F5                            |                              |
| FN+ 6^                     | F6                            |                              |
| FN+ 7&                     | F7                            | Prev song                    |
| FN+ 8*                     | F8                            | Play /Pause                  |
| FN+ 9(                     | F9                            | Next song                    |
| FN+ 0)                     | F10                           | Mute                         |
| FN+ -                      | F11                           | Volume down                  |
| FN+ =+                     | F12                           | Volume up                    |
| FN+ O                      | PAUSE                         | F15                          |
| FN+ I                      | SCROLL LOCK                   | F14                          |
| FN+ U                      | PRTSC                         | F13                          |
| FN+ J                      | INSERT                        | INSERT                       |
| FN+ K                      | HOME                          | HOME                         |
| FN+ L                      | PGUP                          | PGUP                         |
| FN+ M                      | DELETE                        | DELETE                       |
| FN+ ,>                     | PGDN                          | PGDN                         |
| FN+ .<                     | END                           | END                          |
| FN+ WIN                    | Lock/Unlock WIN key           |                              |
| FN+ SPACE                  |                               |                              |
| Hold down for<br>3 seconds | Restored to factory Settings  | Restored to factory Settings |
| FN+ BACKSPACE              | Turn Off/On the LED backlight |                              |

|        |                                                                                                                                            |  |
|--------|--------------------------------------------------------------------------------------------------------------------------------------------|--|
| FN+    | Switching LED effects                                                                                                                      |  |
| FN+  } | LED effect speed up                                                                                                                        |  |
| FN+  { | LED effect speed down                                                                                                                      |  |
| FN+↑:  | LED brightness increase                                                                                                                    |  |
| FN+↓:  | LED brightness decrease                                                                                                                    |  |
| FN+←:  | Switching LED effect directions                                                                                                            |  |
| FN+→:  | Switching LED colors                                                                                                                       |  |
| FN+Z   | Switching the LOGO LED effects in the upper left corner, the default LED effects are streamer, cyclic breathing, neon, steady on, and off. |  |
| FN+X   | Switching the LOGO LED effects in the upper left corner from red, orange, yellow, green, cyan, blue, purple, white, full color.            |  |

The upper left corner of the LED, default is RGB streamer light effect.  
Keyboard indicator:  
When the CAPS LOCK key is on, the relevant LED is constant in White.  
When the WIN key is locked, the relevant LED is constant in White.

More operations, please use web driver, link below:  
<https://cidoo.driveall.cn/#/>

| 有 害 物 质 / Hazardous Substance |           |           |           |                            |                |                   |
|-------------------------------|-----------|-----------|-----------|----------------------------|----------------|-------------------|
| 部件名称                          | 铅<br>(Pb) | 汞<br>(Hg) | 镉<br>(Cd) | 六价铬<br>(Cr <sup>VI</sup> ) | 多溴联苯<br>(PBBs) | 多溴二苯基醚<br>(PBDEs) |
| 电路板组件                         | ×         | ○         | ○         | ○                          | ○              | ○                 |
| 键盘外壳                          | ○         | ○         | ○         | ○                          | ○              | ○                 |

\*本表格依据SJ/T 11364 的规定编制。

○：表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572 规定的限量要求以下。

×：表示该有害物质在该部件的某一均质材料中的含量超出GB/T 26572 规定的限量要求。

 在中华人民共和国境内销售的电器电子产品上将印有“环保使用期”(EPuP)符号，圆圈中的数字代表产品的正常环保使用年限。

|           |      |  |      |  |
|-----------|------|--|------|--|
| 用户<br>信息  | 联系电话 |  | 电子邮件 |  |
|           | 通信地址 |  | 邮政编码 |  |
| 产品<br>信息  | 产品名称 |  | 销售日期 |  |
|           | 产品型号 |  | 发票号码 |  |
| 销售商<br>信息 | 商家名称 |  | 联系电话 |  |
|           | 通信地址 |  | 邮政编码 |  |

注:

- (1) 此表应由销售商盖章确认;
- (2) 对于可适用相关“三包”规定的产品,本保修卡等同与“三包凭证”;
- (3) 维修记录以授权服务机构维修凭证为准,申请服务后,请妥善保管。

(A) 维护、采用或不适当的运输;

(B) 不当使用, 例如但不限于在不适当的温度、湿度或其他不坏环境条件下使用;

(C) 不可抗力或意外事件、网络或电力中断等非我们可合理控制的事由;

(D) 非授权人员擅自修理或折改;

(E) 任何第三方产品或服务;

(F) 将产品用于非指定或预期目的;

(G) 由于我们违反产品使用说明方式使用、产品使用过程中发生的正常损耗或老化、刮痕、擦伤以及因使用涂料、溶剂或其他化学药品导致的问题不属于保证范围。如产品原有识别标签被更改或损毁, 本保证将失效。产品及随附物料的完好和齐备不属于保证范围, 您应在接收产品时当场检验并对任何不符提出异议。

以上是我们对产品作出的全部保证, 且仅在中国大陆司法管辖区域内适用。本保证授予您特定的法律权利, 根据法律您可能还要享有其他权利, 本文件的任何内容均不影响您依据法律规定可能排除或限制的消费权利。

| 产品名称      | 保修范围 | 部件名称 | 保修期(月) | 保修服务类型 | 备注 |
|-----------|------|------|--------|--------|----|
| CIDOO C60 | 主要部件 | 键盘   | 12     | 取送寄修   |    |

**注释和说明**

(1)此表不是对产品规格和配置的描述,产品规格和配置以产品实际为准。

(2)您退货时应交售包装,并配合物流商查验。建议使用产品原始包装。

如该类产品非属保修范围,我们将与您联系并按您确认的方式处理。请务必确保联络信息准确及通讯畅通。如因您的原因导致修理或更换的产品超过2(二)个月未交还给您,视为同意我们按合适的方式处置。

