

A4

297mm

210mm



ENGLISH



WS414

Work Station

ADJUSTABLE RISING DESK

Catatan:

- Input: AC100~240V / 50-60Hz
- Operating Temperature: 0~40°C
- After the WS414 assembly is finished, please press the "O" button before using it (see No.1 Position Reset).
- Before use, please check whether all the cables are fully connected.
- Keep children away from the adjustable rising desk and control units. There is a risk of injury and electric shock.
- Keep all electrical components away from liquids.
- Do not use any damaged cable or electrical parts, as it may cause electric shock and injury.
- Do not open any of the components (riser control box, legs, or motor). There is a risk of electric shock.
- Do not attempt to open or repair the components. Use only manufacturer supplied components and cables.
- This is a heavy product and not suitable for frequent moves. It requires at least two people when moving it.
- Please handle with care and avoid any injury.
- When the table is risen or descended, there is a slight jitter, which is a normal phenomenon from the transmission structure because of the sudden activation and does not affect its service life.



USER MANUAL

How To Use

1. Position Reset

- Unplug the power cable and motor cable and re-plug in.
- Press and hold the "O" button for around 3 seconds until the controller " --- " and then release the button.
- After that the desk will automatically drop to the lowest height, rise to the maximum height, which means the initial setting was successful.

2. Raising and Lowering the Desk

- Press the "△" button to lift the desk, and press the "▽" button to descend the desk.
- Press the "△" button for 3 seconds until the screen flashes and release the button; then the desk will automatically rise to the highest position, and press any button to stop halfway.
- Press the "▽" button for 3 seconds until the screen flashes and release the button; then the desk will automatically descend to the sitting position, and press any button to stop halfway.

3. Height Memory Setting

- Adjust the desk height to your desired standing position.
- Press and hold the "H" or "M" button; when the screen flashes, it means the height memory setting is successful.

To go to standing position memory height:

Press the "H" or "M" button, and then release the button, and the desk will automatically rises or descends to the memory height position. Press any button to stop halfway.

4. Sedentary Reminder

To turn on the reminder setting:

- Press the "T" button to turn on the sedentary reminder, then press it again to change between "r30/ r45/ r60", representing 30 minutes/45 minutes/60 minutes.
- Choose one of the time options "30/45/60" according to your own needs by pressing "T" button. After choosing, you don't need to press any other buttons, and then wait until the screen is turned off, which mean the initial setting is successfully.
- When the selected reminder time is reached, the display will flash "Chr" for 1 minute.
- After 3 consecutive reminders at 5 minutes interval and the table is not used, the screen will automatically turn off.

To turn off the reminder setting:

- Press the "T" button; when the screen displays the digital height, which means the reminder is turned off.
- In the sedentary reminder state, you can press the "△" or "▽" button to adjust the height, and the sedentary reminder will restart the countdown.

Screw List

Part List

PAGE

1

2

3

4


5

6

7



INDONESIA



WS414

Work Station

ADJUSTABLE RISING DESK

Catatan:

- Input: AC100~240V / 50-60Hz
- Suhu Pengoperasian: 0~40°C
- Sebelum pemasangan WS414 selesai, silakan tekan tombol "O" sebelum menggunakannya (lihat No.1 Pengaturan Ulang Posisi).
- Sebelum digunakan, harap periksa apakah semua kabel sudah tersambung sepenuhnya.
- Jauhkan anak-anak dari meja angkat dan unit kontrol yang dapat disusutkan. Ada risiko cedera dan sengatan listrik.
- Jauhkan semua komponen listrik dari cairan.
- Jangan gunakan kabel atau komponen listrik yang rusak karena dapat menyebabkan sengatan listrik dan cedera.
- Jangan membuka komponen apa pun (kotak kontrol, kaki, atau motor). Ada risiko sengatan listrik.
- Jangan mencoba membuka atau memperbaiki komponen. Gunakan hanya komponen dan kabel yang disediakan pabrik.
- Meja ini adalah produk yang berat dan tidak cocok untuk sering berpindah-pindah. Membutuhkan setidaknya dua orang saat memindahkannya.
- Harap jangan dengan baik-nail dan hindari cedera.
- Saat meja dinaikkan atau diturunkan, terdapat sedikit getaran, yang merupakan fenomena normal pada struktur transmisi karena pengaktifan mendadak dan tidak mempengaruhi masa pakainya.



PANDUAN PENGGUNA

Cara Penggunaan

1. Pengaturan Ulang Posisi

- Cabut kabel daya dan kabel motor lalu colokkan kembali.
- Tekan dan tahan tombol "O" selama sekitar 3 detik sampai kontroler " --- " kemudian lepaskan tombol.
- Setelah itu otomatis meja akan turun ke ketinggian terendah, naik ke ketinggian maksimum yang berarti pengaturan awal berhasil.

2. Menaikkan atau Menurunkan Meja

- Tekan tombol "△" untuk menaikkan meja, dan tekan tombol "▽" untuk menurunkan meja.
- Tekan tombol "△" selama 3 detik hingga layar berkedip dan lepaskan tombol; maka meja akan otomatis naik ke posisi tertinggi, dan tekan tombol apapun untuk memberhentikannya.
- Tekan tombol "▽" selama 3 detik hingga layar berkedip dan lepaskan tombol; maka meja akan otomatis turun ke posisi duduk, dan tekan tombol apapun untuk memberhentikannya.

3. Pengaturan Memori Ketinggian

- Sesuaikan ketinggian meja ke posisi yang Anda inginkan.
- Tekan dan tahan tombol "H" atau "M"; bila layar berkedip berarti pengaturan ketinggian memori berhasil.

Untuk menuju ke posisi berdiri tinggi memori:

Tekan tombol "H" atau "M", lalu lepaskan tombol maka meja secara otomatis naik atau turun ke memori posisi ketinggian, lalu tekan tombol apapun memberhentikannya.

4. Peningkat Berdiri

Untuk mengaktifkan pengaturan peningkat:

- Tekan tombol "T" untuk mengaktifkan peningkat berdiri, lalu tekan lagi untuk mengubah antara "r30/ r45/ r60", yang merupakan 30 menit/45 menit/60 menit.
- Pilih salah satu opsi waktu "30/45/60" sesuai kebutuhan Anda dengan menekan tombol "T". Setelah memilih, Anda tidak perlu menekan tombol apapun, lalu tunggu hingga layar mati, yang berarti pengaturan berhasil disimpan.
- Ketika waktu hitung mundur habis, layar akan menampilkan "Chr" selama 1 menit.
- Setelah layar menampilkan peningkat selama 3 kali berturut-turut dengan interval 5 menit dan meja tidak digunakan, layar akan mati secara otomatis.

Untuk mematikan pengaturan peningkat:

- Tekan tombol "T", saat layar menampilkan ketinggian digital, yang berarti peningkat dimatikan.
- Pada saat peningkat berdiri aktif, Anda dapat menekan tombol "△" atau "▽" untuk menyesuaikan ketinggian, dan hitungan mundur akan memulai kembali dari awal.

Daftar Baut

Daftar Baut