Mandis shop

Original		Rechange		Original		Rechange	
	Power		Power	INFOS	Infos	ANGLE INFO	Info / Angle
TTX	TTX	GOTO TEXT	Text / Goto		Left		Left
FAV	Fav	PC FAV MARKER	Fav / Marker / PC	OK	OK	OK	OK
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II		Right		Right
	Mute	DIMMER MUTE	Mute / Dimmer	MENU	Menu	HOME MENU	Menu / Home
	Play	SLOW	Play / Slow		Down		Down
	Pause	STEP-FREEZE	Pause / Step / Freeze	QUIT	Quit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	<<	TUNE-	<< / Tune-	+ VOL	Vol +	+ VOL	Vol +
	>>	TUNE+	>> / Tune+	REC	Rec	REC MODE	Rec / Rec Mode
SOS	Red / SOS	NETFLIX SEARCH	Red / Netflix / Search	+ CH	CH+	+ CH PAGE	CH+ / Page+
SOUS TITRES	Green / Sous	APP REPEAT	Green / APP / Repeat	VOL -	Vol -	VOL -	Vol -
SOUS TITRES	Green / Sous	EQ SUBTITLE	Subtitle / EQ		Stop	HOLD	Stop / Hold
ENREG	Yellow / Enreg	YouTube REPEAT A-B	Yellow / YouTube / Repeat	CH -	CH-	CH PAGE -	CH- / Page-
TIMER	Blue / Timer	Prime Video RANDOM	Blue / Prime Video / Random	1	1	TV 1	1
TIMER	Blue / Timer	TIMER SLEEP	Sleep / Timer	2	2	DVD 2	2
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--	3	3	CD-STB 3	3
	Up		Up	4	4	VIDEO 4	4

Original		Rechange	
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
TV/RADIO	TV / Radio	PROGRAM TV/ RADIO	TV/ Radio /
0	0	HDMI - SAT 0	0
⮌	Back	RETURN BACK	Back / Return

Original	Rechange