

MANUAL (ENGLISH) FUNCTION KEY 1. Power Button On/Off Pause/Play 4. LED Indicator 2. Volume Up/ Next Track Button 5. Micro USB Charging Slot 3. Volume Down/ Previous Track Button MANUAL KEY FUNCTIONS (1) POWER BUTTON ON/OFF PAUSE/PLAY 1. Hold the power button(1) about 3 seconds, turn on the power, and turn on the Bluetooth indication. Hold the power button about 3 seconds to turn the Bluetooth speaker turn off. 2. In music playing mode, short press this button for pause/play. 3. Short press to answer or hang up the phone, double click to reject or redial the call. 2	(2) Volume Up/Next Track In music playing mode, short press the button to change to the next song, long press the button for increasing the volume. (3) Volume Down/Previous Track In music playing mode, short press the button to change to the previous song, long press the button for decreasing the volume. (4) LED Indicator The red light means charging, after charging successfully, the indicator will be off. (5) Micro USB Charging Slot Charge the speaker by USB charging cable. PAIRING YOUR SPEAKER Using your smartphone or other device search Bluetooth pairing name "HELIO" to connect, the colorful LED light will blink quickly, then slowly and the prompt voice will remind the Bluetooth connected. HANDS FREE FUNCTION 1. In Bluetooth Mode, when there is an incoming call, the Helio speaker will report the telephone number. Short press "M" button to answer or hang up the phone; Double click to reject or redial the call. 2. If 2 speakers are synced when there is calling income, press one of speaker "M" to answer the phone. Only one speaker will play the audio. 3	CHARGING YOUR SPEAKER The HELIO comes with a built-in rechargeable battery. Before using the speaker for the first time, we recommend you charge the battery fully. Be sure to turn off the speaker before charging. Use the supplied micro USB cable to charge the speaker. Connect the included micro USB cable to a 5V USB power supply (not included) and the micro USB end into the speaker (2). The LED light (1) will illuminate red when the speaker is charging. The LED light will turn off once speaker is fully charged, at which point the speaker will be ready for use. When the battery is low, a warning sound will prompt. When this occurs, please charge your speaker. SECOND SPEAKER OPTION (NOT INCLUDED) 1. Ensure both speakers are turned off before pairing. 2. Ensure the speakers are not connected to any device before pairing. 3. Turn both speakers on simultaneously. 4. Press one of the speakers "M" button for 2 seconds to pair to each other. After the initial setup, these 2 speakers will pair automatically. 5. On your Bluetooth® enabled device, search the name "HELIO" from the list of available Bluetooth® devices. Once successfully paired you can play two speakers in series at the same time. 4	ONE YEAR WARRANTY Xtreme warrants its products for ONE YEAR against defects in manufacturing under regular consumer use with original receipt of retail purchase. We believe in our products and want to provide you with a replacement, if needed, but we have to know about the problem while the product is still under warranty. If you discover a defect covered by this warranty, please contact us about receiving a replacement. In order to use the products warranty the customer must provide proof of the retailers receipt. *Any customers outside of the U.S. will be responsible for shipping and handling charges if a replacement is required that is not due to a manufacturing defect. If there is not a manufacturing defect, shipping and handling will be applied. Xtreme's warranty is limited to our products only. Our warranty does not cover the replacement or repair cost of any third-party accessory, electronic device or personal property. For instructions about how to obtain warranty service for your product, please contact Customer Service at customerservice@xtremecables.com Package Contents: Bluetooth® TWS Speaker Micro USB Charging Cable Manual Specifications: Range: 30ft Frequency Response Range: 90Hz- 20kHz Speaker Output: 3W Charge Time: 3-4 Hours Play Time: 2-3 Hours Battery: 300mAh 5	XTREME® DIGITAL LIFESTYLE ACCESSORIES HELIO HAUT-PARLEUR BLUETOOTH® TRUE WIRELESS 855-999-8041 www.xtremecables.com
855-999-8041 www.xtremecables.com HELIO DIGITAL LIFESTYLE ACCESSORIES TRUE WIRELESS BLUETOOTH® SPEAKER	GARANTIE UN AN Nous croyons en nos produits et nous voulons vous fournir un remplacement, si nécessaire, mais nous devons connaître le problème alors que le produit est encore sous garantie. Si vous découvrez un défaut un remplacement, contactez-nous pour recevoir un remplacement. Pour utiliser la garantie des produits, le client doit fournir la preuve du reçu des détaillants. * Tous les clients situés en dehors des États-Unis seront responsables des frais d'expédition et de maintenance si un remplacement est nécessaire et n'est pas dû à un défaut de fabrication. S'il n'y a pas de défaut de fabrication, les frais d'expédition et de maintenance seront appliqués. La garantie de Xtreme est limitée à nos produits uniquement. Notre garantie ne couvre pas le coût de remplacement ou de réparation d'un accessoire tiers, d'un appareil électronique ou d'un bien personnel. Pour obtenir des instructions sur la façon d'obtenir un service de garantie pour votre produit, veuillez contacter le service à la clientèle au customerservice@xtremecables.com Contenu du Colis: Haut-Parleur Bluetooth® TWS Câble de Charge Micro USB Manuel Caractéristiques: Bluetooth 5.0 Game: 9m Sortie Haut-Parleur: 3W Temps de Charge: 3-4 Heures Batterie: 300mAh 5	CHARGER VOTRE HAUT-PARLEUR L'HELIO est livré avec une batterie rechargeable intégrée. Avant d'utiliser l'enceinte pour la première fois, nous vous recommandons de charger complètement la batterie. Assurez-vous d'éteindre le haut-parleur avant de le charger. Utilisez le câble micro USB fourni pour charger l'enceinte. Connectez le câble micro USB inclus à une alimentation USB 5V (non incluse) et l'enceinte micro USB dans le haut-parleur. La lumière LED s'allumera en rouge lorsque l'enceinte se recharge. La lumière LED s'éteint une fois que l'enceinte est complètement chargée, à quel point l'enceinte sera prête à être utilisée. Lorsque la batterie est faible, un son d'avertissement s'affiche. Lorsque cela se produit, veuillez charger votre haut-parleur. OPTION DEUXIÈME HAUT-PARLEUR (NON INCLUS). 1. Assurez-vous que les deux haut-parleurs sont éteints avant le couplage. 2. Assurez-vous que les haut-parleurs ne sont connectés à aucun appareil avant le couplage. 3. Allumez les deux enceintes simultanément. 4. Appuyez sur l'un des boutons "M" des enceintes pendant 2 secondes pour se couper. Après la configuration initiale, ces 2 enceintes se coupleront automatiquement. 5. Sur votre appareil compatible Bluetooth®, recherchez le nom «HELIO» dans la liste des appareils Bluetooth® disponibles. Une fois le couplage réussi, vous pouvez écouter deux enceintes en même temps. 4	(2) Augmentation du volume / Piste suivante En mode de lecture de musique, appuyez brièvement sur le bouton pour passer à la chanson suivante, appuyez longuement sur le bouton pour augmenter le volume. (3) Baisser le volume / Piste précédente En mode de lecture de musique, appuyez brièvement sur le bouton pour passer à la chanson précédente, appuyez longuement sur le bouton pour diminuer le volume. (4) Indicateur LED Le voyant rouge signifie que la charge est terminée, après une charge réussie, l'indicateur sera éteint. (5) Fente de chargement micro USB Chargez le haut-parleur par câble de chargement USB CONNEXION BLUETOOTH Utilisez un téléphone portable ou un autre appareil pour rechercher le nom d'appareil Bluetooth "HELIO" pour vous connecter, le voyant LED clignotera rapidement, la lumière LED colorée clignotera lentement et la voix rapide rappellera le Bluetooth connecté 1. En mode Bluetooth, lorsque l'il y a un appel entrant, le haut-parleur Helio signalera le numéro de téléphone. Appuyez brièvement sur le bouton «M» pour répondre ou raccrocher le téléphone; Double-cliquez pour rejeter ou recomposer l'appel. 2. Si 2 haut-parleurs sont synchronisés lorsqu'il y a un revenu d'appel, appuyez sur l'un des haut-parleurs «M» pour répondre au téléphone. Un seul haut-parleur jouera l'audio. 3. Appuyez brièvement pour répondre ou raccrocher le téléphone, double-cliquez pour rejeter ou recomposer l'appel. 2. En mode de lecture de musique, appuyez brièvement sur ce bouton pour mettre en pause / lire. 1. Maintenez le bouton d'alimentation (1) enfoncé pendant 3 secondes environ, mettez l'appareil sous tension et activez l'indication Bluetooth. Pendant la lecture, maintenez le bouton d'alimentation enfoncé pendant environ 3 secondes et les haut-parleurs Bluetooth s'éteignent. 2. En mode de lecture de musique, appuyez brièvement sur ce bouton pour mettre en pause / lire. 3. Appuyez brièvement pour répondre ou raccrocher le téléphone, double-cliquez pour rejeter ou recomposer l'appel. 2	MANUAL (FRANÇAIS) CLÉ DE FONCTION 1. Bouton d'alimentation marche / arrêt Pause / lecture 2. Bouton d'augmentation du volume / piste suivante 3. Bouton de réduction du volume / piste précédente 4. Indicateur LED 5. Emplacement de chargement micro USB

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator& your body.