

INDOOR DIGITAL TIMER 052-8814-2

Instructions:

Charge the Battery: Plug the timer into wall outlet for 10 minutes to charge internal battery. Note: You can then unplug the timer from the wall outlet and comfortably hold it in your hand to program the timer.

To Set the Current Time:

Press and hold the CLOCK button. At the same time, press the HOUR and MINUTE button as many times as necessary to advance the display to the correct time. Hold down the DAY button until the display shows the correct day. Note: If setting the current time during spring/summer press and hold the CLOCK button for 3-5 seconds to activate daylight savings time feature before setting the current time.

To Program the Timer:

1. Press the PROG button once to display the first ON/OFF setting "1 ON ---".
2. Press the MINUTE and HOUR buttons as necessary to set the ON time you want. To change from AM to PM toggle 12 times.
3. Press the DAY button as necessary to choose the day or group of days you want for the time setting.
4. Press the PROG button again to display the second ON/OFF setting "1 OFF ---".
5. Repeat the procedure to create the OFF setting.

Repeat Steps 1 through 5 for additional ON/OFF settings. Press the CLOCK button to exit program mode.

To connect/operate the timer:

Plug device in to the timer and turn the device on. Plug timer into wall outlet.

NOMA[®]

INDOOR DIGITAL TIMER MINUTERIE NUMÉRIQUE D'INTÉRIEUR 052-8867-6 and 052-8814-2

Instructions

Charge the Battery:

Plug the timer into wall outlet for 10 minutes to charge internal battery. Note: You can then unplug the timer from the wall outlet and comfortably hold it in your hand to program the timer.

To Set the Current Time:

Press and hold the CLOCK button. At the same time, press the HOUR and MINUTE button as many times as necessary to advance the display to the correct time. Hold down the DAY button until the display shows the correct day. Note: If setting the current time during spring/summer press and hold the CLOCK button for 3-5 seconds to activate daylight savings time feature before setting the current time.

To Program the Timer:

1. Press the PROG button once to display the first ON/OFF setting "1 ON ---".
 2. Press the MINUTE and HOUR buttons as necessary to set the ON time you want. To change from AM to PM toggle 12 times.
 3. Press the DAY button as necessary to choose the day or group of days you want for the time setting.
 4. Press the PROG button again to display the second ON/OFF setting "1 OFF ---".
 5. Repeat the procedure to create the OFF setting.
- Repeat Steps 1 through 5 for additional ON/OFF settings. Press the CLOCK button to exit program setting mode.

Review ON/OFF Settings:

It is important to review all 20 settings, even if you only used a few, to make sure there are no extra, unintended settings. Press the PROG button (hold down to scroll) until the display cycles through all 20 ON/OFF pairs. Stop on any setting you want to remove or change.

To Revise a Setting:

Press the PROG button (hold down to scroll) until the display shows the setting you want. Press the HOUR, MINUTE and WEEK buttons as necessary to revise the displayed ON/OFF time and day(s).

To Remove or Restore a Setting:

Press the PROG button (hold down to scroll) until the display shows the setting you want to remove or restore. Press the RST-ROL button. If removing, the display will replace the setting with dashes. If restoring, the display will show the previous setting.

To Connect/Operate the Timer:

Plug device in to the timer and turn the device on. Plug timer into wall outlet.

To Override the Timer:

Press the ON-OFF button as necessary to display:

- "ON" - the plugged-in device is switched on permanently.
- "OFF" - the plugged-in device is switched off permanently.
- "AUTO" - the plugged-in device follows your programmed timer settings.

Daylight Savings Time Feature:

Press and hold the CLOCK-DST for 3-5 seconds to advance the time of day one hour for daylight savings time. "+1h" will appear on the display. Press and hold the CLOCK-DST button again to set the time back one hour and "DST" will disappear.

125 V AC / 60 Hz

15 A / 1875 W resistive • résistive

10 A / 1250 W tungsten • tungstène

8 A ballast • ballast

Random Setting Security Feature:

Press the CLOCK button once. Then press and hold the HOUR-RND button for 3-5 seconds. "RND" will appear on the display. The random setting function will turn the plugged-in device on and off at random. The device will turn on 2-30 minutes after the preset ON time and turn OFF 2-30 minutes after the preset OFF time. Preset ON/OFF time must be greater than 10 minutes. The random function will only operate during the programmed on/off events. To cancel the random function, press and hold the HOUR-RND button again for 3-5 seconds and the "RND" will disappear from the display.

Things to know about ON/OFF timers:

- The display panel automatically returns to time of day if you don't press any buttons for 15 seconds.
- If you are interrupted before completing a setting, simply press the PROG button until you reach the setting where you left off.

3-year Limited Warranty:

This Noma® product carries a three (3) year warranty against defects in workmanship and materials. Trileaf Distribution agrees to replace the defective product free of charge within the stated warranty period, when returned by the original purchaser with proof of purchase. This product is not guaranteed against wear or breakage due to misuse and/or abuse.

Instructions

Chargez la batterie :

Brancher la minuterie dans une prise murale pendant 10 minutes pour charger la batterie interne. Remarque : Vous pouvez alors débrancher la minuterie de la prise murale et la tenir confortablement dans la main pour la programmer.

Pour régler l'heure actuelle :

Appuyez et tenez le bouton CLOCK. En même temps, appuyez sur le bouton HOUR (HEURE) et MINUTE autant de fois que nécessaire pour faire avancer l'affichage à la bonne heure. Gardez le bouton DAY (jour) enfoncé jusqu'à ce que l'affichage montre la bonne journée.

Remarque: En régler l'heure actuelle pendant le printemps ou l'été, appuyez et gardez le bouton HOUR pendant 3-5 secondes pour activer la fonction d'heure d'été avant de régler l'heure actuelle.

Pour programmer la minuterie :

1. Appuyez sur le bouton PROG une fois pour afficher le premier réglage ON/OFF « 1 ON --- ».
2. Appuyez sur les boutons MINUTE et HOUR au besoin pour régler l'heure de marche ON que vous désirez. Pour changer de AM à PM basculez 12 fois.
3. Appuyez sur le bouton DAY au besoin pour choisir le jour ou le groupe de jours que vous désirez pour le réglage de l'heure.
4. Appuyez sur le bouton PROG à nouveau pour afficher le deuxième réglage ON/OFF « 1 OFF --- ».
5. Répétez la procédure pour créer le réglage OFF (arrêt).

Répétez les étapes 1 et 5 pour d'autres réglages ON/OFF (marche/arrêt).

Appuyez sur le bouton CLOCK pour sortir du mode pour régler le programme.



MINUTERIE NUMÉRIQUE D'INTÉRIEUR, 052-8867-6 and 052-8814-2

Instructions

Chargez la batterie : Branchez la minuterie dans une prise murale pendant 10 minutes pour charger la batterie interne. Remarque : Vous pouvez alors débrancher la minuterie de la prise murale et la tenir confortablement dans la main pour la programmer.

Pour régler l'heure actuelle :

Appuyez et tenez le bouton CLOCK. En même temps, appuyez sur le bouton HOUR (HEURE) et MINUTE autant de fois que nécessaire pour faire avancer l'affichage à la bonne heure. Gardez le bouton DAY (jour) enfoncé jusqu'à ce que l'affichage montre la bonne journée.

Pour programmer la minuterie :

1. Appuyez sur le bouton PROG une fois pour afficher le premier réglage ON/OFF « 1 ON --- ».
2. Appuyez sur les boutons MINUTE et HOUR au besoin pour régler l'heure de marche ON que vous désirez. Pour changer de AM à PM basculez 12 fois.
3. Appuyez sur le bouton DAY au besoin pour choisir le jour ou le groupe de jours que vous désirez pour le réglage de l'heure.
4. Appuyez sur le bouton PROG à nouveau pour afficher le deuxième réglage ON/OFF « 1 OFF --- ».
5. Répétez la procédure pour créer le réglage OFF (arrêt).