Manuals+

☰

Contents [hide]

Sing-e 2A9NQ-MULTI-SPEAKER Multi-Mode Speaker

Specifications

- Power Source: Built-in rechargeable battery
- Input: DC 5V
- Supported Formats: MP3, WAV
- Connectivity: Bluetooth, TF Card, USB, AUX
- Microphone Input: Yes

Product Usage Instructions

Power On/Off

To power on the speaker, press the power button. To power off the speaker, press and hold the power button.

Battery Charging

Use the provided DC 5V cable to connect to the built-in battery charging jack. The LED indicator will light up when charging.

MIC Input

Insert the microphone into the designated input port to enjoy singing.

Mode Selection

Tap the control panel to switch between BT (Bluetooth), TF CARD, USB, LINE IN, and FM modes. Press and hold the control panel to switch lighting modes.

Music Playback

In BT, TF card, and USB modes, use short presses to play/pause music. In FM mode, short press to search for radio stations. Play next/previous music or stations accordingly.

AUX Connection

Use the AUX input to connect external devices such as a PC, MP3 players, phones, or CDs.

BT Connection

To connect via Bluetooth, power on the speaker or press the MODE key to enter BT mode. Pair your mobile device by searching for the BT device named "SY-SPEAKER". Once paired, it will automatically connect on subsequent use within 10 seconds.

Note on Charging

This product does not support charging while playing. Ensure to charge fully before use and charge until the indicator is off before resuming use.

Function, Operation, and Features

1. **ON/OFF**
   Speaker power off / speaker power on.
2. **DC 5V**
   Built-in battery charging jack. When the DC 5V cable is inserted, the LED lights up.
3. **MIC**
   Insert the microphone into the input port and enjoy singing.
4. **M/** ☼ Tap to switch between BT, TF CARD, USB, LINE IN, and FM.
   Press and hold the control light switch and the lighting mode.
5. ▶▶**I/V+**Play the next music in BT, TF card, and USB modes. Play the next station in FM mode.
6. ▶**II/TWS** Short press music to play/pause, short-press FM mode to automatically search for radio stations. Double-click the P/P button on the slave speaker to disconnect from the secondary speaker. Hold down the P/P key on the main speaker

to disconnect the secondary speaker from the phone.

7. **I◀◀/V−** Play the previous music in BT, TF card, and USB modes. Previous stations are played in FM mode.

8. **AUX**

   AUXIN can connect PC, MP3, Phone, CD, etc.

9. **USB**

   Support USB interface, can play MP3 and WAV format music.

10. **TF**

    Support TF card, can play MP3 and WAV format music.

11. **BT connection**

- Power on the product or press the MODE key to enter the BT mode.
- Open the mobile device (mobile phone, etc.) in BT mode, search for the BT device, and the project pairing name (SY-SPEAKER) appears.
- After the device is paired for the first time, it will automatically connect for the second time within 10 seconds. (Only one BT device can be connected to each speaker.)

Please note:

This product does not support charging while playing. When the power is too low, please turn off the device and charge it in time, until the charging indicator is off, you can turn it on and continue to use

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, under Part 15 of the FCC Rules. These limits are designed to provide

reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used according to the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet the general RF exposure requirements. The device can be used in portable exposure.e

Frequently Asked Questions

- **Q: Can I charge the speaker while using it?**
  A: No, this product does not support charging while playing. Please charge fully before use.
- **Q: How do I disconnect secondary speakers?**
  A: Double click the P/P button on the slave speaker to disconnect from the secondary speaker. Hold down the P/P key on the main speaker to disconnect the secondary speaker from the phone.

Documents / Resources

[Sing-e 2A9NQ-MULTI-SPEAKER Multi Mode Speaker](#) [[pdf](#)] Instruction Manual

2A9NQ-MULTI-SPEAKER, 2A9NQMULTISPEAKER, 2A9NQ-MULTI-SPEAKER Multi Mode Speaker, 2A9NQ-MULTI-SPEAKER, Multi Mode Speaker, Mode Speaker

References

- [User Manual](#)

📁 SinG-e

🏷 2A9NQ-MULTI-SPEAKER, 2A9NQ-MULTI-SPEAKER Multi Mode Speaker, 2A9NQMULTISPEAKER, Mode Speaker, Multi Mode Speaker, SinG-e

—Previous Post
[SinG-e ZQS6165 Portable Bluetooth Speaker User Manual](#)

—

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube