

# Installation, Operation, and Maintenance


## Upflow/Horizontal and Dedicated Downflow Gas-Fired, Direct/Non-Direct Vent, Single Stage Condensing Furnaces with High Efficiency Motor

### Upflow, Convertible to Horizontal Right or Horizontal Left

A951X040BU3SAC  
A951X060BU4SAC  
A951X080BU4SAC  
A951X080CU5SAC  
A951X100CU5SAC  
A951X120DU5SAC

### Downflow Only

A951X040BD3SAC  
A951X060BD3SAC  
A951X080BD4SAC  
A951X100CD5SAC  
A951X120DD5SAC



*Note: Graphics in this document are for representation only. Actual model may differ in appearance.*



#### **⚠ WARNING**

##### **FIRE HAZARD!**

Failure to follow this Warning could result in property damage, severe personal injury, or death.

This Warning applies to installations with a flammable refrigeration system. The furnace must be powered except for service. The furnace shall be installed and connected according to installation instructions and wiring diagrams that are provided with the evaporator coil.

#### **⚠ CAUTION**

##### **COIL REQUIREMENT!**

Failure to follow this Caution could result in property damage or personal injury. 4GXC\* and 4MXC\* coils installed on upflow furnaces in vertical, horizontal left, or horizontal right orientations without a factory installed metal drain pan shield must use a MAY\*FERCOLKITAA kit. Coils installed on upflow furnaces must have drain pans that are suitable for 400° F (205° C) or have a metal drain pan shield. Downflow furnaces do not require a metal drain pan shield or the use of the MAY\*FERCOLKITAA kit.

### **⚠ SAFETY WARNING**

Only qualified personnel should install and service the equipment. The installation, starting up, and servicing of heating, ventilating, and air-conditioning equipment can be hazardous and requires specific knowledge and training. Improperly installed, adjusted or altered equipment by an unqualified person could result in death or serious injury. When working on the equipment, observe all precautions in the literature and on the tags, stickers, and labels that are attached to the equipment.

# SAFETY SECTION — FURNACES

**Important:** — This document pack contains a wiring diagram and service information. This is customer property and is to remain with this unit. Please return to service information pack upon completion of work.

## ⚠ WARNING

### FIRE OR EXPLOSION HAZARD!

Failure to follow safety warnings exactly could result in a fire or explosion causing property damage, personal injury or loss of life.

— Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance. — WHAT TO DO IF YOU SMELL GAS

- Do not try to light any appliance.
  - Do not touch any electrical switch; do not use any phone in your building.
  - Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
  - If you cannot reach your gas supplier, call the fire department.
- Installation and service must be performed by a qualified installer, service agency, or the gas supplier.

## ⚠ WARNING

### EXPLOSION HAZARD!

Failure to follow this Warning could result in property damage, personal injury or death. Install a gas detecting warning device in case of a gas leak. **NOTE:** The manufacturer of your furnace does not test any detectors and makes no representations regarding any brand or type of detector.

## ⚠ WARNING

### FIRE OR EXPLOSION HAZARD!

Failure to follow the safety warnings exactly could result in serious injury, death, or property damage.

Never test for gas leaks with an open flame. Use a commercially available soap solution made specifically for the detection of leaks to check all connections. A fire or explosion may result causing property damage, personal injury, or loss of life.

## ⚠ WARNING

### ELECTRICAL SHOCK, FIRE, OR EXPLOSION HAZARD!

Failure to follow this Warning could result in dangerous operation, property damage, severe personal injury, or death.

Improper servicing could result in dangerous operation, property damage, severe personal injury, or death.

- Before servicing, disconnect all electrical power to furnace.
- When servicing controls, label all wires prior to disconnection. Reconnect wires correctly.
- Verify proper operation after servicing.

## ⚠ WARNING

### CARBON MONOXIDE POISONING HAZARD!

Failure to follow this Warning could result in property damage, severe personal injury, or death.

To ensure furnace is vented properly, do not replace factory supplied venting components with field fabricated parts. Fabricating parts can result in damaged vents and components allowing carbon monoxide to escape the venting system.

## ⚠ WARNING

### CARBON MONOXIDE HAZARD!

Failure to follow this Warning could result in property damage, severe personal injury, or death.

Do not attempt to change the venting system. Follow the installation and operation instructions for the venting system.

## ⚠ WARNING

### FIRE HAZARD!

Failure to follow this Warning could result in property damage, severe personal injury, or death.

Do not install the furnace directly on carpeting, tile or other combustible material other than wood flooring. For vertical downflow applications, subbase (BAYBASE205) must be used between the furnace and combustible flooring. When the downflow furnace is installed vertically with a cased coil, a subbase is not required.

**⚠ WARNING****WARNING!**

This product can expose you to chemicals including lead, which are known to the State of California to cause cancer and birth defects or other reproductive harm.

For more information go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).

**⚠ WARNING****EXPLOSION HAZARD!**

Failure to follow this Warning could result in property damage, severe personal injury, or death.

Propane gas is heavier than air and may collect in any low areas or confined spaces. In addition, odorant fade may make the gas undetectable except with a warning device. If the gas furnace is installed in a basement, an excavated area or a confined space, it is strongly recommended to contact a gas supplier to install a gas detecting warning device in case of leak. The manufacturer of your furnace does not test any detectors and makes no representations regarding any brand or type of detector.

**⚠ WARNING****ELECTRICAL SHOCK HAZARD!**

Failure to follow this Warning could result in property damage, severe personal injury, or death.

Do not bypass the door switch or panel loop by any permanent means.

**⚠ WARNING****ELECTRICAL SHOCK HAZARD!**

Failure to follow this Warning could result in property damage, severe personal injury, or death.

Do not touch any components other than the Menu and Option buttons on the IFC when setting up the system or during fault code recovery.

**⚠ WARNING****FIRE OR EXPLOSION HAZARD!**

Failure to follow this Warning could result in property damage, severe personal injury, or death.

Do **NOT** attempt to manually light the furnace.

**⚠ WARNING****CARBON MONOXIDE POISONING HAZARD!**

Failure to follow this Warning could result in property damage, severe personal injury, or death.

Follow the service and/or periodic maintenance instructions for the Furnace and venting system.

**⚠ WARNING****CARBON MONOXIDE POISONING HAZARD!**

Failure to follow this Warning could result in serious personal injury or death.

Make sure that the blower door is in place and not ajar. Dangerous fumes could escape an improperly secured door.

**⚠ WARNING****ELECTRICAL SHOCK HAZARD!**

Failure to follow this Warning could result in property damage, severe personal injury, or death.

Disconnect power to the unit before removing the blower door. Allow a minimum of 10 seconds for IFC power supply to discharge to 0 volts.

**⚠ WARNING****SAFETY HAZARD!**

Failure to follow this Warning could result in property damage, severe personal injury, or death.

These furnaces are not approved or intended for installation in trailers or recreational vehicles. Installation in manufactured (mobile) housing is only approved with BAYMFGH Kit.

**⚠ WARNING****EXPLOSION HAZARD!**

Failure to follow this Warning could result in property damage, severe personal injury, or death.

In the event that electrical, fuel, or mechanical failures occur, shut gas supply off at the manual gas valve located on the supply gas piping coming into the furnace before turning off the electrical power to the furnace. Contact the service agency designated by your dealer.

**⚠ WARNING**

**EXPLOSION HAZARD!**

Failure to follow this Warning could result in property damage, serious personal injury, or death.

Do not store combustible materials, gasoline, or other flammable vapors or liquids near the unit.

**⚠ WARNING**

**SAFETY HAZARD!**

Failure to follow this Warning could result in property damage, severe personal injury, or death.

Do not use semi-rigid metallic gas connectors (flexible gas lines) within the furnace cabinet.

**⚠ WARNING**

**INSTALLATION WARNING – HIGH VOLTAGE MOVING PARTS!**

Failure to follow this Warning could result in property damage, severe personal injury, or death.

Bodily injury can result from high voltage electrical components, fast moving fans, and combustible gas. For protection from these inherent hazards during installation and servicing, the main gas valve must be turned off and the electrical supply must be disconnected. If operating checks must be performed with the unit operating, it is the technician's responsibility to recognize these hazards and proceed safely.

**⚠ WARNING**

**SAFETY HAZARD!**

Failure to follow this Warning could result in property damage, severe personal injury, or death.

Do not install the filter in the return duct directly above the furnace in horizontal applications. Install the filter remotely.

**⚠ WARNING**

**SAFETY HAZARD!**

Failure to follow this Warning could result in property damage, severe personal injury, or death.

Turn the power to the furnace off before servicing filters to avoid contact with moving parts.

**⚠ WARNING**

**CARBON MONOXIDE HAZARD!**

Failure to follow this Warning could result in property damage, severe personal injury, or death.

Furnace venting into an unlined masonry chimney or concrete chimney is prohibited.

**⚠ WARNING**

**CARBON MONOXIDE HAZARD!**

Failure to follow this Warning could result in property damage, severe personal injury, or death.

The chimney liner must be thoroughly inspected to insure no cracks or other potential areas for flue gas leaks are present in the liner. Liner leaks will result in early deterioration of the chimney.

**⚠ WARNING**

**SHOCK HAZARD!**

Failure to follow this Warning could result in property damage, severe personal injury, or death.

If a disconnect switch is present, it must always be locked in the open position before servicing the unit.

**⚠ WARNING**

**ELECTRICAL SHOCK HAZARD!**

Failure to follow this Warning could result in an electrical shock, fire, injury or death.

Ensure cabinet has an uninterrupted or unbroken ground in accordance with National Electrical Code, ANSI/ NFPA 70 – 'latest edition' and Canadian Electrical Code, CSA C22.1 or local codes to minimize personal injury if an electrical fault should occur.

**⚠ WARNING**

**OVERHEATING AND EXPLOSION HAZARD!**

Failure to follow this Warning could result in property damage, personal injury or death.

Should overheating occur, or the gas supply fail to shut off, shut off the gas valve to the unit before shutting off the electrical supply.



**⚠ CAUTION****IMPROPER VOLTAGE CONNECTION!**

Failure to follow this Caution could result in property damage.

Do NOT connect the furnace line voltage to a GFCI protected circuit.

**⚠ CAUTION****CORROSION WARNING!**

Failure to follow this Caution could result in property damage or personal injury.

Do not install the furnace in a corrosive or contaminated atmosphere.

**⚠ CAUTION****SAFETY HAZARD!**

Failure to follow this Caution could result in property damage or personal injury.

The vent for this appliance shall not terminate; (1) Over public walkways; or (2) Near soffit vents or crawl space vents or other areas where condensate or vapor could create a nuisance or hazard or cause property damage; or (3) Where condensate vapor could cause damage or could be detrimental to the operation of regulators, relief valves, or other equipment.

**⚠ CAUTION****SHARP EDGE HAZARD!**

Failure to follow this Caution could result in property damage or personal injury.

Be careful of sharp edges on equipment or any cuts made on sheet metal while installing or servicing.

**⚠ CAUTION****BACKUP WRENCH REQUIRED!**

Failure to follow this Caution could result in property damage or personal injury.

Use a backup wrench on the gas valve when installing gas piping to prevent damage to the gas valve and manifold assembly.

**⚠ CAUTION****FREEZE CAUTION!**

Failure to follow this Caution could result in property damage or personal injury.

If complete furnace shutdown is done during the cold weather months, provisions must be taken to prevent freeze-up of all water pipes and water receptacles.

**⚠ CAUTION****FREEZE CAUTION!**

Failure to follow this Caution could result in property damage or personal injury.

When the vent pipe is exposed to temperatures below freezing, i.e., when it passes through unheated spaces, etc., the pipe must be insulated with 1/2 inch (12.7 mm) thick Armaflex-type insulation or equal. If the space is heated sufficiently to prevent freezing, then the insulation would not be required. If domestic water pipes are not protected from freezing then the space meets the condition of a heated space.

**⚠ CAUTION****FREEZE CAUTION!**

Failure to follow this Caution could result in property damage or personal injury.

Whenever your house is to be vacant, arrange to have someone inspect your house for proper temperature. This is very important during freezing weather. If for any reason your furnace should fail to operate damage could result, such as frozen water pipes.

**⚠ CAUTION****FREEZE CAUTION!**

Failure to follow this Caution could result in property damage or personal injury.

Caution should be taken to prevent drains from freezing or causing slippery conditions. Excessive draining of condensate may cause saturated ground conditions that may result in damage to plants.

**⚠ CAUTION****IGNITION FUNCTION!**

Failure to follow this Caution may result in poor ignition characteristics.

Maintain manifold pressure in high altitude installations.

**⚠ CAUTION****WATER DAMAGE!**

Failure to follow this Caution could result in property damage or personal injury.

It is recommended that an external overflow drain can be installed in all applications over a finished ceiling to prevent property damage or personal injury from leaking condensate.

**⚠ CAUTION**

**HOT SURFACE!**

Failure to follow this Caution could result in personal injury.

Do NOT touch igniter. It is extremely hot.

**⚠ CAUTION**

**FURNACE SERVICE CAUTION!**

Failure to follow this Caution could result in property damage or personal injury.

Label all wires prior to disconnection when servicing controls. Verify proper operation after servicing. Wiring errors can cause improper and dangerous operation.

**⚠ CAUTION**

**WIRING INFORMATION!**

Failure to follow this Caution could result in property damage or personal injury.

The integrated furnace control is polarity sensitive. The hot leg of the 120 VAC power must be connected to the BLACK field lead.

**⚠ WARNING**

**CARBON MONOXIDE POISONING HAZARD!**

Failure to follow the steps outlined below for each appliance connected to the venting system being placed into operation could result in carbon monoxide poisoning or death.

**The following steps shall be followed for each appliance connected to the venting system being placed into operation, while all other appliances connected to the venting system are not in operation:**

- Inspect the venting system for proper size and horizontal pitch as required in the National Fuel Gas Code, ANSI Z223.1/NFPA 54 or the CSA B149.1 *Natural Gas and Propane Installation Code* and these instructions. Determine there is no blockage or restriction, leakage, corrosion or other deficiencies which could cause an unsafe condition.
- Close all doors and windows between the space in which the appliance(s) connected to the venting system are located. Also close fireplace dampers.
- Turn on clothes dryers and any appliance not connected to the venting system. Turn on any exhaust fans such as range hoods so they are operating at maximum speed. Do not operate a summer exhaust fan.
- Follow the lighting instructions. Place the appliance being inspected into operation. Adjust the thermostat so appliance is operating continuously.
- Test for spillage from draft hood equipped appliances at the draft hood relief opening after 5 minutes of main burner operation. Use the flame of a match or candle.
- If improper venting is observed during any of the above tests, the venting system must be corrected in accordance with the National Fuel Gas Code, ANSI Z221.1/NFPA 54 and/or CSA B149.1 *Natural Gas and Propane Installation Code*.
- After it has been determined that each appliance connected to the venting system properly vents when tested, return all doors, windows, exhaust fans, etc. to their previous condition of use.

**⚠ CAUTION****VENTING REQUIREMENT!**

Failure to follow this Caution could result in property damage or personal injury.

For condensing furnaces, Do NOT run vent through chimney for wood burning or oil Furnaces or incinerators. If remaining free area between single wall flue pipe and masonry chimney is to be used for another gas appliance, venting area must be sufficient to vent that appliance and that appliance must be connected to chimney with separate entry openings.

**IMPORTANT** – *The single wall flue pipe joints must be sealed. The 90° elbow connection to vertical pipe must be sealed to prevent condensate leakage to base of masonry chimney.*

**⚠ CAUTION****VENTING REQUIREMENT!**

Failure to follow this Caution could result in property damage or personal injury.

Condensing furnaces may be vented through UNUSED chimneys. Do NOT run vent through chimney for wood burning or oil Furnaces or incinerators or any other gas appliance.

**IMPORTANT** – *The single wall flue pipe joints must be sealed. The 90° elbow connection to vertical pipe must be sealed to prevent condensate leakage to base of masonry chimney.*

**⚠ CAUTION****EQUIPMENT DAMAGE!**

UV light exposure can cause the plastic blower material to deteriorate which could lead to Blower Housing Damage.

For units containing a plastic Blower Housing, Do NOT install third party Ultra-Violet Air Cleaners where the Blower Housing can be exposed to UV light.

For more information, visit [www.trane.com](http://www.trane.com) and [www.americanstandardair.com](http://www.americanstandardair.com) or contact your installing dealer.  
6200 Troup Highway  
Tyler, TX 75707

**Coil Caution****⚠ CAUTION****COIL REQUIREMENT!!**

Failure to follow this Caution could result in property damage or personal injury.

4GXC\* and 4MXC\* coils installed on upflow furnaces in vertical, horizontal left, or horizontal right orientations without a factory installed metal drain pan shield must use a MAY\*FERCOLKITAA kit. Coils installed on upflow furnaces must have drain pans that are suitable for 400° F (205° C) or have a metal drain pan shield. Downflow furnaces do not require a metal drain pan shield or the use of the MAY\*FERCOLKITAA kit.

# Table of Contents

|                                         |    |                                        |     |
|-----------------------------------------|----|----------------------------------------|-----|
| Accessories.....                        | 9  | Twinning .....                         | 56  |
| Document Pack Contents.....             | 10 | Condensate Drain Instructions.....     | 57  |
| Part List.....                          | 10 | Vertical Applications.....             | 58  |
| Product Specifications.....             | 11 | Horizontal Applications.....           | 61  |
| Furnace Installation Guidelines .....   | 14 | General Start-up and Adjustment.....   | 62  |
| Safety Practices and Precautions.....   | 14 | Preliminary Inspections .....          | 62  |
| General Guidelines .....                | 14 | Lighting Instructions .....            | 62  |
| Locations and Clearances .....          | 15 | Control and Safety Switch              |     |
| Outline Drawing .....                   | 16 | Adjustment .....                       | 62  |
| Wiring Diagrams .....                   | 18 | Furnace Combustion Air Exhaust         |     |
| Airflow Tables .....                    | 19 | Options.....                           | 63  |
| CFM Versus Temperature Rise.....        | 22 | Upflow Position - Top Vented           |     |
| Furnace General Installation.....       | 23 | Combustion Air .....                   | 65  |
| Horizontal Installation in an Attic or  |    | Upflow Position - Left Side Vented     |     |
| Crawlspace .....                        | 23 | Combustion Air .....                   | 65  |
| Gas Piping .....                        | 24 | Horizontal Left Position - Top Vented  |     |
| Combustion and Input Check.....         | 26 | Combustion Air .....                   | 68  |
| Gas Valve Adjustment.....               | 27 | Furnace in Horizontal Left Position -  |     |
| High Altitude Derate.....               | 28 | Side Vented Combustion Air .....       | 71  |
| General Venting .....                   | 29 | Furnace in Horizontal Right Position - |     |
| Typical Venting .....                   | 30 | Top Vented Combustion Air.....         | 73  |
| Special Case Venting .....              | 31 | Furnace in Horizontal Right Position - |     |
| Vent Terminations .....                 | 32 | Left Vented Combustion Air.....        | 76  |
| Attaching Vent Piping .....             | 32 | Downflow Furnace - Top Vented          |     |
| Maximum Vent Length Table               |    | Combustion Air .....                   | 79  |
| A951X .....                             | 34 | Downflow Furnace - Left Side Vented    |     |
| Horizontal Venting .....                | 35 | Combustion Air .....                   | 80  |
| Horizontal Venting Through Wall         |    | Integrated Furnace Control Menu.....   | 83  |
| with Concentric Vent Kit .....          | 37 | Belly Band Location .....              | 85  |
| Venting Through The Roof.....           | 41 | Setting Airflow .....                  | 86  |
| Air for Combustion and Ventilation..... | 43 | Integrated Furnace Control Display     |     |
| Duct Connections.....                   | 45 | Codes .....                            | 87  |
| Return Air Filters .....                | 53 | Fault Code Recovery .....              | 88  |
| Electrical Connections .....            | 55 | Troubleshooting.....                   | 89  |
| Field Wiring .....                      | 55 | Sequence of Operation .....            | 106 |
|                                         |    | Periodic Servicing Requirements .....  | 107 |

# Accessories

**Table 1. Accessories**


| Model Number             | Description                                                          | Use with                                                                            |
|--------------------------|----------------------------------------------------------------------|-------------------------------------------------------------------------------------|
| MAYBFERCOLKITA           | Heat Shield Kit for B-width 4GXCB or 4MCXB Coils                     | B width 4GXCB or 4MCXB Coils when installed with Upflow Furnace in all orientations |
| MAYCFERCOLKITA           | Heat Shield Kit for C-width 4GXCC or 4MCXC Coils                     | C width 4GXCC or 4MCXC Coils when installed with Upflow Furnace in all orientations |
| MAYDFERCOLKITA           | Heat Shield Kit for D-width 4GXCD or 4MCXD Coils                     | D width 4GXCD or 4MCXD Coils when installed with Upflow Furnace in all orientations |
| BAYHANG                  | Horizontal Hanging Kit                                               | All Upflow Furnaces                                                                 |
| BAYVENT200B              | Sidewall Vent Termination Kit                                        | All Furnaces                                                                        |
| BAYVENTCN200B            | Sidewall Vent Termination Kit (Canada —CPVC)                         | All Furnaces                                                                        |
| BAYAIR30AVENTA           | Concentric Vent Kit                                                  | All Furnaces                                                                        |
| BAYAIR30CNVENT           | Concentric Vent Kit (Canada — CPVC)                                  | All Furnaces                                                                        |
| BAYREDUCE                | Reducing Coupling (CPVC)                                             | All Furnaces                                                                        |
| BAYLIFTB                 | Dual Return Kit (B size extension)                                   | B Cabinet Upflow Furnaces                                                           |
| BAYLIFTC                 | Dual Return Kit (C size extension)                                   | C Cabinet Upflow Furnaces                                                           |
| BAYLIFTD                 | Dual Return Kit (D size extension)                                   | D Cabinet Upflow Furnaces                                                           |
| BAYBASE205               | Downflow Subbase                                                     | All Downflow Furnaces                                                               |
| BAYFLTR203               | Horizontal Filter Kit                                                | B Cabinet Modular Blowers in Downflow/Horizontal                                    |
| BAYFLTR204               | Horizontal Filter Kit                                                | C Cabinet Modular Blowers in Downflow/Horizontal                                    |
| BAYFLTR205               | Horizontal Filter Kit                                                | D Cabinet Modular Blowers in Downflow/Horizontal                                    |
| BAYFLTR206               | Filter Access Door Kit (Downflow only)                               | All Downflow Furnaces                                                               |
| BAYSF1165 <sup>(a)</sup> | 1" SlimFit Box with MERV 4 Filter                                    | All Upflow Furnaces                                                                 |
| BAYSF1255*               | 2" SlimFit Filter Box with MERV4 Filter                              | All Furnaces <sup>(b)</sup>                                                         |
| FLRSF1255                | 1" Filter replacement (Qty 12)                                       | BAYSF1255BA                                                                         |
| BAYLPSS400*              | Propane Conversion Kit with Stainless Steel Burners                  | All Furnaces                                                                        |
| BAYBURNERSS              | All Stainless Steel Natural Gas Burners - Set of Six                 | All Upflow Furnaces - Special Case                                                  |
| BAYMFGH200B              | Manufactured/Mobile Housing Kit                                      | All Furnaces                                                                        |
| BAYCNDTRAP2A             | Inline Condensate Trap Kit used with Special Venting on 2" Vent Pipe | All Furnaces                                                                        |
| BAYCNDTRAP3A             | Inline Condensate Trap Kit used with Special Venting on 3" Vent Pipe | All Furnaces                                                                        |

<sup>(a)</sup> Airflow greater than 1600 CFM requires dual returns

<sup>(b)</sup> Designed to fit all S-Series furnaces with or without transition when used in side return. Fits B width cabinet without a transition in upflow/downflow applications.

## Document Pack Contents

| Item | Qty. | Description                                                                                                                                             |
|------|------|---------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1    | 1    | Condensate Drain Tube Assembly                                                                                                                          |
| 2    | 1    | Inlet Vent (2"- ADP01586 and 3"- ADP01587) <sup>(a)</sup>                                                                                               |
| 3    | 1    | Inlet Vent Gasket                                                                                                                                       |
| 4    | 1    | Outlet Vent Assembly                                                                                                                                    |
| 5    | 1    | Outlet Vent Gasket                                                                                                                                      |
| 6    | 6    | Screws                                                                                                                                                  |
| 7    | 1    | Condensate Trap Grommet                                                                                                                                 |
| 8    | 1    | Plug — Condensate/Gas                                                                                                                                   |
| 9    | 1    | Plug — Electrical                                                                                                                                       |
| 10   | 2    | Grommet — Condensate/Gas                                                                                                                                |
| 11   | 1    | Installation, Operation, and Maintenance                                                                                                                |
| 12   | 1    | Owner Guide                                                                                                                                             |
| 13   | 1    | Limited Warranty                                                                                                                                        |
| 14   | 1    | 2" to 3" Coupling — CPL01544 <sup>(b)</sup>                                                                                                             |
| 15   | 2    | Tinnerman Clips (not pictured)<br><b>Note:</b> Tinnerman Clips should be kept with unit and are used if the door panel flange hole(s) becomes stripped. |
| 16   | 2    | Brand labels <sup>(c)</sup>                                                                                                                             |



<sup>(a)</sup> 3" inlet vent supplied with A951X120DU and A951X120DD only. 2" inlet vent supplied with all other models.

<sup>(b)</sup> Supplied with A951X120DU and A951X120DD only

<sup>(c)</sup> Place appropriate brand label below the warning label on the front panel using stencil marks as guides.

## Part List

|                                                                                                                               |                                                                                                                                                          |                                                                                                                                                                |
|-------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>Igniter</li> <li>Flame Sensor</li> <li>In-shot Burner(s)</li> <li>Gas Valve</li> </ul> | <ul style="list-style-type: none"> <li>Inducer Assembly</li> <li>Blower Motor</li> <li>Blower Wheel</li> <li>IFC (Integrated Furnace Control)</li> </ul> | <ul style="list-style-type: none"> <li>Pressure Switch(es)</li> <li>Main Thermal Limit</li> <li>Roll-Out Switch(es)</li> <li>Reverse Air Switch(es)</li> </ul> |
|-------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|



# Product Specifications

| MODEL                                  | A951X040BU3SAC (a)        | A951X060BU4SAC (a)        | A951X080BU4SAC (a)        | A951X080CU5SAC (a)        |
|----------------------------------------|---------------------------|---------------------------|---------------------------|---------------------------|
| TYPE                                   | Upflow / Horizontal       | Upflow / Horizontal       | Upflow / Horizontal       | Upflow / Horizontal       |
| RATINGS (b)                            |                           |                           |                           |                           |
| Input BTUH                             | 40,000                    | 60,000                    | 80,000                    | 80,000                    |
| Capacity BTUH (ICS) (c) (d)            | 39,000                    | 58,300                    | 77,200                    | 77,800                    |
| Temp. Rise (Min.-Max.)                 | 30 - 60                   | 30 - 60                   | 45 - 75                   | 40 - 70                   |
| AFUE (%) (d)                           | 96.0                      | 96.0                      | 96.0                      | 96.0                      |
| Return Air Temp. (Min. - Max.)         | 45°F - 80°F               | 45°F - 80°F               | 45°F - 80°F               | 45°F - 80°F               |
| BLOWER DRIVE                           | DIRECT                    | DIRECT                    | DIRECT                    | DIRECT                    |
| Diameter — Width (In.)                 | 11 X 8                    | 11 X 8                    | 11 X 8                    | 11 X 10                   |
| No. Used                               | 1                         | 1                         | 1                         | 1                         |
| Speeds (No.) (e)                       | 9                         | 9                         | 9                         | 9                         |
| CFM vs. in. w.g.                       | See Fan Performance Table | See Fan Performance Table | See Fan Performance Table | See Fan Performance Table |
| Motor HP                               | 1/2                       | 3/4                       | 3/4                       | 1                         |
| RPM                                    | 1075                      | 1075                      | 1075                      | 1075                      |
| Volts/Ph/Hz                            | 120 / 1 / 60              | 120 / 1 / 60              | 120 / 1 / 60              | 120 / 1 / 60              |
| FLA                                    | 6.4                       | 8.4                       | 8.4                       | 10.6                      |
| COMBUSTION FAN — Type                  | Centrifugal               | Centrifugal               | Centrifugal               | Centrifugal               |
| Drive — No. Speeds                     | Direct - 1                | Direct - 1                | Direct - 1                | Direct - 1                |
| Motor HP — RPM                         | 3300                      | 3300                      | 3300                      | 3300                      |
| Volts/Ph/Hz                            | 120 / 1 / 60              | 120 / 1 / 60              | 120 / 1 / 60              | 120 / 1 / 60              |
| FLA                                    | 2.14                      | 2.14                      | 2.14                      | 0.66                      |
| FILTER — Furnished?                    | No                        | No                        | No                        | No                        |
| Type recommended                       | High Velocity             | High Velocity             | High Velocity             | High Velocity             |
| Hi Vel. (No.-Size-Thk.)                | 1 - 16 X 25 - 1 in.       | 1 - 16 X 25 - 1 in.       | 1 - 16 X 25 - 1 in.       | 1 - 20 X 25 - 1 in.       |
| VENT PIPE DIAMETER — Min (in.) (f) (g) | 2 Round                   | 2 Round                   | 2 Round                   | 2 Round                   |
| HEAT EXCHANGER                         |                           |                           |                           |                           |
| Type — Fired                           | 409 Stainless Steel       | 409 Stainless Steel       | 409 Stainless Steel       | 409 Stainless Steel       |
| — Unfired                              | 29-4C Stainless Steel     | 29-4C Stainless Steel     | 29-4C Stainless Steel     | 29-4C Stainless Steel     |
| Gauge (Fired)                          | 20                        | 20                        | 20                        | 20                        |
| ORIFICES — Main                        |                           |                           |                           |                           |
| Nat. Gas Qty. — Drill Size             | 2 - 45                    | 3 - 45                    | 4 - 45                    | 4 - 45                    |
| LP Gas Qty. — Drill Size               | 2 - 56                    | 3 - 56                    | 4 - 56                    | 4 - 56                    |
| GAS VALVE                              | Redundant - One Stage     | Redundant - One Stage     | Redundant - One Stage     | Redundant - One Stage     |
| PILOT SAFETY DEVICE                    |                           |                           |                           |                           |
| Type                                   | 120 V SiNi Igniter        | 120 V SiNi Igniter        | 120 V SiNi Igniter        | 120 V SiNi Igniter        |
| BURNERS — Type                         | Multiport Inshot          | Multiport Inshot          | Multiport Inshot          | Multiport Inshot          |
| Number                                 | 2                         | 3                         | 4                         | 4                         |
| POWER CONN. — V/Ph/Hz (h)              | 120 / 1 / 60              | 120 / 1 / 60              | 120 / 1 / 60              | 120 / 1 / 60              |
| Ampacity (In Amps)                     | 10.3                      | 12.8                      | 12.8                      | 14.1                      |
| Max. Overcurrent Protection (Amps)     | 15                        | 15                        | 15                        | 15                        |
| PIPE CONN. SIZE (in.)                  | 1/2                       | 1/2                       | 1/2                       | 1/2                       |

## Product Specifications

| MODEL                                  | A951X100CU5SAC (a)        | A951X120DU5SAC (a)        | A951X040BD3SAC (a)        | A951X060BD3SAC (a)        |
|----------------------------------------|---------------------------|---------------------------|---------------------------|---------------------------|
| TYPE                                   | Upflow / Horizontal       | Upflow / Horizontal       | Downflow                  | Downflow                  |
| RATINGS (b)                            |                           |                           |                           |                           |
| Input BTUH                             | 100,000                   | 120,000                   | 40,000                    | 60,000                    |
| Capacity BTUH (ICS) (c) (d)            | 97,400                    | 113,400                   | 38,900                    | 57,600                    |
| Temp. Rise (Min.-Max.)                 | 40 - 70                   | 40 - 70                   | 30 - 60                   | 35 - 65                   |
| AFUE (%) (d)                           | 95.0                      | 95.0                      | 96.0                      | 96.0                      |
| Return Air Temp. (Min. - Max.)         | 45°F - 80°F               | 45°F - 80°F               | 45°F - 80°F               | 45°F - 80°F               |
| BLOWER DRIVE                           | DIRECT                    | DIRECT                    | DIRECT                    | DIRECT                    |
| Diameter — Width (In.)                 | 11 X 10                   | 11 X 10                   | 11 X 8                    | 11 X 8                    |
| No. Used                               | 1                         | 1                         | 1                         | 1                         |
| Speeds (No.) (e)                       | 9                         | 9                         | 9                         | 9                         |
| CFM vs. in. w.g.                       | See Fan Performance Table | See Fan Performance Table | See Fan Performance Table | See Fan Performance Table |
| Motor HP                               | 1                         | 1                         | 1/2                       | 1/2                       |
| RPM                                    | 1075                      | 1075                      | 1075                      | 1075                      |
| Volts/Ph/Hz                            | 120 / 1 / 60              | 120 / 1 / 60              | 120 / 1 / 60              | 120 / 1 / 60              |
| FLA                                    | 10.6                      | 10.6                      | 6.4                       | 6.4                       |
| COMBUSTION FAN — Type                  | Centrifugal               | Centrifugal               | Centrifugal               | Centrifugal               |
| Drive — No. Speeds                     | Direct - 1                | Direct - 1                | Direct - 1                | Direct - 1                |
| Motor HP — RPM                         | 3300                      | 3300                      | 3300                      | 3300                      |
| Volts/Ph/Hz                            | 120 / 1 / 60              | 120 / 1 / 60              | 120 / 1 / 60              | 120 / 1 / 60              |
| FLA                                    | 0.66                      | 0.66                      | 2.14                      | 2.14                      |
| FILTER — Furnished?                    | No                        | No                        | No                        | No                        |
| Type recommended                       | High Velocity             | High Velocity             | High Velocity             | High Velocity             |
| Hi Vel. (No.-Size-Thk.)                | 1 - 20 X 25 - 1 in.       | 1 - 20 X 25 - 1 in.       | 2 - 14 X 20 -1 in.        | 2 - 14 X 20 -1 in.        |
| VENT PIPE DIAMETER — Min (in.) (f) (g) | 2 Round                   | 3 Round                   | 2 Round                   | 2 Round                   |
| HEAT EXCHANGER                         |                           |                           |                           |                           |
| Type — Fired                           | 409 Stainless Steel       | 409 Stainless Steel       | 409 Stainless Steel       | 409 Stainless Steel       |
| — Unfired                              | 29-4C Stainless Steel     | 29-4C Stainless Steel     | 29-4C Stainless Steel     | 29-4C Stainless Steel     |
| Gauge (Fired)                          | 20                        | 20                        | 20                        | 20                        |
| ORIFICES — Main                        |                           |                           |                           |                           |
| Nat. Gas Qty. — Drill Size             | 5 - 45                    | 6 - 45                    | 2 - 45                    | 3 - 45                    |
| LP Gas Qty. — Drill Size               | 5 - 56                    | 6 - 56                    | 2 - 56                    | 3 - 56                    |
| GAS VALVE                              | Redundant - One Stage     | Redundant - One Stage     | Redundant - One Stage     | Redundant - One Stage     |
| PILOT SAFETY DEVICE                    |                           |                           |                           |                           |
| Type                                   | 120 V SiNi Igniter        | 120 V SiNi Igniter        | 120 V SiNi Igniter        | 120 V SiNi Igniter        |
| BURNERS — Type                         | Multiport Inshot          | Multiport Inshot          | Multiport Inshot          | Multiport Inshot          |
| Number                                 | 5                         | 6                         | 2                         | 3                         |
| POWER CONN. — V/Ph/Hz (h)              | 120 / 1 / 60              | 120 / 1 / 60              | 120 / 1 / 60              | 120 / 1 / 60              |
| Ampacity (In Amps)                     | 14.1                      | 14.1                      | 10.3                      | 10.3                      |
| Max. Overcurrent Protection (Amps)     | 15                        | 15                        | 15                        | 15                        |
| PIPE CONN. SIZE (in.)                  | 1/2                       | 1/2                       | 1/2                       | 1/2                       |

| MODEL                                  | A951X080BD4SAC (a)        | A951X100CD5SAC (a)        | A951X120DD5SAC (a)        |
|----------------------------------------|---------------------------|---------------------------|---------------------------|
| TYPE                                   | Downflow                  | Downflow                  | Downflow                  |
| RATINGS (b)                            |                           |                           |                           |
| Input BTUH                             | 80,000                    | 100,000                   | 120,000                   |
| Capacity BTUH (ICS) (c) (d)            | 76,900                    | 96,800                    | 115,500                   |
| Temp. Rise (Min.-Max.)                 | 45 - 75                   | 40 - 70                   | 45 - 75                   |
| AFUE (%) (d)                           | 95.0                      | 96.0                      | 95.0                      |
| Return Air Temp. (Min. - Max.)         | 45°F - 80°F               | 45°F - 80°F               | 45°F - 80°F               |
| BLOWER DRIVE                           | DIRECT                    | DIRECT                    | DIRECT                    |
| Diameter — Width (In.)                 | 11 X 8                    | 11 X 10                   | 11 X 10                   |
| No. Used                               | 1                         | 1                         | 1                         |
| Speeds (No.) (e)                       | 9                         | 9                         | 9                         |
| CFM vs. in. w.g.                       | See Fan Performance Table | See Fan Performance Table | See Fan Performance Table |
| Motor HP                               | 3/4                       | 1                         | 1                         |
| RPM                                    | 1075                      | 1075                      | 1075                      |
| Volts/Ph/Hz                            | 120 / 1 / 60              | 120 / 1 / 60              | 120 / 1 / 60              |
| FLA                                    | 9.3                       | 10.6                      | 10.6                      |
| COMBUSTION FAN — Type                  | Centrifugal               | Centrifugal               | Centrifugal               |
| Drive — No. Speeds                     | Direct - 1                | Direct - 1                | Direct - 1                |
| Motor HP — RPM                         | 3300                      | 3300                      | 3300                      |
| Volts/Ph/Hz                            | 120 / 1 / 60              | 120 / 1 / 60              | 120 / 1 / 60              |
| FLA                                    | 2.14                      | 0.66                      | 0.66                      |
| FILTER — Furnished?                    | No                        | No                        | No                        |
| Type recommended                       | High Velocity             | High Velocity             | High Velocity             |
| Hi Vel. (No.-Size-Thk.)                | 1 - 16 X 25 - 1 in.       | 1 - 20 X 25 - 1 in.       | 1 - 24 X 25 - 1 in.       |
| VENT PIPE DIAMETER — Min (in.) (f) (g) | 2 Round                   | 2 Round                   | 3 Round                   |
| HEAT EXCHANGER                         |                           |                           |                           |
| Type — Fired                           | 409 Stainless Steel       | 409 Stainless Steel       | 409 Stainless Steel       |
| — Unfired                              | 29-4C Stainless Steel     | 29-4C Stainless Steel     | 29-4C Stainless Steel     |
| Gauge (Fired)                          | 20                        | 20                        | 20                        |
| ORIFICES — Main                        |                           |                           |                           |
| Nat. Gas Qty. — Drill Size             | 4 - 45                    | 5 - 45                    | 6 - 45                    |
| LP Gas Qty. — Drill Size               | 4 - 56                    | 5 - 56                    | 6 - 56                    |
| GAS VALVE                              | Redundant - One Stage     | Redundant - One Stage     | Redundant - One Stage     |
| PILOT SAFETY DEVICE                    |                           |                           |                           |
| Type                                   | 120 V SiNi Igniter        | 120 V SiNi Igniter        | 120 V SiNi Igniter        |
| BURNERS — Type                         | Multiport Inshot          | Multiport Inshot          | Multiport Inshot          |
| Number                                 | 4                         | 5                         | 6                         |
| POWER CONN. — V/Ph/Hz (h)              | 120 / 1 / 60              | 120 / 1 / 60              | 120 / 1 / 60              |
| Ampacity (In Amps)                     | 13.9                      | 14.1                      | 14.1                      |
| Max. Overcurrent Protection (Amps)     | 15                        | 15                        | 15                        |
| PIPE CONN. SIZE (in.)                  | 1/2                       | 1/2                       | 1/2                       |

(a) Meets Energy Star

(b) For U.S. applications, above input ratings (BTUH) are up to 2,000 feet, derate 4% per 1,000 feet for elevations above 2,000 feet above sea level. For Canadian applications, above input ratings (BTUH) are up to 4,500 feet, derate 4% per 1,000 feet for elevations above 4,500 feet above sea level.

(c) Central Furnace heating designs are certified to ANSI Z21.47 / CSA 2.3.

(d) Based on U.S. government standard tests.

(e) 9 Speed constant torque ECM blower motor

(f) Refer to the Vent Length Table in this document.

(g) All furnace models have a vent outlet diameter that equals 2 in.

(h) The above wiring specifications are in accordance with National Electrical Code; however, installations must comply with local codes.

# Furnace Installation Guidelines

The following sections give general guidelines for the installation of the gas furnaces.

## Safety Practices and Precautions

The following safety practices and precautions must be followed during the installation, servicing, and operation of this Furnace.

1. Use only with the type gas approved for this Furnace. Refer to the Furnace rating plate.
2. Install the Furnace only in a location and position as specified in "Locations and Clearances" of these instructions.
3. Provide adequate combustion and ventilation air to the Furnace space as specified in "Air for Combustion and Ventilation" of these instructions.
4. Combustion products must be discharged outdoors. Connect this Furnace to an approved vent system only, as specified in the "Venting" section of these instructions.
5. Never test for gas leaks with an open flame. Use a commercially available soap solution made specifically for the detection of leaks to check all connections, as specified in the "Gas Piping" section of these instructions.
6. Always install the Furnace to operate within the Furnace's intended temperature-rise range with a duct system which has an external static pressure within the allowable range, as specified on the unit rating plate. Airflow within temperature rise for cfm versus static is shown in the CFM Versus Temperature Rise section in this document accompanying this Furnace.
7. When a Furnace is installed so that the supply ducts carry air circulated by the Furnace to areas outside the space containing the Furnace, the return air shall also be handled by a duct(s) sealed to the Furnace casing and terminating outside the space containing the Furnace.
8. A gas-fired Furnace for installation in a residential garage must be installed as specified in "Location and Clearances" section of these instructions.
9. The furnace may be used for temporary heating of buildings or structures under construction only when the following conditions have been met:
  - a. The Furnace venting system must be complete and installed per manufacturer's instructions.
  - b. The Furnace is controlled only by a room Comfort Control (no field jumpers).
  - c. The Furnace return air duct must be complete and sealed to the Furnace.
  - d. The Furnace input rate and temperature rise must be verified to be within the nameplate marking.
  - e. A minimum 4" MERV 11 air filter must be in place.
  - f. 100% of the Furnace combustion air requirement must come from outside the structure.
  - g. The Furnace return air temperature range is between 45 and 80 Fahrenheit.  
80% models = 55°F  
90%+ models = 45°F
  - h. Clean the Furnace, duct work, and components upon substantial completion of the construction process, and verify Furnace operating conditions including ignition, input rate, temperature rise, and venting, according to the manufacturer's instructions.
10. **In the Commonwealth of Massachusetts, this product must be gas piped by a Licensed Plumber or Gas Fitter.**

This Furnace is certified to leak 1.4% or less of nominal air conditioning CFM delivered when pressurized to .5" water column with all inlets, outlets, and drains sealed.

## General Guidelines

The manufacturer assumes no responsibility for equipment installed in violation of any code or regulation.

It is recommended that Manual J of the Air Conditioning Contractors Association (ACCA) or A.R.I. 230 be followed in estimating heating requirements. When estimating heating requirements for installation at Altitudes above 2000 ft., remember the gas input must be reduced. See Combustion and Input Check.

**Material in this shipment has been inspected at the factory and released to the transportation agency without known damage. Inspect exterior of carton for evidence of rough handling in shipment. Unpack carefully after moving equipment to approximate location. If damage to contents is found, report the damage immediately to the delivering agency.**

Codes and local utility requirements governing the installation of gas fired equipment, wiring, plumbing, and flue connections must be adhered to. In the absence of local codes, the installation must conform with latest edition of the National Fuel Gas Code ANSI Z223.1 / NFPA 54 • National Installation Code, CAN/CGA B149.1. The latest code may be obtained from the American Gas Association Laboratories, 400 N. Capitol St. NW, Washington D.C. 20001.  
1-800-699-9277 or [www.aga.org](http://www.aga.org).

These furnaces have been classified as CATEGORY IV furnaces in accordance with latest edition of ANSI Z21.47 standards • CSA 2.3. Category IV furnaces operate with positive vent static pressure and with a flue loss less than 17 percent. These conditions require special venting systems, which must be gas tight and water tight. These Category IV Direct Vent furnaces are approved for installation in Manufactured/ Mobile housing when used with BAYMFGH200B.

A manufactured (mobile) home installation must conform with the *Manufactured Home Construction and Safety Standard, Title 24 CFR, Part 3280*, or when this standard is not applicable, the *Standard for Model Manufactured Home Installation, NFPA 225*, or the *Canadian Standard for Manufactured Homes, CSA Z240 MH*.

## Locations and Clearances

The location of the furnace is normally selected by the architect, the builder, or the installer. However, before the furnace is moved into place, be sure to consider the following requirements:

1. Is the location selected as near the chimney or vent and as centralized for heat distribution as practical?
2. Do all clearances between the furnace and enclosure equal or exceed the minimums stated in Clearance Table below?

| Minimum clearance to combustible materials             |       |
|--------------------------------------------------------|-------|
| Closet                                                 |       |
| Sides                                                  | 0 in. |
| Back                                                   | 1 in. |
| Top                                                    | 1 in. |
| Front                                                  | 0 in. |
| Bottom                                                 | 0 in. |
| Flue                                                   | 0 in. |
| 24 in. minimum front clearance recommended for service |       |
| Horizontal Closet and Alcove                           |       |
| Right Side                                             | 0 in. |
| Left Side                                              | 0 in. |
| Back                                                   | 1 in. |
| Top                                                    | 1 in. |
| Bottom                                                 | 0 in. |
| Flue                                                   | 0 in. |
| Horizontal Flue (discharge on left)                    |       |
| Closet                                                 |       |
| Right Side                                             | 0 in. |
| Left Side                                              | 0 in. |
| Rear                                                   | 1 in. |
| Top                                                    | 1 in. |


|        |       |
|--------|-------|
| Bottom | 0 in. |
| Flue   | 0 in. |


3. Is there sufficient space for servicing the furnace and other equipment? A minimum of 24 inches front accessibility to the furnace must be provided. Any access door or panel must permit removal of the largest component.
4. Are there at least 3 inches of clearance between the furnace combustion air openings in the front panel and any closed panel or door provided?
5. Are the ventilation and combustion air openings large enough and will they remain unobstructed? If outside air is used, are the openings set 12" above the highest snow accumulation level?
6. Allow sufficient height in supply plenum above the furnace to provide for cooling coil installation, if the cooling coil is not installed at the time of this furnace installation.
7. The furnace shall be installed so electrical components are protected from water.
8. A vertical downflow furnace without a coil, must use BAYBASE205 when installed on combustible flooring.
9. If the furnace is installed in a garage, it must be installed so that the burners, and the ignition source are located not less than 18 inches above the floor and the furnace must be located or protected to avoid physical damage from vehicles.
10. The gas furnace must not be located where excessive exposure to contaminated combustion air will result in safety and performance related problems. Avoid the following contaminants:
  - a. Permanent wave solutions
  - b. Chlorinated waxes and cleaners
  - c. Chlorine based swimming pool chemicals
  - d. Water softening chemicals
  - e. De-icing salts or chemicals
  - f. Carbon tetrachloride
  - g. Halogen type refrigerants
  - h. Cleaning solvents (such as perchloroethylene)
  - i. Printing inks, paint removers, varnishes, etc.
  - j. Hydrochloric acid, Cements and glues
  - k. Antistatic fabric softeners for clothes dryers
  - l. Masonry acid washing materials

**IMPORTANT:** The furnace must be installed level. The only allowable variation would be slightly to the left and/ or forward in upflow installations or slightly toward the front in horizontal installations. This is necessary for proper condensate drainage.


# Outline Drawing

Table 2. 17.5", 21" and 24.5" Upflow Cabinets





# Wiring Diagrams





# Airflow Tables

## Upflow

| Furnace Airflow (CFM) Vs. External Static Pressure (in. W.C.) |     |              |            |            |            |            |            |
|---------------------------------------------------------------|-----|--------------|------------|------------|------------|------------|------------|
| Model                                                         | Tap |              | 0.1        | 0.3        | 0.5        | 0.7        | 0.9        |
| A951X040BU3SAC                                                | 1   | SCFM / Watts | 510 / 34   | 314 / 43   | 118 / 52   | -          | -          |
|                                                               | 2   | SCFM / Watts | 532 / 36   | 341 / 45   | 150 / 54   | -          | -          |
|                                                               | 3   | SCFM / Watts | 877 / 91   | 748 / 104  | 620 / 118  | 491 / 131  | 362 / 144  |
|                                                               | 4   | SCFM / Watts | 933 / 106  | 813 / 120  | 693 / 133  | 573 / 147  | 452 / 161  |
|                                                               | 5   | SCFM / Watts | 1056 / 140 | 950 / 156  | 843 / 172  | 737 / 188  | 631 / 204  |
|                                                               | 6   | SCFM / Watts | 1111 / 157 | 1009 / 174 | 908 / 190  | 806 / 207  | 705 / 223  |
|                                                               | 7   | SCFM / Watts | 1174 / 182 | 1078 / 199 | 983 / 216  | 887 / 233  | 791 / 251  |
|                                                               | 8   | SCFM / Watts | 1376 / 285 | 1297 / 305 | 1218 / 325 | 1140 / 344 | 1061 / 364 |
|                                                               | 9   | SCFM / Watts | 1512 / 382 | 1445 / 403 | 1378 / 424 | 1312 / 445 | 1245 / 466 |

| Furnace Airflow (CFM) Vs. External Static Pressure (in. W.C.) |     |              |            |            |            |            |            |
|---------------------------------------------------------------|-----|--------------|------------|------------|------------|------------|------------|
| Model                                                         | Tap |              | 0.1        | 0.3        | 0.5        | 0.7        | 0.9        |
| A951X060BU4SAC                                                | 1   | SCFM / Watts | 840 / 91   | 702 / 101  | 565 / 111  | 427 / 121  | 290 / 130  |
|                                                               | 2   | SCFM / Watts | 1001 / 137 | 893 / 149  | 786 / 162  | 678 / 174  | 571 / 186  |
|                                                               | 3   | SCFM / Watts | 1140 / 193 | 1051 / 207 | 963 / 221  | 875 / 235  | 786 / 249  |
|                                                               | 4   | SCFM / Watts | 1208 / 223 | 1128 / 238 | 1048 / 253 | 969 / 268  | 889 / 283  |
|                                                               | 5   | SCFM / Watts | 1299 / 270 | 1224 / 284 | 1148 / 298 | 1073 / 312 | 998 / 327  |
|                                                               | 6   | SCFM / Watts | 1413 / 343 | 1348 / 359 | 1283 / 375 | 1217 / 391 | 1152 / 406 |
|                                                               | 7   | SCFM / Watts | 1444 / 354 | 1380 / 370 | 1315 / 386 | 1251 / 403 | 1186 / 419 |
|                                                               | 8   | SCFM / Watts | 1727 / 612 | 1674 / 631 | 1622 / 650 | 1570 / 668 | 1518 / 687 |
|                                                               | 9   | SCFM / Watts | 1790 / 694 | 1741 / 712 | 1691 / 729 | 1642 / 747 | 1593 / 765 |

| Furnace Airflow (CFM) Vs. External Static Pressure (in. W.C.) |     |              |            |            |            |            |            |
|---------------------------------------------------------------|-----|--------------|------------|------------|------------|------------|------------|
| Model                                                         | Tap |              | 0.1        | 0.3        | 0.5        | 0.7        | 0.9        |
| A951X080BU4SAC                                                | 1   | SCFM / Watts | 911 / 94   | 766 / 104  | 622 / 115  | 477 / 125  | 332 / 136  |
|                                                               | 2   | SCFM / Watts | 1075 / 139 | 963 / 153  | 851 / 168  | 740 / 182  | 628 / 197  |
|                                                               | 3   | SCFM / Watts | 1215 / 185 | 1121 / 202 | 1028 / 219 | 934 / 236  | 840 / 253  |
|                                                               | 4   | SCFM / Watts | 1250 / 203 | 1164 / 221 | 1077 / 239 | 990 / 257  | 903 / 274  |
|                                                               | 5   | SCFM / Watts | 1349 / 251 | 1272 / 271 | 1194 / 291 | 1116 / 310 | 1039 / 330 |
|                                                               | 6   | SCFM / Watts | 1453 / 313 | 1387 / 335 | 1321 / 356 | 1254 / 378 | 1188 / 400 |
|                                                               | 7   | SCFM / Watts | 1505 / 340 | 1438 / 362 | 1372 / 384 | 1305 / 406 | 1239 / 427 |
|                                                               | 8   | SCFM / Watts | 1657 / 453 | 1597 / 477 | 1538 / 500 | 1479 / 524 | 1419 / 547 |
|                                                               | 9   | SCFM / Watts | 1878 / 669 | 1815 / 686 | 1752 / 702 | 1690 / 718 | 1627 / 735 |

## Airflow Tables

| Furnace Airflow (CFM) Vs. External Static Pressure (in. W.C.) |     |              |            |            |            |            |             |
|---------------------------------------------------------------|-----|--------------|------------|------------|------------|------------|-------------|
| Model                                                         | Tap |              | 0.1        | 0.3        | 0.5        | 0.7        | 0.9         |
| A951X080CU5SAC                                                | 1   | SCFM / Watts | 643 / 45   | 384 / 53   | 125 / 62   | -          | -           |
|                                                               | 2   | SCFM / Watts | 1125 / 126 | 982 / 142  | 838 / 158  | 694 / 174  | 551 / 190   |
|                                                               | 3   | SCFM / Watts | 1192 / 140 | 1038 / 157 | 884 / 174  | 730 / 191  | 576 / 208   |
|                                                               | 4   | SCFM / Watts | 1509 / 245 | 1377 / 268 | 1246 / 291 | 1115 / 314 | 983 / 337   |
|                                                               | 5   | SCFM / Watts | 1548 / 257 | 1428 / 281 | 1308 / 304 | 1187 / 328 | 1067 / 352  |
|                                                               | 6   | SCFM / Watts | 1602 / 320 | 1467 / 345 | 1331 / 371 | 1196 / 396 | 1061 / 421  |
|                                                               | 7   | SCFM / Watts | 1640 / 352 | 1512 / 379 | 1383 / 406 | 1255 / 433 | 1127 / 459  |
|                                                               | 8   | SCFM / Watts | 1831 / 521 | 1778 / 550 | 1726 / 579 | 1673 / 608 | 1621 / 637  |
|                                                               | 9   | SCFM / Watts | 2351 / 886 | 2278 / 918 | 2204 / 950 | 2131 / 982 | 2058 / 1014 |

| Furnace Airflow (CFM) Vs. External Static Pressure (in. W.C.) |     |              |            |            |            |             |             |
|---------------------------------------------------------------|-----|--------------|------------|------------|------------|-------------|-------------|
| Model                                                         | Tap |              | 0.1        | 0.3        | 0.5        | 0.7         | 0.9         |
| A951X100CU5SAC                                                | 1   | SCFM / Watts | 1013 / 104 | 847 / 116  | 680 / 129  | 514 / 142   | 348 / 155   |
|                                                               | 2   | SCFM / Watts | 1261 / 168 | 1126 / 185 | 990 / 202  | 854 / 219   | 718 / 236   |
|                                                               | 3   | SCFM / Watts | 1519 / 267 | 1407 / 290 | 1296 / 313 | 1184 / 336  | 1072 / 358  |
|                                                               | 4   | SCFM / Watts | 1554 / 283 | 1446 / 307 | 1337 / 330 | 1229 / 353  | 1120 / 377  |
|                                                               | 5   | SCFM / Watts | 1749 / 385 | 1651 / 411 | 1554 / 436 | 1457 / 462  | 1359 / 488  |
|                                                               | 6   | SCFM / Watts | 1868 / 464 | 1778 / 491 | 1688 / 519 | 1599 / 546  | 1509 / 574  |
|                                                               | 7   | SCFM / Watts | 2018 / 573 | 1936 / 602 | 1853 / 631 | 1770 / 660  | 1688 / 689  |
|                                                               | 8   | SCFM / Watts | 2191 / 718 | 2112 / 750 | 2033 / 782 | 1954 / 815  | 1875 / 847  |
|                                                               | 9   | SCFM / Watts | 2395 / 966 | 2303 / 981 | 2212 / 996 | 2120 / 1012 | 2028 / 1027 |

| Furnace Airflow (CFM) Vs. External Static Pressure (in. W.C.) |     |              |            |            |            |             |             |
|---------------------------------------------------------------|-----|--------------|------------|------------|------------|-------------|-------------|
| Model                                                         | Tap |              | 0.1        | 0.3        | 0.5        | 0.7         | 0.9         |
| A951X120DU5SAC                                                | 1   | SCFM / Watts | 707 / 46   | 443 / 55   | 179 / 64   | -           | -           |
|                                                               | 2   | SCFM / Watts | 1344 / 163 | 1218 / 183 | 1092 / 202 | 966 / 222   | 840 / 241   |
|                                                               | 3   | SCFM / Watts | 1532 / 225 | 1419 / 247 | 1307 / 268 | 1195 / 290  | 1083 / 312  |
|                                                               | 4   | SCFM / Watts | 1584 / 247 | 1477 / 270 | 1370 / 292 | 1263 / 315  | 1156 / 338  |
|                                                               | 5   | SCFM / Watts | 1915 / 401 | 1818 / 428 | 1722 / 454 | 1625 / 480  | 1529 / 506  |
|                                                               | 6   | SCFM / Watts | 2104 / 525 | 2016 / 553 | 1927 / 582 | 1839 / 610  | 1750 / 639  |
|                                                               | 7   | SCFM / Watts | 2132 / 546 | 2045 / 575 | 1958 / 604 | 1870 / 633  | 1783 / 662  |
|                                                               | 8   | SCFM / Watts | 2410 / 833 | 2328 / 868 | 2247 / 903 | 2165 / 937  | 2084 / 972  |
|                                                               | 9   | SCFM / Watts | 2472 / 909 | 2401 / 944 | 2329 / 979 | 2257 / 1013 | 2186 / 1048 |

### Downflow

| Furnace Airflow (CFM) Vs. External Static Pressure (in. W.C.) |     |              |            |            |            |            |            |
|---------------------------------------------------------------|-----|--------------|------------|------------|------------|------------|------------|
| Model                                                         | Tap |              | 0.1        | 0.3        | 0.5        | 0.7        | 0.9        |
| A951X040BD3SAC                                                | 1   | SCFM / Watts | 378 / 28   | 153 / 32   | -          | -          | -          |
|                                                               | 2   | SCFM / Watts | 514 / 35   | 330 / 45   | 145 / 55   | - / 64     | - / 74     |
|                                                               | 3   | SCFM / Watts | 765 / 69   | 618 / 81   | 471 / 93   | 324 / 105  | 178 / 116  |
|                                                               | 4   | SCFM / Watts | 827 / 81   | 691 / 94   | 554 / 106  | 418 / 119  | 281 / 132  |
|                                                               | 5   | SCFM / Watts | 988 / 124  | 879 / 140  | 770 / 156  | 661 / 171  | 553 / 187  |
|                                                               | 6   | SCFM / Watts | 1085 / 156 | 986 / 173  | 887 / 190  | 787 / 207  | 688 / 224  |
|                                                               | 7   | SCFM / Watts | 1125 / 170 | 1030 / 188 | 934 / 205  | 839 / 222  | 743 / 239  |
|                                                               | 8   | SCFM / Watts | 1129 / 170 | 1035 / 187 | 941 / 204  | 847 / 221  | 753 / 239  |
|                                                               | 9   | SCFM / Watts | 1492 / 369 | 1419 / 390 | 1346 / 411 | 1273 / 431 | 1200 / 452 |

| Furnace Airflow (CFM) Vs. External Static Pressure (in. W.C.) |     |              |            |            |            |            |            |
|---------------------------------------------------------------|-----|--------------|------------|------------|------------|------------|------------|
| Model                                                         | Tap |              | 0.1        | 0.3        | 0.5        | 0.7        | 0.9        |
| A951X060BD3SAC                                                | 1   | SCFM / Watts | 624 / 47   | 451 / 57   | 277 / 68   | 104 / 79   | -          |
|                                                               | 2   | SCFM / Watts | 866 / 89   | 734 / 102  | 602 / 116  | 470 / 129  | 338 / 142  |
|                                                               | 3   | SCFM / Watts | 949 / 113  | 833 / 128  | 718 / 142  | 602 / 156  | 486 / 171  |
|                                                               | 4   | SCFM / Watts | 1122 / 165 | 1025 / 182 | 928 / 200  | 831 / 217  | 733 / 235  |
|                                                               | 5   | SCFM / Watts | 1178 / 191 | 1087 / 209 | 996 / 227  | 905 / 246  | 814 / 264  |
|                                                               | 6   | SCFM / Watts | 1260 / 233 | 1180 / 252 | 1100 / 271 | 1021 / 290 | 941 / 309  |
|                                                               | 7   | SCFM / Watts | 1370 / 296 | 1299 / 316 | 1228 / 336 | 1158 / 355 | 1087 / 375 |
|                                                               | 8   | SCFM / Watts | 1480 / 365 | 1416 / 387 | 1352 / 408 | 1287 / 429 | 1223 / 450 |
|                                                               | 9   | SCFM / Watts | 1504 / 384 | 1440 / 406 | 1376 / 427 | 1312 / 449 | 1249 / 470 |

| Furnace Airflow (CFM) Vs. External Static Pressure (in. W.C.) |     |              |            |            |            |            |            |
|---------------------------------------------------------------|-----|--------------|------------|------------|------------|------------|------------|
| Model                                                         | Tap |              | 0.1        | 0.3        | 0.5        | 0.7        | 0.9        |
| A951X080BD4SAC                                                | 1   | SCFM / Watts | 499 / 36   | 306 / 43   | 113 / 49   | -          | -          |
|                                                               | 2   | SCFM / Watts | 1017 / 143 | 922 / 158  | 828 / 173  | 734 / 188  | 640 / 203  |
|                                                               | 3   | SCFM / Watts | 1119 / 176 | 1029 / 192 | 940 / 207  | 850 / 223  | 761 / 239  |
|                                                               | 4   | SCFM / Watts | 1205 / 215 | 1125 / 233 | 1044 / 250 | 964 / 268  | 883 / 285  |
|                                                               | 5   | SCFM / Watts | 1237 / 231 | 1160 / 250 | 1083 / 268 | 1006 / 286 | 928 / 305  |
|                                                               | 6   | SCFM / Watts | 1378 / 315 | 1309 / 334 | 1240 / 354 | 1172 / 373 | 1103 / 393 |
|                                                               | 7   | SCFM / Watts | 1453 / 360 | 1389 / 380 | 1324 / 399 | 1260 / 419 | 1195 / 439 |
|                                                               | 8   | SCFM / Watts | 1618 / 496 | 1562 / 518 | 1505 / 540 | 1449 / 561 | 1392 / 583 |
|                                                               | 9   | SCFM / Watts | 1794 / 682 | 1742 / 704 | 1691 / 726 | 1639 / 748 | 1587 / 770 |

| Furnace Airflow (CFM) Vs. External Static Pressure (in. W.C.) |     |              |            |            |             |             |             |
|---------------------------------------------------------------|-----|--------------|------------|------------|-------------|-------------|-------------|
| Model                                                         | Tap |              | 0.1        | 0.3        | 0.5         | 0.7         | 0.9         |
| A951X100CD5SAC                                                | 1   | SCFM / Watts | 1002 / 103 | 823 / 117  | 644 / 130   | 465 / 144   | 285 / 157   |
|                                                               | 2   | SCFM / Watts | 1385 / 223 | 1276 / 243 | 1167 / 264  | 1057 / 284  | 948 / 304   |
|                                                               | 3   | SCFM / Watts | 1527 / 286 | 1430 / 310 | 1333 / 333  | 1236 / 357  | 1139 / 380  |
|                                                               | 4   | SCFM / Watts | 1610 / 328 | 1516 / 352 | 1421 / 377  | 1326 / 401  | 1231 / 425  |
|                                                               | 5   | SCFM / Watts | 1761 / 433 | 1677 / 459 | 1593 / 486  | 1509 / 512  | 1425 / 538  |
|                                                               | 6   | SCFM / Watts | 1861 / 492 | 1783 / 520 | 1706 / 549  | 1628 / 577  | 1551 / 605  |
|                                                               | 7   | SCFM / Watts | 1984 / 548 | 1902 / 577 | 1820 / 606  | 1738 / 635  | 1656 / 663  |
|                                                               | 8   | SCFM / Watts | 2173 / 728 | 2097 / 760 | 2020 / 792  | 1944 / 824  | 1867 / 856  |
|                                                               | 9   | SCFM / Watts | 2342 / 945 | 2269 / 973 | 2196 / 1002 | 2123 / 1031 | 2050 / 1060 |

| Furnace Airflow (CFM) Vs. External Static Pressure (in. W.C.) |     |              |            |            |            |            |             |
|---------------------------------------------------------------|-----|--------------|------------|------------|------------|------------|-------------|
| Model                                                         | Tap |              | 0.1        | 0.3        | 0.5        | 0.7        | 0.9         |
| A951X120DD5SAC                                                | 1   | SCFM / Watts | 680 / 47   | 419 / 56   | 159 / 66   | -          | -           |
|                                                               | 2   | SCFM / Watts | 1025 / 237 | 1063 / 259 | 1101 / 282 | 1139 / 304 | 1177 / 327  |
|                                                               | 3   | SCFM / Watts | 1566 / 268 | 1461 / 292 | 1357 / 316 | 1253 / 340 | 1149 / 363  |
|                                                               | 4   | SCFM / Watts | 1803 / 393 | 1711 / 420 | 1619 / 446 | 1527 / 472 | 1435 / 498  |
|                                                               | 5   | SCFM / Watts | 1891 / 445 | 1801 / 472 | 1711 / 500 | 1621 / 527 | 1532 / 555  |
|                                                               | 6   | SCFM / Watts | 2132 / 568 | 2025 / 601 | 1919 / 633 | 1812 / 666 | 1705 / 698  |
|                                                               | 7   | SCFM / Watts | 2154 / 644 | 2068 / 675 | 1982 / 705 | 1896 / 736 | 1810 / 766  |
|                                                               | 8   | SCFM / Watts | 2344 / 837 | 2267 / 870 | 2190 / 902 | 2113 / 934 | 2035 / 967  |
|                                                               | 9   | SCFM / Watts | 2414 / 896 | 2333 / 928 | 2251 / 961 | 2170 / 993 | 2088 / 1026 |

# CFM Versus Temperature Rise

**Table 4. Heating Table — Upflow**

| CFM VS. TEMPERATURE RISE |     |     |     |      |      |      |      |      |      |      |      |      |      |      |      |      |      |
|--------------------------|-----|-----|-----|------|------|------|------|------|------|------|------|------|------|------|------|------|------|
| MODEL                    |     |     |     |      |      |      |      |      |      |      |      |      |      |      |      |      |      |
|                          | 700 | 800 | 900 | 1000 | 1100 | 1200 | 1300 | 1400 | 1500 | 1600 | 1700 | 1800 | 1900 | 2000 | 2100 | 2200 | 2300 |
| A951X040BU3SAC           | 55  | 48  | 44  | 39   | 36   | 33   | 30   |      |      |      |      |      |      |      |      |      |      |
| A951X060BU4SAC           |     |     | 63  | 58   | 52   | 49   | 46   | 43   | 41   | 40   |      |      |      |      |      |      |      |
| A951X080BU4SAC           |     |     | 71  | 68   | 64   | 61   | 57   | 54   | 51   | 48   | 45   |      |      |      |      |      |      |
| A951X080CU5SAC           |     |     |     | 68   | 65   | 59   | 56   | 54   | 49   | 46   | 44   |      |      |      |      |      |      |
| A951X100CU5SAC           |     |     |     |      |      |      |      | 68   | 65   | 61   | 57   | 55   | 53   | 49   | 46   |      |      |
| A951X120CU5SAC           |     |     |     |      |      |      |      |      | 67   | 65   | 60   | 55   | 54   | 51   | 48   | 44   | 41   |

**Table 5. Heating Table — Downflow**

| CFM VS. TEMPERATURE RISE |                             |     |     |     |     |      |      |      |      |      |      |      |      |      |      |      |      |      |      |
|--------------------------|-----------------------------|-----|-----|-----|-----|------|------|------|------|------|------|------|------|------|------|------|------|------|------|
| MODEL                    | CFM (CUBIC FEET PER MINUTE) |     |     |     |     |      |      |      |      |      |      |      |      |      |      |      |      |      |      |
|                          | 500                         | 600 | 700 | 800 | 900 | 1000 | 1100 | 1200 | 1300 | 1400 | 1500 | 1600 | 1700 | 1800 | 1900 | 2000 | 2100 | 2200 | 2300 |
| A951X040BD3SAC           | 57                          | 53  | 46  | 45  | 37  | 34   | 31   |      |      |      |      |      |      |      |      |      |      |      |      |
| A951X060BD3SAC           |                             |     |     |     | 63  | 58   | 52   | 48   | 44   | 41   |      |      |      |      |      |      |      |      |      |
| A951X080BD4SAC           |                             |     |     |     | 72  | 69   | 65   | 62   | 57   | 53   | 49   | 48   |      |      |      |      |      |      |      |
| A951X100CD5SAC           |                             |     |     |     |     |      |      |      | 68   | 65   | 62   | 58   | 55   | 53   | 50   | 48   | 44   |      |      |
| A951X120DD5SAC           |                             |     |     |     |     |      |      |      |      | 72   | 69   | 66   | 64   | 58   | 56   | 53   | 52   | 49   | 44   |

# Furnace General Installation

The following sections give general instructions for the installation of the gas furnaces.


|                                                                                                                                                                                          |  |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|
| <p><b>Note:</b> For the A951X furnace, a 1/4" nut driver is required to remove the two screws at the top of the front panel. The front panel can then be removed by lifting upwards.</p> |  |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|

## Horizontal Installation in an Attic or Crawlspace

The upflow condensing furnace may be installed in an attic or crawl space in the horizontal let or right position for needed airflow direction. The horizontal furnace installation in an attic should be on a service platform large enough to allow for proper clearances on all sides and service access to the front of the furnace. See "the Locations and Clearance section," p. 15. Line contact is only permissible between lines formed by intersections of the top and two sides of the furnace casing and building joists, studs, or framing.

The furnace may be placed horizontally in a crawl space on a pad or other noncombustible material which will raise the unit for sufficient protection from moisture.

The Furnace must be supported at both ends when installed horizontally. The Furnace must also be elevated approximately 6 inches to allow clearance for the condensate drain to exit the cabinet in the **horizontal position**.




FURNACE MUST BE SUPPORTED AT ALL FOUR CORNERS. BAYHANG - OPTIONAL HORIZONTAL HANGING BRACKET KIT

TO APPROVED OPEN / VENTED DRAIN

Note: The overflow stand pipe termination must be even with or slightly below the bottom of the condensate trap.  
Note: Water from the overflow pipe must drain into the emergency drain pan.

## Horizontal Installation Hanging Using Straps


The furnace may be installed hanging in a hanging position using straps. The furnace should be supported at both ends and have an additional support in the center of the furnace in front.




## Gas Piping

**Important:** When converting the gas piping from the factory default, the plug must be removed from the new gas piping location and swapped with the grommet from the default location. The upflow furnace default is left side gas piping. The downflow furnace default is right side gas piping.


Upflow furnace with gas piping on left side




Upflow furnace with gas piping on right side




Downflow furnace with gas piping on left side




Downflow furnace with gas piping on right side




Horizontal left furnace with gas piping out left side




Horizontal left furnace with gas piping out right side



Horizontal right furnace with gas piping out left side



Horizontal right furnace with gas piping out right side



The upflow/horizontal furnace is shipped standard for left side installation of gas piping. An opening with plug is provided on the right side for an alternate gas piping arrangement.

The installation of piping shall be in accordance with piping codes and the regulations of the local gas company. Pipe joint compound must be resistant to the chemical reaction with liquefied petroleum gases.

**Important:** If local codes allow the use of flexible gas appliance connector, always use a new listed connector. Do not use a connector which has previously serviced another gas appliance.

Refer to the piping table for delivery sizes. Connect gas supply to the unit, using a ground joint union and a manual shut-off valve. National codes require a condensation drip leg to be installed ahead of the gas valve.

The furnace and its individual shut-off valve must be disconnected from the gas supply piping system during any pressure testing of that system at test pressures in excess of 1/2 psig (3.5 kPa).

The furnace must be isolated from the gas supply piping by closing its individual manual shut-off valve during any pressure testing of the gas supply piping system at test pressures equal to or less than 1/2 psig (3.5 kPa).

**Note:** Maximum pressure to the gas valve for natural gas is 13.8\" W.C. Minimum pressure is 5.0\" W.C. Maximum pressure to the gas valve for propane is 13.8\" W.C. Minimum pressure is 11.0\" W.C.

| NATURAL GAS ONLY                                                          |                |     |     |     |     |     |     |
|---------------------------------------------------------------------------|----------------|-----|-----|-----|-----|-----|-----|
| TABLE OF CUBIC FEET PER HOUR OF GAS FOR VARIOUS PIPE SIZES AND LENGTHS    |                |     |     |     |     |     |     |
| PIPE SIZE                                                                 | LENGTH OF PIPE |     |     |     |     |     |     |
|                                                                           | 10             | 20  | 30  | 40  | 50  | 60  | 70  |
| 1/2                                                                       | 131            | 90  | 72  | 62  | 55  | 50  | 46  |
| 3/4                                                                       | 273            | 188 | 151 | 129 | 114 | 104 | 95  |
| 1                                                                         | 514            | 353 | 284 | 243 | 215 | 195 | 179 |
| 1-1/4                                                                     | 1060           | 726 | 583 | 499 | 442 | 400 | 368 |
| This table is based on Pressure Drop of 0.3 inch W.C. and 0.6 SP. GR. Gas |                |     |     |     |     |     |     |

All gas fittings must be checked for leaks using a soapy solution before lighting the furnace. **DO NOT CHECK WITH AN OPEN FLAME!**

For propane conversions on all S-Series Furnaces, use BAYLPSS400\* conversion kit with stainless steel burners.

When installing our furnaces in a manufactured house, use Manufactured Housing Accessory Kit, BAYMFGH200B.

| ORIFICE SIZES     |                   |                                |             |
|-------------------|-------------------|--------------------------------|-------------|
| INPUT RATING BTUH | NUMBER OF BURNERS | MAIN BURNER ORIFICE DRILL SIZE |             |
|                   |                   | NAT. GAS                       | PROPANE GAS |
| 40,000            | 2                 | 45                             | 56          |
| 60,000            | 3                 | 45                             | 56          |
| 80,000            | 4                 | 45                             | 56          |
| 100,000           | 5                 | 45                             | 56          |
| 120,000           | 6                 | 45                             | 56          |

## Combustion and Input Check

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |                                 |      |      |      |      |      |      |      |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------|------|------|------|------|------|------|------|
| <ol style="list-style-type: none"> <li>1. Make sure all gas appliances are off except the furnace.</li> <li>2. Clock the gas meter with the furnace operating (determine the dial rating of the meter) for one revolution.</li> <li>3. Match the "Sec" column in the gas flow table with the time clocked.</li> <li>4. Read the "Flow" column opposite the number of seconds clocked.</li> <li>5. Use the following factors <u>if necessary</u>: <ol style="list-style-type: none"> <li>a. For 1 Cu. Ft. Dial Gas Flow CFH = Chart Flow Reading ÷ 2</li> <li>b. For 1/2 Cu Ft. Dial Gas Flow CFH = Chart Flow Reading ÷ 4</li> <li>c. For 5 Cu. Ft. Dial Gas Flow CFH = 10X Chart Flow Reading ÷ 4</li> </ol> </li> <li>6. Multiply the final figure by the heating value of the gas obtained from the utility company and compare to the nameplate rating. This must not exceed the nameplate rating.</li> </ol> | Gas Flow in Cubic Feet Per Hour |      |      |      |      |      |      |      |
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | 2 Cubic Foot Dial               |      |      |      |      |      |      |      |
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | Sec.                            | Flow | Sec. | Flow | Sec. | Flow | Sec. | Flow |
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | 10                              | 732  | 31   | 236  | 52   | 141  | 86   | 85   |
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | 11                              | 666  | 32   | 229  | 53   | 138  | 88   | 83   |
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | 12                              | 610  | 33   | 222  | 54   | 136  | 90   | 81   |
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | 13                              | 563  | 34   | 215  | 55   | 133  | 94   | 78   |
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | 14                              | 523  | 35   | 209  | 56   | 131  | 98   | 75   |
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | 15                              | 488  | 36   | 203  | 57   | 128  | 100  | 73   |
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | 16                              | 458  | 37   | 198  | 58   | 126  | 104  | 70   |
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | 17                              | 431  | 38   | 193  | 59   | 124  | 108  | 68   |
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | 18                              | 407  | 39   | 188  | 60   | 122  | 112  | 65   |
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | 19                              | 385  | 40   | 183  | 62   | 118  | 116  | 63   |
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | 20                              | 366  | 41   | 179  | 64   | 114  | 120  | 61   |
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | 21                              | 349  | 42   | 174  | 66   | 111  | 130  | 56   |
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | 22                              | 333  | 43   | 170  | 68   | 108  | 140  | 52   |
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | 23                              | 318  | 44   | 166  | 70   | 105  | 150  | 49   |
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | 24                              | 305  | 45   | 163  | 72   | 102  | 160  | 46   |
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | 25                              | 293  | 46   | 159  | 74   | 99   | 170  | 43   |
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | 26                              | 282  | 47   | 156  | 76   | 96   | 180  | 41   |
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | 27                              | 271  | 48   | 153  | 78   | 94   | 190  | 39   |
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | 28                              | 262  | 49   | 149  | 80   | 92   | 200  | 37   |
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | 29                              | 253  | 50   | 146  | 82   | 89   |      |      |
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | 30                              | 244  | 51   | 144  | 84   | 87   |      |      |




Gas Valve Adjustment

Changes can be made by adjusting the manifold pressure, or changing orifices (orifice change may not always be required). To adjust the manifold pressure:

1. Turn off all electrical power to the system.
2. Loosen (Do Not remove) the pressure tap test set screw one turn with 3/32" hex wrench.
  - a. The pressure tap adjustment kit (KIT07611) contains a 3/32" hex wrench, a 5/16" hose and a connector and can be ordered through Global Parts.
3. Attach a manifold pressure gauge with flexible tubing to the outlet pressure boss marked "OUT P" on White- Rodgers gas valve model 36J.
4. Turn on system power with NO call for heat.
5. Adjust 1st stage gas heat by removing the low (LO) adjustment regulator cover screw. For single stage furnaces, refer to top figure and remove the OUTLET regulator cover screw.
  - a. To increase outlet pressure, turn the regulator adjust screw clockwise.
  - b. To decrease outlet pressure, turn the regulator adjust screw counterclockwise.
  - c. Adjust regulator until pressure shown on manometer matches the pressure specified in the table.

The input of no more than nameplate rating and no less than 93% of the nameplate rating, unless the unit is derated for high altitude.
  - d. Replace and tighten the regulator cover screw securely.
6. Cycle the valve several times to verify regulator setting.
  - a. Repeat steps 5-7 if needed.
7. Turn off all electrical power to the system.
8. Remove the manometer and flexible tubing and tighten the pressure tap screw.
9. Using a leak detection solution or soap suds, check for leaks at the pressure outlet boss and pressure tap test screw.
10. Turn on system power and check operation of the unit.



| Maximum and Minimum INLET Pressure (inches w.c.)                                   |             |             |
|------------------------------------------------------------------------------------|-------------|-------------|
|                                                                                    | Natural Gas | Propane Gas |
| Maximum                                                                            | 13.8        | 13.8        |
| Minimum                                                                            | 5           | 11          |
| Maximum and Minimum Fuel Manifold Pressure Settings (inches w. c.) 2nd Stg/1st Stg |             |             |
| All models (A951X)                                                                 | 3.5         | 10          |
| Orifice sizes for Natural Gas and Propane                                          |             |             |
| All models (A951X)                                                                 | 45          | 56          |



## High Altitude Derate

| <p>Input ratings (BTUH) of these Furnaces are based on sea level operation and should not be changed at elevations up to 2,000 ft. (610 m).</p> <p>If the installation is 2,000 ft. (610 m) or above, the Furnace input rate (BTUH) shall be reduced 4% for each 1,000 ft. above sea level.</p> <p>Installations of this furnace at altitudes above 2,000 ft. (610 m) shall be made utilizing the Vent Length table and/or Part Numbers for Replacement Orifices table in these installation instructions. The Furnace input rate shall be checked by clocking the gas flow rate (CFH) and multiplying by the heating value obtained from the local utility supplier for the gas being delivered at the installed altitude. Input rate changes can be made by adjusting the Manifold Pressure (min 3.0 - max 3.7 in. W.C. - Natural Gas) or changing orifices (orifice change may not always be required).</p> <p>If the desired input rate can not be achieved with a change in Manifold Pressure, then the orifices must be changed. Propane installations will require an orifice change.</p> <p><b>Important:</b> <i>Reinstall the replacement orifices to the same depth as the orifices supplied with the equipment.</i></p> <p>See the table for help in selecting orifices if orifice change is required. Furnace input rate and temperature rise should be checked again after changing orifices to confirm the proper rate for the altitude.</p> <p>The vent length table shows the required vent lengths for installations at various altitudes. Optional high altitude kits are available for installations over 5000 feet. Installations above 12,000 feet are not allowed.</p> | <table><tr><th colspan="4">PART NUMBERS FOR REPLACEMENT ORIFICES</th></tr><tr><th>DRILL SIZE</th><th>PART NUMBER</th><th>DRILL SIZE</th><th>PART NUMBER</th></tr><tr><td>44</td><td>ORF00501</td><td>54</td><td>ORF00555</td></tr><tr><td>45</td><td>ORF00644</td><td>55</td><td>ORF00693</td></tr><tr><td>46</td><td>ORF00909</td><td>56</td><td>ORF00907</td></tr><tr><td>47</td><td>ORF00910</td><td>57</td><td>ORF00908</td></tr><tr><td>48</td><td>ORF01099</td><td>58</td><td>ORF01338</td></tr><tr><td>49</td><td>ORF00503</td><td>59</td><td>ORF01339</td></tr><tr><td>50</td><td>ORF00493</td><td></td><td></td></tr></table> | PART NUMBERS FOR REPLACEMENT ORIFICES |             |  |  | DRILL SIZE | PART NUMBER | DRILL SIZE | PART NUMBER | 44 | ORF00501 | 54 | ORF00555 | 45 | ORF00644 | 55 | ORF00693 | 46 | ORF00909 | 56 | ORF00907 | 47 | ORF00910 | 57 | ORF00908 | 48 | ORF01099 | 58 | ORF01338 | 49 | ORF00503 | 59 | ORF01339 | 50 | ORF00493 |  |  |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------|-------------|--|--|------------|-------------|------------|-------------|----|----------|----|----------|----|----------|----|----------|----|----------|----|----------|----|----------|----|----------|----|----------|----|----------|----|----------|----|----------|----|----------|--|--|
| PART NUMBERS FOR REPLACEMENT ORIFICES                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |                                       |             |  |  |            |             |            |             |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |  |  |
| DRILL SIZE                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | PART NUMBER                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | DRILL SIZE                            | PART NUMBER |  |  |            |             |            |             |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |  |  |
| 44                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | ORF00501                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | 54                                    | ORF00555    |  |  |            |             |            |             |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |  |  |
| 45                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | ORF00644                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | 55                                    | ORF00693    |  |  |            |             |            |             |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |  |  |
| 46                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | ORF00909                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | 56                                    | ORF00907    |  |  |            |             |            |             |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |  |  |
| 47                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | ORF00910                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | 57                                    | ORF00908    |  |  |            |             |            |             |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |  |  |
| 48                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | ORF01099                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | 58                                    | ORF01338    |  |  |            |             |            |             |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |  |  |
| 49                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | ORF00503                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | 59                                    | ORF01339    |  |  |            |             |            |             |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |  |  |
| 50                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | ORF00493                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |                                       |             |  |  |            |             |            |             |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |  |  |
| <p>Turn the main Gas Valve toggle switch within the unit to the "OFF" position. Turn the external gas valve to "ON". Purge the air from the gas lines. After purging, check all gas connections for leaks with a soapy solution – <b>DO NOT CHECK WITH AN OPEN FLAME</b>. Allow 5 minutes for any gas that might have escaped to dissipate.</p> <p>Propane Gas being heavier than air may require forced ventilation. Turn the toggle switch on the Gas Valve in the unit to the "ON" position.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |                                       |             |  |  |            |             |            |             |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |    |          |  |  |

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |                                                                |                                                                      |      |      |      |      |      |      |      |       |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------|----------------------------------------------------------------------|------|------|------|------|------|------|------|-------|
| <p>The table lists the main burner orifices used with the furnace. If a change of orifices is required to correct the furnace input rating refer to the part number for replacement orifices table.</p> <p>Installation of this furnace at altitudes above 2000 ft (610m) shall be in accordance with local codes, or in the absence of local codes, the <i>National Fuel Gas Code, ANSI Z223.1/NFPA 54</i> or <i>National Standard of Canada, Natural Gas and Propane Installation Code, CSA B149.1</i>. Installation of this furnace at altitudes above 2,000 ft (610 m) shall be made in accordance with the listed high altitude conversion kit available with the furnace.</p> | Orifice<br>Twist Drill<br>Size If<br>Installed at<br>Sea Level | Altitude Above Sea Level<br>and Orifice Required at Other Elevations |      |      |      |      |      |      |      |       |
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |                                                                | 2000                                                                 | 3000 | 4000 | 5000 | 6000 | 7000 | 8000 | 9000 | 10000 |
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | 42                                                             | 42                                                                   | 43   | 43   | 43   | 44   | 44   | 45   | 46   | 47    |
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | 43                                                             | 44                                                                   | 44   | 44   | 45   | 45   | 46   | 47   | 47   | 48    |
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | 44                                                             | 45                                                                   | 45   | 45   | 46   | 47   | 47   | 48   | 48   | 50    |
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | 45                                                             | 46                                                                   | 47   | 47   | 47   | 48   | 48   | 49   | 49   | 50    |
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | 46                                                             | 47                                                                   | 47   | 47   | 48   | 48   | 49   | 49   | 50   | 51    |
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | 47                                                             | 48                                                                   | 48   | 49   | 49   | 49   | 50   | 50   | 51   | 52    |
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | 54                                                             | 54                                                                   | 55   | 55   | 55   | 55   | 55   | 56   | 56   | 56    |
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | 55                                                             | 55                                                                   | 55   | 55   | 56   | 56   | 56   | 56   | 56   | 57    |
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | 56                                                             | 56                                                                   | 56   | 57   | 57   | 57   | 58   | 59   | 59   | 60    |
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | 57                                                             | 58                                                                   | 59   | 59   | 60   | 60   | 61   | 62   | 63   | 63    |
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | 58                                                             | 59                                                                   | 60   | 60   | 61   | 62   | 62   | 63   | 63   | 64    |
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | From National Fuel Gas Code — Table E.1.1(d)                   |                                                                      |      |      |      |      |      |      |      |       |

General Venting


|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>FURNACE EXHAUST MUST BE VENTED TO THE OUTDOORS. THESE FURNACES ARE INDUCED DRAFT VENTED AND MUST <b>NOT</b> BE CONNECTED TO ANY VENT SERVING ANOTHER APPLIANCE. PLEASE NOTE THAT THESE FURNACES USE <b>POSITIVE-PRESSURE</b> VENT SYSTEMS.</p> <p>Proper venting is essential to obtain maximum efficiency from a condensing Furnace. Proper installation of the vent system is necessary to assure drainage of the condensate and prevent deterioration of the vent system.</p> <p>ETL has certified the design of condensing Furnaces for a minimum of 0" clearance from combustible materials to single wall plastic vent pipe.</p> <p>The recommended system is assembled from 2" or 3" plastic pipe and fittings found in the Approved Vent Pipe Materials Table. Where the system is routed to the outdoors through an existing masonry chimney containing flue products from another gas appliance, or where required by local codes, then 3" venting of Type 29- 4C stainless steel must be used in place of PVC material.</p> <p>These Furnaces have been classified as CATEGORY IV Furnaces in accordance with ANSI Z21.47 "latest edition" standards. Category IV - a central furnace that operates with a positive vent static pressure and with a flue loss less than 17 percent. These conditions require special venting systems, which must be gas tight and water tight.</p> | <p><b>Note:</b> When an existing Furnace is removed from a venting system serving other gas appliances, the venting system is likely to be too large to properly vent the <u>remaining attached appliances</u>.</p> <p><b>Important:</b> These Furnaces may be installed as Direct Vent (sealed combustion) or as Nondirect Vent (single pipe). The Furnaces are shipped <b>DIRECT VENT</b> with sealed combustion.</p> <p><b>Important:</b> Products installed in Canada must use vent systems that are certified to the Standard for Type BH Gas Venting Systems (ULC S636) for Class II-A venting systems (up to 65°C). Components of the vent system must not be interchanged with other vent systems or unlisted pipe or fittings. Plastic components, specified primers, and glues must be from a single system manufacturer and not intermixed with other system manufacturer's vent system parts. In addition, the first three feet of the vent pipe must be visible for inspection.</p> <p><b>When the vent pipe is exposed to temperatures below freezing, e.g., when it passes through unheated spaces, etc., the pipe must be insulated with 1/2 inch (12.7 mm) thick Armaflex-type insulation or equal.</b></p> <p><b>If the space is heated sufficiently to prevent freezing, then the insulation will not be required. If domestic water pipes are not protected from freezing then the space meets the condition of a heated space.</b></p> |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>3" Venting requirements</p> <p><b>Important:</b> To determine if your application requires 3" venting, see the Maximum Vent Length Table.</p> <p><b>Important:</b> Horizontal venting application must use the 2" x 3" offset reducing coupling. Vertical venting applications do not require the reducing coupling to be offset.</p> <p><b>Note:</b> If your furnace comes with a factory supplied 2" X 3" offset reducing coupling it is used for 3" vent pipe installation. Make sure the marking "TOP" is located on the top side of the pipe in horizontal venting applications. The straight side of the coupling must be on bottom for proper drainage of condensate</p> <p><b>Note:</b> For Canadian applications, BAYREDUCE 2" x 3" offset reducing coupling meets ULC-S636 requirements. Make sure the marking "TOP" is located on the top side of the pipe. The straight side of the coupling must be on bottom for proper drainage of condensate in horizontal venting.</p> | <div><p><b>LABEL SAYS "TOP"</b></p><p>CPL01544<br/>2" TO 3" COUPLING</p><p>BAYREDUCE may be used in Canadian applications to meet ULC-S636</p><p>CPL01544 IS FACTORY SUPPLIED ONLY WITH THE 120,000 BTUH FURNACE MODELS</p></div> <div><p>CPL01544<br/>2" TO 3" COUPLING</p><p>BAYREDUCE may be used in Canadian applications to meet ULC-S636</p><p>CPL01544 IS FACTORY SUPPLIED ONLY WITH THE 120,000 BTUH FURNACE MODELS</p></div> |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|


## Typical Venting

This combustion air intake has a built-in condensate collection system. Condensate that may collect is drained by field supplied 1/2" ID tubing. The tubing must be routed to form a trap and water seal (see Figure 1, p. 30, Figure 2, p. 30, and Figure 3, p. 30). A field supplied hose clamp is recommended but not be required. The tubing is not under pressure. Combustion air piping must be square cut and de-burred for proper drainage. For side entry combustion inlet applications, ensure the drain is pointed downwards.


**Figure 1. Upflow Top Entry**






**Figure 2. Horizontal Top Entry**



**Figure 3. Upflow Side Entry**





Special Case Venting

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p><b>Special instructions for direct vent furnace air intake.</b></p> <p>In certain applications, particularly when the furnace is located in a basement, there are certain conditions that can be met where warm humid air from the outside is drawn into combustion air piping. If the area where the piping is located is conditioned below 70° F, condensation could occur inside the piping and ultimately drain into the furnace compartment, which could lead to premature component failure.</p> <p>We recommend following one of the options to prevent this condition from occurring and possibly damaging components within the furnace:</p>                                                                                                                                                                                                                     | <p><b>Note:</b> Inlet air piping is not considered to be part of the venting system. The inlet air piping may be made from PVC.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <p><b>Option 1</b></p> <p>If possible, slope the inlet combustion air piping away from the furnace. Condensation that may occur will now drain outside of the home. The combustion air outlet piping must remain sloped back to the furnace.</p> <p><b>Note:</b> Combustion air drain fitting must remain capped if not using the drain function. See "Condensate Drain Instructions," p. 57 section.</p> <p>Option 1</p>  <p>Combustion air exhaust</p> <p>Combustion air intake</p> <p>Slope equals 1/4" per foot</p> <p>Primary drain vent stack must terminate below the bottom of the condensate trap</p> <p>To an approved vented drain</p>                                                                                                                                          | <p><b>Option 3 — Side combustion air intake</b></p> <p>If sloping the combustion air intake pipe is not possible, install an approved DWV Tee as close to the furnace as possible with drain and trap.</p> <p><b>Note:</b> Combustion air drain fitting must remain capped if not using the drain function. See "Condensate Drain Instructions," p. 57 section.</p> <p>Option 3</p>  <p>Combustion air intake</p> <p>Combustion air exhaust</p> <p>Approved DWV Tee</p> <p>Field fabricated trap</p> <p>Primary drain vent stack must terminate below the bottom of the condensate trap</p> <p>To an approved vented drain</p> |
| <p><b>Option 2 — Top combustion air intake</b></p> <p>If sloping the combustion air intake pipe is not possible, install a DWV Tee as close to the furnace as possible with drain and trap to prevent condensation from occurring in the furnace cabinet. Do not tee AC condensate and combustion air condensate trap together.</p> <p><b>Note:</b> Combustion air drain fitting must remain capped if not using the drain function. See "Condensate Drain Instructions," p. 57 section.</p> <p>Option 2</p>  <p>Slope equals 1/4" per foot</p> <p>Combustion air exhaust</p> <p>Combustion air intake</p> <p>Approved DWV Tee</p> <p>Field fabricated trap</p> <p>Primary drain vent stack must terminate below the bottom of the condensate trap</p> <p>To an approved vented drain</p> |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |

## Vent Terminations

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                                                                                                                               |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>For <b>DIRECT VENT APPLICATION:</b> The Furnaces must be vented to the exterior of the house and combustion air <b>MUST</b> come through the inlet air pipe from OUTSIDE AIR.</p> <p><b>Note:</b> BAYVENT* accessories can be used for inlet and outlet terminals when the pipes do not exit the structure together. For Canadian applications, venting systems must meet ULC-S636 requirements.</p> <p>For <b>NONDIRECT VENT APPLICATION:</b> The Furnace shall be vented to the exterior of the house, but combustion air may enter from the surrounding area as long as combustion air requirements are met. (See AIR FOR COMBUSTION AND VENTILATION)</p> | <p>Vent terminations</p> <ul style="list-style-type: none"> <li>• BAYVENT200B</li> <li>• BAYAIR30AVENTA</li> </ul> <p>Vent terminations — Canadian applications. Meets ULC-S636 requirements.</p> <ul style="list-style-type: none"> <li>• BAYVENTCN200B</li> <li>• BAYAIR30CNVENT</li> </ul> |
| <p><b>FURNACE VENT / INLET PIPE INSTALLATION IN TWO PRESSURE ZONE CONFIGURATIONS ARE NOT ALLOWED</b></p> <p><b>Note:</b> For single pressure zone applications, see the Horizontal Venting section.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                         |                                                                                                                                                                                                                                                                                               |

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |                                                                                      |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|
| <p>The following are <b>EXAMPLES ONLY</b>.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |                                                                                      |
| <p><b>EX. 1 —</b></p> <p>Example 1 shows the vent pipe exhausting through the roof and the inlet air coming from the interior of the house. The inlet air coming from the interior of the house must meet combustion requirements for area, etc., as shown in the section AIR FOR COMBUSTION AND VENTILATION in this document.</p> <p><b>Note:</b> If only the flue gas pipe is to the outside of the structure, a straight section of pipe (long enough to exit the Furnace cabinet) must be attached to the inlet air side with an elbow (which is 5 to 10 equiv. ft.) installed on the end to prevent dust and debris from falling directly into the Furnace.</p> |   |
| <p><b>EX. 2 —</b></p> <p>The inlet air does not have to come from outside the structure. Example 2 shows the inlet air, may come from the attic if the requirements for combustion air are met as shown in the section AIR FOR COMBUSTION AND VENTILATION.</p> <p><b>Note:</b> If only the flue gas pipe is to the outside of the structure, a straight section of pipe (long enough to exit the Furnace cabinet) must be attached to the inlet air side with an elbow (which is 5 to 10 equiv. ft.) installed on the end to prevent dust and debris from falling directly into the Furnace.</p>                                                                     |  |

## Attaching Vent Piping

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p><b>VENT FITTING MATERIAL – PLASTIC</b></p> <p>Gas and liquid tight single wall vent fittings, designed for resistance to corrosive flue condensate, <b>MUST</b> be used throughout. Listed in the Approved Vent Pipe Materials table are designations for different types of 2" and 3" size pipe and fittings that meet these requirements. The materials listed are various grades of PVC, CPVC, ABS, PolyPro® by DuraVent, Z-Dens by Novaflex Group, Innoflue® by Centrotherm, ECCO™ polypropylene venting system, and PolyFlue™ polypropylene venting systems.</p> |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p><b>ATTACHING VENT PIPING</b></p> <p><b>Important:</b> Products installed in Canada must use vent systems that are certified to the Standard for Type BH Gas Venting Systems (ULC S636) for Class II-A venting systems (up to 65°C). Components of the vent system must not be interchanged with other vent systems or unlisted pipe or fittings. Plastic components, specified primers, and glues must be from a single system manufacturer and not intermixed with other system manufacturer's vent system parts. In addition, the first three feet of the vent pipe must be visible for inspection.</p> <p><b>PIPE JOINTS:</b> All joints must be fastened and sealed per manufacturer instructions and local and national codes to prevent escape of combustion products into the building.</p> |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

## MANUFACTURED MODULAR VENTING SYSTEMS

**⚠ WARNING****CARBON MONOXIDE POISONING HAZARD!**

Failure to follow this Warning may result in property damage, severe personal injury, or death.

See the Approved Vent Pipe Materials table for manufactured modular venting systems that are approved for use with this product. Follow the manufacturer's installation instructions when installing the venting system.

**⚠ WARNING****CARBON MONOXIDE POISONING HAZARD!**

Failure to follow this Warning may result in property damage, severe personal injury, or death.

Do not use cement on polypropylene venting systems. Follow the manufacturer's installation instructions when installing the venting system.

For manufactured modular venting systems that are approved with this product see PVC vent fitting material table. Do not drill into polypropylene venting pipes

## BONDING OF PVC

**Note:** It is recommended that the first joints from the Furnace be connected and sealed with high temperature RTV. This will enable the pipes to be removed later without cutting.

Be sure to properly support these joints.

Commercially available solvent cement for PVC must be used to join PVC pipe fittings. Follow instructions on container carefully.

Pipe and Fitting – ASTM D1785, D2466, D2661, & D2665

PVC Primer and Solvent Cement – ASTM D2564

Procedure for Cementing Joints – Ref ASTM D2855


1. Cut pipe square, remove ragged edges and burrs. Chamfer end of pipe, then clean fitting socket and pipe joint area of all dirt, grease, moisture or chips.
2. After checking pipe and socket for proper fit, wipe socket and pipe with cleaner-primer. Apply a liberal coat of primer to inside surface of socket and outside of pipe.  
DO NOT ALLOW PRIMER TO DRY BEFORE APPLYING CEMENT.
3. Apply a thin coat of cement evenly in the socket. Quickly apply a heavy coat of cement to the pipe end and insert pipe into fitting with a slight twisting movement until it bottoms out.
4. Hold the pipe in the fitting for 30 seconds to prevent tapered socket from pushing the pipe out of the fitting.
5. Wipe all excess cement from the joint with a rag. Allow 15 minutes before handling. Cure time varies according to fit, temperature and humidity.

Connection of the pipe and collar of the combustion air inlet should just be a friction fit. It is recommended that the inlet air joint be sealed with RTV type sealant to allow the joint to be separated for possible future service. The inlet and vent pipes must be properly supported throughout the entire length.

**Note:** Follow venting instructions carefully when using PVC cement.

**Important:** All joints must be water tight. Flue condensate is somewhat acidic, and leaks can cause equipment damage.

Seal INLET AIR PIPE with RTV sealant



## APPROVED VENT PIPE MATERIALS

## PVC VENT FITTING MATERIAL

These fittings are available from your Gas Furnace Distributors.

## ANSI/UL 1738 APPROVED VENT PIPE MATERIAL

| ASTM STANDARD | PIPE TYPE | ALLOWABLE TEMPERATURE °F | MARKING |
|---------------|-----------|--------------------------|---------|
| N/A           | N/A       | 158                      | UL 1738 |

## PVC

| ASTM STANDARD | PIPE TYPE       | ALLOWABLE TEMPERATURE °F | MARKING    |
|---------------|-----------------|--------------------------|------------|
| D2665         | DWV PIPE        | 158                      | ASTM D2665 |
| D1785         | SCH 40, 80, 120 | 158                      | ASTM 1785  |
| D2241         | SDR SERIES      | 158                      | ASTM D2241 |

## CPVC

| ASTM STANDARD | PIPE TYPE  | ALLOWABLE TEMPERATURE °F | MARKING    |
|---------------|------------|--------------------------|------------|
| D2846         | CPVC 41    | 212                      | ASTM D2846 |
| F441          | SCH 40, 80 | 212                      | ASTM F441  |

| F442                                                                                                                                                                            | SDR SERIES | 212                      | ASTM F442  |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------|--------------------------|------------|
| ABS                                                                                                                                                                             |            |                          |            |
| ASTM STANDARD                                                                                                                                                                   | PIPE TYPE  | ALLOWABLE TEMPERATURE °F | MARKING    |
| D2661                                                                                                                                                                           | SCH 40 DWV | 180                      | ASTM D2661 |
| PolyPro® by DuraVent, Z-Dens by Novaflex Group, Innoflue® by Centrotherm, System 1738 by IPEX, ECCO™ polypropylene venting system, and PolyFlue™ polypropylene venting systems. |            |                          |            |
| ASTM STANDARD                                                                                                                                                                   | PIPE TYPE  | ALLOWABLE TEMPERATURE °F | MARKING    |
| N/A                                                                                                                                                                             | N/A        | 230                      | ULC-S636   |

**Note:** Beginning March 1, 2024, PVC Cellular Core and ABS Cellular Core vent materials are not approved.

# Maximum Vent Length Table A951X

| Maximum Vent Length Table                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | Maximum Total Equivalent Length In Feet<br>for Vent and Inlet Air (See Notes) |                       |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------|-----------------------|
| Model                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | 2 Inch or 2.5 Inch Pipe                                                       | 3 Inch or 4 Inch Pipe |
| Altitude 0–2,000 Feet                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |                                                                               |                       |
| A951X040BU3SAC, A951X040BD3SAC,<br>A951X060BD3SAC, A951X060BU4SAC                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | 200                                                                           | 200                   |
| A951X080BU4SAC, A951X080BD4SAC,<br>A951X080CU5SAC                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | 100                                                                           | 200                   |
| A951X100CU5SAC, A951X100CD5SAC                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | 50                                                                            | 200                   |
| A951X120DU5SAC, A951X120DD5SAC                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | Note 1                                                                        | 200                   |
| Altitude 2,001–5,400 Feet                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |                                                                               |                       |
| A951X040BU3SAC, A951X040BD3SAC,<br>A951X060BD3SAC, A951X060BU4SAC                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | 200                                                                           | 200                   |
| A951X080BU4SAC, A951X080BD4SAC,<br>A951X080CU5SAC                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | 80                                                                            | 120                   |
| A951X100CU5SAC, A951X100CD5SAC                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | 50                                                                            | 150                   |
| A951X120DU5SAC, A951X120DD5SAC                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | Note 1                                                                        | 200                   |
| Altitude 5,401–7,800 Feet                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |                                                                               |                       |
| A951X040BU3SAC, A951X040BD3SAC,<br>A951X060BD3SAC, A951X060BU4SAC                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | 100                                                                           | 150                   |
| A951X080BU4SAC, A951X080BD4SAC,<br>A951X080CU5SAC                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | 50                                                                            | 70                    |
| A951X100CU5SAC, A951X100CD5SAC                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | Note 1                                                                        | 100                   |
| A951X120DU5SAC, A951X120DD5SAC                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | Note 1                                                                        | 100                   |
| Altitude 7,801–10,100 Feet                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |                                                                               |                       |
| A951X040BU3SAC, A951X040BD3SAC,<br>A951X060BD3SAC, A951X060BU4SAC                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | 50                                                                            | 90                    |
| A951X080BU4SAC, A951X080BD4SAC,<br>A951X080CU5SAC                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | Note 1                                                                        | 50                    |
| A951X100CU5SAC, A951X100CD5SAC                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | Note 1                                                                        | 50                    |
| A951X120DU5SAC, A951X120DD5SAC                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | Note 1                                                                        | 50                    |
| Notes:                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |                                                                               |                       |
| <ol style="list-style-type: none"> <li>Not allowed</li> <li>For PolyPro® by Duravent, Z-DENS by Novaflex Group, InnoFlue® by Centrotherm, ECCO™ polypropylene venting system, and Polyflue™ manufactured modular venting systems that are in the approved vent pipe material table, fitting equivalent vent lengths may be different from what is shown in Note 6. Refer to the venting system manufacturer's installation instruction for appropriate venting diameters and equivalent lengths.</li> <li>Minimum vent length for all models: 15' equivalent.</li> <li>DO NOT MIX PIPE DIAMETERS IN THE SAME LENGTH OF PIPE OUTSIDE THE FURNACE CABINET (Except adapters at the top of the furnace). If different inlet and vent pipe sizes are used, the vent pipe must adhere to the maximum length limit shown in the table above (See note 7 below for exception). The inlet pipe can be of a larger diameter, but never smaller than the vent pipe.</li> <li>MAXIMUM PIPE LENGTHS MUST NOT BE EXCEEDED! THE LENGTH SHOWN IS NOT A COMBINED TOTAL, IT IS THE MAXIMUM LENGTH OF EACH (Vent or Inlet air pipes).</li> <li>One SHORT radius 90° elbow is equivalent to 10' of 4" pipe, 10' of 3" pipe, or 8' of 2" pipe. One LONG radius elbow is equivalent to 6' of 4" pipe, 7' of 3" pipe, or 5' of 2" pipe. Two 45° elbows equal one 90° LONG elbow. One MITERED elbow is equivalent to 12' of 3" pipe or 12' of 2" pipe.</li> <li>The termination tee or bend must be included in the total number of elbows. If the BAYAIR30AVENTA or BAYAIR30CNVENT termination kit is used, the equivalent length of pipe is 5 feet. For BAYVENT200B and BAYVENTCN200B the equivalent length is 0 feet.</li> <li>For Canadian applications, venting systems must meet ULC-S636 requirements.</li> <li>The INLET AIR of one pipe systems require the installation of a minimum of one 90° elbow (to prevent dust and debris from falling straight into the furnace).</li> </ol> |                                                                               |                       |



# Horizontal Venting

**Note:** Insure that vent piping is sloped 1/4" per foot and that piping is supported properly to prevent sags and condensate pooling.

3" Venting requirements


**Important:** To determine if your application requires 3" venting, see the Maximum Vent Length Table.

**Important:** Horizontal venting application must use the 2" x 3" offset reducing coupling. Vertical venting applications do not require the reducing coupling to be offset.


**When the vent pipe is exposed to temperatures below freezing, e.g., when it passes through unheated spaces, etc., the pipe must be insulated with 1/2 inch (12.7 mm) thick Armaflex-type insulation or equal.**

**If the space is heated sufficiently to prevent freezing, then the insulation will not be required. If domestic water pipes are not protected from freezing then the space meets the condition of a heated space.**

**Note:** If your furnace comes with a factory supplied 2" X 3" offset reducing coupling it is used for 3" vent pipe installation. Make sure the marking "TOP" is located on the top side of the pipe in horizontal venting applications. The straight side of the coupling must be on bottom for proper drainage of condensate.




**Note:** For Canadian applications, BAYREDUCE 2" x 3" offset reducing coupling meets ULC-S636 requirements. Make sure the marking "TOP" is located on the top side of the pipe. The straight side of the coupling must be on bottom for proper drainage of condensate in horizontal venting.



## COMBUSTIBLE MATERIAL WALL

A minimum clearance of 1" to combustible materials must be maintained when using single wall stainless steel venting. Shield material to be a minimum of 24 gauge stainless or aluminized sheet metal. Minimum dimensions are 12"x12". Shield must be fastened to both inside and outside of wall. Use screws or anchor type fasteners suited to the outside or inside wall surfaces.



## NONCOMBUSTIBLE MATERIAL WALL

The hole through the wall must be large enough to maintain pitch of vent and properly seal. Use cement mortar seal on inside and outside of wall.




Table 6. Horizontal Venting Through Wall

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |  |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|
| <p>The vent for this appliance shall not terminate</p> <ol style="list-style-type: none"><li>Over public walkways; or</li><li>Near soffit vents or crawl space vents or other areas where condensate or vapor could create a nuisance or hazard or cause property damage; or</li><li>Where condensate vapor could cause damage or could be detrimental to the operation of regulators, relief valves, or other equipment.</li></ol>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |  |
| <p><b>Possible configurations for two pipe venting systems located in the same pressure zone.</b></p> <p><b>Important:</b> Maintain 12" minimum clearance above highest anticipated snow level or grade, whichever is greater.</p> <p><b>Note:</b> All distances are centerline to centerline.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |  |
| <div><p>12" Min.<br/>15" Max.</p><p>6" Min.<br/>24" Max.</p><p>INLET</p><p>VENT</p><p>9" Minimum<br/>minimum from end<br/>of exhaust pipe to<br/>end of inlet pipe</p><p>4" MAX.</p></div> <div><p>12" Min.<br/>15" Max.</p><p>6" Min.<br/>24" Max.</p><p>INLET</p><p>VENT</p><p>9" Minimum<br/>minimum from end<br/>of exhaust pipe to<br/>end of inlet pipe</p><p>5" MAX.</p></div> <div><p>12" Min.<br/>15" Max.</p><p>6" Min.<br/>24" Max.</p><p>INLET</p><p>VENT</p><p>9" Minimum<br/>minimum from end<br/>of exhaust pipe to<br/>end of inlet pipe</p><p>6" MAX.</p></div> <div><p>12" Min.<br/>15" Max.</p><p>6" Min.<br/>24" Max.</p><p>INLET</p><p>VENT</p><p>9" Minimum<br/>minimum from end<br/>of exhaust pipe to<br/>end of inlet pipe</p><p>4" Min.<br/>24" Max.</p></div> <div><p>Elbow and Tee<br/>Must be as close<br/>together as<br/>possible</p><p>12" Min.<br/>15" Max.</p><p>6" Min.<br/>24" Max.</p><p>INLET</p><p>VENT</p><p>9" Minimum<br/>minimum from end<br/>of exhaust pipe to<br/>end of inlet pipe</p><p>4" Min.<br/>24" Max.</p></div> <div><p>12" Min.<br/>15" Max.</p><p>6" Min.<br/>24" Max.</p><p>INLET</p><p>VENT</p><p>9" Minimum<br/>minimum from end<br/>of exhaust pipe to<br/>end of inlet pipe</p><p>6" Max.<br/>to wall</p></div> <div><p>12" Min.<br/>15" Max.</p><p>6" Min.<br/>24" Max.</p><p>INLET</p><p>VENT</p><p>9" Minimum<br/>minimum from end<br/>of exhaust pipe to<br/>end of inlet pipe</p><p>12" Min. between<br/>inlet and vent<br/>terminations</p></div> |  |

## Horizontal Venting Through Wall with Concentric Vent Kit

**These Furnaces may be installed as direct vent (as shipped) or as nondirect vent. Installation must conform to national, state, and local codes.**

The BAYVENT200B, BAYVENTCN200B, BAYAIR30AVENTA, and BAYAIR30CNVENT vent & inlet terminals kits must be located at least 12" minimum above normally expected snow accumulation level.

Avoid areas where staining or condensate drippage may be a problem.

Location of the vent/wind terminal should be chosen to meet the requirements for either direct or non-direct vent applications.

**PITCH** — Venting through the wall must maintain 1/4" per foot pitched upward to insure that condensate drains back to the Furnace.

**FLUE GAS DEGRADATION** — The moisture content of the flue gas may have a detrimental effect on some building materials.

This can be avoided by using the roof or chimney venting option. When wall venting is used on any surface that can be affected by moisture, it is recommended that a corrosion resistant shield (24 inches square) be used behind the vent terminal.

This shield can be wood, plastic, sheet metal, etc. Also, silicone caulk all cracks, seams and joints within 3 feet of the vent terminal.

*The vent for this appliance shall not terminate*


1. Over public walkways; or
2. Near soffit vents or crawl space vents or other areas where condensate or vapor could create a nuisance or hazard or cause property damage; or
3. Where condensate vapor could cause damage or could be detrimental to the operation of regulators, relief valves, or other equipment.

For Canadian installations, if you used a ULC-S636 approved manufactured modular venting system, a copy of the manufacturer's instructions should remain with the system.


The installation instruction can be obtained from the vent termination manufacturer. BAYVENTCN200B and BAYAIR30CNVENT meet ULC-S636 requirements.

### BAYVENT200B / BAYVENTCN200B

**Note:** For Canadian applications, horizontal vent termination kits must meet ULC-S636.



### BAYAIR30AVENTA / BAYAIR30CNVENT(Sidewall)



## Furnace General Installation

**Important:** The Commonwealth of Massachusetts requires compliance with regulation 248 CMR 4.00 and 5.00 for installation of through – the – wall vented gas appliances as follows:


For all side wall horizontally vented gas fueled equipment installed in every dwelling, building or structure used in whole or in part for residential purposes, including those owned or operated by the Commonwealth and where the side wall exhaust vent termination is less than seven (7) feet above finished grade in the area of the venting, including but not limited to decks and porches, the following requirements shall be satisfied:

1. **INSTALLATION OF CARBON MONOXIDE DETECTORS.** At the time of installation of the side wall horizontal vented gas fueled equipment, the installing plumber or gasfitter shall observe that a hard wired carbon monoxide detector with an alarm and battery back-up is installed on the floor level where the gas equipment is to be installed. In addition, the installing plumber or gasfitter shall observe that a battery operated or hard wired carbon monoxide detector with an alarm is installed on each additional level of the dwelling, building or structure served by the side wall horizontal vented gas fueled equipment. It shall be the responsibility of the property owner to secure the services of qualified licensed professionals for the installation of hard wired carbon monoxide detectors.
  - a. In the event that the side wall horizontally vented gas fueled equipment is installed in a crawl space or an attic, the hard wired carbon monoxide detector with alarm and battery back-up may be installed on the next adjacent floor level.
  - b. In the event that the requirements of this subdivision can not be met at the time of completion of installation, the owner shall have a period of thirty (30) days to comply with the above requirements; provided, however, that during said thirty (30) day period, a battery operated carbon monoxide detector with an alarm shall be installed.
2. **APPROVED CARBON MONOXIDE DETECTORS.** Each carbon monoxide detector as required in accordance with the above provisions shall comply with NFPA 720 and be ANSI/UL 2034 listed and IAS certified.
3. **SIGNAGE.** A metal or plastic identification plate shall be permanently mounted to the exterior of the building at a minimum height of eight (8) feet above grade directly in line with the exhaust vent terminal for the horizontally vented gas fueled heating appliance or equipment. The sign shall read, in print size no less than one-half (1/2) inch in size, "GAS VENT DIRECTLY BELOW. KEEP CLEAR OF ALL OBSTRUCTIONS".
4. **INSPECTION.** The state or local gas inspector of the side wall horizontally vented gas fueled equipment shall not approve the installation unless, upon inspection, the inspector observes carbon monoxide detectors and signage installed in accordance with the provisions of 248 CMR 5.08(2) (a)1 through 4.

This appliance requires a special venting system. If BAYAIR30AVENTA or BAYVENT200B are used, a copy of the installation instructions for the kit shall remain with the appliance or equipment at the completion of installation. The venting system installation instructions can be obtained from the manufacturer by writing to the following address:

Trane and American Standard  
6200 Troup Highway  
Tyler, TX 75707  
Attention: Manager of Field Operations Excellence

## Horizontal Vent Clearances





| Non-Direct Vent Termination Clearances                                                                                                                                                                                                                                                                                                                                                                                                                                             |                                                                                                                                                        |                                                                                                                                           |                                                                                                                                                                                                |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |                                                                                                                                                        | Canadian Installations                                                                                                                    | US Installations                                                                                                                                                                               |
| A=                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | Clearance above grade, veranda, porch, deck, or balcony                                                                                                | 12 inches (30 cm)                                                                                                                         | 12 inches (30 cm)                                                                                                                                                                              |
| B=                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | Clearance to window or door that may be opened                                                                                                         | 12 inches (30 cm) for appliances > 10,000 BTUH (3 kw) and ≤ 100,000 BTUH (30 kw), 36 inches (91 cm) for appliances > 100,000 BTUH (30 kw) | 4 feet (1.2m) below or to the side of opening; 1 foot (0.3m) above opening                                                                                                                     |
| C=                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | Clearance to permanently closed window                                                                                                                 | *                                                                                                                                         | *                                                                                                                                                                                              |
| D=                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | Vertical clearance to ventilated soffit located above the terminal within a horizontal distance of 2 feet (61 cm) from the center line of the terminal | *                                                                                                                                         | *                                                                                                                                                                                              |
| E=                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | Clearance to unventilated soffit                                                                                                                       | *                                                                                                                                         | *                                                                                                                                                                                              |
| F=                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | Clearance to outside corner                                                                                                                            | *                                                                                                                                         | *                                                                                                                                                                                              |
| G=                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | Clearance to inside corner                                                                                                                             | *                                                                                                                                         | *                                                                                                                                                                                              |
| H=                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | Clearance to each side of center line extended above meter/regulator assembly                                                                          | 3 feet (91 cm) with a height 15 feet (4.5 m) above the meter/regulator assembly                                                           | *                                                                                                                                                                                              |
| I=                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | Clearance to service regulator vent outlet                                                                                                             | 3 feet (91 cm)                                                                                                                            | *                                                                                                                                                                                              |
| J=                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | Clearance to nonmechanical air supply inlet to building or the combustion air inlet to any other appliance                                             | 12 inches (30 cm) for appliances > 10,000 BTUH (3 kw) and ≤ 100,000 BTUH (30 kw), 36 inches (91 cm) for appliances > 100,000 BTUH (30 kw) | 4 feet (1.2 m) below or to side of opening; 1 foot (300 m) above opening                                                                                                                       |
| K=                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | Clearance to a mechanical air supply inlet                                                                                                             | 6 feet (1.83m)                                                                                                                            | 3 feet (91 cm) above if within 10 feet (3m) horizontally                                                                                                                                       |
| L=                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | Clearance above a paved sidewalk or paved driveway located on public property                                                                          | 7 feet (2.13 m) and not located above public walkways or other areas where condensate or vapor can cause a nuisance or hazard             | 7 feet (2.13 m) and not located above public walkways or other areas where condensate or vapor can cause a nuisance or hazard                                                                  |
| M=                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | Clearance under veranda, porch, deck, or balcony                                                                                                       | 12 inches (30 cm) if veranda, porch, deck, or balcony is fully open on a minimum of two sides beneath the floor                           | 12 inches (30 cm) where the area beneath the veranda, porch, deck, or balcony is open on not less than two sides. The vent terminal is prohibited in this location where only one side is open |
| <b>Notes:</b><br>1. The Canadian venting installations must be in accordance with local codes or in the absence of local codes with the current CSA B149.1 Natural Gas and Propane Installation Code.<br>2. The US venting installations must be in accordance with local codes or in the absence of local codes with the current ANSI Z223.1/NFPA 54 National Fuel Gas Code.<br>* Clearance in accordance with local installation codes and the requirements of the gas supplier. |                                                                                                                                                        |                                                                                                                                           |                                                                                                                                                                                                |

## Furnace General Installation




| Direct Vent Termination Clearances                                                                                                                                                   |                                                                                                                                                        |                                                                                                                                           |                                                                                                                                                                                                |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                                                      |                                                                                                                                                        | Canadian Installations                                                                                                                    | US Installations                                                                                                                                                                               |
| A=                                                                                                                                                                                   | Clearance above grade, veranda, porch, deck, or balcony                                                                                                | 12 inches (30 cm)                                                                                                                         | 12 inches (30 cm)                                                                                                                                                                              |
| B=                                                                                                                                                                                   | Clearance to window or door that may be opened                                                                                                         | 12 inches (30 cm) for appliances > 10,000 BTUH (3 kw) and ≤ 100,000 BTUH (30 kw), 36 inches (91 cm) for appliances > 100,000 BTUH (30 kw) | 9 inches (23 cm) for appliances > 10,000 BTUH (3 kw) and ≤ 50,000 BTUH (15 kw), 12 inches (30 cm) for appliances > 50,000 BTUH (15 kw)                                                         |
| C=                                                                                                                                                                                   | Clearance to permanently closed window                                                                                                                 | *                                                                                                                                         | *                                                                                                                                                                                              |
| D=                                                                                                                                                                                   | Vertical clearance to ventilated soffit located above the terminal within a horizontal distance of 2 feet (61 cm) from the center line of the terminal | *                                                                                                                                         | *                                                                                                                                                                                              |
| E=                                                                                                                                                                                   | Clearance to unventilated soffit                                                                                                                       | *                                                                                                                                         | *                                                                                                                                                                                              |
| F=                                                                                                                                                                                   | Clearance to outside corner                                                                                                                            | *                                                                                                                                         | *                                                                                                                                                                                              |
| G=                                                                                                                                                                                   | Clearance to inside corner                                                                                                                             | *                                                                                                                                         | *                                                                                                                                                                                              |
| H=                                                                                                                                                                                   | Clearance to each side of center line extended above meter/regulator assembly                                                                          | 3 feet (91 cm) with a height 15 feet (4.5 m) above the meter/regulator assembly                                                           | *                                                                                                                                                                                              |
| I=                                                                                                                                                                                   | Clearance to service regulator vent outlet                                                                                                             | 3 feet (91 cm)                                                                                                                            | *                                                                                                                                                                                              |
| J=                                                                                                                                                                                   | Clearance to nonmechanical air supply inlet to building or the combustion air inlet to any other appliance                                             | 12 inches (30 cm) for appliances > 10,000 BTUH (3 kw) and ≤ 100,000 BTUH (30 kw), 36 inches (91 cm) for appliances > 100,000 BTUH (30 kw) | 9 inches (23 cm) for appliances > 10,000 BTUH (3 kw) and ≤ 50,000 BTUH (15 kw); 12 inches (30 cm) for appliances > 50,000 BTUH (15 kw)                                                         |
| K=                                                                                                                                                                                   | Clearance to a mechanical air supply inlet                                                                                                             | 6 feet (1.83m)                                                                                                                            | 3 feet (91 cm) above if within 10 feet (3m) horizontally                                                                                                                                       |
| L=                                                                                                                                                                                   | Clearance above a paved sidewalk or paved driveway located on public property                                                                          | 7 feet (2.13 m) and not located above public walkways or other areas where condensate or vapor can cause a nuisance or hazard             | 7 feet (2.13 m) and not located above public walkways or other areas where condensate or vapor can cause a nuisance or hazard                                                                  |
| M=                                                                                                                                                                                   | Clearance under veranda, porch, deck, or balcony                                                                                                       | 12 inches (30 cm) if veranda, porch, deck, or balcony is fully open on a minimum of two sides beneath the floor                           | 12 inches (30 cm) where the area beneath the veranda, porch, deck, or balcony is open on not less than two sides. The vent terminal is prohibited in this location where only one side is open |
| Notes:                                                                                                                                                                               |                                                                                                                                                        |                                                                                                                                           |                                                                                                                                                                                                |
| 1. The Canadian venting installations must be in accordance with local codes or in the absence of local codes with the current CSA B149.1 Natural Gas and Propane Installation Code. |                                                                                                                                                        |                                                                                                                                           |                                                                                                                                                                                                |
| 2. The US venting installations must be in accordance with local codes or in the absence of local codes with the current ANSI Z223.1/NFPA 54 National Fuel Gas Code.                 |                                                                                                                                                        |                                                                                                                                           |                                                                                                                                                                                                |
| * Clearance in accordance with local installation codes and the requirements of the gas supplier.                                                                                    |                                                                                                                                                        |                                                                                                                                           |                                                                                                                                                                                                |

Venting Through The Roof

Support Horizontal pipe every 3'0" with the first support as close to the furnace as possible. Induced draft blower, housing, and furnace must not support the weight of the flue pipe.



**Note:** All measurements are from centerline to centerline.




VENTING THROUGH CEILING

When penetrating roof with PVC vent pipe, a flexible flashing may be used for a weather tight seal. Lubricate flexible seal on flashing before PVC pipe is pushed through the seal. (Field Supplied)

**Note:** No vent cap is the preferred method for vertical vent termination in extremely cold climates.

**Note:** In extreme climate conditions, insulate the exposed pipe above the roof line with Armaflex type insulation.




## Venting Through an UNUSED Chimney

Venting Routed Through a Masonry Chimney

**Important:** Refer to Section 12.6.8 of NFPA 54 / ANSI 223.1 2012 when routing vent piping through a chimney.

**Important:** The single wall flue pipe joints must be sealed. The 90° elbow connection to vertical pipe must be sealed to prevent condensate leakage to base of masonry chimney.



## Venting Through an UNUSED Chimney

**Important:** Refer to Section 12.6.8 of NFPA 54 / ANSI 223.1 2012 when routing vent piping through a chimney.

**Important:** The single wall flue pipe joints must be sealed. The 90° elbow connection to vertical pipe must be sealed to prevent condensate leakage to base of masonry chimney.

### VENT FITTING MATERIAL – STAINLESS STEEL

Gas and liquid tight single wall metal vent fitting, designed for resistance to corrosive flue condensate such as Type 29-4C MUST be used throughout.

These fittings and fitting accessories are to be field supplied.


### DIRECTION OF STAINLESS STEEL FITTING

All stainless steel fitting must be installed with male end towards the Furnace.

All horizontal stainless steel sections must be positioned with the seam on top.

All long horizontal sections must be supported to prevent sagging.

All pipe joints must be fastened and sealed to prevent escape of combustion products into the building.





Downward Venting

Furnace may be in vertical or horizontal configuration.

**Notes:**

1. Condensate trap for vent pipe must be a minimum of 6 inches in height.
2. Condensate trap for vent and inlet pipe must be connected into a condensate drain pump; an open or vented drain; or it can be connected to the outlet hose of the Furnace condensate trap. Outdoor draining of the Furnace and coil condensate is permissible if allowed by local codes.
3. The condensate trap should be primed at initial start up prior to heating season operation.

All horizontal pipes must be supported at maximum of 3 foot intervals

Slope 1/4" per ft.

Slope 1/4" per ft.

6" Min.

Downward vent length is limited to a maximum of 15 equivalent feet.

Upflow or Downflow Furnace

SEE NOTES

Caution should be taken to prevent drains from freezing or causing slippery conditions that could lead to personal injury. Excessive draining of condensate may cause saturated ground conditions that may result in damage to plants.

Air for Combustion and Ventilation

Adequate flow of combustion and ventilating air must not be obstructed from reaching the Furnace. Air openings provided in the Furnace casing must be kept free of obstructions which restrict the flow of air. Airflow restrictions affect the efficiency and safe operation of the Furnace. Keep this in mind should you choose to remodel or change the area which contains your Furnace. Furnaces must have a free flow of air for proper performance.

Provisions for combustion and ventilation air shall be made in accordance with "latest edition" of Section 9.3, Air for Combustion and Ventilation, of the National Fuel Gas Code, ANSI Z223.1 / NFPA 54, or Sections 8.2, 8.3 or 8.4 of CSA B149.1 Installation Codes, and applicable provisions of the local building codes. Special conditions created by mechanical exhausting of air and fireplaces must be considered to avoid unsatisfactory Furnace operation.

Furnace location may be in an **unconfined** space or a **confined** space.

**Unconfined** space are installations with 50 cu. ft. or more per 1000 BTU/hr input from all equipment installed. Unconfined spaces are defined in the table and illustration for various furnace sizes. These spaces may have adequate air by infiltration to provide air for combustion, ventilation, and dilution of flue gases. Buildings with tight construction (for example, weather stripping, heavily insulated, caulked, vapor barrier, etc.), may need additional air provided as described for confined space.

| Minimum Area in Square Feet for Unconfined Space Installations |                                                                     |
|----------------------------------------------------------------|---------------------------------------------------------------------|
| Furnace Maximum BTUH Input Rating                              | With 8 Ft. Ceiling, Minimum Area in Square Feet of Unconfined Space |
| 40,000                                                         | 250                                                                 |
| 60,000                                                         | 375                                                                 |
| 80,000                                                         | 500                                                                 |
| 100,000                                                        | 625                                                                 |
| 120,000                                                        | 750                                                                 |

**UNCONFINED**

**50 CU. FT. OR MORE PER 1000 BTU/HR INPUT ALL EQUIP. INSTALLED**

NO DOORS

FURNACE WATER HEATER CLOTHES DRYER

**Confined** spaces are installations with less than 50 cu. ft. of space per 1000 BTU/ hr input from all equipment installed. Confined spaces are defined in the table and illustration for various furnace sizes. Air for combustion and ventilation requirements can be supplied from inside the building.

1. The following types of installations will **require** use of OUTDOOR AIR for combustion, due to chemical exposures:
- Commercial buildings
  - Buildings with indoor pools
  - Furnaces installed in commercial laundry rooms
  - Furnaces installed in hobby or craft rooms
  - Furnaces installed near chemical storage areas
- Exposure to the following substances in the combustion air supply will also require OUTDOOR AIR for combustion:
- Permanent wave solutions

## Furnace General Installation

- Chlorinated waxes and cleaners
- Chlorine based swimming pool chemicals
- Water softening chemicals
- Deicing salts or chemicals
- Carbon Tetrachloride
- Halogen type refrigerants
- Cleaning solvents (such as perchloroethylene)
- Printing inks, paint removers, varnish, etc.
- Hydrochloric acid
- Cements and glues
- Antistatic fabric softeners for clothes dryers
- Masonry acid washing material


**Note:** *Extended warranties are not available in some instances. Extended warranty does not cover repairs to equipment installed in establishments with corrosive atmospheres, including but not limited to, dry cleaners, beauty shops, and printing facilities.*

| Minimum Free Area in Square Inches Each Opening (Furnace Only) in a Confined Space |                 |                   |                     |
|------------------------------------------------------------------------------------|-----------------|-------------------|---------------------|
| Furnace Max BTUH Input Rtg.                                                        | Air From Inside | Air From Outside  |                     |
|                                                                                    |                 | Vertical Duct (a) | Horizontal Duct (b) |
| 40,000                                                                             | 100             | 10                | 20                  |
| 60,000                                                                             | 100             | 15                | 30                  |
| 80,000                                                                             | 100             | 20                | 40                  |
| 100,000                                                                            | 100             | 25                | 50                  |
| 120,000                                                                            | 120             | 30                | 60                  |


(a) 1 Square inch per 4000 BTU/hr Vertical Duct.  
(b) 1 Square inch per 2000 BTU/hr Horizontal Duct.

### CONFINED

**LESS THAN 50 CU. FT.  
PER 1000 BTU/HR INPUT  
ALL EQUIP. INSTALLED**






All air from inside the building The confined space shall be provided with two permanent openings communicating directly with an additional room(s) of sufficient volume so that the combined volume of all spaces meets the criteria for an unconfined space. The total input of all gas utilization equipment installed in the combined space shall be considered in making this determination. Refer to the Minimum Free Area in square inches for confined spaces table, for minimum open areas required.



All air from outdoors The confined space shall be provided with two permanent openings, one commencing within 12 inches of the top and one commencing within 12 inches of the bottom of the enclosure.

The openings shall communicate directly, or by ducts, with the outdoors or spaces (crawl or attic) that freely communicate with the outdoors. Refer to the Minimum Free Area in square inches for confined spaces table, for minimum open areas required.



# Duct Connections

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>Air duct systems should be installed in accordance with standards for air conditioning systems, National Fire Protection Association Pamphlet No. 90. They should be sized in accordance with ACCA Manual D or whichever is applicable. Check on controls to make certain they are correct for the electrical supply.</p> <p>Central furnaces, when used in connection with cooling units, shall be installed in parallel or on the upstream side of the cooling units to avoid condensation in the heating element, unless the furnace has been specifically approved for downstream installation. With a parallel flow arrangement, the dampers or other means used to control flow of air shall be adequate to prevent chilled air from entering the furnace, and if manually operated, must be equipped with means to prevent operation of either unit unless the damper is in full heat or cool position.</p> <p>Flexible connections of nonflammable material may be used for return air and discharge connections to reduce the transmission of vibration. Though these units have been specifically designed for quiet, vibration free operation, air ducts can act as sounding boards and could, if poorly installed, amplify the slightest vibration to the annoyance level.</p> | <p>When the furnace is located in a utility room adjacent to the living area, the system should be carefully designed with returns which minimize noise transmission through the return air grille. Although these winter air conditioners are designed with large blowers operating at moderate speeds, any blower moving a high volume of air will produce audible noise which could be objectionable when the unit is located very close to a living area. It is often advisable to route the return air ducts under the floor or through the attic. Such design permits the installation of air return remote from the living area (i.e. central hall).</p> <p>When the furnace is installed so that the supply ducts carry air circulated by the furnace to areas outside the space containing the furnace, the return air shall also be handled by a duct(s) sealed to the furnace and terminating outside the space containing the furnace. For furnaces not equipped with a cooling coil, it is recommended that the outlet duct be provided with a removable access panel. The opening shall be accessible when the furnace is installed and shall be of such a size that the heat exchanger can be viewed for possible openings using light assistance or a probe can be inserted for sampling the air stream. The removable cover must be sealed to prevent air leaks.</p> |
| <p><b>Where there is no complete return duct system, the return connection must be run full size from the Furnace to a location outside the utility room, basement, attic, or crawl space.</b></p> <p><b>Do Not</b> install return air through the back of the Furnace cabinet.</p> <p><b>Do Not</b> install return air through the side of the furnace cabinet on horizontal applications without following the guidelines in Return Air Filter section of this document.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <p>Carbon monoxide, fire or smoke can cause serious bodily injury, death, and/or property damage.</p> <p>A variety of potential sources of carbon monoxide can be found in a building or dwelling such as gas-fired clothes dryers, gas cooking stoves, water heaters, furnaces and fireplaces. The U.S. Consumer Product Safety Commission recommends that users of gas-burning appliances install carbon monoxide detectors as well as fire and smoke detectors per the manufactures installation instructions to help alert dwelling occupants of the presence of fire, smoke or unsafe levels of carbon monoxide. These devices should be listed by Underwriters Laboratories, Inc. <i>Standards for Single and Multiple Station Carbon Monoxide Alarms, UL 2034</i> or CSA International Standard, <i>Residential Carbon Monoxide Alarming Devices, CSA 6.19</i>.</p>                                                                                                                                                                                                                                                                                                                                                                                                                    | <p><b>Note:</b> The manufacturer of your Furnace DOES NOT test any detectors and makes no representations regarding any brand or type of detector.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| <p><b>Note:</b> Seal per local codes</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |

Table 7. Supply Duct Connections












|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |                                                                                                                                                                                                                                                                                                                             |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <div><div><div>⚠ CAUTION</div><div>COIL REQUIREMENT!!</div><div>Failure to follow this Caution could result in property damage or personal injury. 4GXC* and 4MXC* coils installed on upflow furnaces in vertical, horizontal left, or horizontal right orientations without a factory installed metal drain pan shield must use a MAY*FERCOLKITAA kit. Coils installed on upflow furnaces must have drain pans that are suitable for 400° F (205° C) or have a metal drain pan shield. Downflow furnaces do not require a metal drain pan shield or the use of the MAY*FERCOLKITAA kit.</div></div></div> | <p><b>Note:</b> The "Coil Requirement" caution is applicable to:</p> <ul style="list-style-type: none"><li>Upflow furnace with coil,</li><li>Furnace in horizontal left with coil and</li><li>Furnace in horizontal right with "A" coil</li></ul>                                                                           |
| <div><div>Upflow Furnace with Coil</div><div></div><div>Refer to <a href="#">Step 1.</a></div></div>                                                                                                                                                                                                                                                                                                                                                                                                                     | <div><div>Upflow Furnace with Coil</div><div><p><b>Note:</b> There are no longer guide holes located on the furnace flange.</p></div><div>Refer to <a href="#">Step 2.</a>, <a href="#">Step 3.</a>, <a href="#">Step 4.</a></div></div> |
| <div><div>Upflow Furnace without Coil</div><div><p>Caution. The first 6–12 inches of the supply duct must be insulated to protect from high temperatures.</p></div><div>Refer to <a href="#">Step 1.</a>, <a href="#">Step 4.</a>, <a href="#">Step 5.</a></div></div>                                                                                                                                                                                                                                                  | <div><div>Furnace in Horizontal Left with Coil</div><div></div><div>Refer to <a href="#">Step 1.</a></div></div>                                                                                                                        |

Table 7. Supply Duct Connections (continued)

|                                                                                                                                                                                                                                                                                                                   |                                                                                                                                                                                                                                                                                                                                                                                                          |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p><b>Furnace in Horizontal Left with Coil</b></p> <p><b>Note:</b> There are no longer guide holes located on the furnace flange.</p>  <p>Refer to <a href="#">Step 6.</a>, <a href="#">Step 3.</a>, <a href="#">Step 4.</a></p> | <p><b>Furnace in Horizontal Right with "A" Coil</b></p> <p><b>Note:</b> Flat or dedicated horizontal coils may require flanges to be bent upward.</p>  <p>Refer to <a href="#">Step 7.</a>, <a href="#">Step 8.</a>, <a href="#">Step 9.</a>, <a href="#">Step 6.</a></p>                                              |
| <p><b>Furnace in Horizontal Right with "A" Coil</b></p>  <p>Refer to <a href="#">Step 10.</a>, <a href="#">Step 4.</a></p>                                                                                                     | <p><b>Downflow Furnace with Coil</b></p> <p><b>Note:</b> 4GXC* or 4MXC* coils installed on a downflow furnace do not require a metal drain pan shield or the use of the MAY*FERCOLKITAA kit.</p>  <p>Refer to <a href="#">Step 7.</a>, <a href="#">Step 8.</a>, <a href="#">Step 9.</a>, <a href="#">Step 6.</a></p> |

**Table 7. Supply Duct Connections (continued)**

|                                                                                                                                                                                                                                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p style="text-align: center;"><b>Downflow Furnace with Coil</b></p>  <p style="text-align: center;">Refer to <a href="#">Step 11.</a>, <a href="#">Step 4.</a></p> | <p style="text-align: center;"><b>Horizontal Right and Downflow Furnace — no Coil</b></p> <p><b>Important:</b> A BAYBASE is required when installing the furnace on a combustible floor.</p>   <p style="text-align: center;">Refer to <a href="#">Step 1.</a>, <a href="#">Step 12.</a>, <a href="#">Step 4.</a></p> |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

### Installation Instructions

1. Bend furnace flanges up.
2. Set the coil on top of the furnace.
3. Screw through the coil cabinet into the furnace flange. Guide holes are located on the coil.
4. Seal per local codes and requirements.
5. Insulate the first 6–12 inches of the supply duct.
6. Support the furnace and coil independently.
7. Cut the back flange along perforation.
8. Starting at the back of the furnace, cut the side flanges along perforations until past the end of the heat shield to avoid interference when bending.
9. Bend furnace side flanges down.
10. Match the coil up flush to the back of the furnace.
11. Set the furnace on top of the coil so that it is flush with the back of the furnace.
12. Attach ducting.

Table 8. Return Duct Connections





|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |                                                                                                                                                                                                                                                                                    |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <div><b>Return Ducting General Guidelines</b><ul style="list-style-type: none"><li>• Back returns are not allowed on any S-Series Furnaces</li><li>• Side returns are not allowed on downflow or horizontal S-Series Furnaces</li><li>• Mounting flanges must be located on ducting</li><li>• Shoot screws through the mount flanges into the furnace cabinet</li><li>• Always seal per local codes and requirements</li><li>• Furnace, coil, and ducting must be supported separately</li><li>• An external overflow drain pan must be installed in all applications over a finished ceiling to prevent property damage</li></ul></div> |                                                                                                                                                                                                                                                                                    |
| <div><b>Upflow Furnace with Bottom Return in Closet with Remote Filter</b><p>Refer to <a href="#">Step 1.</a>, <a href="#">Step 2.</a>, <a href="#">Step 3.</a>, <a href="#">Step 4.</a></p></div>                                                                                                                                                                                                                                                                                                                                                     | <div><b>Upflow Furnace with Bottom Return in Closet with Filter Box</b><p>Refer to <a href="#">Step 1.</a>, <a href="#">Step 5.</a>, <a href="#">Step 6.</a>, <a href="#">Step 4.</a></p></div> |
| <div><b>Upflow Furnace with Bottom Return Mounted on a Ducted Pedestal</b><p>Refer to <a href="#">Step 1.</a>, <a href="#">Step 7.</a>, <a href="#">Step 8.</a>, <a href="#">Step 4.</a></p></div>                                                                                                                                                                                                                                                                                                                                                    | <div><b>Upflow Furnace with Bottom Return Mounted on a Ducted Pedestal with Filter Box</b><p>Refer to <a href="#">Step 1.</a>, <a href="#">Step 9.</a>, <a href="#">Step 4.</a></p></div>      |

Table 8. Return Duct Connections (continued)









|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p><b>Upflow Furnace with Bottom and Side Returns Mounted on a Ducted Pedestal with Side Return and Filter Box</b></p> <p><b>Important:</b> Make sure the condensate and thermostat wiring holes are sealed on the cabinet side with the side return. The plugs and grommets may need to be changed with those on the opposite side of the cabinet.</p> <p><b>Important:</b> Make sure not to cut the cabinet in the "No Cut" area.</p> <p><b>Note:</b> Use Optional BAYLIFT kit to lift furnace. Follow kit instructions.</p> <p><b>Note:</b> The furnace bottom pedestal must be a minimum of 6" in height.</p>  <p>Refer to <a href="#">Step 1.</a>, <a href="#">Step 10.</a>, <a href="#">Step 11.</a>, <a href="#">Step 12.</a>, <a href="#">Step 13.</a>, <a href="#">Step 14.</a>, <a href="#">Step 15.</a>, <a href="#">Step 4.</a></p> | <p>17.5" Filter Cabinet with BAYLIFT Kit</p>  <p>No Cut Area      Cutouts      Flush with back of furnace cabinet</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <p>21" Filter Cabinet with BAYLIFT Kit</p>  <p>No Cut Area      Cutouts      Flush with back of furnace cabinet</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | <p><b>Upflow Furnace with Side Return</b></p> <p><b>Important:</b> Make sure the condensate and thermostat wiring holes are sealed on the cabinet side with the side return. The plugs and grommets may need to be changes with those on the opposite side of the cabinet.</p> <p><b>Important:</b> Make sure not to cut the cabinet in the "No Cut" area.</p> <p><b>Note:</b> Return air on right side with the condensate on the left <u>or</u> return air on left with the condensate on the right do not require a transition.</p> <p><b>Note:</b> If using a filter box, use a transition, if possible, to attach the filter box to the furnace cabinet.</p>  <p>No Cut Area      Use four corner guides to create cutout</p> <p>Refer to <a href="#">Step 16.</a>, <a href="#">Step 17.</a>, <a href="#">Step 18.</a>, <a href="#">Step 19.</a></p> |



Table 8. Return Duct Connections (continued)

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |                                                                                                                                                                                                                                                                                      |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p><b>Upflow Furnace with Two Side Returns</b></p> <p><b>Important:</b> One of the sides must have a transition to allow the condensate and thermostat wiring to exit the cabinet.</p> <p><b>Important:</b> If a transition is not a viable option, a hole may be drilled in the bottom of the cabinet to allow the condensate to exit. Also, a hole will need to be drilled in the side of the cabinet for the thermostat wiring to exit.</p> <p><b>Important:</b> Make sure not to cut the cabinet in the "No Cut" area.</p> <p><b>Note:</b> If using one transition, the condensate and thermostat wiring will exit on the transition side.</p> <p><b>Note:</b> If using a filter boxes, use transitions, if possible, to attach the filter boxes to the furnace cabinet. If transitions are not used, condensate may exit through the bottom of the furnace.</p>  <p>No Cut Area</p> <p>Refer to <a href="#">Step 16.</a>, <a href="#">Step 17.</a>, <a href="#">Step 18.</a>, <a href="#">Step 19.</a></p> | <p><b>Downflow Furnace with Top Return</b></p>  <p>Refer to <a href="#">Step 20.</a>, <a href="#">Step 21.</a>, <a href="#">Step 3.</a>, <a href="#">Step 4.</a></p>                              |
| <p><b>Downflow Furnace with Top Return and Plenum</b></p>  <p>Refer to <a href="#">Step 20.</a>, <a href="#">Step 22.</a>, <a href="#">Step 3.</a>, <a href="#">Step 4.</a></p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | <p><b>Downflow Furnace with Top Return and Plenum with Filter Box</b></p>  <p>Refer to <a href="#">Step 20.</a>, <a href="#">Step 23.</a>, <a href="#">Step 24.</a>, <a href="#">Step 4.</a></p> |

### Installation Instructions

1. Remove the bottom plate.
2. Set the furnace on the base inside closet.
3. Install remote filter.
4. Seal per local codes and requirements.
5. Set the furnace on the filter box inside closet.
6. Must have grill present for air.
7. Set the furnace on the ducted pedestal. The ducted pedestal will use ducted air from a remote location.
8. Install filter at a remote location.
9. Set the furnace on the filter box. The ducted pedestal will use ducted air from a remote location.
10. Create ducting and set the furnace in place.
11. Match the filter cabinet flush to the back and bottom sides of the furnace cabinet and secure in place with screws.
12. Mark the two areas to be cut out for the return air.
13. Cut out the two sections of the cabinet and BAYLIFT kit to be removed.
14. Attach ducting to the filter box.
15. The ducted pedestal will use ducted air from a remote location.
16. Using guides, remove the cutout for the side return.
17. Create ducting and set the furnace in place. Use screws to attach ducting to the furnace cabinet.
18. Seal bottom panel per local codes and requirements.
19. Seal all other panels per local codes and requirements.
20. Remove the top plate.
21. Attach the ducting to the top of the furnace.
22. Attach the plenum ducting to the top of the furnace.
23. Attach the filter box to the top of the furnace.
24. Attach ducting.

# Return Air Filters

## TYPICAL UPFLOW RETURN AIR FILTER INSTALLATIONS

Filters are not factory supplied for upflow furnaces. Filter size needed will be dependent on type of filter and CFM requirement. Filters must be installed externally to the unit.

**Important:** *It is recommended to transition return ducting to the same size as the opening. It is acceptable for return duct or filter frame to extend forward of the opening but plastic plugs **MUST** be installed in any opening that the duct or filter frame may cover.*

## Upflow Return Air Filters

| Furnace Width | Filter Qty and Size |
|---------------|---------------------|
| 17-1/2"       | 1 — 16" x 25" x 1"  |
| 21"           | 1 — 20" x 25" x 1"  |
| 24-1/2"       | 1 — 24" x 25" x 1"  |


**Note:** *For upflow furnace models in any configuration, where the airflow requirement exceeds 1600 CFM - Furnaces will require return air openings and filters on: (1) both sides, or (2) one side and the bottom, or (3) just on the bottom.*

## Preparation for Upflow Bottom and Side Return Air Filter Installations

All return air duct systems should provide for installation of return air filters.

1. Determine the appropriate position to set the furnace in order to connect to existing supply and return ductwork.
2. For upflow side return installations, remove the insulation around the opening in the blower compartment
3. The side panels of the upflow furnace include locating notches that are used as guides for cutting an opening for return air, refer to the figure and the upflow furnace outline drawing for duct connection dimensions for various furnaces.
4. If a 3/4" flange is to be used for attaching the air inlet duct, add to cut where indicated by dotted lines. Cut corners diagonally and bend outward to form flange.
5. If flanges are not required, and a filter frame is installed, cut between locating notches as in illustration.
6. The bottom panel of the upflow furnace must be removed for bottom return air.


## UPFLOW FURNACES ONLY




**RETURN AIR FILTERS FOR MODULAR BLOWER IN HORIZONTAL CONFIGURATION**

When the modular blower is installed in the horizontal configuration, the return air filters must be installed exterior to the modular blower cabinet. Remote filter grilles may be used for homeowner convenience, refer to [Figure 4, p. 54](#) or the filters may be installed in the duct work upstream of the modular blower, refer to [Figure 5, p. 54](#).  
Filter kits are available for horizontal applications.  
**Direct coupled side returns are not allowed to the blower cabinet.**

**Figure 4. Remote Filter Installation**



**Figure 5. Duct Filter Installation**



**TYPICAL DOWNFLOW FURNACE RETURN AIR FILTER INSTALLATIONS**

Filters are not factory supplied for downflow furnaces. Filter size needed will be dependent on type of filter and CFM requirement. Filters must be installed externally to the unit.

**Downflow Return Air Filters**

| Furnace Width | Filter Qty and Size |
|---------------|---------------------|
| 17-1/2"       | 2 — 14" x 20" x 1"  |
| 21"           | 2 — 16" x 20" x 1"  |
| 24-1/2"       | 2 — 16" x 20" x 1"  |

# Electrical Connections

Make wiring connections to the unit as indicated on enclosed wiring diagram. As with all gas appliances using electrical power, this furnace shall be connected into a permanently live electric circuit. It is recommended that furnace be provided with a separate "circuit protection device" electric circuit. The furnace must be electrically grounded in accordance with local codes or in the absence of local codes with the National Electrical Code, ANSI/NFPA 70, if an external electrical source is utilized. **The integrated furnace control is polarity sensitive.** The hot leg of the 120V power supply must be connected to the black power lead as indicated on the wiring diagram. Refer to the Wiring Diagram section in this document and unit wiring diagram attached to furnace.

## ⚠ WARNING


### FIRE HAZARD!

Failure to follow this Warning could result in property damage, severe personal injury, or death.


This Warning applies to installations with a flammable refrigeration system. The furnace must be powered except for service. The furnace shall be installed and connected according to installation instructions and wiring diagrams that are provided with the evaporator coil.

## Field Wiring

Table 9. A951X



Twinning



# Condensate Drain Instructions

The following sections give general instructions for the installation of the gas furnace condensate drains. Repositioning of the condensate trap is covered in the exhaust air options section.

Cutouts with plugs and grommets are provided on the left and right hand side of the furnace cabinets for drain connections *IN VERTICAL APPLICATIONS*. The standard arrangement is for the drain connection on the left side. The tubing may have to be trimmed in this application to avoid kinking.

The **upflow (vertical application)** also has provisions for right side drain connections. Exchange the grommet and plugs from the left and right side. Trim all excess tubing to avoid kinking.

It is always recommended that an auxiliary drain pan be installed under a horizontally installed evaporator or 90% Gas Furnace. Connect the auxiliary drain line to a separate drain line (no trap is needed in this line).

**Horizontal applications require repositioning the condensate canister trap. Additionally the drain tubing connected to the inducer housing may need to be repositioned for removing the plug and reconnecting the tubing to the lower connection on the inducer housing.**

Connections must be made to an **OPEN/ VENTED DRAIN**.

**Note:** All condensate drain piping supplies included with the furnace are intended for internal piping only and should not be applied external to the furnace. All external piping must use 1/2" minimum size PVC pipe and fittings throughout for drain connections (fittings, pipe and PVC solvent cement not provided with furnace, must be field supplied). A 3/4" coupling is supplied to connect to systems that are using 3/4" piping with an air conditioner coil.

**Note:** A corrosion resistant condensate pump must be used if a pump is required for a specific drain system.

## ⚠ CAUTION

### Water Damage/Property Damage!

It is recommended that a drain pan be installed under the furnace to prevent property damage or personal injury from leaking condensate.

**Important:** The condensate drain should be installed with provisions to prevent winter freeze-up of the condensate drain line. Frozen condensate will block drains, resulting in furnace shutdown. If the drain line cannot be installed in a conditioned space and/ or its surrounding ambient temperature is expected to fall below freezing, then heat tape should be applied as required to prevent freezing (per manufacturer's instructions). The heat tape should be rated at 5 or 6 watts per foot at 120 volts. Self-regulating (preferred) or thermostatically controlled heat tape is required.





Typical sources of UL listed heat tapes are W.W. Granger, Inc. (Wintergard Plus™ Series), McMaster Carr Supply Co. (3554 Series), or your equipment supplier.

The condensate drain may be cleaned or inspected by removal of the drain tube at the header.

Evaporator and Furnace condensate drain piping may be manifolded together. A primary drain vent stack must be installed and terminated below the outlet of the secondary heat exchanger drain connection to prevent water from damaging Furnace controls if the primary drain outlet plugs up.

**Where the Furnace is installed above a finished ceiling, the primary drain vent stack must be installed such that overflow from the vent stack opening will flow into an auxiliary drain pan in order to prevent water damage to the finished ceiling below.**





Vertical Applications

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p><b>VERTICAL APPLICATIONS</b></p> <p><b>Upflow furnace -</b></p> <p>Remove the plug from the side panel where the condensate will exit. Install the condensate grommet into the side panel. Install the connection tubing from the trap to the side of the unit and trim all excess tubing to avoid kinks.</p>                                                                                                                                                                                                                                                                                                                                                                          | <p><b>Note:</b> For easiest installation, remove the spring clip from the end of the condensate line and feed through the grommet.</p> <p><b>Important:</b> Condensate grommet must be installed for proper operation.</p>                                                                                                                                                                                                                                                                                                                                                              |
|  <p>Diagram showing the left side of the furnace with the condensate drain assembly. Labels include: COIL PRIMARY DRAIN, FIELD FABRICATED TRAP, CONDENSATE GROMMET, PRIMARY DRAIN VENT STACK MUST TERMINATE BELOW THE BOTTOM OF THE CONDENSATE TRAP, and LEFT SIDE DRAIN.</p>                                                                                                                                                                                                                                                                                                                           |  <p>Diagram showing the right side of the furnace with the condensate drain assembly. Labels include: COIL PRIMARY DRAIN, FIELD FABRICATED TRAP, CONDENSATE GROMMET, and RIGHT SIDE DRAIN.</p>                                                                                                                                                                                                                                                                                                       |
|  <p>Diagram showing the left side of the furnace with the condensate drain assembly. Labels include: LEFT SIDE DRAIN, COIL PRIMARY DRAIN, FIELD FABRICATED TRAP, CONDENSATE GROMMET, and PRIMARY DRAIN VENT STACK MUST TERMINATE BELOW THE BOTTOM OF THE CONDENSATE TRAP.</p> <p>IF THE FURNACE IS INSTALLED OVER A FINISHED CEILING, OVERFLOW FROM THE PRIMARY DRAIN VENT STACK MUST FLOW INTO AN AUXILIARY DRAIN PAN TO PREVENT DAMAGE TO THE FINISHED CEILING BELOW</p> <p>CONDENSATE PUMP</p> <p>CONDENSATE PIPED TO OPEN VENTED DRAIN</p> <p>CONDENSATE PIPES MUST NOT BE BELOW WATER SURFACE</p> |  <p>Diagram showing the right side of the furnace with the condensate drain assembly. Labels include: COIL PRIMARY DRAIN, CONDENSATE GROMMET, and PRIMARY DRAIN VENT STACK MUST TERMINATE BELOW THE BOTTOM OF THE CONDENSATE TRAP.</p> <p>IF THE FURNACE IS INSTALLED OVER A FINISHED CEILING, OVERFLOW FROM THE PRIMARY DRAIN VENT STACK MUST FLOW INTO AN AUXILIARY DRAIN PAN TO PREVENT DAMAGE TO THE FINISHED CEILING BELOW</p> <p>CONDENSATE PIPED TO OPEN VENTED DRAIN OR CONDENSATE PUMP</p> |



|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>LEFT SIDE DRAIN WITH EVAPORATOR AND CONDENSATE DRAIN PIPING MANIFOLDED TOGETHER.</p> <p>COIL PRIMARY DRAIN</p> <p>CONDENSATE GROMMET</p> <p>IF THE FURNACE IS INSTALLED OVER A FINISHED CEILING, OVERFLOW FROM THE PRIMARY DRAIN VENT STACK MUST FLOW INTO AN AUXILIARY DRAIN PAN TO PREVENT DAMAGE TO THE FINISHED CEILING BELOW</p> <p>PRIMARY DRAIN VENT STACK MUST TERMINATE BELOW THE BOTTOM OF THE CONDENSATE TRAP</p> <p>CONDENSATE PIPED TO OPEN VENTED DRAIN</p> <p>CONDENSATE PIPE MUST NOT BE BELOW WATER SURFACE</p> <p>CONDENSATE PUMP</p> <p>OR</p> | <p><b>Downflow furnace</b> - Cut the 90 degree section of the condensate tubing off and connect the tubing to the condensate trap. Install the condensate grommet into the bottom panel. Cut to length as needed.</p> <p>DOWNFLOW FURNACES WITH BOTTOM DRAIN</p> <p>IF THE FURNACE IS INSTALLED OVER A FINISHED CEILING, OVERFLOW FROM THE PRIMARY DRAIN VENT STACK MUST FLOW INTO AN AUXILIARY DRAIN PAN TO PREVENT DAMAGE TO THE FINISHED CEILING BELOW</p> <p>CONDENSATE GROMMET</p> <p>PRIMARY DRAIN VENT STACK MUST TERMINATE BELOW THE BOTTOM OF THE CONDENSATE TRAP</p> <p>COIL PRIMARY DRAIN</p> <p>CONDENSATE PIPED TO OPEN VENTED DRAIN</p> |
| <p><b>Downflow furnace with Left Side Condensate</b></p> <ol style="list-style-type: none"> <li>1. Remove left hand condensate plug.</li> <li>2. Install into bottom cross member.</li> </ol>                                                                                                                                                                                                                                                                                                                                                                        | <p>Left Side Gas Entry</p> <p>Left Side Condensate</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| <p>Plug the bottom hole with plug provided in document pack.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |

## Condensate Drain Instructions

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>Attaching the condensate drain line.</p> <ol style="list-style-type: none"> <li>1. Locate the condensate grommet and the condensate drain line assembly in the doc pack.</li> <li>2. Insert the condensate grommet in the 1-5/8" hole in the side of the cabinet.</li> <li>3. Remove the fitting at the end of the drain line assembly and insert it through the cabinet from the inside out. Attach the 90 degree section of the hose to the condensate drain trap.</li> <li>4. Cut off the excess tube and reinstall the end fitting to the drain hose.</li> </ol>                                                                                                                                                                                                                                                                                                      | <p>DOWNFLOW FURNACES<br/>LEFT SIDE DRAIN</p> <p>1-5/8" DIAMETER HOLE MUST BE CUT IN LEFT SIDE OF CASE. BOTTOM HOLE MUST BE PLUGGED.</p> <p>IF THE FURNACE IS INSTALLED OVER A FINISHED CEILING, OVERFLOW FROM THE PRIMARY DRAIN VENT STACK MUST FLOW INTO AN AUXILIARY DRAIN PAN TO PREVENT DAMAGE TO THE FINISHED CEILING BELOW</p>  <p>CONDENSATE GROMMET</p>                                                                                                                                                         |
| <p><b>Downflow furnace with Right Side Condensate</b> - Drill an 11/16 inch diameter hole in the right side of the case at the dimensions shown.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| <p>Plug the bottom hole with plug provided in document pack.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <p>Attaching the condensate drain line.</p> <ol style="list-style-type: none"> <li>1. Locate the condensate drain line assembly in the doc pack.</li> </ol> <p><b>Important:</b> <i>It is best to cut the condensate drain hose assembly longer than 4 inches and then fit in place. It can then be trimmed to needed length. The 4 inch measurement is an approximation.</i></p> <ol style="list-style-type: none"> <li>2. Cut the condensate drain line assembly as shown.</li> <li>3. Use a field supplied hose clamp to secure the condensate drain line to the condensate trap.</li> <li>4. Insert a field supplied piece of 1/2" CPVC pipe through the 11/16" hole drilled through the cabinet and insert into drain line hose. Secure with the spring clip.</li> </ol> <p><b>Note:</b> <i>Seal around the condensate drain tubing where it exits the cabinet.</i></p> |  <p>Cut hose</p> <p>Approx. 4"</p> <p>DOWNFLOW FURNACES<br/>RIGHT SIDE DRAIN</p> <p>11/16" DIAMETER HOLE MUST BE CUT IN RIGHT SIDE OF CASE. BOTTOM HOLE MUST BE PLUGGED. CUT FACTORY SUPPLIED CONDENSATE ASSEMBLY HOSE AND ATTACH TO FIELD SUPPLIED CPVC TUBE. SECURE WITH SPRING CLIP AND FIELD SUPPLIED HOSE CLAMP.</p> <p>IF THE FURNACE IS INSTALLED OVER A FINISHED CEILING, OVERFLOW FROM THE PRIMARY DRAIN VENT STACK MUST FLOW INTO AN AUXILIARY DRAIN PAN TO PREVENT DAMAGE TO THE FINISHED CEILING BELOW</p> |

## Horizontal Applications


### HORIZONTAL APPLICATIONS

**Upflow models in horizontal** - It is always recommended that the auxiliary drain pan be installed under a horizontally installed evaporator and/or 90% gas furnace. Connect the auxiliary drain pan to a separate drain line (no trap is needed in this line). Connections must be made to an **OPEN/VENTED DRAIN**. Outdoor draining of the furnace and coil condensate is permissible if allowed by local codes. Caution should be taken to prevent drains from freezing or causing slippery conditions that could lead to personal injury. Excessive draining of condensate may cause saturated ground conditions that may result in damage to plants.

**Note:** Use 1/2" or larger PVC or CPVC pipe and fittings as required for drain connections (fittings, pipe and solvent cement not provided).

**Note:** A corrosion resistant condensate pump must be used if a pump is required for a specific drain system.

**Important:** The condensate drain should be installed with provisions to prevent winter freeze-up of the condensate drain line. Frozen condensate will block drains, resulting in furnace shutdown. If the drain line cannot be installed in a conditioned space, then UL listed heat tape should be applied as required to prevent freezing (per manufacturer's instructions). The heat tape should be rated at 5 or 6 watts per foot at 120 volts. Self-regulating (preferred) or thermostatically controlled heat tape is required.



FURNACE MUST BE SUPPORTED AT ALL FOUR CORNERS. BAYHANG - OPTIONAL HORIZONTAL HANGING BRACKET KIT

TO APPROVED OPEN / VENTED DRAIN

**Note:** The overflow stand pipe termination must be even with or slightly below the bottom of the condensate trap.

**Note:** Water from the overflow pipe must drain into the emergency drain pan.


To prevent AC condensate from backing up into the furnaces, follow these instructions for condensate drainage.

**Note:** 1. The overflow stand pipe termination must be even with or slightly below the bottom of the condensate trap.

**Note:** 2. Water from the overflow pipe must drain into the emergency drain pan.


**Note:** 3. It is recommended to use the secondary drain. The secondary drain pipe must terminate over the emergency drain pan.

**Note:** 4. Emergency drain pan.



④

Horizontal Right



④

Horizontal Left

### NOTICE

#### PROPERTY DAMAGE!

Failure to follow this Notice could result in intermittent operation, improper operation, or product damage.

A blocked main drain with an overflow standpipe that is higher than the bottom of the condensate trap and/or a condensate pressure switch hose that is not trimmed to fit can result in an E09 Condensate Pressure Switch Trip error or in extreme cases, an E04 Rollout Thermal Limit Trip error.

An overflow standpipe must be installed. The overflow standpipe must have an opening even with or slightly below the bottom of the condensate trap. The condensate pressure switch hose must be trimmed to fit.

# General Start-up and Adjustment

The following sections give instructions for the general start-up and adjustment of the gas furnaces.

## Preliminary Inspections

|                                                                                                                                                                                                                                                                                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p><b>With gas and electrical power "OFF", ensure:</b></p> <ol style="list-style-type: none"><li>1. Duct connections are properly sealed.</li><li>2. Filters are in place.</li><li>3. Venting is properly assembled.</li><li>4. Blower vestibule panel is in place and all screws in place.</li></ol> | <p>Turn knob on main gas valve within the unit to the "<b>OFF</b>" position. Turn the external gas valve to "ON". Purge the air from the gas lines. After purging, check all gas connections for leaks with a soapy solution.</p> <p>— <b>DO NOT CHECK WITH AN OPEN FLAME.</b> Allow 5 minutes for any gas that might have escaped to dissipate. Turn the gas valve in the unit to the "ON" position.</p> <p>Propane Gas being heavier than air may require forced ventilation. Turn the toggle switch on the Gas Valve in the unit to the "ON" position.</p> |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

## Lighting Instructions

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |                                                                                                                                                                                                                               |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>Lighting instructions appear on each unit. Each installation must be checked out at the time of initial start up to ensure proper operation of all components. Check out should include putting the unit through one complete cycle as outlined below.</p> <p>Turn on the main electrical supply and set the comfort control above the indicated temperature. The igniter will automatically heat, then the gas valve is energized to permit the flow of gas to the burners. After ignition and flame is established, the flame control module monitors the flame and supplies power to the gas valve until the comfort control is satisfied.</p> | <p><b>⚠ WARNING</b></p> <p><b>FIRE OR EXPLOSION HAZARD!</b></p> <p>Failure to follow this Warning could result in property damage, severe personal injury, or death. Do <b>NOT</b> attempt to manually light the furnace.</p> |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

|                                                                                                                                                                                                                                                                            |                                                                                                                                                                                                                                                                                                                     |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p><b>To shut off</b></p> <p>For complete shutdown: Turn the toggle or control switch located on the main gas valve inside the unit to the "OFF" position and the external main gas shutoff valve to the "OFF" position. Disconnect the electrical supply to the unit.</p> |                                                                                                                                                                                                                                                                                                                     |
| <p>Whenever your house is to be vacant, arrange to have someone inspect your house for proper temperature. This is very important during freezing weather. If for any reason your furnace should fail to operate damage could result, such as frozen water pipes.</p>      | <p><b>⚠ CAUTION</b></p> <p><b>FREEZE CAUTION!</b></p> <p>Failure to follow this Caution could result in property damage or personal injury.</p> <p>If complete furnace shutdown is done during the cold weather months, provisions must be taken to prevent freeze-up of all water pipes and water receptacles.</p> |

## Control and Safety Switch Adjustment

|                                                                                                                                                                                                                                                                                                         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p><b>LIMIT SWITCH CHECK OUT</b></p> <p>The limit switch is a safety device designed to close the gas valve should the furnace become overheated. Since proper operation of this switch is important to the safety of the unit, it <b>must be checked out on initial start up by the installer.</b></p> | <p>To check for proper operation of the limit switches, set the thermostat to a temperature higher than the indicated temperature to bring on the gas valve. Restrict the airflow by blocking the return air to the blower. When the furnace reaches the maximum outlet temperature as shown on the rating plate, the burners must shut off. If they do not shut off after a reasonable time and overheating is evident, a faulty limit switch is probable and the limit switch must be replaced. After checking the operation of the limit control, be sure to remove the paper or cardboard from the return air inlet, or reconnect the blower.</p> |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

# Furnace Combustion Air Exhaust Options

|                                                                                                                                                                                                                                                                                                                                                                  |                                                                                                                                                                                                                                                                                                             |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p><b>Important:</b> All plugs must be in place for sealed combustion.</p> <p><b>Note:</b> Default is left side for electric and natural gas connections. Default for the combustion air inlet and exhaust is top of the furnace.</p> <p><b>Important:</b> If the locations are changed from the defaults, the default holes not being used must be plugged.</p> | <p><b>Note:</b> If the electrical and natural gas connections are moved to the right side, remove the plugs and move them to the left side. The grommets will move from the left side to the right side.</p> <p><b>Note:</b> The grommets are different for the natural gas and condensate connections.</p> |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

The following sections give instructions for the different furnace orientations and the options for venting the inlet and exhaust combustion air.

**Important:** When looking at the different orientations, the direction of the combustion air exhaust in the illustration’s description is after the furnace has been rotated, if needed.

Table 10. Combustion Air Venting Options









| Upflow Orientation or Installation                                                                                                |                                                                                                                                              |
|-----------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------|
| <p>Combustion air exhaust vented out top.</p>   | <p>Combustion air exhaust vented through left side.</p>   |
| Horizontal Left Orientation or Installation                                                                                       |                                                                                                                                              |
| <p>Combustion air exhaust vented out top.</p>  | <p>Combustion air exhaust vented through left side.</p>  |


Table 11. Combustion Air Venting Options Continued

|                                                                                                                                                                                                                                                                                                                                                                                |                                                                                                                                                                                                           |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>Refer to the illustrations below to find the approved venting options for horizontal right furnace models.</p> <p><b>Important:</b> The combustion air exhaust must be vented to the outdoors.</p> <p><b>Note:</b> The combustion air inlet does not have to be on the same side as the combustion air exhaust.</p>                                                         |                                                                                                                                                                                                           |
| Horizontal Right Orientation or Installation                                                                                                                                                                                                                                                                                                                                   |                                                                                                                                                                                                           |
| <p>Combustion air exhaust vented out top.</p>                                                                                                                                                                                                                                                 | <p>Combustion air exhaust vented through left side.</p> <p><b>Note:</b> Requires a hole to be drilled in the case.</p>  |
| <p>Refer to the illustrations below to find the approved venting options for downflow furnace models.</p> <p><b>Important:</b> The combustion air exhaust must be vented to the outdoors.</p> <p><b>Note:</b> The combustion air inlet does not have to be on the same side as the combustion air exhaust.</p> <p><b>Note:</b> Right side combustion air entry is allowed.</p> |                                                                                                                                                                                                           |
| Downflow Orientation or Installation                                                                                                                                                                                                                                                                                                                                           |                                                                                                                                                                                                           |
| <p>Combustion air exhaust vented out top.</p>                                                                                                                                                                                                                                               | <p>Combustion air exhaust vented through left side.</p>                                                               |


## Upflow Position - Top Vented Combustion Air

No changes need to be made to the inducer when installing the upflow furnace with the combustion air vented through the top.

**Important:** Trim the condensate pressure switch tubing to length to ensure there is no sag or trap created.



1. Attach the vent outlet gasket to the vent outlet.
2. Install vent outlet to top of cabinet using 2 screws supplied in the doc pack.
3. Install vent inlet gasket and vent inlet using 4 screws supplied in the doc pack.




4. Slide PVC pipe through vent outlet adaptor and insert into inducer outlet.
5. Twist to insure PVC is fully inserted.
6. Tighten the clamp on the end of the 45 degree elbow.
7. Tighten the clamp on the outlet vent adaptor.

**Note:** The vent outlet adapter is used for strain relief against the weight of the venting. The clamp should be tightened after the internal connection is made.

8. Install the combustion air inlet PVC pipe.

**Note:** If required, transition to larger venting within 2' of the cabinet. CPL01544 – 2" x 3" offset coupling may be used and is factory supplied with 120 KBTUH furnaces. Canadian applications may use BAYREDUCE to meet ULC-S636 requirements.



## Upflow Position - Left Side Vented Combustion Air


Changes need to be made to the inducer orientation when installing the upflow furnace with the combustion air vented through the side.

The figure to the top left in next page shows the furnace as it is sent from the factory.

Use the following steps to modify the furnace for upflow with side venting of combustion air.

**Important:** Right side vent outlet is not allowed because condensate will not drain.

## Furnace Combustion Air Exhaust Options




Before proceeding, lay unit on its back to make conversion easier.


1. Disconnect all drain tubes from condensate trap.

**Note:** When removing condensate hoses from the condensate trap, hold the trap with your hand to prevent the trap from breaking. Removing the trap before the hoses is also an option.


2. Remove drain tubing from bottom of inducer housing.
3. Remove rain gutter tubing from inducer outlet.
4. Remove tubing from condensate pressure switch.
5. Loosen hose clamp and remove 45 degree adapter. If the rubber boot pulls out of the inducer opening, remove from the adapter and reinstall onto the inducer. Remove the elbow and discard.




6. Remove two 3" plugs on left side of cabinet. To be used for combustion air and vent exhaust.
7. Install the two 3" plugs into the two 3" default openings on the top of the cabinet.




8. Remove the three inducer mounting screws.
9. Rotate inducer counter-clockwise so that the inducer outlet aligns with the exhaust vent outlet.
10. Insert and re-tighten screws to 30 in.-lbs. Do not overtighten.








11. Attach the vent outlet gasket to the vent outlet.
12. Install vent outlet to top of cabinet using 2 screws supplied in the dock pack.
13. Install vent inlet gasket and vent inlet using 4 screws supplied in the dock pack.
14. Install the grommet for the condensate drain tube. The drain may be located on either side of the cabinet.




15. Slide PVC through vent outlet adaptor and insert into inducer outlet.
16. Twist to insure PVC is fully inserted.
17. Tighten the two clamps.
18. Install the combustion air inlet pipe.

**Note:** The vent outlet adapter is used for strain relief against the weight of the venting. The clamp should be tightened after the internal connection is made.

**Note:** If required, transition to larger venting within 2' of the cabinet. An 2" x 3" offset coupling is required if the transition is made in a horizontal plane. Use coupling CPL01544 (Canadian applications may use BAYREDUCE to meet ULC-S636 requirements.) See Horizontal Venting section for proper orientation of 2" x 3" offset coupling.



19. Remove port cap at bottom of inducer and connect inducer condensate tubing. Connect other end of inducer condensate tubing to top port on the condensate trap. Cut tubing to length, if necessary.
  20. Install previously removed port cap onto bottom port of the inducer. (As viewed in upflow)
  21. Connect condensate pressure switch tubing to pressure port on the condensate trap.
- Important:** Trim the condensate pressure switch tubing to length to ensure there is no sag or trap created.
22. Remove port plug from rain gutter and install in new position on opposite side of the rain gutter.
  23. Connect rain gutter condensate hose to the rain gutter and the lower port of the condensate trap. Cut to length, if necessary.




### Horizontal Left Position - Top Vented Combustion Air

Changes need to be made to the inducer orientation when installing the upflow furnace in the horizontal left position with the combustion air vented through the side. Additional changes are needed for hose routing, condensate trap orientation, and inducer hoses.

The figure below shows the furnace as it is sent from the factory.

Use the following steps to modify the furnace for horizontal left with side venting of combustion air.




Before proceeding, lay unit on its back to make the conversion easier.

1. Remove all drain hoses from condensate trap.


**Note:** When removing condensate hoses from the condensate trap, hold the trap with your hand to prevent the trap from breaking. Removing the trap before the hoses is also an option.

2. Remove drain tubing from bottom of inducer housing.
3. Remove rain gutter tubing from inducer outlet.
4. Remove tubing from condensate pressure switch.
5. Remove the screws that hold the condensate trap bracket. The condensate trap should not be removed from the condensate trap bracket. Remove assembly and retain for later installation.


**Note:** There is a plastic adapter with O-rings located inside the cold header that is held in place by the condensate trap bracket. Do not lose this adapter. This adapter needs to be in place when the condensate trap bracket is reattached.




6. Loosen hose clamp and remove 45 degree adapter. If the rubber boot pulls out of the inducer opening, remove from the adapter and reinstall onto the inducer. Remove the elbow and discard.




7. Remove three inducer screws.
8. Rotate the inducer so that the outlet is pointing vertically.
9. Use the three screws to reattach the inducer to the cold header to 30 in.-lbs. Do not overtighten.



10. Remove 3" plug on left side of unit. To be used for condensate trap.
11. Install condensate trap grommet.
12. Remove two 3" plugs on right side of cabinet. To be used for combustion air exhaust and inlet.
13. Reuse the two 3" plugs to seal the two 3" default openings on the top of the furnace.




14. Attach the vent outlet gasket to the vent outlet.
15. Install vent outlet to top of cabinet using 2 screws supplied in the dock pack..
16. Install vent inlet gasket and vent inlet using 4 screws supplied in the dock pack.



17. Slide PVC through vent outlet adaptor and insert into inducer outlet.
18. Twist to insure PVC is fully inserted.
19. Tighten the two clamps.
20. Install the combustion air inlet PVC pipe.

**Note:** The vent outlet adapter is used for strain relief against the weight of the venting. The clamp should be tightened after the internal connection is made.

**Note:** If required, transition to larger venting within 2' of the cabinet. CPL01544 – 2" x 3" offset coupling may be used and is factory supplied with 120 MBTUH furnaces. Canadian applications may use BAYREDUCE to meet ULC-S636 requirements.



### Condensate Trap Installation




21. Reinstall the condensate adapter if it was earlier removed or ensure adapter is still in place.

**Important:** The condensate adapter must be present for proper condensate drain operation.

22. Install condensate trap into new location by fitting into grommet and aligning the hole on the condensate trap with the hole labeled "HL".

**Important:** When installing a 21.0" wide S-Series furnace, the condenser trap grommet must be rotated so that the notch in the grommet faces the outer edge of the furnace cabinet as shown in the illustrations to the top left in next page. This allows the rain gutter tubing to fully seat onto the lower condensate port trap.

23. Hand tighten screw with a 1/4" nut driver. Do not over torque or use a drill gun.




24. Remove port cap on left of inducer and connect inducer condensate tubing. Connect other end of inducer condensate tubing to top port on the condensate trap. Cut tubing to length, if necessary.

25. Install previously removed port cap onto bottom port of the inducer.

26. Connect condensate pressure switch tubing to pressure port on the condensate trap.

**Important:** Trim the condensate pressure switch tubing to length to ensure there is no sag or trap created

27. Connect rain gutter condensate hose to the rain gutter and the lower port of the condensate trap.




## Furnace in Horizontal Left Position - Side Vented Combustion Air

Changes do not need to be made to the inducer orientation when installing the upflow furnace in the horizontal left position with the combustion air vented through the top. Changes are needed for hose routing, condensate trap orientation, and inducer port caps.

The figure below shows the furnace as it is sent from the factory.

Use the following steps to modify the furnace for horizontal left with top venting of combustion air.




Before proceeding, lay unit on its back to make the conversion easier.

1. Remove all drain hoses from condensate trap.


**Note:** When removing condensate hoses from the condensate trap, hold the trap with your hand to prevent the trap from breaking. Removing the trap before the hoses is also an option.

2. Remove drain tubing from bottom of inducer housing.
3. Remove rain gutter tubing from inducer outlet.
4. Remove tubing from condensate pressure switch.
5. Remove the screws that hold the condensate trap bracket. The condensate trap should not be removed from the condensate trap bracket. Remove assembly and retain for later installation.


**Note:** There is a plastic adapter with O-rings located inside the cold header that is held in place by the condensate trap bracket. Do not lose this adapter. This adapter needs to be in place when the condensate trap bracket is reattached.



6. Remove plug from 3" hole.
7. Install condensate trap grommet.



8. Attach the vent outlet gasket to the vent outlet.
9. Install vent outlet to top of cabinet using 2 screws supplied in the doc pack.
10. Install vent inlet gasket and vent inlet using 4 screws supplied in the doc pack.



11. Slide PVC through vent outlet adaptor and insert into inducer outlet.
12. Twist to insure PVC is fully inserted.




## Furnace Combustion Air Exhaust Options

13. Tighten the two clamps.

14. Install the combustion air inlet PVC pipe.

**Note:** The vent outlet adapter is used for strain relief against the weight of the venting. The clamp should be tightened after the internal connection is made.

**Note:** If required, transition to larger venting within 2' of the cabinet. An 2" x 3" offset coupling is required if the transition is made in a horizontal plane. Use coupling CPL01544 (Canadian applications may use BAYREDUCE to meet ULC-S636 requirements.) See Horizontal Venting section for proper orientation of 2" x 3" offset coupling.



### Condensate Trap Installation


15. Reinstall the condensate adapter if it was earlier removed or ensure adapter is still in place.

**Important:** The condensate adapter must be present for proper condensate drain operation.

16. Install condensate trap into new location by fitting into grommet and aligning the hole on the condensate trap with the hole labeled "HL".

**Important:** When installing a 21.0" wide S-Series furnace, the condenser trap grommet must be rotated so that the notch in the grommet faces the outer edge of the furnace cabinet as shown in the illustrations to the top right. This allows the rain gutter tubing to fully seat onto the lower condensate port trap.

17. Hand tighten screw with a 1/4" nut driver. Do not over torque or use a drill gun.




18. Remove port cap on left side of inducer and connect inducer condensate tubing. Connect other end of inducer condensate tubing to top port on the condensate trap. Cut tubing to length, if necessary.

19. Install previously removed port cap onto bottom port of the inducer. (As viewed in upflow)

20. Connect condensate pressure switch tubing to pressure port on the condensate trap.

**Important:** Trim the pressure switch tubing to length to ensure there is no sag or trap created.

21. Remove port plug from rain gutter and install in new position on opposite side of the rain gutter.
22. Connect rain gutter condensate hose to the rain gutter and the lower port of the condensate trap. Route rain gutter condensate hose to the right of the inducer motor.




### Furnace in Horizontal Right Position - Top Vented Combustion Air

Changes need to be made to the inducer orientation when installing the upflow furnace in the horizontal right position with the combustion air vented through the left side. Additional changes are needed for hose routing, condensate trap location, and inducer port caps, and the condensate plug.

The figure below shows the furnace as it is sent from the factory.

Use the following steps to modify the furnace for horizontal right with left side venting of combustion air.




Before proceeding, lay unit on its back to make the conversion easier.

1. Remove all drain hoses from condensate trap.

**Note:** When removing condensate hoses from the condensate trap, hold the trap with your hand to prevent the trap from breaking. Removing the trap before the hoses is also an option.


2. Remove drain tubing from bottom of inducer housing.
3. Remove rain gutter tubing from inducer outlet.
4. Remove tubing from condensate pressure switch.
5. Remove the screws that hold the condensate trap bracket. The condensate trap should not be removed from the condensate trap bracket. Remove assembly and retain for later installation.
6. Remove the adapter located inside the condensate trap connection on the cold header and retain for later installation.

**Note:** The plastic adapter with O-rings located inside the cold header that is held in place by the condensate trap bracket. Do not lose this adapter. This adapter needs to be in place when the condensate trap bracket is reattached.




7. Remove 3" plug on right side of unit. To be used for condensate trap.
8. Install condensate trap grommet.
9. Remove two 3" plugs on left side of cabinet.
10. Reuse the two 3" plugs to seal the two 3" default openings on the top of the cabinet.








11. Attach the vent outlet gasket to the vent outlet.
12. Install vent outlet to top of cabinet using 2 screws supplied in the doc pack.
13. Install vent inlet gasket and vent inlet using 4 screws supplied in the doc pack.



14. Remove three inducer screws.
15. Loosen hose clamp and remove 45 degree adapter. If the rubber boot pulls out of the inducer opening, remove from the adapter and reinstall onto the inducer.
16. Rotate the inducer so that the outlet is pointing vertically.
17. Use the three inducer screws to reattach the inducer to the cold header. Torque to 30 in.-lbs. Do not overtighten.



18. Remove condensate drain plug from top right location on cold header.
19. Place condensate drain plug onto the cold header outlet located on the bottom left of the cold header.




20. Slide PVC through vent outlet adaptor and insert into inducer outlet.
21. Twist to insure PVC is fully inserted.
22. Tighten the two clamps.
23. Install the combustion air inlet PVC pipe.

**Note:** The vent outlet adapter is used for strain relief against the weight of the venting. The clamp should be tightened after the internal connection is made.



**Note:** If required, transition to larger venting within 2' of the cabinet. CPL01544 – 2" x 3" offset coupling may be used and is factory supplied with 120 MBTUH furnaces. Canadian applications may use BAYREDUCE to meet ULC-S636 requirements.



## Condensate Trap Installation




24. Reinstall the condensate adapter if it was earlier removed or ensure adapter is still in place.

**Important:** The condensate adapter must be present for proper condensate drain operation.


25. Install condensate trap into new location by fitting into grommet and aligning the hole on the condensate trap with the hole labeled "HR".

**Important:** When installing a 21.0" wide S-Series furnace, the condenser trap grommet must be rotated so that the notch in the grommet faces the outer edge of the furnace cabinet as shown in the illustrations below and to the top right. This allows the rain gutter tubing to fully seat onto the lower condensate port trap.

26. Hand tighten screw with a 1/4" nut driver. Do not over torque or use a drill gun.



27. Remove port cap on the right side of the inducer and connect inducer condensate tubing. Connect other end of inducer condensate tubing to top port on the condensate trap. Cut tubing to length, if necessary.
28. Install previously removed port cap onto bottom port of the inducer.
29. Connect condensate pressure switch tubing to pressure port on the condensate trap.  
**Important:** Cut to length to ensure there is no sag or trap created.
30. Connect rain gutter condensate hose to the rain gutter and the lower port of the condensate trap.




### Furnace in Horizontal Right Position - Left Vented Combustion Air

Changes need to be made to the inducer orientation when installing the upflow furnace in the horizontal right position with the combustion air vented through the bottom. Additional changes are needed for hose routing, condensate trap location, and inducer port caps, and the condensate plug.

The figure below shows the furnace as it is sent from the factory.

Use the following steps to modify the furnace for horizontal right with bottom venting of combustion air.



Before proceeding, lay unit on its back to make the conversion easier.


1. Remove all drain hoses from condensate trap.

**Note:** When removing condensate hoses from the condensate trap, hold the trap with your hand to prevent the trap from breaking. Removing the trap before the hoses is also an option.


2. Remove drain tubing from bottom of inducer housing.

3. Remove rain gutter tubing from inducer outlet.
4. Remove tubing from condensate pressure switch.
5. Remove the screws that hold the condensate trap bracket. The condensate trap should not be removed from the condensate trap bracket. Remove assembly and retain for later installation.
6. Remove the condensate adapter located inside the condensate trap connection on the cold header and retain for later installation.




**Note:** The plastic condensate adapter with O-rings located inside the cold header that is held in place by the condensate trap bracket. Do not lose this adapter. The condensate adapter needs to be in place when the condensate trap bracket is reattached.




7. Remove 3" plug on right side of unit. To be used for condensate trap.
8. Install condensate trap grommet.
9. Remove 3" plugs on the left side of the cabinet. To be used for combustion air inlet.
10. Reuse the two 3" plugs to seal the two 3" default openings on the top of the furnace.



11. Remove three inducer screws.
12. While the inducer is loose, remove condensate drain plug from top right location on cold header.
13. Place condensate drain plug onto the cold header outlet located on the bottom left of the cold header.
14. Rotate the inducer 180 degrees so that the elbow is pointing towards the left.
15. Use the three inducer screws to reattach the inducer to the cold header. Torque to 30 in.-lbs. Do not overtighten.




16. Cut 3" hole in bottom panel using large dimple as guide.




17. Attach the vent outlet gasket to the vent outlet.
18. Install vent outlet to top of cabinet using 2 screws supplied in the doc pack.
19. Install vent inlet gasket and vent inlet using 4 screws supplied in the doc pack.

**Note:** The vent outlet adapter is used for strain relief against the weight of the venting. The clamp should be tightened after the internal connection is made.

**Note:** If required, transition to larger venting within 2' of the cabinet. An 2" x 3" offset coupling is required if the transition is made in a horizontal plane. Use coupling CPL01544 (Canadian applications may use BAYREDUCE to meet ULC-S636 requirements.) See Horizontal Venting section for proper orientation of 2" x 3" offset coupling.



20. Slide PVC through vent outlet adaptor and insert into inducer outlet.
21. Twist to insure PVC is fully inserted.
22. Tighten the two clamps.
23. Install the combustion air inlet PVC pipe.



### Condensate Trap Installation




24. Reinstall the condensate adapter if it was earlier removed or ensure adapter is still in place.

**Important:** The condensate adapter must be present for proper condensate drain operation.

25. Install condensate trap into new location by fitting into grommet and aligning the hole on the condensate trap with the hole labeled "HR".

**Important:** When installing a 21.0" wide S-Series furnace, the condenser trap grommet must be rotated so that the notch in the grommet faces the outer edge of the furnace cabinet as shown in the illustrations to the top right. This allows the rain gutter tubing to fully seat onto the lower condensate port trap.


26. Hand tighten screw with a 1/4" nut driver. Do not over torque or use a drill gun.



27. Remove port cap on the right side of inducer and connect inducer condensate tubing. Connect other end of inducer condensate tubing to top port on the condensate trap. Cut tubing to length, if necessary.
28. Install previously removed port cap onto bottom port of the inducer. (As viewed in upflow)
29. Connect condensate pressure switch tubing to pressure port on the condensate trap.


**Important:** Cut to length to ensure there is no sag or trap created.

30. Remove port plug from rain gutter and install in new position on opposite side of the rain gutter.
31. Connect rain gutter condensate hose to the rain gutter and the lower port of the condensate trap. Route rain gutter condensate hose to the right of the inducer motor.




### Downflow Furnace - Top Vented Combustion Air

No changes need to be made to the inducer when installing the downflow furnace with the combustion air vented through the top.



1. Attach the vent outlet gasket to the vent outlet.
2. Install vent outlet to top of cabinet using 2 screws supplied in the doc pack.
3. Install vent inlet gasket and vent inlet using 4 screws supplied in the doc pack.




4. Slide PVC pipe through vent outlet adaptor and insert into inducer outlet.
5. Twist to insure PVC is fully inserted.
6. Tighten the two clamps.
7. Install the combustion air inlet PVC pipe.

**Note:** The vent outlet adapter is used for strain relief against the weight of the venting. The clamp should be tightened after the internal connection is made.

**Note:** If required, transition to larger venting within 2' of the cabinet. CPL01544 – 2" x 3" offset coupling may be used and is factory supplied with 120 MBTUH furnaces. Canadian applications may use BAYREDUCE to meet ULC-S636 requirements.

**Important:** Trim the pressure switch tubing to length to ensure there is no sag or trap created.




### Downflow Furnace - Left Side Vented Combustion Air

Changes need to be made to the inducer orientation when installing the downflow furnace with the combustion air vented through the side.

The figure below shows the furnace as it is sent from the factory.

Use the following steps to modify the furnace for downflow with side venting of combustion air.

**Important:** Right side vent outlet is not allowed because condensate will not drain.




Before proceeding, lay unit on its back to make conversion easier.

1. Disconnect all drain tubes from condensate trap.


**Note:** When removing condensate hoses from the condensate trap, hold the trap with your hand to prevent the trap from breaking.

**Note:** If preferred, the trap may be removed before the hoses.


2. Remove drain tubing from bottom of inducer housing.
3. Remove rain gutter tubing from inducer outlet.
4. Remove tubing from condensate pressure switch.




5. Remove two 3" plugs on left side of cabinet. To be used for combustion air exhaust and inlet.
6. Reuse the two 3" plugs to seal the two 3" default openings on the top of the cabinet.



7. Loosen hose clamp and remove 45 degree adapter. If the rubber boot pulls out of the inducer opening, remove from the adapter and reinstall onto the inducer. Remove the elbow and discard.




8. Remove the three inducer mounting screws.
9. Rotate inducer counterclockwise so that the inducer outlet aligns with the exhaust vent outlet.
10. Reinsert and tighten screws to 30 in.-lbs. Do not overtighten.



11. Attach the vent outlet gasket to the vent outlet.
12. Install vent outlet to cabinet using 2 screws supplied in the doc pack.


13. Install vent inlet gasket and vent inlet using 4 screws supplied in the doc pack.
14. Install the grommet for the condensate drain tube. The drain may be located on either side of the cabinet.



15. Slide PVC through vent outlet adaptor and insert into inducer outlet.
16. Twist to insure PVC is fully inserted.
17. Tighten the two clamps.
18. Install the combustion air inlet PVC pipe.

**Note:** The vent outlet adapter is used for strain relief against the weight of the venting. The clamp should be tightened after the internal connection is made.


**Note:** If required, transition to larger venting within 2' of the cabinet. An 2" x 3" offset coupling is required if the transition is made in a horizontal plane. Use coupling CPL01544 (Canadian applications may use BAYREDUCE to meet ULC-S636 requirements.) See Horizontal Venting section for proper orientation of 2" x 3" offset coupling.



19. Remove port cap at bottom of inducer and connect inducer condensate tubing. Connect other end of inducer condensate tubing to top port on the condensate trap. Cut tubing to length, if necessary.
20. Install previously removed port cap onto bottom port of the inducer.
21. Connect condensate pressure switch tubing to pressure port on the condensate trap.


**Important:** Trim the condensate pressure switch tubing to length to ensure there is no sag or trap created.

22. Remove port plug from rain gutter and install in new position on opposite side of the rain gutter.
23. Connect rain gutter condensate hose to the rain gutter and the lower port of the condensate trap. Cut to length, as required.






# Integrated Furnace Control Menu



## A951X System Status Menu




**IdL** = Idle, no demand for cooling, heating, or fan  
**Ht** = Demand for gas heat  
**CP1** = Demand for compressor cooling / Heat pump  
**COF** = Demand for continuous fan  
**dFt** = Demand for outdoor unit defrost, furnace running in gas heat mode  
**tP 1-9** = Tap selected for airflow

### NOTE:

- (1) The menu status displayed is solely dependent on the input of 24VAC that is applied to the low voltage terminal strip.
- (2) The status will alternate between the system mode and the airflow request every 2 seconds.
- (3) If an error occurs, an E\*. \* will alternately flash with the system mode and airflow request. See first example

# Belly Band Location

Distance from belly band to the back side off motor for minimum vibration


|  <p>Blower housings and wheel removed from view for clarity.</p> | Furnace Model Number                                                                                                       | Dimension "A" (inches) |
|---------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------|------------------------|
|                                                                                                                                                   | A951X060BU4SAC<br>A951X080BU4SAC                                                                                           | 2.65                   |
|                                                                                                                                                   | A951X080BD4SAC                                                                                                             | 3.54                   |
|                                                                                                                                                   | A951X100CU5SAC                                                                                                             | 3.81                   |
|                                                                                                                                                   | A951X040BU3SAC<br>A951X040BD3SAC<br>A951X060BD3SAC<br>A951X080CU5SAC<br>A951X100CD5SAC<br>A951X120DU5SAC<br>A951X120DD5SAC | 3.91                   |

# Setting Airflow

With all ductwork connected and a clean filter in place, measure the External Static Pressure (ESP) of the unit in locations below. Use the appropriate airflow table in the Airflow Tables section for the furnace and outdoor unit installed.

Measurements must be made prior to the evaporator coil, if equipped, and after the filter.

**Note:** Check out [fieldtechhelp.com](http://fieldtechhelp.com) to watch a short video.



**A951X080BU4 Furnace Airflow (CFM) at. External Static Pressure (in. W.C.) versus Tap**

|     |              | Static     |            |                           |                           |            |
|-----|--------------|------------|------------|---------------------------|---------------------------|------------|
|     |              | 0.1        | 0.3        | 0.5                       | 0.7                       | 0.9        |
| Tap |              |            |            |                           |                           |            |
| 1   | SCFM / Watts | 911 / 94   | 766 / 104  | 622 / 115                 | 477 / 125                 | 332 / 136  |
| 2   | SCFM / Watts | 1075 / 139 | 963 / 153  | 851 / 168                 | 740 / 182                 | 628 / 197  |
| 3   | SCFM / Watts | 1215 / 185 | 1121 / 202 | 1028 / 219                | 934 / 236                 | 840 / 253  |
| 4   | SCFM / Watts | 1250 / 203 | 1164 / 221 | 1077 <sup>(a)</sup> / 239 | 990 / 257                 | 903 / 274  |
| 5   | SCFM / Watts | 1349 / 251 | 1272 / 271 | 1194 / 291                | 1116 <sup>(a)</sup> / 310 | 1039 / 330 |
| 6   | SCFM / Watts | 1453 / 313 | 1387 / 335 | 1321 / 356                | 1254 / 378                | 1188 / 400 |
| 7   | SCFM / Watts | 1505 / 340 | 1438 / 362 | 1372 / 384                | 1305 / 406                | 1239 / 427 |
| 8   | SCFM / Watts | 1657 / 453 | 1597 / 477 | 1538 / 500                | 1479 / 524                | 1419 / 547 |
| 9   | SCFM / Watts | 1878 / 669 | 1815 / 686 | 1752 / 702                | 1690 / 718                | 1627 / 735 |

<sup>(a)</sup> Example 1

Example 1: A951X080BU4SAB (Default Tap 7)

Cooling / HP

- 3 Ton Single Stage Outdoor
- Total ESP = 0.7" W.C.

- Required Airflow = 1050 cfm (3T x 350 cfm/ton)
- New Tap Number = Tap 5 (Re-check static pressure and adjust airflow as necessary)

# Integrated Furnace Control Display Codes

| Menu Options |                                                                                                     |
|--------------|-----------------------------------------------------------------------------------------------------|
| <i>IdL</i>   | Idle                                                                                                |
| <i>Err</i>   | Active Alarm Errors                                                                                 |
| <i>L6F</i>   | Last 6 Faults (To clear — Hold Option button down for 5 seconds after entering the <i>L6F</i> menu) |
| <i>Cr</i>    | Code Release Number                                                                                 |
| <i>COd</i>   | Cooling Off Delay (Seconds)                                                                         |
| <i>OdU</i>   | Outdoor Unit Type                                                                                   |
| <i>COF</i>   | Blower Constant Fan Airflow                                                                         |
| <i>HOd</i>   | Heat Off Delay (Seconds)                                                                            |
| <i>gHC</i>   | Gas Heating CFM                                                                                     |
| <i>rUn</i>   | Run Test Mode                                                                                       |

| Error Codes      |                                                                             |
|------------------|-----------------------------------------------------------------------------|
| Alarm Error Code | Alarm Explanation                                                           |
| <i>E01</i>       | Loss of the IRQ or other internal failures (Internal IFC error)             |
| <i>E2.1</i>      | Retry Exceeded (Flame never sensed, one hour lockout after 6 times)         |
| <i>E2.2</i>      | Recycles Exceeded (Flame sensed then lost, one hour lockout after 10 times) |
| <i>E2.3</i>      | Gas Valve Not Energized When It Should Be exceeded after 10 times           |
| <i>E3.1</i>      | Shorted Pressure Switch                                                     |
| <i>E3.2</i>      | Open Pressure Switch                                                        |
| <i>E04</i>       | Open Limit (Main Thermal, Rollout Switch, or Reverse Airflow Switch)        |
| <i>E05</i>       | Flame detected, should not be present                                       |
| <i>E6.1</i>      | Voltage reversed polarity                                                   |
| <i>E6.2</i>      | Bad grounding                                                               |
| <i>E6.3</i>      | (1) Igniter relay fails                                                     |
|                  | (2) Igniter open                                                            |
| <i>E7.1</i>      | Gas valve (MVL) is energized when it should be off                          |
| <i>E08</i>       | Flame current is low, but still strong enough to allow operation            |
| <i>E09</i>       | Open Inducer Limit Switch or Condensate Pressure Switch                     |
| <i>E11</i>       | Gas valve not energized when it should be                                   |
|                  | Gas valve relay stuck closed                                                |
| <i>E12</i>       | Open fuse                                                                   |

## Fault Code Recovery

### Fault Code Recovery

1. To view the last 6 faults, press the "Menu" key until the "Last 6 Faults" (L6F) menu appears.
2. Enter the menu by pressing the "Option" key.
3. The last 6 faults can be viewed.


### Clearing the Last 6 Faults

1. To clear the last 6 faults, press the "Menu" key until the "Last 6 Faults" (L6F) menu appears.
2. Enter the menu by pressing the "Option" key.
3. Hold the "Option" key for at least 5 seconds.
4. Release and a set of 3 dashes will be seen 3 times. This confirms the faults have been cleared.

### Resetting Factory Defaults

1. Display must be in Idle Mode.
2. Push the "Menu" and "Option" buttons at the same time for 15 seconds then release.
3. The 7 segment will flash "Fd" 3 times. This confirms the unit has been reset to the factory defaults.

A951X IFC Component Layout



# Troubleshooting

The following pages include troubleshooting flowcharts in reference to the A951X single stage furnaces only


The information contained is for reference only and does not cover all scenarios or problems that may be encountered.

ONLY qualified technicians should attempt to install, troubleshoot, or repair this appliance.

Failure to follow all cautions and/or warnings could result in personal or property damage, including death.


| Error Codes      |                                                                             |
|------------------|-----------------------------------------------------------------------------|
| Alarm Error Code | Alarm Explanation                                                           |
| E01              | Loss of the IRQ or other internal failures (Internal IFC error)             |
| E2_1             | Retry Exceeded (Flame never sensed, one hour lockout after 6 times)         |
| E2_2             | Recycles Exceeded (Flame sensed then lost, one hour lockout after 10 times) |
| E2_3             | gas Valve Not Energized When It Should Be exceeded after 10 times           |
| E3_1             | Shorted Pressure Switch                                                     |
| E3_2             | Open Pressure Switch                                                        |
| E04              | Open Limit (Main Thermal, Rollout Switch, or Reverse Airflow Switch)        |
| E05              | Flame detected, should not be present                                       |
| E6_1             | Voltage reversed polarity                                                   |
| E6_2             | Bad grounding                                                               |
| E6_3             | (1) Igniter relay fails                                                     |
|                  | (2) Igniter open                                                            |
| E7_1             | Gas valve (MVL) is energized when it should be off                          |
| E08              | Flame current is low, but still strong enough to allow operation            |
| E09              | Open Inducer Limit Switch or Condensate Pressure Switch                     |
| E 11             | See Troubleshooting Instructions                                            |
| E 12             | Open fuse                                                                   |
| E 14 / E 18      | Refer troubleshooting flow chart                                            |

# A951X IFC Component Layout





## GETTING STARTED



Refer to Gas Furnace Silicon Nitride Ignitor Models Service Manual to supplement this information.  
Publication Number 34-3405-08

### DEFINITION :

Internal Failure of the Control Board

### E01 Fault Code

Replace IFC



## DEFINITION

RETRY Lock Out = 3 unsuccessful tries for ignition within a single call for heat. Lockout period is for one hour

**Flame has never been sensed**

Turn all gas appliances on

## 2.1 Fault Code



There are two flame sense pads located on the IFC, marked "FP". To measure flame current, use a VOM set to DC volts. Flame current will vary depending on the type of meter used. Typical flame current ranges from 0.75 – 3.0 micro-amps (0.75 – 3.0 VDC)



## DEFINITION

RECYCLE Lock Out = 10 recycles within a single call for heat. Lockout period is for one hour.

## Flame is sensed & then lost

Turn all gas appliances on

## 2.2 Fault Code



There are two flame sense pads located on the IFC, marked "FP". To measure flame current, use a VOM set to DC volts. Flame current will vary depending on the type of meter used. Typical flame current ranges from 0.75 – 3.0 micro-amps (0.75 – 3.0 VDC)

### DEFINITION

Gas Valve not energized when it should be 10 times within the same call for heat.

**24VAC not sensed on MVL 10 times**

### 2.3 Fault Code

Replace IFC

### DEFINITION

An error has occurred with the PS1, indicating that the pressure switch is closed when it should be open.

**In most cases, the pressure switch is not the problem.**

**NOTE:** Verify pressure switch wiring and tube routing are correct.


### Note #1

OL = Open Switch

0 ohms = Closed Switch

### 3.1 Fault Code

Cycle power OFF to the furnace and remove Orange wire from PS1



## DEFINITION

An error has occurred with the PS1 indicating that the pressure switch is either open when it should be closed.

**In most cases, the pressure switch is not the problem.**

**NOTE:** Verify pressure switch wiring and tube routing are correct.

PS1 Open errors can occasionally happen when wind gusts occur.


## 3.2 Fault Code


### Note #1

24 volts = Open Switch  
0 volts = Closed Switch

### Note #2

Measured pressure is negative, greater than refers to magnitude only.






## DEFINITION:


Limit switches are safety devices that will open when an abnormal high temperature has been sensed.  
**REMOVE ALL JUMPER WIRING TO SWITCHES!**  
 Under no circumstances, shall these switches be left jumpered when not troubleshooting.

## 4.0 Fault Code Flame Rollout



**DEFINITION:**


Flame is sensed when it should not be sensed.





## DEFINITION


Polarity Fault – Incoming high voltage wiring is reversed



## DEFINITION

Ground Fault - Incoming or chassis ground connection is not sensed

## 6.2 Fault Code




### DEFINITION


Igniter Relay Fault – The control board has sensed that the igniter relay has stuck closed

Ignitor Fault – The control board has sensed that the ignitor circuit is open or shorted.

### 6.3 Fault Code





DEFINITION: External Gas Valve  
Circuit Error (24 volts is present  
when it should not be present)




**DEFINITION:**  
The flame sense current is less than 0.5 micro-amp DC

## 08 Fault Code



There are two flame sense pads located on the IFC, marked "FP". To measure flame current, use a VOM set to DC volts. Flame current will vary depending on the type of meter used. Typical flame current ranges from 0.75 – 3.0 micro-amps (0.75 – 3.0 VDC)




## Definition:

Condensate Pressure Switch Open: The condensate system is free flowing and opened the safety switch OR

Inducer Limit: This error is normally caused by improper installation or application of the furnace venting system.

## 09 Fault Code




Definition:  
The IFC has detected that internal gas valve  
relays have failed.

### 11 Fault Code

Verify all wiring  
Replace IFC


Definition:  
The onboard 5 amp fuse is open or missing.

### 12 Fault Code



## DEFINITION:

These errors has been reported in association with the S9X2 model furnaces on initial start-up. They are not valid errors but can typically be corrected by following the flow chart.



# Sequence of Operation

## Gas Heating

1. R – W contacts close on the thermostat sending 24VAC to the W1 low voltage terminal of the IFC. Technician should read 24VAC from W1 to B/C. The seven-segment LED will read:  
 $H\bar{L}$  = Gas Heating
2. The IFC performs a self-check routine and then confirms that the:
  - a. Condensate pressure switch and Inducer limit switch are closed by sending 24VAC out the HLO terminal and monitoring the ILI input.
  - b. Flame roll-out switches (FRS) 1 & 2, main thermal limit (TCO), and any reverse air flow (RAF) switches are closed by sending 24VAC out the HLO terminal and monitoring the HLI input.
  - c. Pressure switch 1 (PS1) is opened by sending 24VAC out the HLO terminal, through the limit switches, and monitoring the PS1 input.

**Note:** If a thermal limit is open, 24VAC will not be present at the pressure switch.
3. After steps a, b, and c are confirmed, the inducer relay is closed energizing the inducer motor.
4. As the inducer ramps up, PS will close.
5. When PS closes, the ignitor relay on the IFC will close. The ignitor is energized. The ignitor warm up is approximately 17 seconds.
6. After the ignitor warm up, the gas valve relay is closed, which energizes the gas valve solenoid to allow ignition.
7. The first burner will ignite, and flame will crossover to the remaining burners, establishing current to the flame sensor. Proof of flame must be established within 4 seconds.

**Note:** There are two flame sense pads located on the IFC marked as "FP". To measure the flame current, use a VOM set to DC volts. 1VDC = 1 micro-amp. Flame current will vary depending on the type of meter used. Typical flame current ranges from 0.75 – 3.0 micro-amps (0.75 – 3 VDC).

8. Once flame sense has been established, a timer on the IFC starts, and the indoor blower will energize after the blower "Heat On Delay" has completed.. The seven-segment LED for example will alternately read:  
 $H\bar{L}$  = Gas heating  
 $\bar{L}P5$  = Speed Tap 5
9. When the temperature raises enough to satisfy the thermostat setting, contacts R-W will open.
10. The gas valve relay will open, closing the gas valve. The inducer will continue to run for approximately 5 seconds to remove any combustion by-products from inside the furnace.
11. The indoor blower continues to run to remove heat from the heat exchangers. The blower off time is field adjustable through the IFC menu setup option. The seven segment LED will read  $\bar{I} d\bar{L}$  = Idle, no thermostat demand.

## Cooling / Heat Pump

1. R-Y1-G contacts on the thermostat close sending 24VAC to the Y1 and G low voltage terminals on the IFC. Technician should read 24VAC between Y1-B/C and between G-B/C.
2. 24VAC is sent to the OD unit via thermostat wiring.
3. The indoor blower ramps to the cooling / heat pump airflow. The seven-segment LED, for example, will alternately read:  
 $\bar{C}P\bar{I}$  = Cooling / Heat Pump  
 $\bar{L}P7$  = Speed Tap 7
4. When the temperature is lowered / raised (PH mode) enough to satisfy the thermostat setting, contacts R-Y-G will open.
5. The OD unit shuts off and the indoor blower shuts off, unless a blower "Cool Off Delay" has been enabled in the IFC setup menu options. The seven-segment LED will read  $\bar{I} d\bar{L}$  = Idle, no thermostat demand.



# Periodic Servicing Requirements

## 1. GENERAL INSPECTION – *Examine the furnace installation annually for the following items:*

- a. All flue product carrying areas external to the Furnace (i.e. chimney, vent connector) are clear and free of obstruction. A vent screen in the end of the Vent (flue) Pipe must be inspected for blockage annually, if applicable.
- b. The vent connector is in place, slopes upward and is physically sound without holes or excessive corrosion.
- c. The return air duct connection(s) is physically sound, is sealed to the Furnace and terminates outside the space containing the Furnace.
- d. The physical support of the Furnace should be sound without sagging, cracks, gaps, etc., around the base so as to provide a seal between the support and the base.

## 2. FILTERS – Filters should be cleaned or replaced (with high velocity filters only), monthly and more frequently during high use times of the year such as midsummer or midwinter.

## 3. BLOWERS – The Blower size and speed determine the air volume delivered by the Furnace. The Blower motor bearings are factory lubricated and under normal operating conditions do not require servicing. Annual cleaning of the Blower wheel and housing is recommended for maximum air output, and this must be performed only by a qualified servicer or service agency.

## 4. IGNITER – This unit has a special hot surface direct ignition device that automatically lights the burners. Please note that it is very fragile and should be handled with care. ! CAUTION Do NOT touch igniter. It is extremely hot.

## 5. BURNER – Gas burners do not normally require scheduled servicing, however, accumulation of foreign material may cause a yellowing flame or delayed ignition. Either condition indicates that a service call is required. For best operation, burners must be cleaned annually using brushes and vacuum cleaner. Turn off gas and electric power supply. To clean burners, remove burner bottom plate (2 screws) and bottom burner bracket (2 screws). Twist burner towards slot, lift, and push forward away from orifice. Remove burners.

Alternate method — Remove manifold assembly, bottom burner plate, and bottom burner bracket. Remove burners.

**Note:** Be careful NOT to break igniter when removing burners.

Clean burners with brush and/ or vacuum cleaner. Reassemble parts by reversal of the above procedure.

**Note:** Natural gas units should not have any yellow tipped flames. This condition indicates that a service call is required. For best operation, burners must be cleaned annually using brushes and vacuum cleaner

**Note:** On Propane units, due to variations in BTU content and altitude, servicing may be required at shorter intervals.

## 6. HEAT EXCHANGER/ FLUE PIPE – These items must be inspected for signs of corrosion, and/ or deterioration at the beginning of each heating season by a qualified service technician and cleaned annually for best operation. To clean flue gas passages, follow recommendations below:

- a. Turn off gas and electric power supply.
- b. Inspect flue pipe exterior for cracks, leaks, holes or leaky joints. Some discoloration of PVC pipe is normal.
- c. Remove door from Furnace.
- d. Inspect around insulation covering flue collector box. Inspect induced draft Blower connections from recuperative cell and to the flue pipe connection.
- e. Remove burners. (See 5. Burner)
- f. Use a mirror and flashlight to inspect interior of Heat Exchanger, be careful not to damage the Igniter, Flame Sensor or other components.
- g. If any corrosion is present, the Heat Exchanger should be cleaned by a qualified service technician.
- h. After inspection is complete replace burners and Furnace door.
- i. Restore gas supply. Check for leaks using a soap solution. Restore electrical supply. Check unit for normal operation.

## 7. COOLING COIL CONDENSATE DRAIN - If a cooling coil is installed with the Furnace, condensate drains should be checked and cleaned periodically to assure that condensate can drain freely from coil to drain. If condensate cannot drain freely water damage could occur.

### About Trane and American Standard Heating and Air Conditioning

Trane and American Standard create comfortable, energy efficient indoor environments for residential applications. For more information, please visit [www.trane.com](http://www.trane.com) or [www.americanstandardair.com](http://www.americanstandardair.com).



The manufacturer has a policy of continuous data improvement and it reserves the right to change design and specifications without notice. We are committed to using environmentally conscious print practices.