Acrox RX1K Wireless Keyboard with Nano Receiver User Guide

Contents

1 Acrox RX1K Wireless Keyboard with Nano Receiver
2 Specifications
3 Product Usage Instructions
4 FAQs
5 FCC
6 Functional Introduction
7 Installing the batteries
8 Documents / Resources
8.1 References
9 Related Posts

Acrox

Acrox RX1K Wireless Keyboard with Nano Receiver



Specifications

- Product: Wireless Keyboard w/Nano Receiver
- Version: 1.00
- Batteries: AAA x 2

Product Usage Instructions

Functional Introduction

1. Media Player on: Turn on the Media player program
2. Volume down (Voice-): Decrease the computer's sound volume.
3. Volume up (Voice+): Increase the computer's sound volume.
4. Mute: Mute (turns off) the computer's sound

Installing the Batteries

1. Step 1: Take the battery cover off.
2. Step 2: Insert the battery as shown inside the battery compartment.
3. Step 3: Replace the cover.

Setup Connection between Receiver and Keyboard

1. Insert the battery into the Keyboard.
2. Plug the Nano receiver into the USB port on your computer; the LED indicator will flash for 10 seconds to complete connecting.
3. If the device does not work, turn it into pairing mode.
4. For pairing: Re-plug the receiver into the USB port on your computer, then press the keyboard ESC + K; the LED indicator will flash for 15 seconds. Please re-plug again until the Led indicator turns off to complete pairing.
5. If the keyboard does not work after 15 seconds, pair them again. (The receiver has an auto-pairing function).
6. The LED indicator on the Keyboard flashes steadily when it is in pairing mode.

FAQs

- **Q: What should I do if my keyboard is not working after following the pairing instructions?**
  - A: If the keyboard does not work after 15 seconds of pairing, please try pairing them again. Ensure to follow the correct steps mentioned in the manual.

FCC

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, under Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used by the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Radiation Exposure Statement:

The product complies with the FCC portable RF exposure limit set forth for an uncontrolled environment and is safe for intended operation as described in this manual. Further RF exposure reduction can be achieved if the product can be kept as far as possible from the user body or set the device to lower output power if such a function is available.

Functional Introduction



Key Function (* compound key, Press with Fn key)			
1.		Media Player on	Turn on the Media player program
2		Volume down (Voice-)	Decrease the computer's sound volume.
3.		Volume up (Voice+)	Increase the computer's sound volume.
4.		Mute	Mute (turns off) the computer's sound
5.		Previous	Switch to the previous media track
6.		Next	Switch to the next media track
7.		Play/Pause	Switch between playing and pausing media
8.		Stop(Media)	Stop playing the media in the media player
9.		Homepage(www/e)	Start the default Web browser and loads the home Web page
10.		Outlook(E-mail)→Default	Start the default e-mail program
11.		My Computer	My Computer
12.		My Favorites	Open My favorite after into Internet browser application
13.	LED Indicator		Num Lock / Caps Lock / Low Battery(Pairing Indicator)
14	ON/OFF Switch		
15	Battery Cover		
16	Nano Receiver		

Installing the batteries

- **Step 1**: Take the battery cover off.
- **Step 2**: Insert the battery as shown inside the battery compartment.
- **Step 3**: Replace the cover.



Warning:

Please insert the battery in the correct position according to the instruction label on the mouse & Keyboard.

Set up the Connection between the Receiver and the Keyboard.

1. Insert the battery into the Keyboard, then follow the steps below.
2. Plug the Nano receiver into the USB port on your computer, the LED indicator will flash 10sec. To complete connecting.

3. If the device does not work, please turn it into pairing mode.
4. Pairing: Re-plug the receiver into the USB port on your computer, then press the board “ESC + K “the LED indicator will flash 15sec. Please re-plug again, the Led indicator will off complete the paring. If the keyboard does not work after 15 seconds, pair them again. (The receiver has auto auto-pairing function).
5. The LED indicator on the Keyboard flashes steadily when it is in pairing mode and stops blinking when it is successfully paired with the receiver.
6. When the low energy, the battery indicator on the keyboard will start to blink.



Documents / Resources

	Acrox RX1K Wireless Keyboard with Nano Receiver [pdf] User Guide KB65, RX1K Wireless Keyboard with Nano Receiver, RX1K, Wireless Keyboard with Nano Receiver, Keyboard with Nano Receiver, Nano Receiver, Receiver

References

- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth

SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.