AKKO 3061 Mechanical Keyboard User Manual

AKKO 3061 Mechanical Keyboard User Manual

Contents

Technical Specifications

Dimensions	292 x 101 x 37mm
Weight	Approximately 0.5KG
Country of Origin	China
Type	Mechanical Keyboard
Keycap	PBT Material
Interface	Type-C To USB
Multimedia Keys	YES
N-Key Rollover	YES
Custom Keys	YES (use Akko Marco V1.0)

HotKeys

Fn+	ESC	=	~
	1 - 0		F1 - F10
	-		F11
	=		F12
	Backspace		Delete

Fn+	W	=	↑
	A		←
	S		↓
	D		→
	I		Insert

Fn+	P	=	PrtSc
	C		Calculator
	M		Mute
	<		Decrease Volume
	>		Increase Volume

System Commands

| Fn+W (Long press 3S)	Fn+Right Win+ R (Long press 3S)
Swap W A S D with ↑ ↓ ← →.	Switch to right Win key to become the Menu key. Press and hold to switch back.

Left Win+Right Win (Long press 5S)	Fn+Left Win/Right Win
Restore to the factory settings.	Press to lock the Win key and press again to unlock.

Single – Color Backlight

* Backlight function is only available on the backlight version of 3061s.

Fn+	[	=	Dim
	]		Bright
	\		Lighting effects cycles among Steady / Breathe / One-key light up / One-key light off Wave / Ripple / Raindrop

Akko Macro V1.0 Macro Setup Instruction 1

1. Akko Macro V1.0 is hardware-based and works without software-driven.

2. The following keys cannot be programmed: "Esc", "Fn", "Left Win" and "Right Win".

3. Press and hold Fn + Win for 3 seconds to switch to the Macro mode. When the keyboard is re-connected or the system is restarted, the Macro mode will be exited. You need to switch to the Macro mode again to use programmed keys.

4. Akko Macro V1.0 does not support simultaneous trigger, that is, pressing "AB" at the same time will trigger the two keys in the order of A followed by B.

5. Akko Macro V1.0 does not support customized interval time, that is, the trigger interval between key A and key B cannot be defined and will follow the system's default trigger time.

Akko Macro V1.0 Macro Setup Instruction 2

Clear Macro: If a key has been defined, after entering the Macro editor, you can press "FN + the key" to clear its definition.
If you want to re-customize that key, press "FN + the key" again to start the new Macro recording after clearing its old definition.

Macro Recording Example: Define "A" as "AKKOGEAR"

Step 1: Press Fn + left Win for 3 seconds to enter the Macro mode.

Step 2: Press Fn + ESC to launch Macro editor.

Step 3: Press Fn + A. This means we choose key "A" to record.

Step 4: Press A, K, K, O, G, E, A, R in order as replacement definition of "A".

Step 5: Press Fn + A again to end the Macro recording of key "A".

At this point, pressing "A" in notepad will display "AKKOGEAR".

If you want to create a Macro for key "B", press Fn + B to start the Macro recording.

Step 6: Press Fn + Esc to exit Macro editor.

Under the Macro mode, you can configure the keys and Macros you set.

Step 7: Press and hold Fn + Left Win for 3 seconds to exit the Macro mode and return to the default key definition.

## Akko Warranty and Service Statement

1. Akko provides 1-yr warranty for customers in mainland China. For other regions, please contact your seller (Akko distributor) for specific warranty policy.

2. If the warranty window expires, customers need to pay for repairs. Akko will also provide instructions if users prefer to repair the keyboard by themselves. However, users shall take full responsibility for any loss happened during self-repair.

3. Dissembling the keyboard without manufacturer/seller's instruction will immediately void the warranty.

4. The return and warranty policy may vary in different platforms and are subject to the specific distributor at the time of purchase.

Precautions	Man-made damage is not limited to immersion, falling off, and pulling off the wires with excessive forces, etc.

www.akkogear.com

@akkogear.de

Facebook

http://weixin.qq.com/r/aDtOVoXE6tiVrcE19256

http://qr.weibo.cn/g/49ssmq

Documents / Resources

AKKO 3061 Mechanical Keyboard [pdf] User Manual
3061 Mechanical Keyboard, 3061, Mechanical Keyboard, Keyboard

References

- **Akko (@akkogear) • Instagram photos and videos**
- **Akkoè‰¾é…·å®˜æ–¹ç½‘ç«™ | æ½®æµæ—¶å°šå¤–è®¾_Akkoæœºæ¢°é"®ç›˜å®˜ç½'**