**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**DURACELL C-CTx4**

# Duracell Coppertop C Alkaline Batteries Instruction Manual

## Introduction

Duracell Coppertop All-Purpose alkaline C batteries are engineered for dependable, long-lasting power. These batteries are suitable for a wide range of household and office devices, ensuring readiness when needed. Duracell guarantees these batteries against defects in material and workmanship, offering repair or replacement should any device be damaged due to a battery defect.
Key features include:

- **Long-lasting Power:** Designed for consistent performance in electronic devices.
- **Reliable for Everyday Devices:** Ideal for toys, remote controls, flashlights, clocks, radios, and portable electronics.
- **Guaranteed 10 Years in Storage:** Ensures batteries are ready for use even after extended storage periods.
- **Quality Assurance:** Each Duracell product is guaranteed against material and workmanship defects.

## Safety Information

**WARNING: May explode or leak, and cause burn injury, if mishandled.**

- Do not recharge non-rechargeable batteries.
- Do not dispose of batteries in fire.
- Do not mix with different battery types or brands.
- Ensure correct polarity (+/-) when inserting batteries.
- Do not disassemble batteries.
- Replace all used batteries at the same time.
- Do not carry batteries loose in your pocket or purse to prevent short-circuiting.
- Do not remove the battery label.
- Keep batteries away from children. If swallowed, consult a physician at once. For information on treatment, call (202) 625-3333 collect.

## Setup and Installation

1. **Identify Battery Compartment:** Locate the battery compartment on your device. This is often found on the back, bottom, or side of the device.
2. **Open Compartment:** Open the battery compartment cover. This may involve sliding a latch, unscrewing a screw, or pressing a release button.
3. **Observe Polarity:** Note the polarity markings (+ and -) inside the battery compartment. These indicate the correct orientation for battery insertion.
4. **Insert Batteries:** Insert the Duracell Coppertop C batteries according to the polarity markings. The positive (+) end typically aligns with the positive terminal in the device, and the negative (-) end with the negative terminal.
5. **Close Compartment:** Securely close the battery compartment cover.
6. **Test Device:** Turn on your device to ensure the batteries are correctly installed and providing power.

## Operating Instructions

Duracell Coppertop C batteries are designed for immediate use in compatible devices. Once installed, the device should function as intended. For optimal performance and longevity:

- Always use the correct battery size (C) as specified by your device manufacturer.
- Replace all batteries in a device at the same time to avoid performance issues or potential leakage from mixed old and new batteries.
- Remove batteries from devices that will not be used for extended periods to prevent potential damage from leakage.

## Maintenance and Storage

Proper maintenance and storage can extend the life and ensure the reliability of your Duracell Coppertop C batteries:

- **Storage Conditions:** Store batteries in a cool, dry place at normal room temperature. Avoid extreme temperatures, as these can reduce battery performance and shelf life.
- **Shelf Life:** Duracell Coppertop C batteries are guaranteed to hold power for up to 10 years in storage.
- **Packaging:** Keep unused batteries in their original packaging until ready for use to prevent accidental short-circuiting.
- **Disposal:** Dispose of used batteries according to local regulations. Do not throw batteries into household waste or fire.

## Specifications

| Feature | Detail |
|---|---|
| Brand | DURACELL |
| Model Number | C-CTx4 |
| Battery Cell Composition | Alkaline |
| Battery Capacity | 1500 Milliamp Hours |
| Number of Batteries | 4 C batteries required (included) |

| | |
|---|---|
| Product Dimensions | 3.88 x 1.69 x 4.5 inches |
| Item Weight | 10.41 ounces |
| Guaranteed in Storage | 10 Years |
| Recommended Uses | Radio, Toys, Flashlights, Remote Controls |

## Warranty and Support

Duracell guarantees these batteries against defects in material and workmanship. Should any device be damaged due to a battery defect, Duracell will repair or replace it at their option. This warranty ensures the quality and reliability of Duracell products.

**Legal Disclaimer: Warranty does not cover misuse of product.**

For further assistance or warranty claims, please refer to the contact information provided on the product packaging or visit the official Duracell website.

## Product Visuals




Image: A 4-pack of Duracell Coppertop C batteries in their retail packaging, highlighting the 'Guaranteed 10 Years in Storage' claim.




Image: A single Duracell C battery with text emphasizing 'Long Lasting Power'.




Image: A graphic highlighting the 'Guaranteed 10 Years in Storage' feature for Duracell batteries.




Image: A graphic stating '#1 Trusted Battery Brand' with a Duracell battery.




Image: A graphic illustrating 'Power You Can Trust' with icons of devices like a robot toy, remote control, flashlight, clock, and radio, indicating broad compatibility.

## Official Product Video

Your browser does not support the video tag.

Video: A short official video from Duracell (Merchant Video) showcasing Duracell Coppertop D Alkaline Batteries, highlighting their long-lasting power and recloseable packaging. While this video features D batteries, the general product benefits and brand quality apply to C batteries as well.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B00000JHQC**

More documents and user manuals: **https://manuals.plus/**