Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Magic Wand HV-260

Magic Wand Massager Instruction Manual

Model: HV-260

Introduction

Thank you for choosing the Magic Wand Massager. This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your device. Please read it thoroughly before first use and retain it for future reference.



Figure 1: The Magic Wand Massager

This image shows the main unit of the Magic Wand Massager, highlighting its cream-colored body, round vibrating head, and attached power cord with a standard North American plug.

Important Safety Information

Please read and understand all safety warnings before using this product.

- **USE IN NORTH AMERICA ONLY:** This device is designed for use with North American electrical outlets and voltage standards.
- **KEEP AWAY FROM WATER:** To prevent electric shock, do not use this device near water, in a bathtub, shower, or sink. Do not immerse the device in water or any other liquid.
- **NOT FOR INTERNAL USE:** This massager is intended for external use only.
- **MEDICAL CONDITIONS:** IMPORTANT: Any individual who may be pregnant, has a pacemaker, suffers from diabetes, phlebitis, and/or thrombosis, is at an increased risk of developing blood clots due to recent surgery, or who has pins/screws or other medical devices in their body should consult with a physician before using a massaging device designed for home use.
- **UNPLUG WHEN NOT IN USE:** Always unplug the massager from the electrical outlet when not in use and before cleaning.
- **NO RETURNS:** Please note that this product is non-returnable.

Product Features

The Magic Wand Massager is engineered for effective muscle relaxation and stress relief, offering robust performance and user-friendly design.

- **Powerful Vibration:** Provides constant, powerful vibration for deep tissue massage.
- **Dual Speed Control:** Features two distinct speed settings:
  - Low: 5000 Revolutions Per Minute (RPM)
  - High: 6000 Revolutions Per Minute (RPM)
- **Durable Construction:** Made from dense plastic or metal for longevity.
- **Ergonomic Design:** Non-phallic appearance for comfortable and versatile use.
- **Corded Electric:** Ensures consistent power without the need for batteries.



Figure 2: Product Packaging Highlighting Features

This image displays the product packaging, which lists key features such as powerful, penetrating vibrations, relaxation of sore muscles, tension relief, and dual speed control. It also includes the official website: www.MagicWandOriginal.com and the UPC: 0896909001916.

Setup

Before using your Magic Wand Massager for the first time, follow these simple steps:

1. **Unpack:** Carefully remove the massager and all packaging materials from the box. Inspect the device for any signs of damage.
2. **Power Connection:** Ensure the massager's power switch is in the "OFF" position. Plug the massager's power cord into a standard North American electrical outlet (120V AC).



Figure 3: Massager in Packaging

This image shows the Magic Wand Massager as it appears within its original packaging, indicating the model number HV-260.

Operating Instructions

Follow these steps to operate your Magic Wand Massager:

1. **Power On:** Once plugged in, slide the power switch to the desired speed setting. The massager offers two speeds: Low (I) and High (II).
2. **Application:** Gently apply the vibrating head of the massager to the body part where you desire relief.
3. **Massage Technique:** Move the massager slowly over the area for a few minutes, applying gentle pressure. Adjust pressure and movement as needed for comfort and effectiveness.
4. **Power Off:** When finished, slide the power switch to the "OFF" (O) position.
5. **Unplug:** Always unplug the massager from the electrical outlet after each use.

Indications for Use: The Magic Wand Massager is indicated for the temporary relief of minor aches and pains associated with sore muscles and stress.

Maintenance and Care

Proper care will ensure the longevity of your Magic Wand Massager.

- **Cleaning:** Always unplug the massager before cleaning. Wipe the surface of the massager with a clean, damp cloth. Do not use abrasive cleaners or immerse the device in water.
- **Storage:** Store the massager in a cool, dry place, away from direct sunlight and moisture. Keep the power cord neatly coiled to prevent damage.
- **Inspection:** Periodically inspect the power cord and the massager for any signs of damage. If damage is found, discontinue use immediately and contact customer support.

Troubleshooting

If you experience issues with your Magic Wand Massager, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Massager does not turn on.	Not plugged in; Power switch is off; Power outlet is not functioning.	Ensure the massager is securely plugged into a live electrical outlet. Check that the power switch is set to 'I' (Low) or 'II' (High). Test the outlet with another device.
Weak or inconsistent vibration.	Low power supply; Internal component issue.	Ensure the massager is plugged directly into a wall outlet, avoiding extension cords if possible. If the issue persists, the unit may require service.
Unusual noise or smell.	Internal malfunction.	Immediately unplug the massager and discontinue use. Contact customer support for assistance.

Specifications

Attribute	Detail
Model Number	HV-260
Brand	Magic Wand
Manufacturer	Vibratex
Power Source	Corded Electric
Speeds	Low (5000 RPM), High (6000 RPM)
Product Dimensions	12.5 x 2.5 x 2 inches (31.75 x 6.35 x 5.08 cm)
Item Weight	1.4 Pounds (0.63 kg)
Material	Dense Plastic or Metal
Intended Use	Whole Body

Figure 4: Massager Dimensions

This image illustrates the approximate length of the Magic Wand Massager, which is 14 inches (36 cm).

Warranty and Support

Warranty: The Magic Wand Massager comes with a 1-year limited warranty from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage resulting from misuse, accident, alteration, or unauthorized repair.

For warranty claims or technical support, please visit the official website:www.MagicWandOriginal.com. Please have your model number (HV-260) and purchase information ready when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00005M1WE

More documents and user manuals: **https://manuals.plus/**