Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun MR5550CA-WH

Braun MR5550CA Multiquick Professional Hand Blender

Model: MR5550CA-WH

Introduction

This instruction manual provides important information for the safe and efficient operation of your Braun MR5550CA Multiquick Professional Hand Blender. Please read these instructions carefully before first use and keep them for future reference.

Important Safety Instructions

- Always unplug the appliance after use and before cleaning.
- Do not immerse the motor unit in water or other liquids.
- Keep hands and utensils out of the container while blending to prevent serious injury and/or damage to the unit.
- Blades are sharp. Handle with care.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting the appliance.

Package Contents



Figure 1: Complete Set. This image displays the full Braun Multiquick Professional Hand Blender set, including the main motor unit, the blending shaft, a whisk attachment, a chopper attachment with its bowl, and a measuring beaker. All components are white and clear plastic, arranged neatly for viewing.

- Hand Blender Motor Unit
- Blending Shaft (Anti-splashing)
- Chopper Attachment with Bowl
- Metal Whisk Attachment
- Covered Beaker / Juicer Container
- Wall Holder

Setup

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Initial Cleaning:** Before first use, wash all parts that will come into contact with food (blending shaft, chopper bowl, whisk, beaker) in warm soapy water. Rinse thoroughly and dry. The attachments are dishwasher safe.
3. **Assembling the Blending Shaft:** Align the blending shaft with the motor unit and twist until it clicks into place.
4. **Assembling the Chopper:** Place the blade into the chopper bowl, add ingredients, then place the chopper lid (which connects to the motor unit) onto the bowl and twist to secure.
5. **Assembling the Whisk:** Insert the whisk into the whisk gear box, then attach the gear box to the motor unit.
6. **Wall Holder Installation (Optional):** The wall holder can be mounted to a wall using screws (not included) for convenient storage of the motor unit.

Operating Instructions



Figure 2: Motor Unit Controls. This image shows a close-up of the top part of the Braun Multiquick Hand Blender's motor unit. Visible are the speed selector dial (numbered 1-5) at the very top and the "turbo" button below it, along with the main power button. The design is white with dark grey buttons.

General Operation

- **Power:** The appliance features a powerful 400-watt motor.
- **Speed Selector:** Use the speed selector dial on top of the motor unit to choose your desired speed setting (1-5).
- **Turbo Button:** For maximum power, press and hold the "turbo" button. This provides an instant burst of full power, regardless of the dial setting.
- **Operation Time:** Do not operate the appliance continuously for more than 60 seconds. Allow it to cool down for a few minutes before resuming.

Using the Blending Shaft

1. Attach the blending shaft to the motor unit.
2. Immerse the blending shaft into the ingredients. The anti-splashing design helps contain liquids.
3. Press the main power button or the turbo button to start blending. Move the blender up and down gently for even results.
4. Ideal for soups, sauces, smoothies, and baby food.

Using the Chopper Attachment

1. Place the chopper blade into the chopper bowl.
2. Add ingredients to the bowl. Do not overfill.
3. Attach the motor unit with the chopper lid to the chopper bowl.
4. Press the main power button or turbo button in short pulses to chop ingredients.
5. Suitable for chopping herbs, nuts, onions, and small amounts of meat.

Using the Whisk Attachment

1. Attach the whisk to the whisk gear box, then attach the gear box to the motor unit.

2. Place the whisk into the ingredients (e.g., cream, egg whites).
3. Press the main power button to start whisking. Use lower speeds for gentle mixing and higher speeds for whipping.
4. Ideal for whipping cream, beating eggs, and mixing light batters.

Maintenance and Cleaning

- **Always unplug** the appliance before cleaning.
- **Motor Unit:** Wipe the motor unit with a damp cloth. Do not immerse it in water or any other liquid.
- **Attachments:** The blending shaft, chopper bowl, chopper blade, whisk, whisk gear box, and beaker are **dishwasher safe**. For best results, rinse immediately after use.
- **Blades:** Handle the chopper blade and blending shaft blade with extreme care as they are very sharp.
- **Storage:** Store the appliance and its attachments in a dry place. The included wall holder can be used for convenient storage of the motor unit.

Troubleshooting

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet not working; motor unit not properly attached to accessory.	Check power cord connection; test outlet with another appliance; ensure attachments are securely clicked into place.
Motor runs, but blade/whisk does not move.	Attachment not properly secured; too much load/ingredients.	Ensure attachment is fully engaged; reduce amount of ingredients; check for blockages.
Appliance stops during operation.	Overheating due to prolonged use or excessive load.	Unplug and let the appliance cool down for at least 15-20 minutes before resuming use. Reduce load.
Poor blending/chopping results.	Insufficient liquid (for blending); ingredients too large (for chopping); dull blade.	Add more liquid; cut ingredients into smaller pieces; ensure blade is clean and sharp.

Specifications

Model: MR5550CA-WH

Brand: Braun

Power: 400 Watts

Power Source: Corded Electric

Material: Metal (motor unit components), Plastic (attachments, beaker)

Color: White

Dimensions: Approximately 39.62 x 29.46 x 15.24 cm (Product Dimensions)

Weight: Approximately 1.88 kg

Special Features: Portable, Speed Selector, Turbo Button, Anti-splashing shaft

Dishwasher Safe Parts: Yes (attachments)

Warranty and Support

This Braun MR5550CA Multiquick Professional Hand Blender comes with a**1-year limited warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal household use.
For warranty claims, technical support, or spare parts, please contact Braun customer service. Keep your proof of purchase for warranty validation.
Customer Service: Please refer to the contact information provided in your product packaging or visit the official Braun website for your region.
Online Resources: For additional tips, recipes, and product information, visitwww.braunhousehold.com.

© 2024 Braun. All rights reserved.
Braun is a registered trademark of Braun GmbH, Germany.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00006I4YF

More documents and user manuals: **https://manuals.plus/**