Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

jWIN JX-M55

JWIN Electronics JX-M55 Fog Free Mirror Water Resistant Shower AM/FM Radio User Manual

Model: JX-M55

Introduction

Thank you for purchasing the JWIN Electronics JX-M55 Fog Free Mirror Water Resistant Shower AM/FM Radio. This manual provides important information regarding the setup, operation, maintenance, and troubleshooting of your new device. Please read it thoroughly before use to ensure proper functionality and longevity of the product.
The JX-M55 is designed for use in humid environments, featuring a water-resistant body and speaker, a fog-free mirror, and the ability to receive both AM and FM radio frequencies. Its ultra-slim design allows for convenient shelf or wall mounting.

Product Overview

The JX-M55 combines a radio and a mirror for convenience in a shower environment. Key features include:

- High Sensitive AM/FM Radio for clear reception.
- Ultra Slim Design for easy placement.
- Water Resistant Body & Speaker for safe use in humid conditions.
- Fog Free Mirror for visibility during use.
- Shelf and Wall Mountable for flexible installation.



Figure 1: Front view of the JWIN JX-M55 Shower Radio, showing the mirror, tuning dials, and display.

Setup

1. Battery Installation

The JX-M55 is battery-powered. Locate the battery compartment, typically on the back or side of the unit. Open the compartment cover and insert the required batteries, observing the correct polarity (+/-) as indicated inside the compartment. Close the cover securely to maintain water resistance.

2. Mounting Options

The unit can be placed on a shelf or mounted on a wall. For wall mounting, use appropriate hardware (not included) and ensure the mounting surface is suitable for supporting the radio's weight in a humid environment. If hanging, utilize the integrated loop cord to suspend the unit from a secure fixture.

Operating Instructions

1. Power On/Off

Locate the Power button or dial. Turn the unit on by pressing the button or rotating the dial to the 'ON' position. To turn off, reverse the action.

2. Tuning the Radio

Identify the AM/FM band selector switch. Select your desired band (AM or FM). Use the tuning dial to scan for radio stations. Rotate the dial slowly until you find a clear signal. The LCD display will show the frequency.

3. Volume Control

Adjust the volume using the dedicated volume dial or buttons. Rotate clockwise to increase volume and counter-clockwise to decrease.

4. Using the Fog-Free Mirror

The integrated mirror is designed to resist fogging in humid conditions. For best results, ensure the mirror surface is clean. If fogging occurs, a quick wipe with a soft cloth may be necessary.

Maintenance

1. Cleaning the Unit

To clean the JX-M55, use a soft, damp cloth. Do not use abrasive cleaners or solvents, as these can damage the surface or compromise the water resistance. Ensure the battery compartment is sealed before cleaning.

2. Battery Replacement

When the radio's performance diminishes (e.g., weak sound, difficulty tuning), it may be time to replace the batteries. Follow the battery installation steps outlined in the Setup section. Dispose of old batteries responsibly according to local regulations.

3. Mirror Care

While designed to be fog-free, mineral deposits from water or soap residue can accumulate over time. Clean the mirror surface regularly with a mild glass cleaner and a soft cloth to maintain clarity. Avoid harsh chemicals.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Poor Radio Reception	Weak signal; unit's position; depleted batteries.	Try repositioning the radio to improve signal strength. Ensure the antenna (if external) is fully extended. Replace batteries if they are low. Adjust the tuning dial slowly and precisely.
Mirror Fogs Up	Residue buildup; extreme humidity.	Clean the mirror surface with a mild cleaner and soft cloth. Ensure proper ventilation in the shower area.
No Power / Unit Not Turning On	Dead or incorrectly installed batteries.	Check battery polarity. Replace with fresh batteries.
Distorted Sound	Low batteries; poor reception; volume too high.	Replace batteries. Adjust tuning for a clearer signal. Lower the volume.

Specifications

Model Number	JX-M55
Brand	jWIN
Tuner Technology	FM, AM
Power Source	Battery Powered
Water Resistance Level	Water Resistant
Display Technology	LCD
Product Dimensions	144 x 96 x 48 inches
Item Weight	3 pounds

Warranty and Support

For warranty information or technical support, please refer to the documentation included with your purchase or visit the official jWIN website. Keep your purchase receipt as proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0007M3E9K

More documents and user manuals: **https://manuals.plus/**