Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PADERNO A4982799

Paderno World Cuisine 3-Blade Vegetable Slicer / Spiralizer Instruction Manual

Model: A4982799

Product Overview

The Paderno World Cuisine 3-Blade Vegetable Slicer / Spiralizer is a manual kitchen tool designed to create spiral cuts, vegetable noodles, and ribbon slices from various fruits and vegetables. It features a durable BPA-free ABS plastic frame and stainless steel blades for efficient and consistent results. The unit is counter-mounted with strong suction feet for stability during use.



Image: The Paderno World Cuisine 3-Blade Vegetable Slicer / Spiralizer, a white manual kitchen tool with a crank handle and suction feet.

Package Contents

- 1 x Paderno World Cuisine Vegetable Slicer / Spiralizer Unit
- 3 x Stainless Steel Blades (for vegetable strands & zucchini noodles)

Setup Instructions

1. **Unpack the Unit:** Carefully remove all components from the packaging.
2. **Choose a Surface:** Place the spiralizer on a clean, smooth, and flat countertop.
3. **Secure the Unit:** Press down firmly on each of the four powerful suction feet located at the base of the unit to secure it to the countertop. Ensure the rotating crank handle faces either your left or right side for comfortable operation.
4. **Insert Blade:** Select the desired blade for your cut (e.g., thin noodle, thick noodle, or ribbon) and slide it into the designated slot on the side of the unit until it clicks securely into place.

Operating Instructions

1. **Prepare Produce:** Select a firm fruit or vegetable. Ensure it is at least 1/2 inch thick in diameter and can be up to 10 inches long and 7 inches thick. Trim the ends to create flat surfaces.
2. **Mount Produce:** Attach one end of the fruit or vegetable to the small circular corer on the blade plate. Gently press the prongs of the crank handle onto the opposite end of the produce, ensuring it is centered and held firmly.
3. **Begin Spiralizing:** Use one hand to push the lever handle along the track while simultaneously turning the crank handle with the other hand. The produce will be pushed through the blade, creating spirals or ribbons.
4. **Collect Spirals:** As the spirals are created, they will fall onto your cutting board or a plate placed beneath the unit.
5. **Remove Remaining Core:** Once the produce is fully spiralized, carefully remove any remaining core from the unit.



Image: Various spiralized vegetables, including sweet potato noodles, zucchini spirals, and cabbage shreds, demonstrating the versatility of the slicer's blades.

▶ **Watch video online**
Paderno World Cuisine Blade

Video: A demonstration of the Paderno World Cuisine 3-Blade Vegetable Slicer in action, showing how to spiralize various vegetables like zucchini, sweet potatoes, and cabbage.

Maintenance & Cleaning

To ensure the longevity and hygiene of your spiralizer, follow these cleaning instructions:

- **Disassembly:** Remove the blade from the unit.
- **Washing:** All components of the Paderno World Cuisine 3-Blade Vegetable Slicer are dishwasher safe. For best results, place them on the top rack of your dishwasher.
- **Hand Washing:** If hand washing, use warm, soapy water and a soft brush to clean any food residue from the blades and other parts. Rinse thoroughly.
- **Drying:** Allow all parts to air dry completely before reassembling or storing.

Troubleshooting

If you encounter any issues while using your spiralizer, consider the following common solutions:

- **Unit Not Sticking to Counter:** Ensure the countertop surface is clean, smooth, and dry. Press down firmly on each suction cup to create a strong seal.
- **Produce Not Spiralizing Evenly:** Make sure the fruit or vegetable is centered on both the corer and the prongs. Ensure the ends are cut flat. Very soft or overripe produce may not spiralize well.
- **Blades Not Cutting:** Check that the chosen blade is correctly inserted and securely locked into its slot. Ensure the produce is firm enough for spiralizing.
- **Difficulty Turning Crank:** Apply steady, even pressure to the lever handle while turning the crank. If resistance is too high, the produce might be too hard or not properly aligned.

Specifications

Feature	Detail
Brand	PADERNO
Model Number	A4982799
Product Dimensions	9.38"L x 5.75"W x 8.63"H
Item Weight	1.8 pounds
Material (Body)	BPA-Free ABS Plastic
Blade Material	Stainless Steel
Color	White
Operation Mode	Manual
Product Care Instructions	Dishwasher Safe
Included Components	Spiralizer Unit, 3-Sets Of Blades

Warranty & Support

This Paderno World Cuisine 3-Blade Vegetable Slicer / Spiralizer comes with a**1-Year Manufacturer Warranty**. For warranty claims, technical support, or any product-related inquiries, please contact Paderno World Cuisine customer service:

- **Website:** Visit the official Paderno World Cuisine Store for more information and contact options.
- **Email:** Refer to your product packaging or the official website for the most current customer service email address.
- **Phone:** Refer to your product packaging or the official website for the most current customer service phone number.

Please have your model number (A4982799) and proof of purchase ready when contacting support.

© 2026 Paderno World Cuisine. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0007Y9WHQ

More documents and user manuals: **https://manuals.plus/**