Manuals+
Q & A | Deep Search | Upload

Nintendo NTR-001

Nintendo DS System User Manual

Model: NTR-001
Brand: Nintendo

Introduction

Welcome to the user manual for your Nintendo DS System. This guide provides essential information for setting up, operating, maintaining, and troubleshooting your device. The Nintendo DS features innovative dual screens, microphone-enabled gameplay, and a responsive touch screen, offering a unique interactive experience. It is also backward compatible with Game Boy Advance games, expanding your gaming library.

Product Overview

The Nintendo DS is a portable dual-screen game console developed and manufactured by Nintendo. It features a clamshell design, with two LCD screens, one of which is a touchscreen. The system also includes a built-in microphone and supports Wi-Fi connectivity for multiplayer gaming.

Key Components

- Nintendo DS Console
- Stylus
- AC Adapter (Charger)
- Instruction Manual (This document)

Product Features

- Durable Original DS Game System
- Includes slots for both Game Boy Advance Games & Nintendo DS Games
- Dual LCD screens, with the lower screen being touch-sensitive
- Built-in microphone for voice input
- Wi-Fi capabilities for local and online multiplayer (where supported)

Figure 1: The Nintendo DS System, shown open with its charger and stylus.

Figure 2: A top-down view of the open Nintendo DS System, highlighting the dual screens and controls.

Setup

1. Initial Charging

Before first use, fully charge your Nintendo DS. Connect the AC adapter to the charging port on the back of the console and plug it into a standard wall outlet. The orange charge indicator light will illuminate. Once fully charged, the light will turn off. A full charge typically takes approximately 3 hours.

2. Inserting Game Cards

- **Nintendo DS Game Card:** Insert the Nintendo DS Game Card into Slot-1 located on the top of the console until it clicks into place.
- **Game Boy Advance Game Pak:** Insert the Game Boy Advance Game Pak into Slot-2 located on the front of the console until it clicks into place.

3. Powering On/Off

To power on the system, slide the POWER switch located on the right side of the console upwards and hold it for a moment. To power off, slide the POWER switch upwards again and hold until the screens turn off.

Operating Instructions

Using the Touch Screen and Stylus

The lower screen of the Nintendo DS is a touch screen. Use the included stylus to interact with on-screen elements, select options, and play touch-enabled games. Avoid using sharp objects or excessive force on the screen to prevent damage.

Controls

The Nintendo DS features a D-pad on the left side for directional input, and A, B, X, Y buttons on the right side for actions. START and SELECT buttons are located below the action buttons. L and R shoulder buttons are on the top edge of the console.

Adjusting Volume

The volume slider is located on the left side of the console. Slide it up to increase volume and down to decrease it.

Wi-Fi Connection

Some Nintendo DS games support wireless multiplayer or online features. Refer to the specific game's manual for instructions on how to connect to a wireless network or other DS systems.

Maintenance

Cleaning the Console

Use a soft, dry cloth to wipe down the exterior of the console. For screens, use a soft, lint-free cloth specifically designed for electronics. Do not use abrasive cleaners, solvents, or excessive moisture.

Battery Care

To prolong battery life, avoid exposing the console to extreme temperatures. If the system will not be used for an extended period, fully charge it before storage and recharge it periodically (e.g., every six months) to prevent deep discharge.

Storage

Store the Nintendo DS in a cool, dry place away from direct sunlight, dust, and moisture. Keep it in its closed position to protect the screens.

Troubleshooting

If you encounter issues with your Nintendo DS System, please refer to the following common problems and

solutions:

Problem	Solution
Console does not power on.	Ensure the battery is charged. Connect the AC adapter and allow it to charge for at least 30 minutes before attempting to power on again. Verify the AC adapter is securely plugged into both the console and a working wall outlet.
Screens are blank or flickering.	Power off the system, then power it back on. If the issue persists, ensure the console has not been subjected to physical impact or extreme temperatures.
Game card not recognized.	Remove the game card and reinsert it firmly until it clicks into place. Ensure the game card's contacts are clean. Try a different game card to determine if the issue is with the console or the specific game card.
Touch screen is unresponsive or inaccurate.	Ensure you are using the official Nintendo DS stylus. If the screen is dirty, clean it gently with a soft, lint-free cloth. Some games may require touch screen calibration, which can usually be found in the system settings.

If the problem persists after attempting these solutions, please contact Nintendo Customer Support for further assistance.

Specifications

Feature	Detail
Model Number	NTR-001
Dimensions (Closed)	8.66 x 5.83 x 2.68 inches
Item Weight	0.01 ounces
Batteries	1 Lithium Ion battery (included)
First Available Date	December 12, 2009

Warranty and Support

Nintendo products are manufactured to high standards and undergo rigorous testing. For information regarding your product's warranty, please refer to the warranty card included with your purchase or visit the official Nintendo support website.
For technical support, repair services, or general inquiries, please contact Nintendo Customer Support. Contact information can typically be found on the official Nintendo website or within the product packaging.
Online Support: www.nintendo.com/support/ (Example link, actual link may vary)

© 2024 Nintendo. All rights reserved.