**Manuals+**
Q & A | Deep Search | Upload



## Sunbeam BLSTPB-WGN-000

# Sunbeam MixMaster 350 Watt Stand Mixer Instruction Manual

Model: BLSTPB-WGN-000

## 1. Introduction

Thank you for choosing the Sunbeam MixMaster 350 Watt Stand Mixer. This manual provides important information regarding the safe operation, maintenance, and care of your new appliance. Please read all instructions carefully before first use and retain for future reference.

## 2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before operating this appliance.
- To protect against electrical shock, do not immerse the mixer base, cord, or plug in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Avoid contact with moving parts. Keep hands, hair, clothing, as well as spatulas and other utensils away from beaters during operation to prevent injury and/or damage to the mixer.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Do not use appliance for other than intended use.
- Always ensure the mixer is turned OFF and unplugged before assembling, disassembling, or

cleaning.

## 3. Product Overview

The Sunbeam MixMaster Stand Mixer is designed for efficient mixing with a powerful 350-watt motor and 12 variable speed settings. Key components include:

- **Mixer Head:** Contains the motor and attachment ports. Features a tilt-locking mechanism for easy access.
- **Mixer Base:** Provides stability with nonskid rubber feet.
- **Speed Control Dial:** Adjusts mixing speed from 1 to 12.
- **Power Boost Button:** Provides a temporary surge of power for tough mixing tasks.
- **Attachment Release Button:** For easy removal of beaters or dough hooks.

**Included Accessories:**

- Two 4-quart glass mixing bowls
- Two chrome beaters
- Two dough hooks
- Two whisks

Figure 1: Sunbeam MixMaster Stand Mixer with a single glass bowl and beaters attached, ready for use.

Figure 2: The Sunbeam MixMaster Stand Mixer shown with both the attached mixing bowl and the additional spare glass bowl.

Figure 3: Close-up view of the mixer's handle, highlighting the Power Boost button for additional mixing power.

## 4. Setup

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for storage or shipping.
2. **Clean:** Before first use, wash the mixing bowls, beaters, dough hooks, and whisks in warm, soapy water. Rinse thoroughly and dry. Wipe the mixer base with a damp cloth.
3. **Position:** Place the mixer on a clean, dry, and stable surface. Ensure the nonskid rubber feet are firmly on the counter.
4. **Attach Bowl:** Place a mixing bowl onto the turntable on the mixer base. Ensure it is seated securely.
5. **Insert Attachments:**
    - Ensure the mixer head is tilted back and locked.
    - Insert the desired beaters, dough hooks, or whisks into the attachment ports until they click into place.
    - Lower the mixer head until it locks into the operating position.
6. **Connect Power:** Plug the power cord into a standard electrical outlet.

Figure 4: The stable base of the Sunbeam MixMaster, featuring nonskid rubber feet for secure placement during operation.

## 5. Operating Instructions

1. **Add Ingredients:** Place all desired ingredients into the mixing bowl.
2. **Select Speed:** Turn the speed control dial to the desired setting (1-12). The Soft-Start Technology will gradually increase speed to minimize splatters.
3. **Mixing:** Allow the mixer to operate until ingredients are thoroughly combined. The off-center bowl position helps reduce scraping.
4. **Power Boost:** For thicker mixtures or to quickly incorporate ingredients, press and hold the Power Boost button. Release to return to the selected speed.

5. **Stop Mixing:** Turn the speed control dial to the "OFF" position.
6. **Remove Attachments:** Unplug the mixer. Tilt the mixer head back and press the attachment release button to remove the beaters, dough hooks, or whisks.

Figure 5: The mixer in action, demonstrating its 12 variable speed settings while mixing ingredients in the glass bowl.

Figure 6: The Soft-Start Technology in action, minimizing splatter and flour puffs during the initial mixing phase.

## 6. Maintenance and Cleaning

Proper maintenance ensures the longevity and performance of your Sunbeam MixMaster Stand Mixer.

- **Always unplug the mixer before cleaning.**
- **Mixing Bowls and Attachments:** Wash the glass bowls, beaters, dough hooks, and whisks in warm, soapy water or place them in the dishwasher. Rinse and dry thoroughly.
- **Mixer Base and Head:** Wipe the exterior of the mixer base and head with a damp cloth. Do not use abrasive cleaners or scourers. Do not immerse the mixer base, cord, or plug in water or any other liquid.
- **Storage:** Store the mixer and its accessories in a clean, dry place.

## 7. Troubleshooting

If you encounter issues with your mixer, refer to the following table for common problems and solutions.

| Problem | Possible Cause | Solution |
|---|---|---|
| Mixer does not turn on. | Not plugged in; power outlet not working; speed dial not set. | Ensure the mixer is securely plugged into a working outlet. Turn the speed dial to a setting other than "OFF". |
| Attachments do not rotate. | Attachments not properly inserted. | Ensure attachments are fully inserted and clicked into place. |
| Mixer vibrates excessively. | Uneven surface; heavy load; mixer head not fully locked. | Place mixer on a stable, flat surface. Reduce the load if mixing very thick dough. Ensure the mixer head is fully locked down. |
| Ingredients not mixing evenly. | Insufficient mixing time; ingredients stuck to sides. | Increase mixing time. Stop the mixer and scrape down the sides of the bowl with a spatula. |

## 8. Specifications

| | |
|---|---|
| **Model Number** | BLSTPB-WGN-000 |
| **Brand** | Sunbeam (Manufacturer: Jarden) |
| **Power** | 350 Watts |
| Color | White |
| **Dimensions (D x W x H)** | 13.6" x 14.8" x 12.05" |
| **Weight** | 17.5 pounds |
| **Capacity** | 4 Liters (4-quart bowls) |
| **Control Type** | Knob |
| **Special Feature** | Adjustable Speed Control, Soft-Start Technology |
| **Cord Length** | 30 inches |

## 9. Warranty and Support

This Sunbeam MixMaster Stand Mixer is covered by a manufacturer's warranty. Please refer to the warranty card included with your product for specific terms and conditions. Typically, Sunbeam products come with a 2-year limited warranty.
For technical support, service, or to order replacement parts, please visit the official Sunbeam website or contact their customer service department. Contact information can usually be found on the product packaging or the manufacturer's website.

© 2023 Sunbeam. All rights reserved. Information subject to change without notice.