Panasonic ES2113

Panasonic ES2113 Facial Hair Trimmer User Manual

Model: ES2113

1. Introduction

Thank you for purchasing the Panasonic ES2113 Facial Hair Trimmer. This device is designed for gentle and effective removal of unwanted facial hair, including eyebrows. Its compact design and versatile attachments make it an ideal tool for personal grooming.
Key features include:

- Versatile trimmer for eyebrow and other facial areas.
- Flexible 'Swing Head' to hug contours of the skin.
- Rounded blade tip for gentle use on skin.
- Long-lasting stainless steel blade.
- Compact for easy portability.

2. Important Safety Information

Please read all instructions carefully before use and keep this manual for future reference.

- Do not use this appliance near water (e.g., in a bathtub, shower, or near a sink).
- Keep the appliance dry.
- Do not disassemble the appliance.
- Do not use if the blade or any part of the appliance is damaged.
- Keep out of reach of children.
- Use only for its intended purpose as described in this manual.
- Ensure batteries are inserted correctly according to polarity markings.
- Remove batteries if the appliance will not be used for an extended period.

3. Package Contents

Verify that all items are present in the package:

- Panasonic ES2113 Facial Hair Trimmer unit
- Eyebrow blade attachment
- Downy hair blade attachment
- Eyebrow comb (small)
- Eyebrow comb (large)
- Cleaning brush
- User Manual



Image 1: Panasonic ES2113 Facial Hair Trimmer. This image shows the compact design of the trimmer, likely with its various attachments such as different blades and combs for facial and eyebrow hair trimming.

4. Setup and Battery Installation

The Panasonic ES2113 requires batteries for operation.

1. Ensure the trimmer is switched off.
2. Locate the battery compartment cover, usually at the bottom or back of the unit.
3. Open the battery compartment cover.
4. Insert the required batteries (e.g., 1 x AAA battery, not included) according to the polarity indicators (+/-) inside the compartment.
5. Close the battery compartment cover securely.

Attaching Blades and Combs:

1. Select the desired blade:
    - **Eyebrow Blade:** For precise shaping and trimming of eyebrows.
    - **Downy Hair Blade:** For gentle removal of fine facial hair.

2. Align the chosen blade with the trimmer head and gently push until it clicks into place.
3. For eyebrow trimming, select the appropriate eyebrow comb (small or large) based on desired hair length.
4. Attach the comb over the eyebrow blade, ensuring it is securely fitted.

5. Operating Instructions

General Use:

1. Ensure your skin is clean and dry before use.
2. Switch the trimmer ON.
3. Gently place the blade against the skin. The flexible 'Swing Head' will adapt to your facial contours for a smooth trim.
4. Move the trimmer slowly against the direction of hair growth for effective removal.
5. After use, switch the trimmer OFF.

For Eyebrows:

1. Attach the eyebrow blade and the desired eyebrow comb.
2. Brush your eyebrows into their natural shape.
3. Gently move the trimmer with the comb over your eyebrows to trim them to a uniform length.
4. For shaping, remove the comb and carefully use the eyebrow blade to define the edges, avoiding direct contact with the skin where not intended.

For Downy Facial Hair:

1. Attach the downy hair blade.
2. Hold the skin taut with one hand.
3. Gently glide the trimmer over the desired area in small, controlled strokes. The rounded blade tip ensures gentleness on the skin.

6. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your trimmer.

1. **After Each Use:**
    - Switch the trimmer OFF.
    - Remove the blade attachment.
    - Use the provided cleaning brush to remove any hair clippings from the blade and the trimmer body.
    - Wipe the trimmer body with a dry cloth.
2. **Blade Care:**
    - Do not wash the blades with water unless specified as waterproof (this model is not specified as waterproof).
    - Store blades in a dry place.
    - Replace blades if they become dull or damaged to maintain performance and prevent skin irritation.
3. **Storage:**
    - Store the trimmer and its attachments in a cool, dry place, away from direct sunlight and high humidity.
    - Ensure the trimmer is switched OFF before storing.

7. Troubleshooting

Problem	Possible Cause	Solution
Trimmer does not turn on.	Batteries are dead or incorrectly inserted.	Check battery polarity. Replace with new batteries.
Trimmer performance is poor / pulling hair.	Blades are dull or clogged with hair.	Clean the blades thoroughly. Replace blades if dull.
Skin irritation after use.	Improper technique, dull blades, or sensitive skin.	Ensure gentle strokes. Replace blades. Consider a patch test on a small area first.

8. Specifications

- **Model Number:** ES2113
- **Brand:** Panasonic
- **Power Source:** Battery operated (Batteries Required: Yes)
- **Blade Material:** Stainless Steel
- **Item Weight:** 32 Grams
- **Product Dimensions:** 4.7 x 1.6 x 8.3 inches
- **Recommended Uses:** Trimming (Facial Hair, Eyebrows)
- **Hair Type:** All

9. Warranty and Support

For warranty information or product support, please refer to the warranty card included with your purchase or visit the official Panasonic website. You may also contact Panasonic customer service for assistance.
Panasonic Customer Support: www.panasonic.com/global/consumer/support.html

© 2023 Panasonic Corporation. All rights reserved.