Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Frigidaire STACKIT2

Frigidaire Stacking Kit STACKIT2

FRONT LOAD LAUNDRY INSTRUCTION MANUAL

1. Product Overview

The Frigidaire STACKIT2 Stacking Kit is designed to allow you to safely and efficiently stack your Frigidaire front-loading dryer on top of your Frigidaire front-loading washer. This kit helps conserve space in laundry rooms and provides a stable, secure setup for your appliances.

2. Safety Information

Please read all instructions carefully before installation. Failure to follow these instructions may result in property damage or personal injury.

- Ensure both the washer and dryer are unplugged from the power source before beginning installation.
- Always use appropriate personal protective equipment, such as gloves and safety glasses.
- Two or more people are recommended for lifting and positioning the dryer onto the washer.
- Verify that the floor surface is level and capable of supporting the combined weight of both appliances.
- Do not operate appliances until the stacking kit is fully and securely installed.

3. Package Contents

Verify that all components are present before beginning installation:



Image: Frigidaire STACKIT2 Stacking Kit components. This image displays the main white plastic rail, two smaller white C-shaped plastic brackets, and a small collection of metal screws, all laid out on a white background.

- 1 x Main Stacking Rail (long plastic piece)
- 2 x Rear Brackets (C-shaped plastic pieces)
- Screws for attachment

4. Compatibility

This stacking kit is compatible with the following Frigidaire front-load washer models:

- FTFB4000FS
- FEQB4000ES
- FGQB4000ES

Ensure your washer model is listed above for proper fit and secure installation.

5. Setup and Installation

Preparation:

- Unplug both the washer and dryer from their power outlets.
- Position the washer in its final desired location. Ensure it is level and stable.
- Clear the area around the washer and dryer to allow for easy movement and access.

Installation Steps:

1. **Attach Rear Brackets:** Locate the designated attachment points on the rear top edge of your washer. These may require drilling small pilot holes if not pre-drilled. Secure the two C-shaped rear brackets using the provided screws. A magnetic-tipped screwdriver may be helpful for recessed screw holes.

2. **Position Main Stacking Rail:** Place the long main stacking rail onto the top of the washer, ensuring it aligns with the front and the rear brackets. The rail should sit securely.
3. **Prepare Front Piece (if applicable):** If your kit includes a front piece with double-sided tape, it is recommended to dry-fit the dryer onto the washer first to mark the exact location for the front piece. Use a washable marker or grease pencil to mark the alignment points. Then, remove the dryer, apply the front piece to the washer using the tape, and ensure it is correctly positioned before proceeding.
4. **Lift and Position Dryer:** With the assistance of another person, carefully lift the dryer and align its feet with the grooves and securing points on the main stacking rail. Gently lower the dryer into place, ensuring it is seated firmly and securely.
5. **Verify Stability:** Once the dryer is in place, gently push and pull on the top unit to ensure it is stable and does not wobble. The plastic composition of the kit should secure the units nicely.
6. **Optional: Anti-Vibration Pads:** For enhanced stability and reduced vibration, consider installing anti-vibration foot pads underneath the washer before stacking.
7. **Reconnect Power:** Once installation is complete and verified, plug both the washer and dryer back into their respective power outlets.

6. Operating

Once the Frigidaire Stacking Kit is installed, operate your washer and dryer according to their individual instruction manuals. The stacking kit provides a stable platform for stacked operation.

7. Maintenance

The Frigidaire Stacking Kit requires minimal maintenance. Periodically inspect the kit components for any signs of wear, damage, or loosening of screws. Ensure the units remain level and stable. Clean the plastic components with a soft, damp cloth as needed.

8. Troubleshooting

Problem	Possible Cause	Solution
Dryer wobbles or vibrates excessively when in use.	Units not level; stacking kit not fully secured; anti-vibration pads not used.	Ensure washer and dryer are perfectly level. Re-check all screws and connections of the stacking kit. Consider adding anti-vibration pads under the washer.
Kit components do not fit.	Incorrect washer model; components misaligned.	Verify your washer model against the compatibility list. Re-read installation instructions and ensure proper alignment of all pieces.

9. Specifications

Attribute	Value
Brand Name	Frigidaire
Model Info	STACKIT2
Item Weight	10.4 ounces
Product Dimensions	3 x 27.37 x 2 inches
Color	White
Material Type	Plastic

10. Warranty and Support

Information regarding specific warranty terms and customer support contacts for the Frigidaire STACKIT2 Stacking Kit was not available in the provided product data. Please refer to the official Frigidaire website or your product's original packaging for detailed warranty information and customer service contacts.

© 2023 Frigidaire. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B000LO7FNK

More documents and user manuals: **https://manuals.plus/**