Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun LS5560

Braun Silk-épil LS5560 Electric Shaver User Manual

Model: LS5560

1. Introduction

Thank you for choosing the Braun Silk-épil LS5560 Electric Shaver. This manual provides essential information for the safe and effective use, maintenance, and care of your device. Please read these instructions thoroughly before first use and keep them for future reference.

2. Important Safety Information

To reduce the risk of electric shock, injury, or damage to the appliance, always follow these basic safety precautions:

- Always dry the shaver before and after charging.
- Clean and dry the shaver after each use to prevent skin irritation and bacterial growth.
- Avoid using the device near water or while charging to prevent electrical hazards.
- Do not use the appliance if it is damaged.
- Keep the appliance out of reach of children.
- Only use the charger supplied with the appliance.

3. Package Contents

Your Braun Silk-épil LS5560 package typically includes the following items:

- Braun Silk-épil LS5560 Electric Shaver Unit
- Shaving Head (main attachment)
- OptiShave Attachment
- Exfoliating Attachment
- Bikini Trimmer Attachment
- Cleaning Brush
- Charger
- Storage Pouch

- User Manual (this document)

4. Product Overview

Familiarize yourself with the components of your Braun Silk-épil LS5560 shaver.



Image 1: Front view of the Braun Silk-épil LS5560 Electric Shaver. The device is light purple and white, featuring a shaving head at the top, a central power button, and a trim/shave selector switch. The brand name "Braun Silk-épil" is visible on the body.

Main Components:

1. **Shaving Head:** The primary attachment for hair removal.
2. **Trim/Shave Selector:** A small switch located near the shaving head to select between trimming and shaving functions.
3. **Power Button:** Central button to turn the device on and off.
4. **Attachment Release Buttons:** Located on the sides near the shaving head, used to detach and change accessories.
5. **Charging Port:** Located at the bottom of the device for connecting the charger.

5. Charging the Device

The Braun Silk-épil LS5560 is a rechargeable device. Ensure it is fully charged before first use for optimal performance.

1. Ensure the shaver is dry before charging.
2. Connect the charger to the charging port at the bottom of the shaver.
3. Plug the charger into a suitable electrical outlet.
4. A full charge typically takes approximately 45-60 minutes.
5. The device can be used cordlessly for up to 40 minutes on a full charge. It can also be used while connected to the charger.

6. Operating Instructions

6.1 General Usage Tips

- For best results, use the shaver on clean, dry skin.
- Ensure hairs are not excessively long; trim them first if necessary for optimal shaving performance.
- Stretch the skin taut with your free hand to ensure a close shave and prevent irritation.
- Move the shaver gently against the direction of hair growth.
- While the device can be used in the shower, dry shaving often yields a closer result.

6.2 Attaching and Changing Accessories

1. To remove an attachment, press the release buttons on the sides of the shaver head and gently pull the attachment upwards.
2. To attach a new accessory, align it with the shaver body and press down until it clicks into place.

6.3 Using the Shaving Head

The main shaving head is designed for efficient and close hair removal on legs, underarms, and other body areas.

- Ensure the trim/shave selector is set to "shave".
- Turn on the device using the power button.
- Glide the shaving head over the skin, applying light pressure.

6.4 Using the OptiShave Attachment

The OptiShave attachment is designed to gently stretch the skin, optimizing the shaving surface for a smoother result.

- Attach the OptiShave head to the shaver.
- Proceed with shaving as described for the main shaving head.

6.5 Using the Exfoliating Attachment

The exfoliating attachment helps to prepare the skin by gently removing dead skin cells, which can help prevent ingrown hairs and improve skin texture.

- Attach the exfoliating head to the shaver.
- Gently move the attachment over the skin before or after shaving.

6.6 Using the Bikini Trimmer Attachment

This attachment is specifically designed for precise trimming in sensitive areas like the bikini line.

- Attach the bikini trimmer head.
- Ensure the trim/shave selector is set to "trim".
- Carefully guide the trimmer over the desired area.

7. Maintenance and Cleaning

Regular cleaning ensures optimal performance and hygiene of your shaver.

1. **After Each Use:** Turn off the shaver and remove the attachment. Use the supplied cleaning brush to remove any hair residue from the shaving head and the shaver body.
2. **Rinsing:** The shaver head can be rinsed under running water. Ensure the shaver body is dry before reattaching the head.
3. **Lubrication:** It is recommended to lubricate the shaving foil and cutter block with a drop of light machine oil (e.g., sewing machine oil or specific shaver oil) every 3 months, or after every wash with water, to maintain cutting efficiency.
4. **Storage:** Store the shaver and its accessories in the provided storage pouch in a dry place.

8. Troubleshooting

If you encounter issues with your Braun Silk-épil LS5560, refer to the following common troubleshooting tips:

- **Device not turning on:** Ensure the device is fully charged. If using corded, check the power connection.

- **Poor shaving performance:**
  - Clean the shaving head thoroughly to remove trapped hairs.
  - Ensure the shaving head is correctly attached.
  - Lubricate the shaving foil and cutter block.
  - Consider replacing the shaving head if it is worn or damaged (replacement parts may be available from Braun service centers).
- **Skin irritation:** Ensure the shaver is clean. Use on dry, clean skin. Avoid excessive pressure.

If problems persist, please contact Braun customer service for further assistance.

9. Specifications

Feature	Detail
Brand	Braun
Model Name	Silk-épil LS5560
Item Model Number	LS5560
Power Source	Battery Powered (Rechargeable)
Batteries	2 AA batteries required (internal rechargeable)
Recommended Uses	Leg, Armpit, Facial Hair
Product Dimensions	2.56 x 5.2 x 7.76 inches
Item Weight	15.52 ounces
UPC	798525651585

10. Warranty and Support

For warranty information, product registration, or technical support, please refer to the warranty card included with your product or visit the official Braun website. Keep your purchase receipt as proof of purchase.
Braun Official Website: www.braun.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B000MHT0K2

More documents and user manuals: **https://manuals.plus/**