Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Campingaz 203144

Campingaz 4D QuickPump Instruction Manual

Model: 203144

Product Overview

The Campingaz 4D QuickPump is a versatile, battery-powered air pump designed for both inflation and deflation of airbeds and other inflatable items. Its cordless design offers convenience for outdoor use where external power sources are unavailable. The pump comes with an adapter nozzle compatible with double-lock and piston valves, providing efficient air flow for quick setup and pack-down.



Image: The Campingaz 4D QuickPump, a black, compact air pump, is shown alongside its detachable adapter nozzle. The pump

features an on/off switch and is labeled "Campingaz 4D QuickPump".

Setup

1. Battery Installation

The 4D QuickPump operates on 4 x D/R20 batteries (not included). Ensure you use new, high-quality alkaline batteries for optimal performance and runtime.

1. Locate the battery compartment on the bottom or side of the pump.
2. Open the battery compartment cover.
3. Insert four D/R20 batteries, ensuring the correct polarity (+/-) as indicated inside the compartment.
4. Securely close the battery compartment cover.

2. Attaching the Nozzle

The pump includes an adapter nozzle designed for common valve types.

- For inflation, firmly insert the appropriate end of the adapter nozzle into the inflation port of the pump (usually the top or front outlet).
- For deflation, firmly insert the appropriate end of the adapter nozzle into the deflation port of the pump (usually the side inlet).
- Ensure the nozzle is securely attached to prevent air leakage during operation.

Operating Instructions

Inflation

1. Attach the adapter nozzle to the inflation port of the pump.
2. Insert the other end of the nozzle firmly into the valve of the item you wish to inflate (e.g., airbed, inflatable toy).
3. Locate the ON/OFF switch on the pump and slide it to the "ON" position. The pump will begin to operate.
4. Inflate the item to the desired firmness. Do not overinflate.
5. Once inflated, slide the ON/OFF switch to the "OFF" position.
6. Remove the nozzle from the item's valve and the pump.

Deflation

1. Attach the adapter nozzle to the deflation port of the pump.
2. Insert the other end of the nozzle firmly into the valve of the item you wish to deflate.
3. Slide the ON/OFF switch to the "ON" position. The pump will begin to draw air out of the item.
4. Continue until the item is sufficiently deflated.
5. Once deflated, slide the ON/OFF switch to the "OFF" position.
6. Remove the nozzle from the item's valve and the pump.

Safety Precautions

- Do not operate the pump continuously for more than 30 minutes to prevent overheating. Allow it to cool down between uses if extended operation is required.

- Keep the pump away from water and moisture. This device is not waterproof.
- Do not block the air intake or outlet during operation.
- Keep out of reach of children.
- Do not attempt to inflate items beyond their recommended pressure.

Maintenance

- **Cleaning:** Wipe the exterior of the pump with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners. Ensure the pump is completely dry before storage.
- **Storage:** Store the pump in a cool, dry place, away from direct sunlight and extreme temperatures. If storing for an extended period, remove the batteries to prevent leakage and damage to the pump.
- **Battery Care:** Always remove depleted batteries promptly. If the pump will not be used for a long time, remove the batteries. Dispose of batteries according to local regulations.

Troubleshooting

Problem	Possible Cause	Solution
Pump does not turn on.	• Batteries are dead or low. • Batteries are inserted incorrectly. • ON/OFF switch is not fully engaged.	• Replace with new D/R20 batteries. • Check battery polarity and reinsert correctly. • Ensure the switch is firmly in the "ON" position.
Low airflow or slow inflation/deflation.	• Batteries are low. • Nozzle is not properly sealed to the pump or item valve. • Air intake/outlet is obstructed.	• Replace batteries. • Ensure nozzle is firmly attached and sealed. • Check and clear any obstructions from the air ports.
Pump overheats.	• Continuous operation for too long.	• Turn off the pump and allow it to cool down for at least 15-20 minutes before resuming operation. Avoid continuous use beyond 30 minutes.

Specifications

Model Number	203144
Brand	Campingaz
Power Source	4 x D/R20 Batteries (not included)
Air Flow Rate	340 Litres per minute (approx.)
Head Pressure	27 Mb (approx.)
Runtime	Up to 30 minutes with alkaline batteries

Functions	Inflate and Deflate
Dimensions (L x W x H)	11.3 x 11.3 x 13.5 cm
Weight	350 g
Colour	Black

Warranty and Support

For information regarding warranty coverage, product support, or spare parts, please refer to the official Campingaz website or contact Campingaz customer service directly. Keep your proof of purchase for any warranty claims.
Note: Specific warranty terms may vary by region and retailer.

© 2024 Campingaz. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B000N8KHTS

More documents and user manuals: **https://manuals.plus/**