Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Chef's Choice S662001

Chef'sChoice S662001 Multi-purpose Non-serrated Slicing Blade

User Manual for Model 662 Food Slicer

1. Introduction

This manual provides instructions for the Chef'sChoice S662001 Multi-purpose Non-serrated Slicing Blade. This 7-inch stainless steel blade is designed as a replacement or accessory for the Chef'sChoice Model 662 Food Slicer, enabling precise and smooth slicing of various food items. Please read these instructions carefully before installation and use to ensure safe and optimal performance.



Figure 1: Chef'sChoice S662001 Multi-purpose Non-serrated Slicing Blade. This image displays the circular, silver-colored stainless steel blade, approximately 7 inches in diameter, with a smooth, non-serrated edge.

2. Safety Instructions

Always exercise extreme caution when handling the slicing blade. Blades are very sharp and can cause severe injury if not handled properly.

- **Unplug the Slicer:** Before installing, removing, or cleaning the blade, always ensure the Chef'sChoice Model 662 Food Slicer is unplugged from the power outlet.
- **Wear Protective Gloves:** Consider wearing cut-resistant gloves when handling the blade to prevent accidental cuts.
- **Handle with Care:** Always hold the blade by its center hub or non-sharp edges. Avoid touching the cutting edge directly.
- **Secure Installation:** Ensure the blade is correctly and securely installed on the food slicer before operation. Refer to the Model 662 Food Slicer's instruction manual for detailed installation steps.
- **Storage:** Store the blade safely when not in use, preferably in its original packaging or a protective cover, out of reach of children.

3. Package Contents

- 1 x Chef'sChoice S662001 Multi-purpose Non-serrated Slicing Blade (7-inch, Silver)

4. Setup and Installation

This blade is specifically designed for the Chef'sChoice Model 662 Food Slicer. Refer to your Model 662 Food Slicer's instruction manual for precise blade installation and removal procedures. The following steps are general guidelines:

1. **Ensure Power is Off:** Always unplug the Chef'sChoice Model 662 Food Slicer from the power outlet before beginning.
2. **Remove Existing Blade (if applicable):** If replacing an old blade, carefully remove it according to your slicer's manual. Use caution and protective gloves.
3. **Position the New Blade:** Align the Chef'sChoice S662001 blade with the blade mounting mechanism on your Model 662 Food Slicer. The blade typically has a central opening and possibly alignment pins or grooves.
4. **Secure the Blade:** Fasten the blade securely using the retaining knob or locking mechanism provided on your slicer. Ensure it is tightened firmly but do not overtighten. The blade should be flush and stable.
5. **Verify Installation:** Gently check that the blade is firmly attached and does not wobble.

Important: *Always consult the original instruction manual for your Chef'sChoice Model 662 Food Slicer for detailed, model-specific blade installation and removal procedures.*

5. Operating Instructions

Once the Chef'sChoice S662001 Non-serrated Slicing Blade is securely installed on your Chef'sChoice Model 662 Food Slicer, you can use it for various slicing tasks.

- **Food Compatibility:** This non-serrated blade is ideal for slicing a wide range of foods, including meats, cheeses, breads, fruits, and vegetables, providing clean, smooth cuts.
- **Slicing Thickness:** Adjust the slicing thickness on your Model 662 Food Slicer according to your desired results.
- **Safe Operation:** Always follow the operating instructions and safety guidelines provided in your Chef'sChoice Model 662 Food Slicer manual. Keep hands clear of the blade during operation.

6. Maintenance and Cleaning

Proper maintenance and cleaning will extend the life of your slicing blade and ensure hygienic operation.

- **Unplug Before Cleaning:** Always unplug the food slicer from the power outlet before cleaning the blade.
- **Hand Wash Only:** The Chef'sChoice S662001 blade is designed for hand washing only. Do not wash in a dishwasher, as this can dull the blade and potentially damage its finish.
- **Cleaning Procedure:**
    a. Carefully remove the blade from the slicer as per your Model 662 manual.
    b. Wash the blade immediately after use with warm, soapy water.
    c. Use a soft brush or sponge to clean the blade, avoiding direct contact with the sharp edge.
    d. Rinse thoroughly with clean water.
    e. Dry the blade immediately and completely with a soft cloth to prevent water spots and corrosion.
- **Storage:** Store the clean, dry blade in a safe place, such as its original packaging or a blade guard, away from moisture and out of reach of children.

7. Troubleshooting

This section addresses common concerns related to the slicing blade.

Problem	Possible Cause	Solution
Blade wobbles or is loose.	Improper installation; retaining knob not tightened.	Unplug the slicer. Carefully re-install the blade, ensuring it is correctly seated and the retaining knob is securely tightened. Refer to your slicer's manual.
Blade does not cut smoothly.	Food residue on blade; blade dullness (over time).	Clean the blade thoroughly as per Section 6. If the blade is old and dull, consider replacement.
Difficulty removing blade.	Food residue buildup; blade stuck.	Ensure slicer is unplugged. Apply a small amount of food-grade oil around the hub if stuck. Gently twist and pull. Consult your slicer's manual.

For issues not listed here, please refer to the comprehensive troubleshooting section of your Chef'sChoice Model 662 Food Slicer manual or contact customer support.

8. Specifications

Model Number	S662001
Compatibility	Chef'sChoice Model 662 Food Slicer
Blade Type	Multi-purpose, Non-serrated
Blade Diameter	Approximately 7 inches
Material	Stainless Steel
Color	Silver
Product Dimensions	12.5 x 1.1 x 12.8 inches (packaging/overall item dimensions)
Item Weight	2.2 Pounds
Care Instructions	Hand Wash Only

9. Warranty and Support

The Chef'sChoice S662001 Multi-purpose Non-serrated Slicing Blade comes with a **One-Year Limited Warranty** from the date of purchase. This warranty covers defects in material and workmanship under normal use. It does not cover damage resulting from misuse, abuse, accident, or unauthorized modifications.

For warranty claims, technical support, or inquiries regarding your Chef'sChoice product, please contact Chef's Choice customer service. Refer to the contact information provided with your Chef'sChoice Model 662 Food Slicer or visit the official Chef's Choice website for current support details.

Manufacturer: Chef'sChoice

© 2024 Chef's Choice. All rights reserved. Information subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B000YUENJK

More documents and user manuals: **https://manuals.plus/**