Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Gardena 5574-20

Gardena Handled Brush (Model 5574-20) Instruction Manual

Brand: Gardena | Model: 5574-20

1. Introduction and Overview

The Gardena Handled Brush (Model 5574-20) is a versatile water washing brush designed for gentle yet effective cleaning of various surfaces. Its soft bristles and integrated perimeter strip ensure scratch-free cleaning, making it ideal for delicate items such as garden furniture, vehicles, and other sensitive surfaces. The brush features an integrated water connection for easy attachment to a garden hose and a flow control mechanism for convenient single-hand operation.



Figure 1: Gardena Handled Brush (Model 5574-20) Diagram

2. Safety Information

Please read and understand all safety instructions before operating the Gardena Handled Brush. Failure to follow these instructions may result in injury or damage to the product or property.

- Always ensure all water connections are secure and leak-free before turning on the water supply.
- Do not direct water spray at electrical outlets, wiring, or other electrical components.
- Keep the product out of reach of children and pets when not in use.
- Wear appropriate personal protective equipment, such as gloves, if necessary, to protect your hands from cleaning agents or prolonged water exposure.
- Do not use the brush with hot water exceeding 40°C (104°F).
- Avoid using abrasive cleaning agents that could damage the brush bristles or the surfaces being cleaned.

3. Package Contents

Verify that all components are present in the package:

- 1x Gardena Handled Brush (Model 5574-20)

4. Setup

Follow these steps to set up your Gardena Handled Brush:

1. **Connect to Water Supply:** Attach the integrated hose connector of the Gardena Handled Brush to a standard garden hose. Push firmly until it clicks into place, ensuring a secure and leak-free connection.



Figure 2: Connecting the brush to a garden hose

For a visual guide on connecting and using the brush, please refer to the video below:

▶ **Watch video online**

Video 1: Demonstration of Gardena Handled Brush connection and cleaning various items.

5. Operating Instructions

Once the brush is securely connected to the water supply, you can begin cleaning:

1. **Turn on Water:** Turn on the water supply from your tap.
2. **Adjust Water Flow:** Use the integrated flow control on the handle to adjust the water intensity. The flow can be continuously adjusted and locked in position for comfortable single-hand operation.
3. **Clean Surface:** Gently brush the surface to be cleaned. The soft bristles and the surrounding soft plastic strip are designed to prevent scratches on delicate surfaces.
4. **Optional Soap Stick Insertion:** If desired, you may insert a Gardena soap stick (sold separately) into the designated opening in the brush handle for enhanced cleaning power.



Figure 3: Cleaning a car surface with the handled brush.



Figure 4: Cleaning a car wheel with the handled brush.



Figure 5: Inserting a soap stick into the brush handle (soap sticks sold separately).

6. Maintenance

Proper maintenance ensures the longevity and performance of your Gardena Handled Brush:

- **Cleaning the Brush:** After each use, rinse the brush head thoroughly with clean water to remove any dirt, debris, or residual cleaning agents from the bristles.
- **Storage:** Store the brush in a clean, dry place, away from direct sunlight and extreme temperatures. Ensure the bristles are dry before storing to prevent mildew.
- **Inspection:** Periodically inspect the brush for any signs of wear or damage, especially the bristles and the hose connection. Replace if necessary.

7. Troubleshooting

If you encounter issues with your Gardena Handled Brush, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Low Water Pressure	Hose kinked, tap not fully open, flow control on brush closed.	Check for kinks in the hose. Ensure the water tap is fully open. Adjust the flow control on the brush to the open position.
Water Leaks at Connection	Hose not securely connected, damaged O-ring or connector.	Ensure the hose connector is firmly attached to both the hose and the brush. Inspect the O-ring inside the connector for damage and replace if necessary.
Ineffective Cleaning	Bristles are dirty, stubborn dirt.	Rinse the brush bristles thoroughly. For stubborn dirt, pre-soak the area or use a suitable cleaning solution.

8. Specifications

Feature	Detail
Brand	Gardena
Model	5574-20
Material	Polyethylene terephthalate (PET)
Handle Material	Plastic
Product Dimensions (L x W x H)	31.8 cm x 12 cm x 8.5 cm
Special Features	Adjustable water flow, Scratch-free perimeter strip
Bristle Stiffness	Soft profile bristles
Specific Uses	Vehicles, Delicate surfaces, Garden furniture

9. Warranty and Support

The Gardena Handled Brush (Model 5574-20) is covered by a 5-year Gardena warranty, ensuring quality and reliability. For warranty claims, technical assistance, or any product-related inquiries, please contact Gardena customer service or visit the official Gardena website for detailed support information.

Gardena Official Website: www.gardena.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0013BBTUA

More documents and user manuals: **https://manuals.plus/**