KODAK M820

KODAK EasyShare M820 8-Inch Digital Frame User Manual

Model: M820 (1222009)

Introduction

The KODAK EasyShare M820 Digital Frame allows you to display your favorite digital photos and videos with vibrant color and crisp detail. This 8-inch frame features a 16:9 wide screen, KODAK Color Science technology, and intuitive controls for an enhanced viewing experience. This manual provides essential information for setting up, operating, and maintaining your digital frame.

Setup

1. Unpacking the Frame

Carefully remove all components from the packaging. Ensure you have the digital frame, power adapter, and any included decorative mattes.



Figure 1: The KODAK EasyShare M820 Digital Frame packaging, illustrating the product in use and highlighting key features like the Quick Touch Border and included mattes.

2. Connecting Power

1. Connect the power adapter to the DC IN port on the back of the digital frame.
2. Plug the power adapter into a standard electrical outlet.
3. The frame will automatically power on or enter standby mode.

3. Inserting Memory Cards or USB Drives

The frame supports SD/SDHC memory cards and USB flash drives. Locate the two SD card slots and the USB port on the side or back of the frame.

- Insert a compatible memory card into one of the SD card slots until it clicks into place.
- Insert a USB flash drive into the USB port.
- The frame will automatically detect the inserted media and begin displaying content.

4. Using Decorative Mattes

Your frame includes two decorative mattes (Cranberry Red and Silver) to customize its appearance. To change the matte, gently remove the existing one and snap the desired matte into place around the frame's display area.

Operation

1. Quick Touch Border Controls

The KODAK EasyShare M820 features a Quick Touch Border for easy navigation. Yellow lights illuminate to indicate active touch areas. Use a light touch or slide of your finger on the border to control the frame without leaving fingerprints on the screen.

2. Viewing Photos and Slideshows

- Once media is inserted, the frame will typically start a slideshow automatically.
- Use the Quick Touch Border to navigate through images, pause/play slideshows, and access menu options.
- Customize slideshow settings such as transition effects and display duration through the on-screen menu.

3. Transferring Pictures

You can transfer pictures from your computer to the frame's internal memory (128 MB) or to an inserted memory card using KODAK EasyShare Software, Digital Frame Edition. This software facilitates organizing, editing, and transferring images and multimedia slideshows.

- Install KODAK EasyShare Software on your computer.
- Connect the frame to your computer using a compatible USB cable (not included).
- Follow the software instructions to select and transfer images or created slideshows to the frame.

4. Playing Videos and MP3s

The KODAK EasyShare M820 supports video playback and MP3 audio. Ensure your video files are in a compatible format (e.g., MPEG-1, MPEG-4) for optimal performance. Audio will play through the built-in speakers.

- Navigate to the video or music section using the Quick Touch Border.
- Select the desired file to play.

5. Automatic On/Off Settings

Configure selectable viewing hours to automatically turn the frame on and off, conserving energy and extending product life. Access these settings through the frame's on-screen menu.

Maintenance

1. Cleaning the Screen

To clean the LCD screen, gently wipe it with a soft, lint-free cloth. For stubborn smudges, slightly dampen the cloth with water or a screen-cleaning solution designed for electronics. Avoid using harsh chemicals or abrasive materials.

2. General Care

- Keep the frame away from direct sunlight, excessive heat, and moisture.
- Do not block the ventilation openings on the back of the frame.
- Handle memory cards and USB drives carefully to prevent damage.

Troubleshooting

Problem	Possible Cause / Solution
Frame does not power on.	Ensure the power adapter is securely connected to both the frame and a working electrical outlet. Verify the outlet has power.

Problem	Possible Cause / Solution
No images displayed.	Check if a memory card or USB drive is properly inserted. Ensure the media contains compatible image files. Navigate to the correct source (internal memory, SD card, USB) using the menu.
Videos do not play or only show the first frame.	Verify that video files are in a compatible format (e.g., MPEG-1, MPEG-4). Some video formats may require conversion before playback. Refer to the KODAK EasyShare Software for conversion options.
Quick Touch Border is unresponsive.	Ensure your fingers are clean and dry. Try restarting the frame by unplugging and re-plugging the power adapter.
Poor image quality.	Ensure the original image files are of high resolution. The frame's display resolution is WXGA (16:9 aspect ratio).

For more detailed troubleshooting or issues not listed here, please refer to the comprehensive KODAK EasyShare M820 support resources available online.

Specifications

Feature	Detail
Brand	KODAK
Model Number	1222009 (M820)
Screen Size	8 Inches
Resolution	WXGA
Aspect Ratio	16:9
Internal Memory	128 MB (stores up to 300 pictures)
Memory Card Slots	2 (SD/SDHC compatible)
Connectivity	Wired (USB)
Control Method	Touch (Quick Touch Border)
Power Source	Corded Electric
Frame Material	Plastic
Included Mattes	Silver, Cranberry Red
UPC	041778485026, 041771769772

Warranty and Support

KODAK products are manufactured to high-quality standards. For information regarding your product's warranty, please refer to the warranty card included with your purchase or visit the official KODAK support website.

For technical assistance, product registration, or to download the latest software and drivers, please visit the KODAK support portal. Keep your model number (M820) and serial number (if applicable) ready when contacting support.

- **Online Support:** www.kodak.com/go/support (Example link, actual link may vary)
- **Product Registration:** Register your product to receive updates and support.