Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Presto 05511

Presto 05511 Quick Burger 400-Watt Nonstick Hamburger Cooker Instruction Manual

Model: 05511 | Brand: Presto

Safety Overview Setup Operating Maintenance Troubleshooting Specifications Warranty

Introduction

This manual provides essential instructions for the safe and efficient use of your Presto 05511 Quick Burger 400-Watt Nonstick Hamburger Cooker. Designed for convenience, this countertop appliance allows you to broil a quarter-pound hamburger in approximately two to three minutes. Its design promotes healthier cooking by broiling instead of frying and includes a drip pan to collect excess grease.

Please read all instructions thoroughly before operating the appliance to ensure proper function and safety.

Important Safeguards

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

SAVE THESE INSTRUCTIONS.

Product Overview

The Presto Quick Burger Cooker is a compact appliance designed for quick and efficient cooking of hamburgers and other small items. It features nonstick cooking surfaces and a removable drip pan for easy cleaning.

Components

- Main Unit (Upper and Lower Housing)
- Nonstick Cooking Plates
- Integrated Handle
- Power Cord
- Removable Drip Pan (integrated into lower plate)



Figure 1: The Presto 05511 Quick Burger Cooker in its closed position, showing the top cover with the Presto Burger logo and the attached power cord and handle.



Figure 2: The Presto 05511 Quick Burger Cooker opened, revealing the nonstick cooking plates. The lower plate includes perforations for grease drainage into the drip pan, and the blue handle extension is visible.



Figure 3: A close-up view of the appliance's label, indicating "120 VOLTS A.C. ONLY 400 WATTS" and "MODEL 05/MB1 SERIES 2800D", confirming the electrical specifications and model information.

Setup and First Use

1. **Unpack:** Carefully remove the appliance and all packaging materials. Retain packaging for future storage or transport if needed.
2. **Initial Cleaning:** Before first use, wipe the exterior of the unit with a damp cloth. The removable cooking tray can be washed by hand or in a dishwasher. Ensure all parts are completely dry before plugging in.
3. **Placement:** Place the Quick Burger Cooker on a stable, heat-resistant, and dry surface, away from flammable materials. Ensure there is adequate ventilation around the unit.

4. **Power Connection:** Ensure the appliance is unplugged before placing food. Once ready to cook, plug the power cord into a standard 120V AC electrical outlet.

Operating Instructions

Cooking Hamburgers

1. **Preheat:** Close the cooker and plug it into a 120V AC outlet. Allow the unit to preheat for approximately 3-5 minutes. The indicator light (if present, or simply wait for the unit to reach operating temperature) will signal readiness.
2. **Prepare Patty:** Form a quarter-pound (approximately 4 oz) hamburger patty. For best results and to prevent sticking, a very light coating of cooking spray or oil can be applied to the nonstick cooking surfaces, though it is often not necessary.
3. **Place Patty:** Open the cooker and carefully place the hamburger patty onto the lower cooking plate.
4. **Cook:** Close the cover. The cover locks in place to prevent splatters during cooking. Cook for 2 to 3 minutes for a medium-rare to medium doneness. Adjust cooking time based on desired doneness and patty thickness.
5. **Remove Food:** Once cooked, carefully open the cooker. Use a heat-resistant plastic or wooden spatula to remove the hamburger. Avoid metal utensils that could damage the nonstick coating.
6. **Grease Collection:** The integrated drip pan will collect run-off grease, contributing to healthier cooking.

Using as a Flat Grilling Surface (e.g., for Eggs)

The cover of the Quick Burger Cooker can be removed to allow the lower cooking plate to be used as a flat grilling surface. This is suitable for items like fried or scrambled eggs.

1. **Remove Cover:** With the unit unplugged and cool, carefully detach the top cover.
2. **Preheat:** Plug in the unit and allow the lower plate to preheat.
3. **Cook:** Apply a small amount of cooking oil or butter to the nonstick surface. Cook eggs or other items as desired.
4. **Caution:** When the cover is removed, there is no splatter protection. Exercise caution.

Care and Maintenance

Cleaning

Proper cleaning ensures the longevity and performance of your appliance.

- **Always unplug** the cooker and allow it to cool completely before cleaning.
- The **removable cooking tray** (lower plate) is dishwasher-safe for convenient cleaning. It can also be washed by hand with warm, soapy water and a non-abrasive sponge.
- The **cover and exterior** of the unit can be wiped down with a damp cloth. Do not immerse the main unit or power cord in water or any other liquid.
- For stubborn food residue on nonstick surfaces, soak with warm, soapy water for a few minutes before gently scrubbing with a non-abrasive sponge.
- Do not use abrasive cleaners, scouring pads, or metal utensils, as these can damage the nonstick coating.
- Ensure all parts are thoroughly dry before storing or next use.

Storage

Store the appliance in a cool, dry place. Wrap the power cord neatly around the base or use the provided cord wrap if available to prevent damage.

Troubleshooting

Problem	Possible Cause	Solution
Appliance does not heat up.	Not plugged in; power outlet malfunction.	Ensure the power cord is securely plugged into a working 120V AC outlet. Test the outlet with another appliance.
Food sticks to the cooking surface.	Insufficient preheating; no cooking spray/oil used; damaged nonstick coating.	Allow adequate preheating time. Apply a light coating of cooking spray or oil before adding food. If coating is damaged, contact customer service.
Food is not cooking evenly or quickly.	Appliance not fully preheated; too much food; incorrect cooking time.	Ensure the unit is fully preheated. Do not overload the cooking surface. Adjust cooking time as needed. Ensure the cover is properly closed.
Smoke or unusual odor during operation.	Food residue burning; new appliance odor; excessive grease.	Unplug immediately. Allow to cool and clean thoroughly. A slight odor on first use is normal. Ensure drip pan is emptied. If problem persists, discontinue use and contact support.

Product Specifications

Model Number: 05511

Power: 400 Watts

Voltage: 120V AC Only

Dimensions: Approximately 6 x 12 x 3 inches (Width x Length x Height)

Weight: Approximately 2.1 pounds

Manufacturer: Presto

Features: Nonstick cooking surface, removable cooking tray, drip pan, cover locks for splatter prevention, cover removable for flat grilling.

Warranty and Support

This Presto 05511 Quick Burger Cooker is covered by a**one-year limited warranty** from the date of purchase. This warranty covers defects in material and workmanship under normal household use.

The warranty does not cover damage resulting from accident, misuse, abuse, commercial use, or unauthorized modification of the product.

For warranty service, technical support, or to inquire about replacement parts, please contact Presto Customer Service:
Website: www.gopresto.com

Phone: Refer to the product packaging or the official Presto website for the most current contact information.

Please have your model number (05511) and date of purchase available when contacting support.

© 2023 Presto. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0017UO77E

More documents and user manuals: **https://manuals.plus/**