Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

techno line WS 8001

Techno Line WS 8001 Radio-Controlled Clock Instruction Manual

Introduction

Welcome to your new Techno Line WS 8001 Radio-Controlled Clock. This manual provides detailed instructions for setting up, operating, and maintaining your clock. Please read it thoroughly to ensure optimal performance and longevity of your device.

Safety Information

- Do not expose the device to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping the clock or subjecting it to strong impacts.
- Do not attempt to disassemble or repair the unit yourself. Refer all servicing to qualified personnel.
- Dispose of used batteries responsibly according to local regulations.

Package Contents

Please check that all items are present in your package:

- Techno Line WS 8001 Radio-Controlled Clock
- Instruction Manual (this document)

Product Overview

Familiarize yourself with the design and display features of your WS 8001 clock.



Image: Front view of the Techno Line WS 8001 Radio-Controlled Clock, showing its digital display and silver-grey casing. The display clearly shows the current time, date, day of the week, moon phase, and indoor temperature.

Display Features

- **Time Display:** Shows current time in 12-hour or 24-hour format.
- **Date and Day of the Week:** Displays the current date and day of the week (available in 7 languages).
- **Indoor Temperature:** Shows the current temperature inside the room.
- **Moon Phase:** Indicates the current phase of the moon.
- **Alarm Indicator:** Icon to show if the alarm is active.

Controls (Typical)

While specific button labels are not provided, most radio-controlled clocks feature similar controls:

- **SET Button:** Used to enter and confirm settings.
- **UP/DOWN Buttons:** Used to adjust values during setting.
- **ALARM Button:** For setting and activating/deactivating the alarm.
- **SNOOZE/LIGHT Button:** Activates snooze during an alarm or temporarily illuminates the display.

Setup

1. Battery Installation

1. Locate the battery compartment on the back of the clock.

2. Open the compartment cover.
3. Insert the required batteries (e.g., 2 x AA 1.5V, not included) observing the correct polarity (+ and - markings).
4. Close the battery compartment cover securely.

2. Initial Power-On and Radio Signal Reception

Upon battery insertion, the clock will automatically power on and begin searching for the DCF-77 radio signal. This process can take several minutes to an hour. During this time, a signal icon may flash on the display.

- Place the clock near a window for better reception.
- Avoid placing it near electronic devices that may cause interference.
- Once the signal is received, the time and date will automatically set. The signal icon will become solid.

3. Manual Time Setting (Optional)

If the radio signal is consistently unavailable, you can set the time manually:

1. Press and hold the **SET** button until the display flashes.
2. Use the **UP**/**DOWN** buttons to adjust the hour, then press **SET** to confirm.
3. Repeat for minutes, year, month, and day.
4. Press **SET** again to exit manual setting mode.

4. Time Zone Adjustment

To adjust for different time zones (± 12 hours from the DCF-77 signal):

1. Press the **SET** button briefly until the time zone offset flashes.
2. Use the **UP**/**DOWN** buttons to select the desired offset.
3. Press **SET** to confirm and exit.

Operating Instructions

1. Time Display Modes

To switch between 12-hour (AM/PM) and 24-hour formats, briefly press the **UP** button (or a dedicated 12/24h button if available) during normal time display.

2. Date and Day of the Week Display

The clock automatically displays the date and day of the week. To change the language for the day of the week (7 languages available), refer to the manual setting section or a dedicated language setting option if present (often accessed via the **SET** button).

3. Alarm Function

1. **Setting the Alarm:** Press and hold the **ALARM** button until the alarm time flashes. Use **UP**/**DOWN** to set the desired hour and minutes, pressing **ALARM** to confirm each step.
2. **Activating/Deactivating Alarm:** Briefly press the **ALARM** button to toggle the alarm on or off. An alarm icon will appear/disappear on the display.
3. **Snooze Function:** When the alarm sounds, press the **SNOOZE/LIGHT** button to temporarily silence it. The alarm will sound again after a few minutes (typically 5-10 minutes). To stop the alarm completely, press any other button.

4. Indoor Temperature Display

The current indoor temperature is continuously displayed on the screen. The unit of measurement (Celsius or Fahrenheit) can usually be switched by pressing a dedicated button (e.g., **DOWN** button) or through the settings menu.

5. Moon Phase Display

The clock features a moon phase indicator that automatically updates based on the set date. This graphic representation shows the

current phase of the moon.

Maintenance

- **Cleaning:** Wipe the clock with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Battery Replacement:** When the display becomes dim or the clock stops functioning, replace the batteries with new ones, ensuring correct polarity.

Troubleshooting

Problem	Possible Cause	Solution
No display or weak display	Low or dead batteries; incorrect battery polarity	Replace batteries with new ones, ensuring correct polarity.
Incorrect time or no radio signal reception	Interference; clock too far from signal source; signal blocked	Reposition the clock near a window or away from electronic devices. Allow time for signal acquisition. Manually set the time if necessary.
Alarm not sounding	Alarm not activated; alarm volume too low (if adjustable)	Ensure the alarm icon is displayed. Check alarm settings.

Specifications

Brand	techno line
Model Number	WS 8001
Color	Grey/Silver
Dimensions (L x W x H)	23.6 x 8.5 x 17.6 cm
Weight	328 g
Voltage	1.5 Volts
Material	Plastic, Acrylonitrile Butadiene Styrene
Special Features	Alarm, Noise Display, Radio-Controlled (DCF-77), Indoor Temperature, Moon Phase
Power Source	Battery Powered (Batteries not included)
Display Type	Digital
Mounting Type	Wall Mount or Tabletop

Warranty and Support

For warranty information or technical support, please refer to the documentation provided with your purchase or contact Techno Line customer service directly. Keep your proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B001IAG1EK

More documents and user manuals: **https://manuals.plus/**