Westclox AX-AY-ABHI-08831

Westclox Gen Quartz Travel Alarm (White) - Instruction Manual

Model: AX-AY-ABHI-08831

Introduction

Thank you for choosing the Westclox Gen Quartz Travel Alarm. This compact and reliable alarm clock is designed for ease of use, whether at home or during travel. It features a clear analog display, a pleasant alarm sound, and convenient light and snooze functions.

Image: Front view of the Westclox Gen Quartz Travel Alarm Clock. The clock features a white rectangular casing with rounded edges. The analog dial is white with green numbers and hands. A red bar is visible on top, indicating the alarm status. A light/snooze button is on the top right.

Setup

Battery Installation

The Westclox Gen Quartz Travel Alarm requires one (1) AA battery (not included) for operation.

1. Locate the battery compartment cover on the back of the clock.
2. Remove the cover by sliding it or gently prying it open.
3. Insert one fresh AA battery, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover securely.

Setting the Time

1. Locate the time setting knob on the back of the clock.
2. Rotate the knob in the direction indicated (usually counter-clockwise) to move the hour and minute hands to the current time.
3. Ensure the time is set accurately, especially for AM/PM if the clock has a 12-hour cycle with an alarm indicator.

Operating Instructions

Setting the Alarm

1. Locate the alarm setting knob on the back of the clock.
2. Rotate the alarm setting knob to move the alarm hand to your desired wake-up time.
3. Ensure the alarm hand is precisely aligned with the desired time for accurate alarm activation.

Activating/Deactivating the Alarm

- To activate the alarm, slide the alarm ON/OFF switch (often a bar on the top of the clock) to the "ON" position. A visual indicator (e.g., a red bar) may appear.
- To deactivate the alarm, slide the alarm ON/OFF switch to the "OFF" position.

Snooze Function and Light

- When the alarm sounds, press the large button on the top of the clock to activate the snooze function. The alarm will temporarily stop and sound again after a few minutes.
- Pressing the same button will also illuminate the clock face for easy viewing in low-light conditions. The light will remain on as long as the button is pressed.

Maintenance

Cleaning

To clean the clock, gently wipe the surface with a soft, dry cloth. Do not use abrasive cleaners, solvents, or chemical sprays, as these may damage the clock's finish or internal components.

Battery Replacement

Replace the AA battery annually or when the clock's timekeeping becomes inaccurate, the alarm weakens, or the light dims. Follow the battery installation steps outlined in the "Setup" section.

Storage

If storing the clock for an extended period, remove the battery to prevent leakage and potential damage to the clock's internal circuitry.

Troubleshooting

Problem	Possible Cause	Solution
Clock not keeping accurate time.	Low battery.	Replace the AA battery with a fresh one.
Alarm does not sound.	Alarm not activated or battery low.	Ensure the alarm ON/OFF switch is in the "ON" position. Replace battery if needed.
Light is dim or not working.	Low battery.	Replace the AA battery with a fresh one.

Specifications

- **Model:** AX-AY-ABHI-08831
- **Brand:** Westclox
- **Display Type:** Analog
- **Movement:** Quartz
- **Power Source:** 1 x AA Battery (not included)
- **Color:** White
- **Material:** Plastic
- **Dimensions:** Approximately 2 x 1.5 x 2 inches (Length x Width x Height)
- **Features:** Alarm, Snooze, Light
- **Usage:** Indoor, Tabletop

Warranty and Support

For warranty information or technical support, please refer to the packaging or contact Westclox customer service directly. Contact details can typically be found on the manufacturer's official website or product packaging.

Note: Specific warranty terms and support availability may vary. Please retain your purchase receipt for warranty claims.

© 2024 Westclox. All rights reserved.