Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

GoodCook 248142

Good Cook Digital Precision Timer User Manual

Brand: GoodCook | Model: 248142

Introduction

Thank you for choosing the Good Cook Digital Precision Timer. This versatile timer is designed for accuracy and ease of use in various settings, from kitchen tasks to time management. It features both count-up and count-down capabilities for up to 20 hours, a magnetic easel stand, and a memo clip function for added convenience.

Setup

Battery Installation

The Good Cook Digital Precision Timer requires one (1) AAA alkaline battery (included). To install or replace the battery:

1. Locate the battery compartment on the back of the timer.
2. Slide the battery cover open.
3. Insert one AAA battery, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.
4. Close the battery cover securely.



Figure 1: Rear view of the timer, highlighting the battery compartment and the magnetic easel stand/memo clip.

Operating Instructions

Timer Functions

The timer features three primary buttons on its front face:**H** (Hours), **M** (Minutes), and ► (Start/Stop/Reset).



Figure 2: Front view of the timer, showing the digital display and control buttons.

Setting the Timer (Count-Down)

1. Press the **H** button to set the desired hours. Each press increases the hour by one.
2. Press the **M** button to set the desired minutes. Each press increases the minute by one.
3. To clear the set time, press and hold the**H** and **M** buttons simultaneously until the display resets to 00:00.
4. Once the desired time is set, press the► button to start the countdown. The display will show the remaining time.

5. When the timer reaches zero, an audible alarm will sound. Press the ► button to stop the alarm and reset the timer to the last set time.

Using the Timer (Count-Up)

1. Ensure the timer display is at 00:00. If not, press and hold the**H** and **M** buttons simultaneously to reset it.
2. Press the ► button to start the count-up function. The timer will begin counting upwards from zero.
3. To pause the count-up, press the ► button. Press it again to resume.
4. To reset the count-up timer to 00:00, press and hold the► button while it is paused.

Magnetic Easel Stand and Memo Clip

The timer is equipped with a magnetic easel stand on its back, allowing it to stand freely on a flat surface or attach to metallic surfaces like refrigerators. This stand also functions as a memo clip, providing a convenient way to hold notes or recipes.

Maintenance

Cleaning

To clean the timer, wipe it with a damp cloth. Do not immerse the timer in water or place it in a dishwasher, as this will damage the electronic components.

Battery Care

Replace the AAA battery when the display becomes dim or the timer functions erratically. Remove the battery if the timer will not be used for an extended period to prevent leakage.

Troubleshooting

Problem	Possible Cause	Solution
Display is dim or blank.	Low or dead battery.	Replace the AAA battery. Ensure correct polarity.
Timer does not start/stop.	Button not pressed firmly or internal issue.	Ensure the ► button is pressed firmly. If issue persists, replace battery or contact support.
Alarm is not loud enough.	Environmental noise or personal preference.	Position the timer closer to yourself or in a quieter environment. The alarm volume is fixed.

Specifications

- **Model Number:** 248142
- **Dimensions:** 2.13 x 1 x 2.75 inches
- **Weight:** 2.4 ounces

- **Power Source:** 1 x AAA battery (included)
- **Timer Range:** Counts up or down for up to 20 hours
- **Features:** Magnetic easel stand, memo clip function
- **Color:** White

Warranty and Support

GoodCook stands behind the quality of its products. This product comes with a 100% Satisfaction Guarantee, as indicated on the product packaging. For any questions, concerns, or support needs, please visit the official GoodCook website or contact their customer service department.
Official GoodCook Website: www.goodcook.com

© 2025 GoodCook. All rights reserved. Information subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0028LTEQU

More documents and user manuals: **https://manuals.plus/**