LEXiBOOK ST100

Lexibook ST 100 Universal Remote Control User Manual

Model: ST100

Introduction

This manual provides detailed instructions for setting up and operating your Lexibook ST 100 Universal Remote Control. Please read this manual carefully before use to ensure proper functionality and to maximize your remote control's capabilities.

Package Contents

- Lexibook ST 100 Universal Remote Control
- 2 x AA Batteries
- User Manual (this document)

Remote Control Layout



This image displays the Lexibook ST 100 Universal Remote Control. The top section features device selection buttons (TV1, TV2, VCR1, VCR2, SAT, CBL, DVD, CD, AMP, AUX) and a power button. Below are media control buttons. The central area includes channel and volume controls, along with M1, M2, M3 memory buttons. The lower section contains numeric keys, menu, navigation (up, down, left, right, OK), back, and exit buttons.

Familiarize yourself with the buttons and their functions:

- **Device Selection Buttons (TV1, TV2, VCR1, VCR2, SAT, CBL, DVD, CD, AMP, AUX):** Select the device you wish to control.
- **Power Button:** Turns the selected device on or off.
- **Numeric Keypad (0-9):** For direct channel entry and other numerical inputs.
- **Channel Up/Down (CH+/CH-):** Changes channels.
- **Volume Up/Down (VOL+/VOL-):** Adjusts volume.
- **Mute:** Silences the audio.
- **Navigation Buttons (Up, Down, Left, Right, OK):** For menu navigation and selection.
- **Menu:** Accesses the device's menu.
- **Back:** Returns to the previous screen or menu.
- **Exit:** Exits the current menu or function.
- **AV:** Switches video input sources.
- **FavCH:** Accesses favorite channels.
- **Audio:** Adjusts audio settings or tracks.
- **M1, M2, M3:** Memory buttons for specific functions or macros (refer to advanced setup).

Setup

1. Battery Installation

1. Open the battery compartment cover on the back of the remote control.
2. Insert two (2) AA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
3. Close the battery compartment cover securely.

2. Programming the Remote Control

The Lexibook ST 100 is pre-programmed with codes for over 12,000 models and is compatible with over 2000 brands.

There are two primary methods for programming:

Method A: Automatic Code Search

1. Turn on the device you wish to control (e.g., TV, DVD player) manually.
2. Press and hold the **SET** button on the remote until the indicator light illuminates.
3. Press the corresponding device selection button (e.g., **TV1** for your television). The indicator light will flash.
4. Point the remote at the device and press the **Power** button repeatedly, pausing briefly after each press.
5. When the device turns off, immediately press the **SET** button to save the code. The indicator light will turn off.
6. Test the remote's functions (e.g., volume, channel) to ensure proper operation. If not all functions work, repeat the process to find a more compatible code.

Method B: Manual Code Entry (Refer to a separate code list, not included in this manual)

1. Turn on the device you wish to control.
2. Press and hold the **SET** button until the indicator light illuminates.
3. Press the corresponding device selection button (e.g., **TV1**). The indicator light will flash.
4. Enter the 3 or 4-digit code for your device's brand using the numeric keypad.
5. If the code is valid, the indicator light will turn off.
6. Test the remote's functions. If the device does not respond or not all functions work, try another code from the list for your brand.

The remote control can operate up to 10 different products simultaneously.

Operating the Remote Control

1. **Select Device:** Press the appropriate device selection button (e.g., **TV1**, **DVD**, **SAT**) for the device you want to control. The indicator light may briefly illuminate to confirm selection.
2. **Basic Functions:** Use the **Power**, **CH+**/**CH-**, **VOL+**/**VOL-**, and **Mute** buttons for primary control.
3. **Numeric Input:** Use the **0-9** keypad for direct channel access or other numerical inputs.
4. **Menu Navigation:** Use the **Menu** button to access device menus, and the **Up**/**Down**/**Left**/**Right**/**OK** buttons to navigate and select options.
5. **Input Switching:** Use the **AV** button to cycle through video input sources on your TV.

Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or the indicator light does not illuminate. Always replace both batteries with new AA batteries.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Durability:** The remote features an ergonomic and anti-shock design for enhanced durability.

Troubleshooting

- **Remote not responding to device:**
  - Ensure the remote is pointed directly at the device.
  - Check if the correct device selection button (e.g., TV1) is pressed.
  - Replace the batteries with new ones.

- Re-program the remote using the Automatic Code Search method.

- **Some functions not working after programming:**
  - The current code may not be fully compatible. Repeat the programming process (Automatic Code Search) to find an alternative code.
  - If using Manual Code Entry, try another code from your device's brand list.

- **Indicator light does not illuminate:**
  - Check battery installation and polarity.
  - Replace batteries.

Specifications

Model Number	ST100
Brand	LEXiBOOK
Product Dimensions	1.5 x 2.64 x 6.81 inches
Item Weight	2.88 ounces
Batteries	2 AA batteries (included)
Max. Supported Devices	10
Compatible Devices	TV1, TV2, DVD, CD, VCR1, VCR2, SAT, CBL, AMP, AUX (over 2000 brands, 12,000 models)
Special Feature	Universal, Shockproof Casing

Warranty Information

For detailed warranty information, please refer to the warranty card included with your product or visit the official LEXiBOOK website. Keep your proof of purchase for warranty claims.

Customer Support

If you encounter any issues not covered in this manual or require further assistance, please contact LEXiBOOK customer support. Contact details can typically be found on the official LEXiBOOK website or on the product packaging.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question