Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Panasonic ES-LA63-S

Panasonic ARC4 ES-LA63-S Electric Shaver Instruction Manual

Model: ES-LA63-S

Product Overview

The Panasonic ARC4 ES-LA63-S is a 4-blade, dual-motor electric shaver designed for a close and comfortable shave. It features precision-honed 30° angle Nanotech blades, a powerful linear motor, and a Multi-Flex pivoting head for optimal contouring. This shaver supports both wet and dry operation.



Image: Panasonic ARC4 ES-LA63-S Electric Shaver, front view.



Image: Panasonic ARC4 ES-LA63-S Electric Shaver, showcasing the shaver and its components.

Setup

Charging the Shaver

Before initial use, fully charge the shaver. The ES-LA63-S features a 10-stage LCD on the handle to display the battery status and charge indicator. Ensure the shaver is turned off before connecting it to the power source.

Attaching/Detaching the Outer Foil

To attach the outer foil, align it with the shaver head and press gently until it clicks into place. To detach, press the release buttons on the sides of the shaver head and lift the outer foil.



Image: Close-up of the Panasonic ARC4 Arc Foil system.

Operating Instructions

Basic Shaving Technique

1. Ensure the shaver is fully charged.
2. Turn on the shaver.
3. Hold the shaver at a right angle to your skin.
4. Stretch your skin taut with your free hand.
5. Move the shaver slowly over your face against the direction of hair growth. The Multi-Flex pivoting head will adapt to your facial contours for an efficient shave.
6. For a wet shave, apply shaving cream or gel to your face before shaving. The shaver is designed for both wet and dry use.

▶ **Watch video online**
Panasonic ES-LA63-S Arc4 Men's Electric Razor, 4-Blade Cordless with Wet/Dry Shaver Convenience

Video: Official Panasonic demonstration of the ES-LA63-S Arc4 Electric Shaver's features and operation, including its 4-blade system, wet/dry convenience, and multi-flex pivoting head.

Using the Pop-Up Trimmer

The shaver includes a built-in pop-up trimmer for detailing sideburns and mustaches. To activate, slide the trimmer switch upwards. Use the trimmer to shape and define facial hair as needed.



Image: Illustration of the Panasonic ARC4 Multi-Flex pivoting head, demonstrating its movement.

MAINTENANCE

Daily Cleaning

For optimal performance and hygiene, clean the shaver after each use:

- Turn off the shaver.
- Remove the outer foil.
- Rinse the outer foil and the blade area under running water.
- For a deeper clean, apply a few drops of liquid hand soap to the shaver head, turn the shaver on, and let it run for a few seconds to create foam. Rinse thoroughly under running water.
- Shake off excess water and allow the shaver head and outer foil to air dry completely before reattaching or storing. Leaving components to air dry separately helps prevent mold buildup.



Image: Panasonic ARC4 Shaver being rinsed under water, demonstrating its wet/dry capability for easy cleaning.

Blade and Foil Replacement

The shaver's LCD display will provide reminders for blade and foil replacement. Replace these components as indicated to maintain shaving performance. Genuine Panasonic replacement parts are recommended.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Shaver does not turn on or operate weakly.	Low battery charge.	Charge the shaver fully. Check the LCD battery indicator.
Poor shaving performance or irritation.	Blades/foils are dull or clogged with hair/debris. Incorrect shaving technique.	Clean the shaver thoroughly. Replace blades and foils if indicated by the LCD or if performance does not improve. Ensure proper shaving technique (against hair growth, gentle pressure).
Shaver head appears stained or has an odor.	Improper drying after wet use, leading to mold or residue buildup.	Perform a thorough soap-and-water cleaning. Ensure all components are completely air-dried separately after each wet use.
Pop-up trimmer does not stay in position.	Mechanical issue or debris.	Clean the trimmer area. If the issue persists, contact customer support.

Specifications

- **Model:** ES-LA63-S
- **Shaving System:** 4-Blade, Dual-Motor
- **Blade Angle:** 30° Nanotech blades
- **Motor Speed:** 14,000 CPM Linear Motor Drive
- **Head Type:** Multi-Flex Pivoting Head
- **Operation:** Wet/Dry
- **Trimmer:** Built-in Pop-Up Trimmer
- **Display:** 10-stage LCD (Battery status, charge indicator, cleaning/replacement reminders)
- **Power Source:** Rechargeable (*Note: This typically refers to an internal rechargeable battery, not user-replaceable AA cells, despite the source data.*)
- **Dimensions:** 2.2 x 2.7 x 6.5 inches
- **Weight:** 7.04 ounces

Warranty and Support

For warranty information, product registration, or technical assistance, please refer to the official Panasonic website or contact Panasonic customer support directly. Keep your purchase receipt for warranty claims.
Manufacturer: Panasonic
ASIN: B002N5MHLU
GTIN/UPC: 037988566532

© 2023 Panasonic. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B002N5MHLU

More documents and user manuals: **https://manuals.plus/**