Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun CCR2

Braun CCR2 Clean & Renew Cartridges User Manual

Model: CCR2

Brand: Braun

Introduction

The Braun CCR2 Clean & Renew Cartridges are designed to provide a hygienic cleaning, lubrication, and refreshing scent for your Braun electric shaver. Regular use of these cartridges helps maintain your shaver's peak performance and extends its lifespan. This manual provides essential information on how to properly use and maintain your Clean & Renew cartridges.



Image: Braun CCR2 Clean & Renew Cartridges 2-Pack in retail packaging. This image displays the product as it is sold, highlighting the "Lemonfresh Formula" and "2-Pack" designation.

Product Features

- **Hygienic Cleaning:** The alcohol-based cleaning fluid removes stubble and dirt, eliminating 99.9% of germs.
- **Automatic Lubrication:** The cleaning solution automatically lubricates the shaver blades for optimal cutting efficiency.
- **Refreshing Scent:** Each cleaning cycle leaves your shaver with a fresh lemon scent.
- **Easy Replacement:** Cartridges are designed for quick and mess-free replacement.
- **Optimal Performance:** Regular use ensures your shaver performs like new every day.



Image: A single Braun Clean & Renew cartridge, showing its transparent blue liquid and the "Lemonfresh" logo, indicating the scent of the cleaning solution.

Setup

Follow these steps to install a new Clean & Renew cartridge into your Braun cleaning station:

1. Press the lift button on the cleaning station to open the housing.
2. Carefully remove the used cartridge from the station. Dispose of it responsibly.

3. Open the new Braun Clean & Renew cartridge by removing the protective cap.
4. Slide the new cartridge into the cleaning station until it clicks into place.
5. Close the cleaning station housing.



Image: A Braun Clean & Renew station with a cartridge inserted, illustrating the recommended replacement cycle of approximately every 2 months for optimal performance.

Operating Instructions

Once the cartridge is installed, operating your cleaning station is straightforward:

- After shaving, rinse your shaver head under running water to remove loose hairs.
- Place your Braun electric shaver upside down into the cleaning station. Ensure it is properly seated.
- Press the start button on the cleaning station to initiate the cleaning cycle. The station will automatically clean, lubricate, and dry your shaver.
- The cleaning cycle duration may vary depending on the shaver model and the level of cleaning required.

- Once the cycle is complete, the shaver will be ready for its next use.



Image: A Braun shaver undergoing a cleaning cycle within the Clean & Renew station. The image clearly shows the cleaning fluid circulating through the shaver head, ensuring thorough cleaning and lubrication.

Maintenance

To ensure optimal performance and hygiene, regular maintenance of your cleaning cartridge is necessary:

- **Cartridge Replacement:** Replace the Clean & Renew cartridge approximately every 2 months, or when the cartridge indicator light on your cleaning station illuminates, whichever comes first. This ensures fresh cleaning fluid and effective lubrication.
- **Disposal:** Dispose of used cartridges according to local environmental regulations. The fluid contains alcohol, so ensure proper ventilation when handling.
- **Cleaning Station Care:** Periodically wipe down the exterior of your cleaning station with a damp cloth. Do not immerse the station in water.



Image: Two Braun Clean & Renew cartridges, ready for use or replacement. This visual aids in identifying the product and understanding the typical packaging quantity.

Troubleshooting

If you encounter issues with your Braun Clean & Renew system, consider the following common solutions:

- **Cleaning Not Effective:** Ensure the cartridge is not empty and is properly seated. Replace the cartridge if the fluid level is low or if it has been in use for more than 2 months.
- **Cartridge Indicator Light On:** This indicates that the cartridge needs to be replaced. Follow the setup instructions to install a new one.
- **Shaver Not Drying Properly:** Ensure the cleaning station's fan vents are not obstructed. Allow sufficient time for the drying cycle to complete.
- **Unusual Odor:** If the cleaning fluid develops an unusual odor, replace the cartridge immediately.

Specifications

Feature	Detail
Brand	Braun
Model Number	CCR2
Format	Liquid
Scent	Lemon
Units	2 Count

Feature	Detail
Product Dimensions	13 x 10 x 9 cm; 440 grams
Special Usage	Electronic Shaver Cleaning
Manufacturer	Procter & Gamble

Safety Information

There are no specific safety warnings provided for this product beyond general handling precautions. The cleaning fluid contains alcohol and is flammable. Keep away from open flames and sources of ignition. Store in a cool, well-ventilated area, out of reach of children.

Warranty and Support

For information regarding product warranty, please refer to the documentation included with your Braun cleaning station or visit the official Braun website. For further support or inquiries, please contact Braun customer service.

Official Product Videos

No official product videos are available for embedding based on the provided product data.

© 2024 Braun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Why is the cartridge indicator light flashing on my Braun 590cc Boss cleaning station even though I just installed a new CCR 2 cartridge?

If the cartridge indicator light on your Braun 590cc Boss cleaning station continues to flash after you have inserted a new CCR 2 cartridge, please check the following: Proper Seating: Ensure the cartridge is...

Read full answer

Open the live page

https://manuals.plus/asin/B002NMM3E4

More documents and user manuals: **https://manuals.plus/**