Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Briggs & Stratton 806457

Briggs & Stratton 806457 Intake Gasket User Manual

Genuine Original Equipment Manufacturer (OEM) Part

Introduction

This manual provides essential information for the proper handling, installation, and maintenance of the Briggs & Stratton 806457 Intake Gasket. This component is a genuine Original Equipment Manufacturer (OEM) part designed to ensure optimal performance and fit within compatible Briggs & Stratton engines. Adhering to these instructions will help ensure the longevity and correct function of your equipment.

Safety Information

Always prioritize safety when working with engine components. Before beginning any installation or maintenance, ensure the engine is turned off, cooled down, and disconnected from its power source (e.g., spark plug wire removed). Wear appropriate personal protective equipment, such as gloves and eye protection. Refer to your engine's specific service manual for detailed safety precautions and procedures.

Product Overview



Figure 1: Briggs & Stratton 806457 Intake Gasket. This image displays the genuine OEM intake gasket, typically made from a

composite material, designed to create a seal between the carburetor and the engine's intake manifold.

The Briggs & Stratton 806457 Intake Gasket is a critical component for maintaining the proper air-fuel mixture in your engine. It forms a seal between the carburetor and the intake manifold, preventing air leaks that can lead to poor engine performance, rough idling, or difficulty starting. This OEM part is manufactured to precise specifications for a perfect fit and reliable sealing.

Installation Instructions (Replacement Procedure)

The following steps outline a general procedure for replacing an intake gasket. Specific engine models may have variations. Always consult your engine's service manual for precise instructions.

1. **Preparation:** Ensure the engine is cool and the spark plug wire is disconnected to prevent accidental starting. Clean the area around the carburetor and intake manifold to prevent debris from entering the engine.
2. **Disassembly:** Carefully remove any air filter components, shrouds, or linkages that obstruct access to the carburetor. Disconnect the fuel line from the carburetor (pinch off the fuel line or drain the fuel tank first). Remove the bolts or nuts securing the carburetor to the engine.
3. **Gasket Removal:** Gently separate the carburetor from the intake manifold. Remove the old intake gasket. Inspect the mating surfaces on both the carburetor and the intake manifold for any remaining gasket material, corrosion, or damage. Clean these surfaces thoroughly with a suitable gasket scraper or fine abrasive pad, ensuring they are smooth and free of debris.
4. **New Gasket Installation:** Position the new Briggs & Stratton 806457 Intake Gasket onto the intake manifold or carburetor, ensuring it aligns correctly with all bolt holes and passages. Do not use any sealants unless specifically instructed by your engine's service manual, as this OEM gasket is designed for a dry fit.
5. **Reassembly:** Carefully reattach the carburetor to the intake manifold, ensuring the gasket remains properly seated. Install the securing bolts or nuts and tighten them to the manufacturer's specified torque settings. Overtightening can damage components or distort the gasket.
6. **Final Steps:** Reconnect the fuel line, ensuring it is secure and free of leaks. Reinstall any removed air filter components, shrouds, and linkages. Reconnect the spark plug wire.
7. **Testing:** Start the engine and check for any air leaks around the carburetor and intake manifold area. Listen for unusual noises or observe any changes in engine performance.

Maintenance and Inspection

While the intake gasket itself does not require routine maintenance, periodic inspection of the engine's intake system is recommended to ensure its integrity.

- **Visual Inspection:** Regularly inspect the area around the carburetor and intake manifold for signs of air leaks, such as fuel residue, dirt accumulation, or unusual discoloration.
- **Performance Monitoring:** Pay attention to engine performance. Symptoms like rough idling, surging, loss of power, or difficulty starting can indicate an air leak caused by a failing intake gasket.
- **Replacement Schedule:** Replace the intake gasket whenever the carburetor is removed for service or if signs of a leak are detected. Gaskets are typically single-use components and should not be reused.

Troubleshooting

If you experience engine performance issues after installing a new intake gasket, consider the following:

- **Air Leaks:** The most common issue is an air leak due to improper installation or a damaged gasket. Recheck all connections and ensure the gasket is seated correctly and bolts are torqued to specification.

- **Debris:** Ensure no debris entered the intake manifold or carburetor during installation. Even small particles can obstruct fuel or air passages.
- **Other Components:** If the issue persists, the problem may lie with other engine components (e.g., carburetor, fuel system, ignition system) and not the gasket itself. Consult your engine's service manual or a qualified technician.

Specifications

Briggs & Stratton 806457 Intake Gasket Specifications

Feature	Detail
Part Number	806457
Type	Intake Gasket
Manufacturer	Briggs & Stratton
OEM Status	Genuine Original Equipment Manufacturer Part
Item Weight	Approximately 5 pounds (packaging weight)
UPC	024847259728
Unit Count	1.0 Count

Warranty Information

Specific warranty terms for the Briggs & Stratton 806457 Intake Gasket are subject to the manufacturer's policies. For detailed warranty information, please refer to the documentation included with your original engine or contact Briggs & Stratton directly. Keep your purchase receipt as proof of purchase.

Customer Support

For further assistance, technical support, or to locate authorized service centers, please visit the official Briggs & Stratton website or contact their customer service department. When contacting support, please have your engine model number and the gasket part number (806457) available.

Briggs & Stratton Official Website: www.briggsandstratton.com

Find a Service Dealer: Dealer Locator

© 2023 Briggs & Stratton. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B002WNYGGC

More documents and user manuals: **https://manuals.plus/**