Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Brainerd 64675

BRAINERD 64675 Wood Square Single Toggle Switch/Duplex Outlet Wall Plate

Model: 64675 | Brand: Brainerd

1. Product Overview

The Brainerd 64675 Wood Square Single Toggle Switch/Duplex Outlet Wall Plate is an unfinished wood cover designed to replace standard wall plates for a single toggle switch and a duplex outlet. This product allows for a simple and impactful aesthetic update to any room. Its unfinished surface provides versatility for custom finishing to match various interior designs.



Figure 1: Front view of the Brainerd 64675 Wood Square Single Toggle Switch/Duplex Outlet Wall Plate, showing the unfinished wood texture and the cutouts for one toggle switch and one duplex outlet.

2. Installation Instructions

Installation of the Brainerd 64675 wall plate is designed to be straightforward. Always ensure power is turned off at the circuit breaker before beginning any electrical work.

1. **Preparation:** Ensure the electrical circuit connected to the switch/outlet is de-energized by turning off the corresponding breaker in your electrical panel. Verify with a voltage tester that no power is present.
2. **Remove Existing Wall Plate:** Carefully unscrew and remove the current wall plate from the switch and outlet.
3. **Position New Wall Plate:** Align the Brainerd 64675 wall plate over the switch and outlet openings.
4. **Secure Wall Plate:** Use the provided screws to gently secure the new wall plate to the wall. Do not overtighten, as this can crack the wood or damage the electrical box.

5. **Restore Power:** Once the wall plate is securely installed, restore power at the circuit breaker.



Figure 2: Easy Installation Steps for Wall Plates.



Figure 3: Example of a Brainerd wall plate installed in a kitchen environment.

3. Operating Instructions

The Brainerd 64675 wall plate is a passive component and does not have any operational controls. Its function is purely aesthetic and protective, covering the electrical components of a single toggle switch and a duplex outlet.

4. Maintenance

To maintain the appearance and integrity of your unfinished wood wall plate, follow these guidelines:

- **Cleaning:** Wipe the surface with a soft, dry cloth to remove dust. For minor smudges, a slightly damp cloth can be used, followed immediately by a dry cloth. Avoid abrasive cleaners or harsh chemicals, as these can damage the wood.
- **Finishing:** As this is an unfinished wood product, you may choose to paint, stain, or seal it to match your decor. Follow the instructions of your chosen wood finish product. Ensure the finish is completely dry before re-installing the plate.
- **Inspection:** Periodically check the screws for tightness to ensure the plate remains securely fastened to the wall.

5. Troubleshooting

Most issues with a wall plate are minor and easily resolved:

- **Loose Fit:** If the wall plate feels loose, gently tighten the mounting screws. Do not overtighten.
- **Cracked or Damaged Plate:** If the wood plate becomes cracked or damaged, it should be replaced to maintain safety and appearance.
- **Difficulty Aligning:** Ensure the electrical box is properly recessed and the switch/outlet components are correctly positioned within the wall. Slight adjustments to the electrical components may be necessary for proper alignment.

6. Specifications

Attribute	Detail
Model Number	64675
Brand	Brainerd
Material	Wood
Color	Unfinished
Switch Type Compatibility	Toggle
Outlet Type Compatibility	Duplex Outlet
Configuration	Single Toggle / Duplex Outlet
Installation Type	Screw-In
Product Dimensions	0.32 x 5.28 x 5.67 inches
Item Weight	3.2 ounces
Manufacturer	Liberty Hardware

7. Warranty and Support

The Brainerd 64675 Wood Square Single Toggle Switch/Duplex Outlet Wall Plate is backed by a **Limited Lifetime Warranty** from Liberty Hardware. For specific details regarding warranty coverage, claims, or product support, please refer to the official documentation included with your purchase or visit the Liberty Hardware website.
Manufacturer: Liberty Hardware

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00368CEQG

More documents and user manuals: **https://manuals.plus/**