Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Fissler 21-641-630

Fissler Pressure Cooker Main Unit Handle Instruction Manual

Model: 21-641-630
Brand: Fissler

Introduction

This instruction manual provides essential information for the proper installation, use, and maintenance of your Fissler Pressure Cooker Main Unit Handle, Model 21-641-630. This handle is designed specifically for Fissler Blue Point pressure cookers with a capacity of 4.5L or 6L, corresponding to a pot inner diameter of 8.7 inches (22 cm). Please read this manual thoroughly before attempting to install or use the handle to ensure safe and efficient operation.

Important Safety Instructions

Always follow basic safety precautions when handling pressure cooker parts. Failure to do so may result in injury or damage to the appliance.

- Read and understand all instructions before installing or using the handle.
- Ensure the pressure cooker is completely depressurized and cool before attempting to remove or install the handle.
- Use only genuine Fissler replacement parts. This handle is compatible with Fissler Blue Point 4.5L and 6L models.
- Do not attempt to modify the handle or any part of the pressure cooker.
- Keep out of reach of children.
- Inspect the handle for any signs of damage or wear before each use. Do not use if damaged.

Product Components

The Fissler Pressure Cooker Main Unit Handle is a single, integrated component designed for secure attachment to your pressure cooker's main body.



Figure 1: Fissler Pressure Cooker Main Unit Handle (Model 21-641-630). This image shows the black handle with a silver-colored end piece and a small red indicator dot.

Setup and Installation

Follow these steps to properly install the main unit handle on your Fissler pressure cooker:

1. **Preparation:** Ensure your Fissler pressure cooker is completely cool, empty, and depressurized. Disconnect it from any heat source.
2. **Remove Old Handle (if applicable):** If replacing an existing handle, carefully remove it according to your pressure cooker's original manual. This may involve unscrewing fasteners.
3. **Align New Handle:** Position the new Fissler Main Unit Handle (Model 21-641-630) with the designated attachment points on the main body of your pressure cooker. Ensure the handle is oriented correctly.
4. **Secure Handle:** Gently push the handle into place until it clicks or sits firmly. If your pressure cooker model requires screws or other fasteners for the handle, ensure they are properly inserted and tightened. Do not overtighten.
5. **Verify Installation:** After installation, gently tug on the handle to ensure it is securely attached and does not wobble. It should feel stable and firm.

Operation

The main unit handle is designed to provide a secure and comfortable grip for safely moving and lifting your Fissler pressure cooker. Once properly installed, the handle allows for easy manipulation of the pot during cooking and serving.

- Always use both the main unit handle and the opposing handle (if present) when lifting or moving a hot or full pressure cooker.
- Ensure your grip is firm and secure before lifting.
- Do not use the handle if it feels loose, damaged, or unstable.

Care and Maintenance

Proper care will extend the life of your Fissler pressure cooker handle.

- **Cleaning:** The handle is **not dishwasher safe**. Clean the handle by hand using warm water and a mild dish soap. Wipe with a soft cloth.
- **Drying:** Ensure the handle is completely dry before reattaching it to the pressure cooker or storing it.
- **Storage:** Store the handle in a clean, dry place away from direct heat or extreme temperatures.
- **Inspection:** Periodically inspect the handle for any cracks, chips, or signs of wear. Replace the handle if any damage is observed.

Troubleshooting

If you encounter issues with your Fissler pressure cooker handle, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Handle feels loose after installation.	Not properly secured or fasteners are loose.	Re-check installation steps. Ensure any screws or clips are fully engaged and tightened.
Handle does not fit the pressure cooker.	Incorrect model handle purchased.	Verify your pressure cooker model is a Fissler Blue Point 4.5L or 6L. Ensure the handle model number (21-641-630) matches your requirement.
Handle is damaged (cracked, chipped).	Physical impact or material fatigue.	Discontinue use immediately and replace the handle with a new genuine Fissler part.

Specifications

Attribute	Detail
Brand	Fissler
Model Number	21-641-630
Product Dimensions	6.3"W x 4.53"D x 1.97"H (16 x 11.5 x 5 cm)
Item Weight	5.4 ounces (0.156 kg)
Material	Synthetic resin (Plastic)
Color	Black
Compatible Models	Fissler Blue Point 4.5L / 6L Pressure Cookers
Dishwasher Safe	No

Attribute	Detail
Country of Origin	Germany

Warranty and Support

For specific warranty information regarding your Fissler Pressure Cooker Main Unit Handle, please refer to the official Fissler website or the documentation provided with your original pressure cooker purchase. Fissler products are known for their quality and durability.
If you require further assistance, have questions about installation, or need to purchase additional genuine Fissler parts, please contact Fissler customer support or visit the official Fissler store online:
Visit the Fissler Store on Amazon

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B003EEM840

More documents and user manuals: **https://manuals.plus/**