Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun LS 5100

Braun Silk-epil Lady Shaver LS 5100 User Manual

Model: LS 5100 | Brand: Braun

Important Safety Information

For hygienic reasons, do not share this appliance with other persons. This appliance is not intended for use by children or persons with reduced physical, sensory or mental capabilities, unless they are given supervision by a person responsible for their safety. In general, we recommend that you keep the appliance out of reach of children. Children should be supervised to ensure that they do not play with the appliance. Batteries may leak if empty or not used for a longer time. In order to protect you and the appliance, please remove batteries in a timely manner and avoid skin contact whilst handling leaking batteries.

Product Overview

The Braun Silk-epil Lady Shaver LS 5100 is a battery-operated electric shaver designed for efficient and gentle hair removal on legs, underarms, and the bikini line. It features a floating foil and trimmer system for a close shave.

Key Features:

- Battery operated for cordless convenience.
- Floating foil and trimmer system for a close and comfortable shave.
- Rounded head adapts to body contours for smooth results.
- Includes a trimmer cap for precise use on the bikini line and sensitive areas.



Figure 1: Braun Silk-epil Lady Shaver LS 5100 with its protective trimmer cap attached. The shaver features a foil head and an ergonomic design for comfortable handling.





Figure 2: Braun Silk-epil Lady Shaver LS 5100 without its trimmer cap, revealing the floating foil and integrated trimmer. The device is

designed for efficient hair removal on legs and body.

Setup

Battery Installation:

1. Ensure the shaver is switched off.
2. Locate the battery compartment, typically at the base or back of the shaver.
3. Open the compartment cover.
4. Insert two (2) AAA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
5. Close the battery compartment cover securely.

Operating Instructions

General Shaving:

1. Ensure your skin is clean and dry before use.
2. Switch on the shaver.
3. Gently press the shaver head against your skin.
4. Move the shaver slowly against the direction of hair growth. The floating foil and trimmer will adapt to your body contours for an effective shave.
5. For optimal results, stretch the skin with your free hand to make the hairs stand upright.

Using the Trimmer Cap (for Bikini Line and Sensitive Areas):

1. Attach the trimmer cap to the shaver head.
2. Use the shaver with the cap for precise trimming and shaping in sensitive areas like the bikini line.
3. Move the shaver gently and carefully to avoid irritation.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and hygiene of your shaver.

1. **After Each Use:** Switch off the shaver. Remove the shaver head or foil frame. Tap out any accumulated hair. Use the small cleaning brush (if included) to remove stubborn hairs from the foil and trimmer.
2. **Deep Cleaning:** Periodically, you may rinse the shaver head under running water. Ensure the shaver is switched off and disconnected from any power source (if applicable, though this model is battery-operated). Allow all parts to air dry completely before reassembling or storing.
3. **Storage:** Store the shaver in a dry place, away from direct sunlight and extreme temperatures. Keep the protective cap on the shaver head when not in use.

Troubleshooting

Problem	Possible Cause	Solution
Shaver does not turn on.	Dead or incorrectly inserted batteries.	Check battery polarity. Replace with fresh AAA batteries.

Problem	Possible Cause	Solution
Poor shaving performance / Does not shave closely.	Shaver head is clogged with hair; dull foil or trimmer.	Clean the shaver head thoroughly. Ensure you are shaving against hair growth. Consider replacing the shaver head/foil if it's old.
Skin irritation or nicks.	Excessive pressure; dull foil; sensitive skin.	Apply gentle pressure. Ensure skin is clean and dry. Use the trimmer cap for sensitive areas. If irritation persists, consult a dermatologist.
Shaver head/blade detaches easily.	Improper reassembly after cleaning; worn parts.	Ensure the shaver head is correctly aligned and securely clicked into place. If parts are worn or damaged, contact customer support for replacement options.

Specifications

Feature	Detail
Brand	Braun
Model Name	Silk-epil Lady Shaver 5-100
Item Model Number	4210201003076
Item Weight	12.6 ounces
Package Dimensions	9.09 x 6.42 x 2.24 inches
Power Source	Battery Powered (Electric)
Battery Type	2 AAA batteries required (included)
Recommended Uses	Legs, Underarms, Bikini Line
Special Feature	Floating foil and trimmer, Trimmer cap
Manufacturer	BeautyCenter
Date First Available	August 6, 2012

Warranty and Support

This Braun product is manufactured to meet high-quality standards. For specific warranty details, please refer to the warranty card included with your purchase or visit the official Braun website. In case of product malfunction or for technical assistance, please contact Braun customer support.
Keep your proof of purchase for any warranty claims.

© 2025 Braun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the

question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B004EF00YS

More documents and user manuals: **https://manuals.plus/**