Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Best Price Square JT358 (1NF874010)

User Manual

Whirlpool JT358 VIP34 Microwave Turntable Glass Plate

Model: JT358 (1NF874010)

1. Introduction

This manual provides essential information for the proper installation, use, and maintenance of your new Whirlpool JT358 VIP34 Microwave Turntable Glass Plate. Please read these instructions carefully before using the product to ensure safe and efficient operation.

This glass plate is an original replacement part designed for various microwave oven models, including those from Whirlpool, Bauknecht, KitchenAid, Ignis, Ariston Hotpoint, and V-ZUG. Its primary function is to provide a stable, rotating surface for food items inside the microwave, ensuring even heating.

2. Safety Information

- **Handle with Care:** The turntable plate is made of glass and can break if dropped or subjected to sudden impacts.
- **Temperature Extremes:** Avoid placing extremely hot items directly onto a cold plate, or vice-versa, as this can cause thermal shock and breakage.
- **Cracks or Chips:** Do not use the glass plate if it is cracked, chipped, or damaged in any way. Damaged glass can shatter during use.
- **Proper Placement:** Ensure the plate is correctly seated on the microwave's turntable support and coupler before operating the appliance.
- **Cleaning:** Always allow the plate to cool down before cleaning with water or detergents.

3. Setup

3.1 Unpacking

Carefully remove the glass turntable plate from its packaging. Inspect the plate for any signs of damage during transit. If any damage is observed, do not use the plate and contact your supplier.

3.2 Installation in Microwave

1. Ensure your microwave oven is unplugged from the power outlet before installation.
2. Place the turntable support ring (usually with wheels) inside the microwave cavity.
3. Carefully place the glass turntable plate onto the support ring, ensuring the central indent on the underside of the plate aligns with the microwave's coupler (the rotating shaft in the center of the microwave floor).
4. Gently rotate the plate to confirm it is seated correctly and can turn freely.



This image shows the circular glass turntable plate, designed for use in microwave ovens. It features a smooth, transparent surface and a central hub for rotation.

4. Operating the Turntable Plate

Once installed, the turntable plate operates automatically when the microwave oven is in use. Its rotation ensures that food is exposed to microwave energy from all sides, promoting even cooking and heating.

- **Food Placement:** Place food containers or dishes centrally on the glass plate for optimal balance and rotation.

- **Weight Limit:** Avoid placing excessively heavy items on the plate, as this can strain the turntable motor and support mechanism. Refer to your microwave oven's manual for specific weight limits.
- **Clearance:** Ensure that dishes and food items do not obstruct the plate's rotation or touch the microwave oven's interior walls.

5. Maintenance

5.1 Cleaning

Regular cleaning of the glass turntable plate is essential for hygiene and to prevent food residue buildup.

- **Removal:** For thorough cleaning, carefully lift the glass plate out of the microwave oven.
- **Washing:** Wash the plate with warm, soapy water using a soft sponge or cloth. It is also typically dishwasher safe.
- **Rinsing and Drying:** Rinse thoroughly and dry completely before returning it to the microwave.
- **Stubborn Stains:** For stubborn food stains, a non-abrasive cleaner or a mixture of baking soda and water can be used. Avoid abrasive scouring pads or harsh chemicals that could scratch the glass.

5.2 Care Tips

- Avoid sudden temperature changes to prevent thermal shock.
- Do not use the plate as a cutting surface.
- Store the plate safely when not in use to prevent accidental breakage.

6. Troubleshooting

Problem	Possible Cause	Solution
Plate not rotating	Plate not seated correctly on coupler/support ring. Obstruction preventing rotation. Microwave turntable motor issue.	Ensure plate is properly aligned. Remove any obstructions. If motor issue, consult microwave oven's service manual.
Plate makes noise during rotation	Food debris under plate or support ring. Plate not balanced. Damaged support ring.	Clean under the plate and support ring. Ensure food is centered. Inspect support ring for damage and replace if necessary.
Plate is cracked or chipped	Impact damage. Thermal shock.	Discontinue use immediately. Replace with a new, compatible glass plate.

7. Specifications

Model Name: JT358

Manufacturer Part Number: 1NF874010

ASIN: B004JSXMX6

Brand: Best Price Square (Replacement Part for Whirlpool)

Material: Glass

Diameter: 360 Millimeters (36 cm)

Weight: Approximately 1.41 Kilograms

Compatibility: Original glass plate for Whirlpool, Bauknecht, KitchenAid, Ignis, Ariston Hotpoint, V-ZUG microwave ovens.

8. Warranty and Support

This product is a replacement part. For specific warranty information, please refer to the terms and conditions provided by the seller or the original manufacturer of the microwave oven for which this part is intended. Typically, replacement parts carry a limited warranty against manufacturing defects.

For technical support or inquiries regarding this product, please contact your point of purchase or the customer service department of Best Price Square. Ensure you have your purchase details and the product model number (JT358 / 1NF874010) available when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B004JSXMX6

More documents and user manuals: **https://manuals.plus/**